

FINEST QUALITY

Union Special[®]


LEWIS • C

INDUSTRIA

MACHINES

30

**STYLE
57700B**



ESCANIADO

CLASS 57700

**CATALOG
No.
131L**

**ADVANCED HIGH SPEED
FIFTY THOUSAND SERIES
DIFFERENTIAL FEED
FLAT BED MACHINES**

Union Special **MACHINE COMPANY**

CHICAGO



- ORIGINAL

12 folhas

Catalog No. 131 L
(Supplement to Catalog No. 131 M)

INSTRUCTIONS
FOR
ADJUSTING AND OPERATING
LIST OF PARTS
CLASS 57700

Style
57700 B

First Edition

Copyright 1971
by
Union Special Machine Co.
Rights Reserved in All Countries

Union Special
MACHINE COMPANY
INDUSTRIAL SEWING MACHINES
CHICAGO

Printed in U. S. A.

December, 1970

IDENTIFICATION OF MACHINES

Each Union Special machine is identified by a Style number on a name plate on the machine. Style numbers are classified as standard and special. Standard Style numbers have one or more letters suffixed, but never contain the letter "Z". Example: "Style 57700 B". Special Style numbers contain the letter "Z". When only minor changes are made in a standard machine, a "Z" is suffixed to the Standard Style number. Example: "Style 57700 BZ".

Styles of machines similar in construction are grouped under a Class number which differs from the Style number, in that it contains no letters. Example: "Class 57700".

APPLICATION OF CATALOG

This catalog is a supplement to Catalog No. 131 M and should be used in conjunction therewith. Only the parts found on Style 57700 B but not on Style 57700 L are illustrated. At the back are illustrations identifying the parts by reference number and on the opposite page, the part numbers and descriptions identifies the part. Any part that is a component of another part is indicated by indenting its description under the description of the assembly or base part. Always use the part number in the second column, never use the reference number in the first column when ordering repair parts.

STYLE OF MACHINE

Advanced High Speed, Two Needle, One Looper, Differential Feed Flat Bed Machine, Medium Throw, Needle Bearing Needle Bar Drive, Light Weight Presser Bar and Needle Bar Driving Mechanism, Single Reservoir, Enclosed Positive Automatic Lubricating System, Filtered Oil Return Pumps for Head and Base, Needle Bearings and Bronze Bearings for Feed Bar and Feed Rocker Shafts, Greased and Sealed. Lateral Looper Travel, Single Disc Take-up, Large Handwheel and Improved Belt Guard. Prepared for use with Knee Press for Presser Foot Lifter, Equipped with Rotary Thread Tensions, Maximum Work Space to Right of Needle Bar 8 1/4 Inches.

57700 B Offset differential feed machine for attaching long length rib knit strip cut perpendicular to the wale or parallel with the wale to knitted undergarments and similar operations on medium to medium heavy weight material. Standard gauge No. 12 only. Seam specification 406-BSb-1. Type 121 GS needle. Maximum recommended speed 6000 R. P. M.

NEEDLES

Each Union Special needle has both a type and size number. The type number denotes the kind of shank, point, length, groove, finish and other details. The size number, stamped on the needle shank, denotes largest diameter of blade, measured in thousandths of an inch, midway between shank and eye. Collectively, type and size number represent the complete symbol, which is given on the label of all needles packaged and sold by Union Special.

The standard recommended needle for the machine covered by this catalog is Type 121 GS. Below is the description and sizes available of the recommended needle.

<u>Type No.</u>	<u>Description and Sizes</u>
121 GS	Round shank, round point, short, double groove, struck groove, chromium plated - available in sizes 025, 027, 029, 032, 036, 040, 044, 049, 054.




Fig. 1

THREADING AND OILING DIAGRAM FOR STYLE 57700 B MACHINES

Thread machine as indicated. The looper threading has been enlarged for clarity.

The oil has been drained from the machine before shipping and the reservoir must be filled before starting to operate. To fill machine with oil, remove plug screw in top cover and add oil until needle of oil gauge is in yellow band marked "FULL". Use a straight mineral oil of a Saybolt viscosity of 90 to 125 seconds at 100° Fahrenheit. Maintain oil level in "OPERATE" position and add oil when needle is in yellow band marked "LOW". The machine is automatically lubricated and no oiling other than keeping the main reservoir filled is necessary.

Excessive oil in the main reservoir may be drained at the plug screw in the main frame to the left of the oil gauge.

INSTRUCTIONS FOR MECHANICS

LUBRICATION

CAUTION! Oil has been drained from the main reservoir before shipment, so the reservoir must be filled to the proper level as indicated on oil gauge (A, Fig. 1) before beginning to operate. Run machine slowly for several minutes to distribute the oil to the various parts. Full speed operation can then be expected without damage.

RECOMMENDED OIL

Use a straight mineral oil of a Saybolt viscosity of 90 to 125 seconds at 100° Fahrenheit in the main reservoir. This is equivalent to Union Special specification No. 174. Fill main reservoir at plug screw in upper crank chamber cover (A, Fig. 2) and check oil level at gauge (B). Oil is at maximum level when needle is in yellow band marked "Full". Oil should be added when needle is in yellow band marked "Low".

CAUTION! It is important that these machines not be over filled.

It is recommended that a new machine, or one that has been out of service for an extended period be lubricated as follows: Remove the head cover, clean out lint and directly oil the needle bar link and the needle bar. Replace head cover as no further hand oiling will be required. Run machine slowly for several minutes to distribute oil to the various parts.

Oil may be drained from main reservoir by removing plug screw (C, Fig. 2) located below the cloth plate at front of the machine.

NOTE: Looper avoid and feed lift eccentrics receive oil thru the mainshaft, so when assembling be sure oil holes in the eccentric lines up with oil holes in mainshaft when spot screw is in timespot.

OIL GAUGE

The oil gauge is set at the factory to show the proper oil level in the reservoir. Should an adjustment become necessary, however, the following steps should be followed:

1. Place the machine upright on a level table or bench.
2. Remove the oil reservoir plug screw (C, Fig. 2) and tip machine forward to drain oil from the reservoir.
3. Make sure all oil is drained from main reservoir.
4. Remove lower crank chamber cover, located at the back of the machine.
5. Fill main reservoir to a level even with the bottom contour of the knee press shaft bushing (D, Fig. 2).
6. Loosen lock nut (E) on calibrating screw (F), and turn the screw to the left or right until the gauge needle rests in the middle of the yellow band marked "LOW".
7. Tighten lock nut (E) and replace plug screw (C).
8. Add oil so that gauge needle rests in the middle of the yellow band marked "FULL".




Fig. 2

NEEDLE LEVER BEARING OILER



Fig. 3

Remove the head cover and upper crank chamber cover (G, Fig. 2). Check position of needle lever bearing oiler (A, Fig. 3) located inside the arm casting, below the upper crank chamber cover, which lubricates the needle lever stud (B). Make sure it is tilted downwardly and that its delivery end (C) contacts the inside wall of the bed casting at the back, just above the notch of the needle lever shaft stop collar. (Do not allow the oiler to rest on the needle lever). Allow $1/64$ inch clearance as in Fig. 3.

ALIGNING THE NEEDLE BAR

Align the needle bar (A, Fig. 4) and set to height, using the proper test pins and test plate of the right gauge.

Insert test pin No. 699 L in the left seat of the needle holder and test pin No. 699 R-12 in the right needle seat. Now assemble test plate No. 698 BB-12 to machine using the throat plate attaching screws. The needle bar is located properly if the test pins align with the holes in the test plate and the height of the needle bar is correct when the shoulder of the test pins rest on the test plate, when the needle is at its lowest position.

If test plate and test pins are not available, insert a new set of needles (Type and Size as required) and align the needle bar so the needles center in the needle holes of throat plate. To align needle bar, loosen needle bar clamp screw (B, Fig. 4) and turn bar as required. Tighten clamp screw.

SYNCHRONIZING LOOPER AND NEEDLE MOTIONS

Insert the looper in the looper rocker and turn hand-wheel in operating direction until the point of the looper (A, Fig. 5), moving to the left is even with the left side of right needle (B). Note the height of the eye of the needle with respect to the looper point, then turn hand-wheel in the reverse direction until the looper point again moves to the left, and is even with the left side of the right needle. If the motions synchronize, the height of the eye of the needle with respect to the looper point will be the same. A variation of .005 inch is allowable. If the distance from the eye of the needle to the point of the looper is greatest when the pulley is turned in the operating direction, move the looper drive shaft synchronizing stud (A, Fig. 6) to the rear. Moving it in the opposite direction acts the reverse.

Moving of the looper drive lever shaft synchronizing stud is accomplished as follows: Loosen the clamp screw (B, Fig. 6) of the looper drive lever (C). To move stud to rear (away from operator), a light tap with a small hammer, directly on the stud, is all that is required. To move stud forward (toward operator), remove the cloth plate, oil reservoir top cover and oil reservoir back cover, then, a light tap on the looper drive lever rocker shaft, toward the operator, is all that is required. Then, using the looper drive lever to take up the end play between the looper drive lever rocker shaft and its synchronizing stud, tighten the looper drive lever on the shaft, using screw (B, Fig. 6).




Fig. 4

SYNCHRONIZING LOOPER AND NEEDLE MOTIONS (Continued)

With the looper at the extreme right end of its travel, check the location of the center line of the right looper connecting rod bearing, using gauge No. 21227 CX. Remove nut (C, Fig. 5) and place hole in gauge over threaded stud. The left end of the gauge should locate against the right side of the looper rocker cone (D). If adjustment is necessary, loosen the clamp screw (B, Fig. 6) and reposition the looper drive lever (C) as required. Tighten clamp screw. If gauge is not available, setting can be checked with a scale. The distance between the center line of the looper rocker cone and the center line of the looper lever stud should be $4 \frac{1}{16}$ inches (Fig. 6), when looper is at the extreme right end of its travel.




Fig. 5

SETTING THE LOOPER

Insert a new needle in the right needle seat, type and size as specified. If the looper gauge is $\frac{7}{32}$ inch, for example, set the looper (D, Fig. 6) so the distance from the center of the right needle (E) to the point of the looper is $\frac{7}{32}$ inch, when the looper is at its farthest position to the right. Looper gauge No. 21225- $\frac{7}{32}$ can be used advantageously in making this adjustment. If adjustment is required, loosen nut (F) (it has a left hand thread) and nut (G) on connecting rod (H), turn the connecting rod forward or backward to obtain the $\frac{7}{32}$ inch dimension. Retighten both nuts, first nut (G) and then nut (F). Make sure the left ball joint




Fig. 6

is in vertical position and does not bind after adjustment.

The looper is set correctly in line-of-feed, if, as it moves to the left, behind the needle, its point (A, Fig. 7) brushes, but does not pick at the rear of the needle (B).




Fig. 7

If adjustment is necessary, loosen lock screw (J, Fig. 6) and turn stop screw (K) as required. Turning stop screw clockwise sets the looper to the rear and turning it counter-clockwise acts the reverse. Holding looper to




Fig. 8

SETTING THE LOOPER (Continued)

the front while making this adjustment may prove helpful. Tighten lock screw when setting is obtained and recheck the adjustment.

SETTING HEIGHT OF NEEDLE BAR

The height of the needle (C, Fig. 4) is correct when the top of its eye is $\frac{3}{64}$ inch below the underside of the looper, with the looper point flush with the left side of the needle. If adjustment is necessary, loosen screw (B) and move needle bar (A) up or down as required and retighten screw. Care should be taken not to disturb the alignment of the needle bar when moving the needle bar either up or down.

The needles are to have equal clearance on the right and left sides of needle slots in throat plate.

SETTING THE MAIN FEED DOG

The main feed dog should be set to rise the depth of a full tooth, or approximately $\frac{3}{64}$ inch above the throat plate, at the highest point of travel. The feed dog should be centered in the slots of the throat plate at maximum feed travel.




Fig. 9

To raise or lower the main feed dog, loosen allen screw (A, Fig. 8) and adjust the feed dog holder (B) to set the feed dog at specified height. Retighten screw (A).

NOTE: A change of feed dog height will necessitate a check of the rear needle guard setting.

The main feed dog should have equal clearance on all sides of feed slots in the throat plate at maximum feed travel. To adjust the main feed dog across-the-line-of-feed, loosen screws (C, Fig. 8) and position feed dog as required. Retighten screws (C). To adjust main feed dog in-line-of-feed, loosen nut (A, Fig. 9) and move feed bar as required. Retighten nut.

SETTING THE DIFFERENTIAL FEED DOG

The differential feed dog should also be set to rise the depth of a full tooth above the throat plate, at the highest point of travel and center in the feed slots of the throat plate at maximum feed travel. In addition to this the teeth of the feed dog should be parallel to the top surface of the throat plate across-the-line-of-feed.

To raise or lower the differential feed dog, loosen screw (B, Fig. 9) and set the feed dog at the required height. Retighten screw.

Loosen set screws (C, Fig. 9) and move the differential feed bar (D) forward or backward as required. The loosening of set screws (C) will also allow the differential feed bar (D) to be rotated, so the differential feed dog can be aligned parallel with the top surface of the throat plate, across-the-line-of-feed. Tighten screws securely.

NOTE: Turn machine by hand to make sure the differential feed dog has clearance through its cycle and does not contact the main feed dog at back end of its travel or the throat plate at the forward end of its travel.




Fig. 10

SETTING THE DIFFERENTIAL FEED RATIO

The differential feed ratio is set by loosening screw (A, Fig. 10) and moving the selector slide (B) to the desired position. The screw and selector slide are accessible through the top of the cloth plate on the left side. Moving the differential feed selector slide (B) toward the front increases the amount of differential and moving it back decreases the differential feed. Retighten screw.

This Class of machine has a stretching ratio of $\frac{3}{4}$ to 1 up to a gathering ratio of 2 to 1, depending on the length of stitch set at the main feed dog. Turn machine by hand, making sure the differential feed dog clears the main feed at the back end of its stroke.

CHANGING STITCH LENGTH

Set the stitch to the required length. This is accomplished by loosening locknut (A, Fig. 11) (it has a left hand thread) and turning the stitch adjusting screw (B). Turning screw (B) clockwise shortens the stitch and turning it in a counterclockwise direction lengthens the stitch. The head of the mainshaft (C) is marked with an "S" and an "L", moving the stitch regulating stud toward the "S" shortens the stitch and toward the "L" lengthens the stitch. Retighten locknut (C) after setting the stitch to the required length.




Fig. 11

NOTE: Any change in stitch length will necessitate a corresponding change in the rear needle guard setting and a check of the feed dog height.

SETTING THE REAR NEEDLE GUARD

Set the rear needle guard (C, Fig. 10) horizontally so that it does not quite contact the rear of the right needle (D) when at its most forward point of travel. A clearance of .005 inch is permissible. It should be set as low as possible, yet have its vertical face approach within about 3/64 inch of the needle, until the point of the looper (E), moving to the left, is even with the needle. To move needle guard merely loosen screw (F), move needle guard as required, and retighten screw.

NOTE: Adjustment of the rear needle guard will necessitate a check of the main feed dog height.

SETTING FRONT NEEDLE GUARD

Set the front needle guard so that it pushes the left needle back toward the path of the looper as it moves behind the needle. The looper may brush but not pick at the left needle. It should be set as low as possible, yet have its vertical face push the left needle until the point of the looper is just past the left side of the needle. The front needle guard should not contact the rear needle guard or right needle at any time. To move guard forward or backward, merely loosen screws (G, Fig. 10) move needle guard as required and retighten screws. To raise, lower or rotate needle guard, loosen screws (H), move guard and retighten screws after guard is properly set.




Fig. 12

NOTE: A change in stitch length WILL NOT require a change in front needle guard setting.

THREAD TENSION RELEASE

The thread tension release is set correctly when it begins to function as the presser foot is raised to within 1/8 inch of the end of its travel and is entirely released when the presser foot has reached its highest position.

If adjustment is needed, loosen tension release lever screw (A, Fig. 12), located at the back of the machine and move tension disc separator as required. Retighten screw. After adjustment there should be no binding at any point.

SETTING HEIGHT OF PRESSER BAR

The height of the presser bar (D, Fig. 4) is set correctly if it is possible to remove the presser foot when the foot lifter lever (B, Fig. 12) is fully depressed. Also there should be approximately 1/16 inch clearance between lower surface of the presser bar connection and guide (E, Fig. 4) and the bottom surface of head opening in the bed when the foot lifter lever is released and the presser foot resting on the throat plate, with the feed dog down below the throat plate.

If adjustment is needed, turn handwheel in operating direction until the needle bar is in the low position. Loosen screw (F), then, while holding presser foot down on the throat plate surface, pry up presser bar connection and guide with a screwdriver to obtain the 1/16 inch setting and retighten screw. Check setting by turning handwheel so that needle bar is in its high position and see if presser foot can be removed as mentioned in previous paragraph.




Fig. 13

THREADING

Thread machine as indicated in Fig. 1 and start operating on a piece of fabric.

THREAD TENSION

The needle thread is to be wrapped around the rotary tension 2 1/4 times. Pull the thread through the eyelets and set the left needle thread tension at 2 ounces; the right needle thread tension at 2 1/2 ounces or sufficient tension to produce uniform stitches on the under surface of the fabric.

The looper thread tension is applied at the cast-off support tension disc assembly, and the adjusting nut should be set just below the end of the tension post. The spring must still have free length. The tension on the looper thread should be just sufficient to steady the thread.




Fig. 14

SETTING THE NEEDLE THREAD FRAME EYELET AND TAKE-UP WIRE


Set the needle thread frame eyelet hole (A, Fig. 13) 3/4 inch above the center of mounting screw (B). Lower for more needle thread in the stitch, raise for less. Top of take-up wire (C) to be even with top of holes in the needle thread eyelet (D) when needle bar is at the bottom of its stroke. Lower this setting for less needle loop, reverse for more loop.

SETTING LOOPER THREAD TAKE-UP

The looper thread take-up (A, Fig. 14) is not spotted on the main shaft and, consequently, can be set to compensate for varying conditions. It is set correctly when the looper thread is just cast off the highest lobe of the take-up when the point of the left needle is clearly visible below the underside of the looper. The cast-off plate assembly (B) is adjustable, and its setting determines the amount of thread pulled off by the take-up. Moving the cast-off plate assembly to the top of the screw slots causes more thread to be pulled from the cones, and moving the cast-off plate assembly to the bottom of the screw slots causes less thread to be pulled. The cast-off plate assembly is set correctly when the looper thread just becomes taut as the looper reaches its extreme position to the left.


PRESSER FOOT PRESSURE

Regulate the presser spring regulating screw (E, Fig. 13) so that it exerts only enough pressure on the presser foot to feed the work uniformly when a slight tension is placed on the fabric. Turning it clockwise increases the pressure, counterclockwise acts the reverse.




THROAT PLATE, FOLDER, FOLDER SUPPORT, STRIP TENSION
AND MISCELLANEOUS COVERS

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Amt. Req.</u>
1	57882 A	Plastic Back Plate -----	1
2	22848	Screw, for plastic back and end plate -----	5
3	20	Washer, for plastic back and end plate -----	5
4	80	Screw, for throat plate support -----	2
5	660-313	Well Nut -----	2
6	87	Screw, for throat plate -----	2
7	57724 A-12	Throat Plate -----	1
8	22526 C	Screw, for cloth plate -----	2
9	57801 A	Cloth Plate -----	1
10	22839 E	Screw, for cloth plate -----	1
11	22839 C	Screw, for cloth plate -----	2
12	57802	Cloth Plate Sliding Cover -----	1
13	90	Screw -----	2
14	22526 D	Screw, for cloth plate -----	1
15	52864 R	Folder Support Platform -----	1
16	25 S	Screw -----	1
17	25 CC	Screw -----	2
18	23432	Folder Clamp -----	1
19	52864 N	Folder Support Bracket -----	1
20	22519 K	Screw -----	2
21	23425 V	Washer Plate -----	1
22	52864 V	Folder Support Hinged Bracket -----	1
23	22564	Screw -----	1
24	57885 A	Hinge Pin -----	1
25	43281 K	Hinge Bracket Spring -----	1
26	90	Screw -----	2
27	57880	Throat Plate Support -----	1
28	51280 J	Dowel Pin -----	2
29	57882 D	Plastic End Plate -----	1
30	57882 C	Support Post -----	1
31	22848	Screw -----	2
32	57885	Swinging Cover Hinge -----	1
33	23406 R-5/8	Folder -----	1
34	22848	Screw -----	2
35	57864	Clamp Plate, for folder support bracket -----	1
36	22548	Screw -----	2
37	23439 D	Strip Tension -----	1
38	188 D	Screw -----	2
39	23439 E	Adjustable Pin -----	2




PRESSER-FOOT, NEEDLE BAR, NEEDLE HEAD, HEAD OIL PUMP, PULLEY,
--LOOPER THREAD TAKE-UP AND THREAD TENSION PARTS

Ref. No.	Part No.	Description	Amt. Req.
1	52818-8	Needle Bar Head -----	1
2	52842 G	Thread Guide Wire -----	1
3	28 B	Screw, thread guide wire-----	1
4	88 B	Screw, needle-----	2
5	89	Screw, spot-----	1
6	52717 E-12	Needle Bar, marked "EJ-12" -----	1
7	22513	Screw -----	4
8	35731 A	Presser Bar Connection Guide Plate-----	2
9	51270 B	Needle Thread Take-up Wire -----	1
10	539	Needle Thread Frame Eyelet -----	1
11	20	Washer-----	1
12	22848	Screw -----	1
13	28	Screw -----	2
14	57804	Cast-off Plate -----	1
15	22569 D	Screw -----	2
16	57857	Cast-off Plate Support -----	1
17	51459 A	Looper Thread Guide -----	1
18	57792	Tension Post -----	1
19	51959 B	Tension Disc -----	2
20	51959 K	Tension Spring -----	1
21	51959 D	Tension Nut-----	1
22	14077	Nut -----	2
23	56392	Tension Post Support -----	1
24	21657 AD-4	Tension Disc Separator -----	1
25	56392 B	Needle Thread Tension Post and Eyelet -----	2
26	22856	Thread Nipper Screw -----	3
27	56359 A	Thread Nipper Plate Spring-----	3
28	56359	Thread Nipper Plate -----	3
29	61492 T	Felt Washer -----	4
30	61492 S	Rotary Tension Disc -----	2
31	21657 AE	Needle Thread Tension Release -----	2
32	61492 M-5	Needle Thread Tension Spring -----	2
33	61292 C	Tension Nut-----	2
34	56392 C	Looper Thread Tension Eyelet -----	1
35	22872 A	Screw -----	2
36	57893 B	Head Oil Tube Clamp-----	1
37	57846 B	Looper Rocker Cone Stud Nut -----	1
38	52820 H-12	Presser Foot -----	1
39	13130 B	Presser Foot Shank-----	1
40	91	Screw -----	1
41	73 A	Screw -----	1
42	605	Screw -----	1
43	11534	Spring -----	1
44	52830 C	Yielding Section -----	1
45	52830 D	Adjustable Guide -----	1
46	22561	Screw -----	1
47	52830 H-12	Presser Foot Bottom -----	1
48	22799 B	Hinge Screw -----	1
49	57893	Head Oil Pump Assembly-----	1
50	666-214	Intake Felt -----	1
51	57893 A	Sewing Head Oil Tube -----	1
52	56393 U	Oil Tube Insert -----	2
53	56393 G	Porex Filter -----	1
54	RI-37	Clamp -----	3
55	56393 E	Plastic Oil Tube Connection -----	1
56	56393	Head Oil Pump -----	1
57	56393 N	Oil Tube Support Spring -----	1
58	21169 F	Binding Holder Base -----	1
59	161	Binding Holder Stop Collar -----	1
60	88	Screw -----	1
61	21169 E	Binding Holder Disc -----	1
62	57821 A	Handwheel Assembly-----	1
63	56321 A	Pulley -----	1
64	22894 AB	Screw -----	2
65	57821	Handwheel -----	1
66	22574	Screw -----	3
67	61321 L	Retaining Plate -----	1
68	57725 B	Looper Needle Guard -----	1




DIFFERENTIAL FEED MECHANISM

Ref. No.	Part No.	Description	Amt. Req.
1	57835	Main Feed Rocker Shaft, lower -----	1
2	55235 E	Nut-----	1
3	6042 A	Washer-----	1
4	57836 D	Locking Stud -----	1
5	57836 C	Main Feed Rocker -----	1
6	57836	Bushing-----	2
7	57834 B	Main Feed Rocker Shaft, upper -----	1
8	56335 D	Collar, for lower main feed rocker driving shaft -----	3
9	98	Screw -----	2
10	61341 J	Thrust Washer, for feed bar -----	2
11	57837 D	Differential Feed Bar Guide Plate -----	1
12	57853	Feed Dog Holder Support -----	1
13	57834 C	Oil Wick Retainer -----	1
14	22593	Screw -----	2
15	22593	Screw, for main feed dog -----	2
16	57705 A	Main Feed Dog, marked "ER"-----	1
17	52953 A	Feed Dog Holder -----	1
18	22653 B-12	Screw -----	1
19	51235 G	Washer -----	1
20	52825 B	Rear Needle Guard -----	1
21	52925 D	Needle Guard Holder -----	1
22	22635 E-24	Screw -----	1
23	CL21	Oil Wick -----	2
24	57834 A	Differential Feed Bar -----	1
25	CL21	Oil Wick -----	1
26	57726	Differential Feed Dog, marked "ES"-----	1
27	90	Screw -----	1
28	57834	Main Feed Bar -----	1
29	22637 P-24	Feed Dog Height Adjusting Screw -----	1
30	57834 D	Bushing-----	2
31	56334 A	Bushing-----	2
32	22651 CB-4	Screw -----	1
33	51236 A	Link Pin -----	1
34	22597	Set Screw -----	1
35	57837 E	Driving Link Guide -----	1
36	22565 C	Screw -----	2
37	57837 B	Differential Driving Link Collar -----	1
38	22738 B	Screw -----	1
39	57835 B	Intermittent Differential Feed Bar Driving Link -----	1
40	22758 E	Screw, for differential control lever and link -----	1
41	57835 D	Differential Feed Control Lever Link -----	1
42	57835 C	Differential Feed Control Lever -----	1
43	57837 C	Differential Feed Control Lever Bushing -----	1
44	9937	Nut -----	2
45	69 H	Washer -----	1
46	57835 E	Differential Feed Control Indicator -----	1
47	22874 K	Lock Screw -----	1
48	12934 A	Nut -----	1
49	80265	Washer -----	1
50	907	Nut -----	2
51	57837	Differential Feed Link Sleeve, left -----	1
52	57837 A	Differential Feed Link Sleeve, right -----	1
53	22868 B	Differential Feed Regulating Screw -----	1
54	57836 F-40	Sliding Block, marked "N", .2540 inch wide -----	1
	57836 F-45	Sliding Block, marked "P", .2545 inch wide -----	1
	57836 F-50	Sliding Block, marked "R", .2550 inch wide -----	1
55	57806-040	Stretch Differential Feed Rocker, .040 inch throw -----	1
56	56334 A	Bushing-----	2
57	57836 A	Bushing-----	1
58	14-172	Differential Feed Drive Rocker Shaft -----	1



MAIN SHAFT, TAKE-UP AND FEED DRIVING PARTS

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Amt. Req.</u>
1	29476 ND	Feed Rocker Arm and Feed Crank Link Sub-Assembly -	1
2	55235 E	Nut-----	1
3	6042 A	Washer-----	1
4	55235 D	Locking Stud-----	1
5	22768 B	Screw, for link pin-----	1
6	56336 B	Feed Crank Link Assembly-----	1
7	56336 C	Feed Crank Link Ferrule-----	1
8	51054	Feed Crank Link Pin-----	1
9	666-149	Oil Wick-----	1
10	269	Nut, left hand thread-----	1
11	21657 E	Washer-----	1
12	22525 A	Screw-----	4
13	56322 C	Main Shaft Head Plate-----	1
14	22798 C	Screw-----	1
15	56336	Feed Crank Stud, marked "A"-----	1
16	22543 A	Stitch Regulating Screw-----	1
17	660-269 B	Quad Ring-----	1
18	56336 D	Feed Crank Stud Insert-----	1
19	22801	Screw, for take-up-----	1
20	57822	Main Shaft-----	1
21	56322 B	Gasket-----	1
22	22891 B	Oil Flow Regulating Screw-----	1
23	57823	Looper Thread Take-up-----	1
24	22580	Screw-----	2
25	29476 LK-062	Looper Avoid Eccentric Assembly-----	1
26	77	Screw-----	1
27	56306-062	Looper Avoid Eccentric, .062 inch throw-----	1
28	22894 AA	Screw-----	1
29	39543 N	Thrust Washer, for feed bar-----	2
30	29476 LK-072	Feed Lift Eccentric Assembly-----	1
31	77	Screw-----	1
32	56306-072	Feed Lift Eccentric, .072 inch throw-----	1
33	22894 AA	Screw-----	1
34	57836 E	Differential Feed Connecting Rod-----	1
35	22768 B	Screw-----	1
36	56306-080	Differential Feed Eccentric, .080 inch throw-----	1
37	22894 AA	Screw-----	1



FINEST QUALITY

Union Special®

LEWIS and COLUMBIA

INDUSTRIAL SEWING MACHINES



SALES OFFICES AND REPRESENTATIVES

†Handle Union Special and Columbia only.
‡Handle Lewis and Columbia only.
All others handle Union Special, Lewis and Columbia with certain exceptions.

UNITED STATES

ALABAMA 35206, BIRMINGHAM, 732-84th Street, South, Lloyd D. Baldwin, Tel. 833-9904.

ALABAMA 36107, MONTGOMERY, 3223 Willow Lane Dr., (Zip Code 36110), Tommy Hendrix, Tel. 272-6667.

ARKANSAS 72203, LITTLE ROCK, P.O. Box 1783, James T. Taylor, Tel. (501) 376-3121.

★CALIFORNIA 90021, LOS ANGELES, 1100 E. Pico Blvd., Paul M. Mason, Mgr., Tel. Madison 5-5828.

CALIFORNIA 94110, SAN FRANCISCO, 3420-25th Street, Robert J. Vail, Tel. 415/826-5969.

†CALIFORNIA 94103, SAN FRANCISCO, Apparel City Sewing Machine Co., 1155 Mission St., Tel. MArket 1-6660.

COLORADO 80002, ARVADA, Casey's Sewing Machine Service, 5719 Reed St., Tel. 424-6630.

CONNECTICUT 06811, DANBURY, 22 Barnum Road, Robert W. Gaines, Tel. 746-3652.

FLORIDA 33127, MIAMI, 2525 N.W. 2nd Ave., Trimco Sewing Equipment, Inc., Tel. 633-1138.

FLORIDA 33566, PLANT CITY, 506 N. Gordon St. James C. Morgan, Tel. 752-1829.

★GEORGIA 30324, ATLANTA, 2120 Plasters Bridge Road, N.E., Merritt M. Ambrose, Mgr., Tel. 875-9237.

GEORGIA 30529, COMMERCE, Lakeview Drive, J. Tom Hanley, Tel. 335-4061.

GEORGIA 30030, DECATUR, 1713 Coventry Road, Joe V. Parker, Tel. 377-5559.

GEORGIA 31021, DUBLIN, 1615 Knox St., John W. Jones, Tel. 272-4663.

GEORGIA 30501, GAINESVILLE, RFD #1, John Bradberry, Tel. Cumming, Ga. 887-4732.

GEORGIA 30680, WINDER, 508 Fifth Ave., B. D. Smith, Tel. 867-3208.

★ILLINOIS 60610, CHICAGO, 400 N. Franklin St., Fred L. Koehler, Mgr., Tel. 644-6920.

KANSAS 66208, KANSAS CITY (PRAIRIE VILLAGE) 7351 Rosewood, Cleo C. Smith, Tel. HE 2-1705.

KENTUCKY 40207, LOUISVILLE, P.O. Box 7261, Raymond E. Hinton, Tel. 587-0042.

LOUISIANA 70458, NEW ORLEANS (SLIDELL) 275 Palm Springs Drive, Duane Bunker, Tel. 504/643-2484.

MARYLAND 21215, BALTIMORE, P.O. Box 2505, Ralph B. Foster, Tel. 727-8499.

‡MARYLAND 21204, BALTIMORE, J. Dashew, Inc., 417 W. Baltimore St., Tel. LExington 9-1838.

★MASSACHUSETTS 02111, BOSTON, 179 Lincoln St., William E. Palm, Mgr., Tel. Liberty 2-0147.

MASSACHUSETTS 02021, CANTON, York St., RFD, Roy T. Pedersen, Tel. 828-1412.

MASSACHUSETTS 02767, TAUNTON, P.O. Box #2 Raynham, Walter P. Godek, Tel. VanDyke 2-6149.

MICHIGAN 48223, DETROIT, 14561 Auburn, John Joyce, Tel. 313-584-4210.

MINNESOTA 55426, MINNEAPOLIS, 2800 Texas Ave., St. Louis Park, Minn., Leonard W. Koehler, Tel. 644-6236.

MISSISSIPPI 39209, JACKSON, 327 Eastview St., Jamie A. Boyette, Tel. Fleetwood 5-1976. Larry Lancaster, P.O. Box 1427 (Tupelo) 38801, Tel. 601/842-7650.

†MISSOURI 64105, KANSAS CITY, Textile Machinery Co., 915 Broadway, Tel. Victor 2-9558.

MISSOURI 63114, ST LOUIS, 9022 Pallardy Lane, Carl E. McLaughlin, Tel. Chestnut 1-2368. 8725 Warner (Zip Code 63117), also Jerry Hicks.

†NEW HAMPSHIRE 03060, NASHUA, P.O. Box 257, Herman E. Haberman Jr., Tel. Tuxedo 2-9698.

†NEW JERSEY 07032, NORTH ARLINGTON, 32M Garden Terrace, Joseph Loglisci, Tel. 991-8211.

†NEW JERSEY 07010, RUTHERFORD, 246 Sylvan St., Richard W. Whitson, Tel. Geneva 8-2178.

NEW JERSEY 08091, WEST BERLIN, P.O. Box 26, Frank A. Neff, Tel. 767-4350.

NEW YORK 02110, LATHAM, 57 Sylvan Ave., Clarence A. Wheeler, Tel. 518-785-6371.

NEW YORK 14502, MACEDON, 3 Jupiter Way, James Halbohm, Tel. 986-4693.

★NEW YORK 10001, NEW YORK, 370 7th Ave., (Penn Terminal Bldg.), Clarence L. Rosenquist, Mgr., Tel. Chicker-ing 4-8800.

†NEW YORK 14609, ROCHESTER, A. J. Adams Co., 1051 Culver Rd., Tel. BUTler 8-7250.

NEW YORK 11553, UNIONDALE, 873 Henry St., Anthony Candell, Tel. Ivanhoe 3-7477.

NORTH CAROLINA 27403, GREENSBORO, P.O. Box 226, William D. Harrod, Tel. 299-9367. 4216 Pennysdale Dr., (Zip Code 27407), also Harold E. Miller, Tel. 292-0734.

OHIO 44109, CLEVELAND, 4914 Pearl Road, Cut & Sew Equipment Co., Tel. 661-5901.

OHIO 43216, COLUMBUS, P.O. Box 874, Larry Kelsen, Tel. AXminister 1-1222.

OKLAHOMA 73119, OKLAHOMA CITY, 2226 Southwest 53rd St., G. B. Wiley, Tel. 685-2836.

OREGON, 97220, PORTLAND, 1950 N.E. 118th Ave. Robert E. Ritt. Phone: 503/771-2159 (Portland) 206/624-8083 (Seattle).

PENNSYLVANIA 18105, ALLENTOWN, P.O. Box 542, Luther D. Cassell, Tel. 797-2111.

PENNSYLVANIA 18015, BETHLEHEM, 1212 Camac St., Ed Deegan, Tel. 868-8204.

PENNSYLVANIA 18003, BERWICK, 1013 E. 16th St., Donald McFadden, Tel. 752-2442.

PENNSYLVANIA 18411, CLARKS SUMMIT, 428 West Grove Ave., John J. Lafler, Tel. JUNiper 7-2820.

★PENNSYLVANIA 19124, PHILADELPHIA, 4234 Macalester Ave., Ben W. Merz, Mgr., Tel. Gladstone 5-9800.

†PENNSYLVANIA 15670, NEW ALEXANDRIA, (Pittsburgh), R.D. No. 1, Box 26A, W. Dale Speer, Tel. (Pittsburgh) 563-3589, also R. N. Bates.

PENNSYLVANIA 17567, REAMSTOWN, P.O. Box 176, David M. Bender, Tel. 267-6109, also F. J. Bartosic.

PENNSYLVANIA 17404, YORK, P.O. Box 884, Harding T. Powell, 854-8040, also F. J. Bartosic.

SOUTH CAROLINA 29204, COLUMBIA, P.O. Box 4246, Virlyn R. Crisler, Tel. Sunset 7-0863. P.O. Box 4112, also J. W. Carter, Tel. 254-4255.

SOUTH CAROLINA 29607, GREENVILLE, 25 Sir Abbot St., Orville W. Gregory, Tel. Cedar 9-5539.

TENNESSEE, 37421, CHATTANOOGA, 1711 Ray Jo Circle, John W. Carter 615-892-1489.

TENNESSEE 37919, KNOXVILLE, 3905 Greenleaf Ave., Horace E. Clinard, Tel. 588-1865.

TENNESSEE 38117, MEMPHIS, 4695 Dunn Rd., Richard J. Lindhorst, Tel. Mutual 5-6750.

TENNESSEE 37214, NASHVILLE, 2517 Woodberry Drive, Felix M. Blunkall, Tel. 615-254-7538.

★TEXAS 75247, DALLAS, 6718 Oakbrook Blvd., P.O. Box 47424, J. H. Muir Mgr., Tel. 214/637-5990.

TEXAS 79926, EL PASO, P.O. Box 9573, Edward E. Smith, Tel. 598-2928.

TEXAS 76106, FT. WORTH, 1201 Altamont Dr., Arnold Stierwalt, Tel. 626-3183.

TEXAS 78213, SAN ANTONIO, Jerry Gregory, P.O. Box 13126, Tel. DI 2-5924.

UTAH 84105, SALT LAKE CITY, 1215 E. 13th South St., Larry F. Rosvall, Tel. IN 7-6931.

VIRGINIA 24006, ROANOKE, P.O. Box 1151, Tom Traylor, Tel. 703-342-3233, also P. C. Eble.

CANADA

UNION SPECIAL MACHINE Co. of Canada, Ltd.

BRITISH COLUMBIA, N. BURNABY 2, James Murray, 1522 Madison Ave., Tel. MU 3-3917.

MANITOBA, WINNIPEG 2, Frank Thierman, Rm. 201, Whitla Bldg., 70 Arthur St., Tel. 204-943-4933.

★ONTARIO, TORONTO 28, Peter Fowler, Mgr.-Rep., 355 King St. West, Tel. Empire 6-2939.

★QUEBEC, MONTREAL 11, John Caschetto, Mgr.-Rep., 9595 Charles de Latour St. Tel. 514/387-7191.

FINEST
QUALITY
WORK

HIGHEST
PRODUCTION
RATES

LOWEST
MAINTENANCE
COSTS



Union Special[®]
INDUSTRIAL SEWING MACHINES

UNION SPECIAL maintains sales and service facilities throughout the world. These offices will aid you in the selection of the right sewing equipment for your particular operation. Union Special representatives and service men are factory trained and are able to serve your needs promptly and efficiently. Whatever your location, there is a Union Special Representative to serve you. Check with him today.

ATLANTA, GA.

BOSTON, MASS.

CHICAGO, ILL.

DALLAS, TEXAS

LOS ANGELES, CAL.

NEW YORK, N. Y.

PHILADELPHIA, PA.

MONTREAL, CANADA

TORONTO, CANADA

BRUSSELS, BELGIUM

LEICESTER, ENGLAND

LONDON, ENGLAND

PARIS, FRANCE

STUTTGART, GERMANY

Representatives and distributors in all important industrial cities throughout the world.

Union Special
MACHINE COMPANY

400 N. FRANKLIN ST., CHICAGO, ILL. 60610