

TYPICAL

GK33500A-12 SERIES


HIGH SPEED LOOP BELT LACE SEWING MACHING
INSTRUCTION BOOK
PARTS CATALOGUE

XI'AN TYPICAL INDUSTRIES CO.,LTD.

The front cutter mechanism

The front cutter can cut off the two side edges of materials to make it up to the requested width, then folded to the wanted lace after through edge binder. The edge binder has six sizes available in width: 5/16in, 3/8in, 1/2in, 15mm, 20 mm.

The standard one is 3/8in and the needle gauge is 5.6 mm, for other special size, please note when order is placed.




Main specifications


Needle quantity	Thread quantity	Stitch Lengtyh (mm)	Needle gauge (mm)	Looper	Differential ratio	Cloth Cutter	Presser foot lift volume (mm)	Needle type	Heavy and medium weight material	Speed (S.P.M)
2	3	1.4–4.5	4.8, 5.6, 6.4	1	0.7–1.2	*	6	UY128 GAS	*	4500

Application

Suitable for attaching lace on tronsers and skirts of light and heavy and medium weight material.


1.Oil filling






Fill 2-3 drops of oil in the places marked once every 2 or 3 days.


2. The width adjustment betwee the right and left cutters






- (1) Remove off Upper 1 of the support.
- (2) Loose Press Plate ②, Upper Cutter Crank ④, and Cutter Guard ③.
- (3) Loose the support of the lower cutter, move it right and left to obtain the requested width between the two cutters, meanwhile adjust the position of Lower Cutter Guide Shaft ® to get the size marked in the figure, then tighten Screw ⑤.
- (4) Turn the upper shaft back, when the needle bar moves down the lowest position, adjust Upper Cutter ⑦ to keep about 0.5 mm in conjunction with Lower Cutter ⑥, then tighten the upper cutter.
- (5) Adjust the clearance between Press Plate ② and Upper Cutter ⑦ to about 1 mm and tighten them.
- (6) Adjust the clearance between Cutter Guard 3 and Upper Cutter to about 2 mm and tighten them.
- (7) Reset Upper Cover 1 of the support.

3. Replacing the edge binder




- (1) Remove Screw 1.
- (2) Turn back the balance wheel to move down the feed dog to the lowest position.
- (3) Lift the presser foot and Follow Presser Foot
 - meanwhile press down the front end of the followpresser foot, take out the edge hinder
- (4) With the same method install the necessary binder and tighten the screw.

4. Adjusting the cutter pressure




For sewing heavy weight materials such as jeans, turn Screw ① clockwise to get more pressure. Generally it is better for less pressure of the cutter.


5. Adjusting pressure of the follow presser foot



When sewing heavy weight materials such as jeans, if the pressure of the follow presser foot is too small, the material can not be folded properly through the binder, so loosen Screw 1, turn the collar in direction shown by the arrow to increase the pressure of Follow Presser Foot 3.


6. Replacing the upper cutter







- (1) Remove off Front cover $\textcircled{\scriptsize 1}$ and Top cover $\textcircled{\scriptsize 2}$.
- (2) Remove off Screw (5).
- (3) Adjust Screw 6 to reduce the pressure to minimum degree, take off Upper Cutter 4 .
- (4) Replace the upper cutter in reverse steps and make sure the conjunction.


7. Replacing the lower cutter








- (1) Remove off Front Cover 1 .
- (2) Loosen Screw 4 and take down Lower Cutter 3.
- (3) Insert Lower Cutter ③ in the slot of lower Cutter Support ⑤, make the blade of Lower Cutter ③ horizontal with the upper surface of Throat Plate ⑥ and tighten Screw ④.



Special parts for (1)


No.	Ref.No.	Description	Qt
1	267A03001	Left cover	1
2	267A00012	Left cloth plate	1
3	267A00014	Front cover	1
4	267A01000	Feed dog holder assy	1
5	182610003	Needle holder (4.8)	1
	182610004	Needle holder (5.6)	1
6	248106000	Presser foot (4.8)	1
	248102000	Presser foot (5.6)	1
7	267A00013	Seal plug	1
8	267A00008	Feed dog	1
9	267A00004	Needle plate (4.8)	1
	267A00005	Needle plate (5.6)	1
10	267A02000	Machine casing component	1
	1	I .	L



Special parts for (2)

No.	Ref.No.	Description	Qt
1 2 3 4	267A00001 S150209099 S150299027 110E13100	Cutter connection crank Screw M5 × 12 Screw M4 × 4 Up-knife Slider shaft assy	1 1 1

Special parts for (3)



Special parts for (3)

No.	Ref.No.	Description	Qt
110.	130700001	Supporting board	1 1
2	S150202020	Screw	2
3 4	267A00002	Knife connecting	1
4	S150207009	Screw	1
5 6	130700003	Pin Oil wield	1 1
7	110E14001 130700004	Oil wick Knife rest shaft crank	1
8	S150209034	Screw	1
9	130700005	Knife rest shaft	1
10	130700006	Bushing	2 2 4
11	130700007	Spring bushing	2
12 13	S150207009 130700008	Screw Left knife crank	4 1
14	S150206034	Screw	1
15	130700009	Up-lifter knife	1
16	S150202011	Screw	1
17	130700010	Right knife crank	1
18 19	S150209034 130700011	Screw Up-righter knife	1 1
20	S150202011	Screw	1
21	130700012	Left knife bracket	1
22	S150202019	Screw	2
23	130700013	Left knife holder	1
24 25	130700014 S150202019	Right knife bracket Screw	1
26	130700015	Right knife holder	1
27	S150202010	Screw	2
28	SFB0201001	Screw	2
29	S150202011	Screw	2
30 31	130700016 130700017	Pin Lower knife board	2 1 2 2 2 2 2 2 2
32	130700017	Lower knife board Lower knife shaft	2
33	130700019	Adjust screw	2
34	130700020	Spring	2 2 2
35	130700021	Lower knife	2
36 37	13071 13072	Cover assembly of left knife Chip guide	1 1
38	13072	Chip guide Pin	2
39	S150202012	Screw	2
40	130700025	Material drop plate	1
41	S150202010	Screw	4
42 43	130700026 S150103001	Knife plate Screw	1 3
43	130700027	Front face cover	3 1
45	S150204003	Screw	2
46	248100008	Lapper base	1
47	\$150204003 \$150103008	Screw	1
48 49	S150103008 130700029	Bolt Bushing	1 2
50	130700029	Sub presser shaft	1
51	130700031	Presser bar lifter with screw	1
52	S150217014	Set screw	2
53 54	130700032	Front presser collar	1
54 55	S150207009 130700033	Set screw Front presser spring	2 1
56	130700033	Edge fomer (8mm)	1
	13075	Edge fomer (9mm)	1
	13076	Edge fomer (10mm)	1
	13077	Edge fomer (12mm)	1
	13078 13079	Edge fomer (15mm) Edge fomer (20mm)	1 1
	13079 130T11	5/16"Edge fomer	1
	130T11B	5/16"Edge fomer(L)	i
	130T12	3/8"Edge fomer	1
	130712B	3/8"Edge fomer(L)	1
	130T13 130T13B	1/2"Edge fomer 1/2"Edge fomer(L)	1 1
57	S150202015	Screw	2
58	248100011	Link board	1
59	008400057	Screw	2
60	130700046	Scrap hopper connecting plate	1
61 62	13073 130700048	Scrap hopper trough assy Right material guide	1 1
63	130700048 13070N	Front presser assembly	1
64	S150103011	Screw	4
65	S150503003	Nut	4

•	Besides	adjusting	stitch,please	laypeople	don't	debug	or maintair	ne.
_		,		/				

• Parts are subject to changes in design without prior notice.

XI'AN TYPICAL INDUSTRIES CO.,LTD.

Add: No.355 Taibai South Road, Xi'an,P.R.China-710068

Tel :+86-29-88279091 88279150

Fax :+86-29-88249715 88245215

E-mail:typical@chinatypical.com

Http:www.chinatypical.com

Http:www.globalsources.com