
USER'S MANUAL




SPS/E-Bartacking Series SPS/E-Button Sewing Series

Electronically Controlled Bartacking Machine (Electronic Control Part)

Electronically Controlled Button Sewing Machine (Electronic Control Part)





User's Manual

SPS/E-Bartacking Series SPS/E-Button Sewing Series

Electronically Controlled Bartacking Machine (Electronic Control Part)

Electronically Controlled Button Sewing Machine (Electronic Control Part)

- 1) For proper use of the machine, thoroughly read this manual before use.
- 2) Keep this manual in a safe place for future reference in case the machine


MEE-061117




- 1. Thank you for purchasing our product. Based on the rich expertise and experience accumulated in industrial sewing machine production, SUNSTAR will manufacture industrial sewing machines, which deliver more diverse functions, high performance, powerful operation, enhanced durability, and more sophisticated design to meet a number of user's needs.
- 2. Please read this user's manual thoroughly before using the machine. Make sure to properly use the machine to enjoy its full performance.
- 3. The specifications of the machine are subject to change, aimed to enhance product performance, without prior notice.
- 4. This product is designed, manufactured, and sold as an industrial sewing machine. It should not be used for other than industrial purpose.

Organization of the BARTACK S/M MODEL

1) Electronic Presser Foot Rising Device Attached Type



2) Button Sewing Machine Types



CONTENTS

| 1. Machine Safety Regulations | |
|---|------|
| 1-1) Machine Transportation | |
| 1-2) Machine Installation | |
| 1-3) Machine Repair | |
| 1-4) Machine Operation | |
| 1-5) Devices for Safety | |
| 1-6) Caution Mark Position | |
| 1-7) Contents of Marks | |
| 2. Electronically Controlled Bartacking SM Specifications | |
| 3. Preparations before Use | 10 |
| 3-1) Power Connection | |
| 3-2) Changing Power Voltage | 11 |
| 3-3) Control Box LED Check | 1 |
| 4. SM Operation 1 (Basic) | |
| 4-1) Names and Functions of Keys in the Operation Box | |
| 4-2) Setting Item Data | 12 |
| 4-3) Checking Pattern Shape | · 16 |
| 4-4) Sewing | 16 |
| 4-5) Changing Sewing Pattern | 17 |
| 4-6) Lower Thread Winding | 17 |
| 5. SM Operation 2 (Advanced) | 18 |
| 5-1) User Program | |
| 5-2) Sewing using Combination Function | 10 |
| 5-3) Sewing using Lower Thread Counter | 20 |
| 5-4) Precautions | 21 |
| 6. Using Memory Switch | |
| 6-1) Memory Switch Operation | |
| 6-2) Example of Memory Switch Set-up | |
| 6-3) Memory Switch Functions Table | 26 |
| 7. Maintaining/Repairing | |



| 7-1) Cleaning Control box | 30 |
|--|----|
| 7-2) Replacing Fuse | 30 |
| 7-3) Testing the Machine | |
| 7-4) Other Functions | 35 |
| 7-5) Installing and Replacing ROM | 36 |
| 7-6) Pattern download from PDA (or PC) | 41 |
| 7-7) Pattern download from CF card | 42 |
| 8. Error List | 44 |
| 9. How Select the Sewing Pattern List and the Sewing Lange | 47 |
| 9-1) BS(R)1201 Series | 47 |
| 9-2) BS(R)1202 Series | 48 |
| 10 BASIC MANUAL | 40 |

Machine Safety Regulations

Safety instruction on this manual are defined as Danger, Warning and Caution.

If you do not keep the instructions, physical injury on the human body and machine damage might be occurred.

Caution: When the machine is improperly handled, user injury or physical damage to the machine is expected to occur.

Warning: When the machine is improperly handled, critical injury or death of a user is expected to occur.

Danger: When the machine is improperly handled, critical injury or death of a user is expected to occur, and the high-level of emergency situation would like to happen.

1-1) Machine Transportation

Danger

Those in charge of transporting the machine should know the safety regulations very well. The following indications should be followed when the machine is being transported.

- (a) More than 2 people must transport the machine.
- (b) To prevent accidents from occurring during transportation, wipe off the oil on the machine well.

1-2) Machine Installation



The machine may not work well or breakdown if installed in certain places. Install the machine where the following qualifications agree.

- ② Remove the package and wrappings starting from the top. Take special notice on the nails on the wooden boxes.
- Dust and moisture stains and rusts the machine. Install an airconditioner and clean the
 machine regularly.
- © Keep the machine out of the sun. If the machine is exposed in direct ray of light for a long time, transformation of color and shape can be happened.
- d Leave sufficient space of more than 50cm behind, and on the right, left and back side of the machine for repairing.
- © Do not operate in explosive atmospheres. To avoid explosion, do not operate this machine in an explosive atmosphere including a place where large quantities of aerosol spray product are being used or where oxygen is being administered unless it has been specifically certified for such operation.
- ① The machine were not provided with alocal lighting due to the feature of machine. Therefore the illumination of the working area must be fulfilled by end user.

[Refer] Details for machine installment are described in 4. Machine Installment.

1-3) Machine Repair



When the machine needs to be repaired, only the assigned troubleshooting engineer educated at the company should take charge.

- (a) Before cleaning or repairing the machine, close down the motive power and wait 5 minutes till the machine is completely out of power.
- Not any of the machine specifications or parts should be changed without consulting the
 company. Such changes may make the operation dangerous.
- © Spare parts produced by the company should only be used for replacements.
- ② Put all the safety covers back on after the machine has been repaired.



1-4) Machine Operation



Bartack Series is made to sew patterns on fabrics and other similar material for manufacturing. Follow the following indications when operating the machine.

- Read through this manual carefully and completely before operating the machine.
- (b) Wear the proper clothes for work.
- © Keep hands or other parts of the body away from the machine operation parts(needle, shuttle, thread take-up lever, and pulley etc.) when the machine is being operated.
- Keep the covers and safety plates on the machine during operation.
- (e) Be sure to connect the earthing conductor.
- ① Close down the electric motive power and check if the switch is turned "off" before opening electric boxes such as the control box.
- Stop the machine before threading the needle or checking after work.
- (h) Do not step on the pedal when turning the power on.
- ① Do not use several motor per a electric outlet.
- ① If possible, install the machine away from loud noise such as high frequency welding machines
- Be careful when the upper feed plate comes down to press. Otherwise, the finger or hand height be hurt at smacking.




- 1) Make sure that the cover is in place, while the machine is operating. Otherwise, the belt might injure or cut a finger.
- 2) Make sure that the power is turned "OFF" before examining or adjusting the machine.

1-5) Devices for Safety



- ② Safety label: It describes cautions during operating the sewing machine.
- ⓑ Thread take-up cover: It prevents from any contact between body and take-up lever.
- © Motor cover: It prevents from accidents during rotation of motor.
- Label for specification of power: It describes cautions for safety to protect against electric shock. (Voltage and Hz)
- © Finger guard: It prevent from contacts between a finger and needle.
- f Safety plate: It protects eyes against needle breaks.



1-6) Caution Mark Position

Caution mark is attached on the machine for safety.

Position of Warning Mark

When you operate the machine, observe the directions on the mark.

CAUTION 경 고




Do not operate without finger guard and safety devices. Before threading, changing bobbin and needle, cleaning etc. switch off main switch.

손가락 보호대와 안전장치 없이 작동하지 마신사오

실, 보빈, 바늘교환시나 청소전에는 반드시 주 전원의 스위치를 꺼 주십시오.

| |2



A

WARNING 경고



Hazardous voltage will cause injury.

Be sure to wait at least 360 seconds before opening this cover after turn off main switch and unplug a power cord.

고압 전류에 의해 감전될 수 있으므로 커버를 열 때는 전원을 내리고 전원 플러그를 뽑고 나 서 300초간 기다린 후 여십시오.

1-7) Contents of Marks



Warning

Caution

1)



CAUTION 경 고



Do not operate without finger guard and safety devices. Before threading, changing bobbin and needle, cleaning etc. switch off main switch.

손가락 보호대와 안전장치 없이 작동하지 마십시오.

실, 보빈, 바늘교환시나 청소전에는 반드시 주전원의 스위치를 꺼 주십시오.

2)



WARNING





Hazardous voltage will cause injury. Be sure to wait at least 360 seconds before opening this cover after turn off main switch and unplug a power cord.

고압 전류에 의해 감전될 수 있으므로 커버를 열 때는 전원을 내리고 전원 플러그를 뽑고 나서 360초간 기다린 후 여십시오.



2

Electronically Controlled Bartacking SM Specifications

| Туре | SPS/E-BS1201H | SPS/E-BS1201M | SPS/E-BS1201L | SPS/E-BS1201K | SPS/E-BS1201M (HP) | SPS/E-BR1201M | SPS/E-BR1201L | SPS/E-BR1201K |
|------------------------|--------------------|--|--------------------|----------------|--|----------------------|----------------|--------------------|
| Application | Heavy materials | General materials | Light materials | Knitwear | General materials (hole fixing device) | General materials | Knitwear | Light materials |
| Sewing Scope (X, Y) | | | | X : 40mm, Y | : 30mm (Max) | | | |
| Maximum Speed | 3200spm | 3200spm | 2700spm | 2700spm | 3200spm | 2500spm | 2200spm | 2200spm |
| Stitch Length | | | | 0.05 ~ | 12.7mm | | (42) | |
| Needle | DP×17#19 | DP×5#16 | DP×5#11 | DP×5#11 | DP×5#16 | DP×5#16 | DP×5#11 | DP×5#11 |
| Hook | | Sta | andard shuttle h | ook | | | 2× rotary hool | (|
| Height of Presser foot | | Up to 17mm (step motor is used) | | | | | | |
| Needle Bar Stroke | | 41.2mm | | | | | | |
| Trimmer | | Electronic solenoid type | | | | | | |
| Wiper | | | | | 0 | | | |
| Lower Thread Counter | | | * | 1 | 0 | | | |
| Max Speed Limit | | 2 | Up to 10 | 00 ~ 3,200 spm | with an extern | al switch | 21 - 27 2 | |
| Feeding System | | R-θ method (step motor is used) | | | | | | |
| No. of Stitch Input | | Up to 10,000 stitches | | | | | | |
| No. of Pattern Input | | Up to 99 patterns (default : 32 patterns) | | | | | | |
| Scale Scope | | 20 ~ 200 % (adjustable by 1%) | | | | | | |
| Memory Device | | P-ROM · | | | | | | |
| Motor | | 550W direct drive AC servo motor (standard power: 600 W) | | | | | | |
| Optimal Temperature | 2.7 | 5°C~40°C | | | | | | |
| Optimal Humidity | | 20% ~ 80% | | | | | | |
| Power | | | Single-phase : | 100~240V, 3 | -phase : 200~ | 140V, 50/60H | lz · | |

Preparations before Use

3-1) Power Connection

Voltage SpecificationVoltage information is tagged on the power plug as indicated below.

| 이 기계의 전기 사양은 공장 출고 시 아래의 $oldsymbol{V}$ 표기되로 결선되어 $oldsymbol{S}$ | 있습니다. |
|---|---------|
| The Electric Specification of This Machine is Connected Under V M | larked. |
| V 단상 (1 Phase) | |
| 110V120V220V240V220V240 | V |

- 1. Do NOT use the machine with different voltage specification.
- 2. Please refer to Changing Power Voltage section before changing the voltage.
- Single phase connection (100V, 110V, 120V, 200V, 220V, 240V)
- 3-phase connection (200V, 220V, 240V, 380V)



In case of 3-phase 380V, it is necessary to install an additional trans box on the table (check it out upon making a purchase order).




3-2) Changing Power Voltage

- Use SMPS to maintain constant voltage when changing the input voltage.
- This machine adopts a free voltage system. Use the voltage connector to set voltage status of the main shaft board at 110V or 220V according to the input voltage.




Incorrect setting of the voltage connector may damage the control box.



3-3) Control Box LED Check

• LED displays the power supply status to each board. Therefore when problems occurs, it is easy to identify where the problems were developed.

1. E-SERIES




| LED | Power Supply Status | LED | Power Supply Status |
|------|--------------------------|------|-----------------------------|
| LED1 | Digital Board +5V Input | LED5 | Main Shaft Board 220V Input |
| LED2 | Digital Board +12V Input | LED6 | Main Shaft Board +5V Input |
| LED3 | Step Board +5V Input | LED7 | Main Shaft Board +12V Input |
| LED4 | Step Board +48V Input | | |

11


4

SM Operation 1 (Basic)

4-1) Names and Functions of Keys in the Operation Box



** Previous pattern number will appear when you turn on the power.
Refer to the following functions of LED and keys.







Press to set the machine back to the default value.





Press to increase/decrease the set value or to move the needle bar backward or forward.




One click to call a certain pattern.



- 1) For direct connection type, if the head is laid down on the side while the power is on, "oPEn" will appear. If READY key is on at this time, sewing does not start with your pedaling.
- 2) If the head is laid down on the side while sewing, "oPEn" will not appear until sewing is completed.

4-2) Setting Item Data


You can set each item in the following order.




A. Turn on the power.

Item "Pattern No." will lit up and the previous pattern number will appear.

B. Set the pattern number.




C. Set X Scale %.



- 1) Press SELECT to display item "X-Scale".
- 2) Press +/FORWARD, -/BACK to set within the range of 20%~200%.


D. Set Y Scale %



- 1) Press SELECT to display item "Y-Scale".
- 2) Press +/FORWARD, -/BACK to set within the range of 20%~200%.


E. Adjustment of Presser Plate Height

a. Adjustment of ascending height



- 1) Communication ready Press the key to display the height of the presser foot when it is lifted.
- 2) Set the height within the scope of H 10 ~ H 17 by pressing +/FORWARD and -/BACK.
- 3) Press the READY key to save the changed values and make the machine return to the ready mode.


b. Adjustment of descending height




- 1) CF card download Press the key to display the height of the presser foot when it descends.
- 2) Set the height within the scope of L 1 ~ L 17 by pressing +/FORWARD and -/BACK.
- .3) Press the READY key to save the changed values and make the machine return to the ready mode.



F. Set Sewing Speed



G. Setting Done



- 1) Press READY.
- Presser plate will move/lift and READY light will be on.
 The machine will be on standby
- * You can press SELECT to confirm the setting.



Check the pattern number before starting the machine.


1) If READY is pressed with the pattern number "0" (default status), the machine will move back to original point. Use it to check the machine original point.

2) If you select a pattern that contains no data, error "Er01" will appear. Select other pattern.

4-3) Checking Pattern Shape



- Make sure to check the pattern shape after selecting pattern number.
 If pattern goes beyond the driving limit of the presser plate, needle and presser plate may conflict during sewing and result in serious problems, i.e. needle break.
- 2) Do NOT pedal 2nd step while checking the pattern shape. 2nd step pedaling starts sewing.




- In READY status, press pedal 1st step to bring down the presser plate.
- 2) The presser plate moves by one stitch at every press of +/FORWARD or -/BACK. Press down the keys to move the plate continuously.
- 3) Press RESET to move the needle to the starting point. The presser plate will move up.

◄ CAUTION ▶


Take your foot off the pedal when the needle starts to move (even a stitch).

4-4) Sewing



- 1) Place the work material on the presser plate.
- 2) Pedal 1st step to bring down the presser plate. Take your foot off the pedal to lift the plate.
- Pedal 2nd step with the presser plate down and the sewing will start.
- 4) When the sewing is completed, presser plate will go up and move to the sewing starting point.

2-step pedal switch interconnection




1st step pedaling: clamp function

• 2nd step pedaling: sewing starts




4-5) Changing Sewing Pattern



- 1) Press READY (READY light will turn off).
- 2) Press SELECT to display item "NO".
- 3) Set (B) ~ (F) items in 4-2 and move to the item of checking pattern shape.

4-6) Lower Thread Winding

A. Lower thread winding while sewing




Thread as shown in the picture and wind the lower thread.

B. Lower thread winding only



During lower thread winding, the feed plate does not move but the needle moves. Therefore, make sure no object is under the needle during the winding.



- Press SELECT to select the item "WINDER".
 * If READY is on, WINDER is not selected.
- 2) Press READY.
- 3) Press the pedal switch to 2nd step. Bobbin winder will start to wind.
- 4) Press the pedal switch to 2nd step again. Winding will stop.
- 5) Press READY to end winding.

◆ CAUTION ▶

When using hole fixing device, if you shift to bobbin winding mode and pres READY, the pin hole will go down and the presser plate will move to the original point.

SM Operation 2 (Advanced)

5-1) User Program

You can register and use 26 different programs (P1-P26) as user programs.

The 26 user programs can hold information, i.e. pattern number, X scale %, Y scale %, and sewing speed. It will be convenient for you to register repeatedly used patterns in the user program.

(1) Registering the User Program

Ex) Registering the following set-up as P1.

Pattern Number 3

X scale %: 50%

Y scale %: 80%

Maximum speed limit: 1800spm

- A. Press SELECT and turn on the power.
- B. Press P1.
- C. Press SELECT to display number items
 Press +/FORWARD, -/BACK to set the pattern number at 3.
- D. Press SELECT and use +/FORWARD, -/BACK to set the X scale % at "50%" and Y scale % at "80%" and the maximum speed limit at "1800 spm".
- E. Press **READY** to end registration.
 - * To register P2-P26, press P2-P26 in B of the above and follow the rest of the procedures.
- F. After registration, turn off the power and turn it on again.

| • | P | - |
|---|---|---|
| | _ | |

(2) Selecting the User Program


| Reg. No. | Key(s) | Reg. No. | Key(s) | Reg. No. | Key(s) | Reg. No. | Key(s) |
|-------------|---------|-------------|-----------|-------------|---------|-------------|--------------|
| P01 | P1 | P08 | P1 + P3 | P15 | P2 + P6 | P22 | P1 + P2 + P3 |
| P02 | P2 | P09 | P1 + P4 : | , P16 | P3 + P4 | P23 | P1 + P2 + P4 |
| P03 | P3 | P10 | P1 + P5 | P17 | P3 + P5 | P24 | P1 + P2 + P5 |
| P04 | P4 | P11 | P1 + P6 | P18 | P3 + P6 | P25 | P1 + P2 + P6 |
| P05 | P5 | P12 | P2 + P3 | P19 | P4 + P5 | P26 | P4 + P5 + P6 |
| P06 | P6 | P13 | P2 + P4 | P20 | P4 + P6 | | |
| P07 | P1 + P2 | P14 | P2 + P5 | P21 | P5 + P6 | | |

By default, P1-P26 contain information of pattern number 1, X & Y scale 100%, and speed 1500. To not display P1-P26 mark when scrolling the pattern numbers, set the pattern number "0" in C of the above procedures.



(3) Sewing Operation

- Ex) Do sewing work according to P1 and then according to P3.
- A. Turn on the power.
- B. Press P1.
- C. Press READY. READY lamp will turn on and feed plate will move and go up.
- D. Check the pattern shape (refer to <Checking Pattern Shape> section).
- E. After checking, you can start sewing.
- F. After sewing is completed, press [P3]. Feed plate will search the original point and move to the starting point. (You can change the pattern with a short key (single press) even with the READY lamp on).
- G. Perform D and E of the above procedures.
- * P1-P26 will be displayed when changing pattern using +/FORWARD or -/BACK.



Unregistered programs will not be displayed.

5-2) Sewing using Combination Function

You can list the pre-registered user programs (P1-P26) in Cnb1 and Cnb2 and change the pattern in the order of the programs on the list.

* Maximum number of program combinations you can register in Cnb1 and Cnb2 is 30.

(1) Registration of Combinations

Ex) Combine P1, P2, and P3 (in that order) and register the combination in Cnb1.

A. Turn on the power pressing P1 and SELECT.

B. Press SELECT and then P1.

C. Press SELECT and then P2.

D. Press SELECT and then P3.

E. Press READY to complete the registration.

F. Turn off the power and turn it on again.

** To register in Cnb2, press P2 and SELECT in A of the above procedure.



Patterns that are not registered with function keys (P1-P26) cannot be combined.

127

(2) Sewing Operation

- A. Turn on the power.
- B. Change the pattern number using +/FORWARD or -/BACK. At every press, the pattern number will change as shown below. Scroll down to change.

$$0 \text{ to } 99 \leftrightarrow P1 \text{ to } P26 \blacktriangleleft$$

- * Unregistered P1-P26 and Cnb1-Cnb2 are not displayed.
- C. Press READY READY lamp will be lit and feed plate will move and go up.
- D. Check the pattern shape and start sewing.
- E. Sewing stages are formed according to the combination. Sewing will return to the first stage after each cycle is completed. Sewing will be done repeatedly.
- * ① If you want to go to the previous or the next pattern, press +/FORWARD or -/BACK while READY lamp is on. Number will be changed and the feed plate will move to the starting point.
- * ② P1-P26 in Cnb1-Cnb2 will change if patterns in P1-P26 have been changed after registration in Cnb1-Cnb2.
- Make sure to check each pattern shape (refer to
 Checking Pattern Shape
 section).
- * 4 The machine will automatically shift to the next pattern within the combination (for example Cnb1).



If you undo READY and press RESET during the combination sewing, you will move to the initial state of the selected combination.

5-3) Sewing using Lower Thread Counter

Workload counter can also be used as a lower thread counter. If you are repeating the same pattern, the machine will stop when it reaches the sewing limit of one bobbin. At this time, the lower thread counter should be set at reduction mode.



Caution

The counter is set as a workload counter (addition mode) as default.

To set the counter as a lower thread counter, you need to change the memory switch (refer to FUsing Memory Switch_a).

- A. Press SELECT with the READY light off. "COUNTER" will be displayed.
- B. Press RESET.
- C. Set the sewing limit of a single bobbin, using +/FORWARD and -/BACK.
- D. The counter value will drop by 1 after each sewing is completed.
- E. When you sewed to the set limit, the machine will not sew even you pedal.
- F. Replace the bobbin and press RESET.
- G. Repeat (D) \sim (F).



5-4) Precautions

- A. Make sure to thread and sew after the thread tension plate is shut. The plate opens after trimming.
- B. If error lamp turns on, investigate the cause and take appropriate actions.
- C. Do not pull the sewing fabric, while sewing is conducted. The needle position might be improperly changed. In the case of needle position distortion, press READY twice to bring the needle to the right position.
- D. Do NOT turn off the power with the needle bar down.
 - Sewing speed for different work


| | Sewing speed (SPM) |
|-----------------------------|--------------------|
| | E-Series |
| Denim 8 sheets | 2,700 ~ 3,200 |
| Denim 12 sheets | 2,700 ~ 3,000 |
| Clothes | 2,700 ~ 3,200 |
| Clothes (artificial thread) | 2,500 ~ 2,800 |
| Knit | 2,300 ~ 2,500 |
| Underwear | 2,300 ~ 2,500 |

- E. Set the sewing speed according to the above table in order to prevent thread break from heat.
- F. For materials like underwear, lower the needle bar height in order to prevent jump stitch (refer to <Adjusting Needle Bar Height>).

Using Memory Switch

6-1) Memory Switch Operation

The memory switch has two major functions: general sewing function (changing general operation) and servo moto controlling function (changing servo motor operation).



- 1) Turn on the power pressing READY and RESET.
- 2) For changing general sewing-related functions, press A.
- 3) For changing servo motor control-related functions, press B and operate the memory switch.
- * Turn off the power and back on again after changing the memory switch set-up.

6-2) Example of Memory Switch Set-up

(1) Setting maximum sewing speed

A Turn on the memory switch and press +/FORWARD. You will see "A-01" on the screen.

→ A - 01

B. Press READY and you will see the present set-up.

→ 2000

C. Press -/BACK to change the set-up value to 1800.

1800

D. Register the set-up value by pressing READY.

•

→ A - 01



(2) Setting Softstart Speed

You can change the speed for the first 1-5 stitches by 100 spm.

| | Scope | Default |
|------------|------------|-----------|
| 1st stitch | 400 ~ 900 | 400 spm |
| 2nd stitch | 400 ~ 2700 | 900 spm |
| 3rd stitch | 400 ~ 2700 | 2,300 spm |
| 4th stitch | 400 ~ 2700 | 2,300 spm |
| 5th stitch | 400 ~ 2700 | 2,300 spm |

• The above values may not be the same for all machine types. (above is for M and H types)

For the maximum rotation number, general sewing function No. A-01 (maximum sewing speed) applies first.

| Ex) Changing the 1st stitch 400→900 rpm and the 2nd stitch 900→1,200 rpm | |
|---|-----------------|
| A. Turn on the memory switch and press +/FORWARD to display "A-02" on the screen. | → A - 02 |
| B. Press READY to display the present set-up value (1st stitch speed: 400 spm). | → 1-04 |
| C. Press +/FORWARD to change to "1-09" (changing to 900 spm). | ▶ 1-09 |
| D. Press SELECT (2nd stitch speed 900spm is displayed). | → 2-09 |
| E. Press +/FORWARD to change to "2-12" (changing to 1,200 spm) | → 2-12 |
| F. Register the set-up using READY. | → A - 02 |

(3) Setting Pattern Data Call Function

You can inactivate calling unnecessary patterns. This prevents calling wrong patterns by mistake and helps you call to necessary patterns.

Ex) Inactivating calling of patterns 1 and 2

- A. Turn on the memory switch and press +/FORWARD to display "A-03" on the screen.
- **→** A 03

- B. Press READY to display the present set-up value.
 - @ part : pattern number
 - (b) part : 0 :calling impossible 1 :calling possible
- C. Press /BACK to change "1" in (b) to "0".
- D. Press SELECT to change "1" in @ to "2"
- E. Press -BACK to change "1" in 6 to "0".
- F. Register the set-up using READY.

- **→** 01-1
- **→** 01-0
- **→** 02-1
- **→** 02-0
- **→** A 03

(4) Setting the Counter Function

Ex) Changing production counter (addition mode) to lower thread counter (reduction mode)

- A. Turn on the memory switch and press +/FORWARD to display "A-05" on the screen.
- **→** A 05

B. Press READY to display the present set-up value.

→ 0

C. Press +/FORWARD to set "05-1".

→ 1

a part : 0 : production counter1 : lower thread counter

→ A - 05

D. Register the set-up using READY.



(5) Selecting Upper Thread Holding Function

For pneumatic type, if you want to use an upper thread holding function, change the parameter as below.

- A. Turn on the memory switch and press +/FORWARD to display "A-32" on the screen.

- B. Press READY to display the present set-up value.
 - a part : 0 : holding device OFF
 1 : holding device ON

• 0

C. Press +/FORWARD to change @ "0" to "1"

→ 1

D. Register the set-up using READY.

→ A - 32

(6) Selecting between Integrated/Separated Pedals

For pneumatic type, if you want to use a separated pedal, change the parameter as below.

Ex) Using a separated pedal

- A. Turn on the memory switch and press +/FORWARD to display "A-33" on the screen.
- **→** A 33

- B. Press READY to display the present set-up value.
 - a) part : 0 : integrated pedal1 : separated pedal

→ 0

C. Press +/FORWARD to change @ "0" to "1".

→ 1

D. Register the set-up using READY.

→ A - 33



To use a separated pedal as an integrated pedal, press -BACK between step B and step C and change @ "1" to "0." Then register the change using READY.

6-3) Memory Switch Functions Table

(1) General sewing functions (A Group)





Turn on the power pressing and . Turn on the memory switch pressing P1.

| No. | Functions and Description | Scope | 1 | Default | Uni |
|--------------|---|---|---|------------------|-----------|
| A-01 | Setting maximum sewing speed | General: 100~3,200 Heavy: 100~3,200 Light: 100~2,700 Knitwear: 100~2,700 Buttons: 100~2,700 Hole fixing: 100~3,200 | 2, 2, 2, 2, 2, 2, 2, 2, | 100sp | |
| A-02 | Setting speed for the first 1-5 stitches (Softstart function, different by type) | 1st stitch: 400~900 2nd stitch: 400~2,000 3rd stitch: 400~2,000 4th stitch: 400~2,000 5th stitch: 400~2,000 | 400 spm 900 spm 2,300 spm 2,300 spm 2,300 spm | | |
| A-03 | Setting pattern data calling (You can set for each pattern) | 0 : calling impossible 1 : calling possible | 1201 1~22:1 1 23~99:0 3 | | |
| A-04 | Setting display and change possibility of X,Y scale rate and maximum speed limit (prevent errors or mistakes) | 0 : change impossible 1 : change possible | 25~39.0 3 | 1-99:0 57-99:0 | |
| A-05 | Setting counter function Production counter : addition count Lower thread counter : reduction count | 0 : production counter 1 : lower thread counter | | 0 | |
| A-06 | Setting center point for scale | 0 : original point 1 : sewing start point | | 0 | |
| A-07 | Setting whether to search original point after sewing (sewing with ordinary pattern number) | 0:OFF 1:ON | | 0 | |
| A-08 | Setting whether to search original point after sewing (sewing with function combination) | 0:OFF 1:ON | 0 | | |
| A-09 | Setting drive scope to infinite | 0 : Infinite 1 : limited | | | |
| A-10 | Setting starting angel for X, Y drive | -100 ~ 100° | Belt type : - | 1 | |
| A-11 | Setting trimming speed | 200 ~ 400spm | 4 | 100 | |
| A-12 | Setting reverse rotation after trimming | 0:OFF, 1:ON | 0 | | |
| A-13 | Setting angle for reverse rotation after trimming | 0~70° | 0° | | 1 |
| A-14 | Setting whether to use electronic wiper | 0:OFF 1:ON | 1201, 1202 1254 0 1 | | - |
| A-15 | Faster moving of presser foot after trimming | 0:OFF, 1:ON | 1 | | |
| A-16 | Setting search for original point after certain amount of sewing (after amount set in A-17) | 0:OFF 1:ON | 0 | | |
| A-17 | Number of automatic search for original point | 0~1000 | | 1000 | |
| 4-18 | Time for electronic wiper ON | 4~1024 ms | | 100 ms | 4 |
| A-19 | Canceling trimming | 0 : trim ON 1 : trim OFF | | 0 | |
| 4-20 | Time for solenoid 0 full on (clamp solenoid) | 4~72 ms | detection to be a | 52 ms | 4 |
| A-21 | Time for solenoid 1 full on (trimming solenoid) | 4~1020 ms | | 100 ms | 4 |
| 4-22 | Time for solenoid 2 full on (sub solenoid 2) | 4~1020 ms | | 100 ms | 4 |
| 4-23 | Time for solenoid 3 full on (sub solenoid 3) | 4~1020 ms | | 100 ms | 4 |
| A-24 A-25 | Solenoid 0 duty (clamp solenoid) | 10~25% | | 10% | |
| 4-25 4-26 | Solenoid 1 duty (trimming solenoid) Solenoid 2 duty (sub solenoid 2) | 10~25% | | 20% | |
| 4-20 4-27 | Solenoid 2 duty (sub solenoid 2) Solenoid 3 duty (sub solenoid 3) | 10~25% | - | 20% | 1 |
| A-28 | Delay time for clamp solenoid moving up | 10-2378 | | 2076 | - |
| A-29 | Delay time for clamp solenoid moving down | † - | | • | |
| A-30 | Setting OFF time for electronic wiper | 4~1020 ms | Others Hole fix device 40 ms 100 ms | | 4 |
| A-31 | Setting whether clamp moves up/down after mid trimming | 0:Down, 1:Up | 701113 | 1 | |
| 4-32 | Setting pneumatic thread holder | 0:OFF, 1:ON | | 0 | 1 |
| 4-33 | Setting integrated/separated pedal (For pneumatic only. Others have integrated pedals) | - | | - | |
| A-34 | Setting whether to use pin hole device | 0:OFF 1:ON | Others Hole fix device | | |
| A-35 | Setting whether to use head open/close | 0:OFF 1:ON | Only i | | |
| A-36 | Whether to use upper stop when turn power on | 0:OFF 1:ON | Only in Direct type | | |
| A-37 | Set time for AC off checking | 4~48 [ms] | | 1 20 ms | |
| WARKING. | | 4 ~ 1024 [ms] | 20 ms | | 91 (0.17) |



(2) General sewing functions (C Group)





Turn on the power pressing and . Turn on the memory switch pressing P3.

| No. | Functions and Description | Scope | Default \ | Unit |
|------|--|------------------|--------------|-------------|
| C-01 | When the electronic wiper is used (A15=1), set the standby time from trimming to wiper motion. | 1 ~255[ms] | 165[ms] | 1[ms] |
| C-02 | Set the operating angle of the trimmer solenoid | 1 ~250 [degrees] | 40 [degrees] | 1 [degrees] |

(3) Servo Motor Control Functions (B Group)

Turn on the power pressing






. Turn on the memory switch pressing P2.

| | Functions and Descriptions | Function Name | Scope | _ Default | | | |
|------|--|---------------|-------------------------------|---------------|------------|-------|------------------------------|
| No. | | | | Fortuna III | Forturn IV | Sanyo | Unit / Reference |
| B-01 | Speed for location detection for stop | pos_spd | 2~510 | 220 | 400 | 400 | 2spt |
| B-02 | Speed immediately before stop | end spd2 | 0~255 | 16 | 50 | 50 | 1spt |
| B-03 | Delay time to stop at right position | StopDelay | 4~1020 | 80 | 20 | 20 | 4ms |
| B-04 | First distance of location detection | DIST1 | 0~255 | 50 | 50 | 50 | 1Pulse |
| B-05 | Speed P-Gain | KC1A | 0~1000 | 20 | 15 | 30 | 1 |
| B-06 | Not used | _ | - | | _ | | _ |
| B-07 | Speed D-Gain | KC1C | 0~1000 | 0 | 15 | 0 | 1 |
| B-08 | Not used | _ | - | | _ | | - |
| B-09 | Position P-Gain | KF1A | 0~1000 | 175 | 125 | 100 | 1 |
| B-10 | Not used | - | _ | | - | | - |
| B-11 | Position D-Gain | KF1C | 0~5000 | 1500 | 1750 | 700 | 1 |
| B-12 | Speed unit | spd_unit | 1~255 | | 100npm | | 1rpm 1 |
| B-13 | Strength when pully fix | KH1 | 10~100 | | 40 | | 1 |
| B-14 | Distance recovered when pully fix | KH2 | 10~1000 | | 20 | | 1 |
| B-15 | Speed reduction rate from stop sign to location detection speed | accelA | 2~100 | 60 | 40 | 35 | 2 % |
| B-16 | Speed increase rate | accelB | 10~100 | 70 | 70 | 25 | 1.00 |
| B-17 | Speed reduction rate | accelC | 10~100 | 30 | 40 | 15 | |
| B-18 | Speed reduction rate from location detection speed to stop | accelD | 2~100 | 6 | 8 | 5 | . 1 |
| B-19 | Sewing machine inertia value | Inertia | 0~255 | | 0 | • | Inertia tuning |
| B-20 | Not used | SPMUPPER | _ | | - | | - |
| B-21 | Highest stop position of UDC | UPPosition | 0~8000 | 440 | 720 | 4000 | 1 |
| B-22 | Not used | IND_REFM | _ | 55.50 | _ | | _ |
| B-23 | Second P-Gain | KF2A | 0~1000 | 350 | 500 | 200 | 1 |
| B-24 | Second D-Gain | KF2C | 0~5000 | 2500 | 3000 | 500 | 1 |
| B-25 | SM PULLY SIZE | PULY_SIZEM | 0~8000 | 1140 | 1440 | 8000 | 1 |
| B-26 | Lowest stop position | CutStartM | 0~358 | | 70 | | 1 |
| B-27 | Upper stop position | CutEndM | 0~358 | 800 | 350 | 0 | Fortuna III is a fixed value |
| B-28 | Synchro sensor detection time | SLockTmM ÷ | 5~1275 | | 40×0.1 | | 0.5s |
| B-29 | Overload detection time | OvLoadM | 5~1275 | 30×0.1 | | 0.5s | |
| B-30 | Motor fixing is possible/impossible, while the machine is not in operation | HOLD_FG | 0: impossible 1: possible | 0: impossible | | 1 | |
| B-31 | Direction of servo motor rotation | DIR_MODE | 0: anti-clock 1: clockwise | 1: clockwise | | 1 | |
| B-32 | Original point sensor detection time | Orgtm | 4~1020ms | | 500ms | | 4ms |



Shaded Areas



- B-04 (DIST1): A location where sudden speed reduction takes place for stop. The higher this value, the more stable speed reduction, but final stop distance will be longer.
- B-08 (KC2): Can be calculated by inertia tuning. The higher this value, the slower the distance tracking. (FOR PROFESSIONAL ENGINEERS ONLY)
- B-12 (KF2): Can be calculated by inertia tuning. The higher this value, the slower the speed tracking. (FOR PROFESSIONAL ENGINEERS ONLY)
- B-15 (accelA): Can be calculated by inertia tuning. This represents speed reduction from after pedal stop signal input to sudden stop. The higher value means sudden slowdown, but too high value may result in inability to sudden slowdown.
- B-17 (accelB): Represents level of speed acceleration by pedal. The higher this value, the higher acceleration to the target speed, but speed fluctuation may also increase when reaching the target speed.
- B-18 (accelC): Represents level of speed reduction by pedal. The higher this value, the faster reduction of speed to the target speed, but speed fluctuation may also increase when reaching the target speed.

* Examples of the shaded functions

- (1) Unable to come to sudden stop and stops at one more stitch
 - This happens when the machine has been operating at a very high speed or when the workload is large and the machine cannot reduce speed in short time. Increase B-04 and B-15 values to an appropriate level.
- 2 Motor is slow to adjust to new speed when machine speed is changed
 - This happens when the speed change level is smaller than the machine workload change. Increase B-17 and B-18 values to an appropriate level.

Maintaining/Repairing

7-1) Cleaning Control box

Caution

Turn off the power before cleaning the machine to prevent accidents associated with mistaken machine operation.







[C/B Rack Structure]

Clean the cooling fan and the inside of the control box on a weekly basis.


| No. | Board type | |
|-----|------------------|--|
| 1 | Power board | |
| 2 | 2 Digital board | |
| 3 | Step board | |
| 4 | Main shaft board | |

7-2) Replacing Fuse



■ To prevent electric shock, wait 5 minutes after power off to open the cover.

Make sure to turn the power off when opening the control box. Change to a fuse of a designated capacity.



1 fuses are required.

| No. Capacity | | Use | | |
|--------------|-----|-----------------------|--|--|
| F1 | 15A | Main power protection | | |




7-3) Testing the Machine

Test each part of the machine. If malfunction is found, address the relevant electrical errors.


** To use the machine test function after running the machine test, press SELECT and then move by using +/FORWARD and -/BACK. To completely stop the machine test and then start sewing, turn off the power and turn it back on again.

(1) Running Machine Test



- 1. Turn on the power using P1, P2, and P3 simultaneously.
- 2. TEST sign will briefly appear on the screen and you will then see "t-01".

(2) Testing Step Motor Drive and Original Point Sensor




- 1. Turn on the Machine Test and press READY.
- 2. Press the relevant key and the needle will move.
- X-axis original sensor signal and Y-axis original sensor signal will appear on X-scale lamp and Y-scale lamp, respectively.
- 4. You will know it is OK if the above two lamps are on when the needle is on the left upper side of the feed plate.
- 5. Since the clamp shaft does not use the sensor, the normal operation can be checked with the up/down movement.
- 6. End the test by pressing SELECT.



During the test, make sure that the feed plate does not feed the power to the limit. This may cause problem in power supply.


....

(3) Solenoid Test




- 1. Run the Machine TEST and then press +/FORWARD and -/BACK to display "t-02".
- 2. Press READY.
- 3. Press the relevant key to run the solenoid and the relevant lamp will turn on.
- 4. Press SELECT to end the test.
- Wiper solenoid is an optional function for pneumatic specification (HA).
- For 1254 (pattern taker), RESET button will serve as a presser foot solenoid and the key will activates upper feed plate in pneumatic type.

(4) Testing Main Shaft Motor



- 1. Run the Machine TEST and then press +/FORWARD and -/BACK to display "t-03".
- 2. Press READY.
- Press READY and the motor will rotate. Speed of the main shaft motor will be displayed on the screen. Press READY again to stop.
- 4. Adjust the speed using +/FORWARD and -/BACK keys.
- 5. Press SELECT to end the test.

(5) Testing Encoder



- 1. Run the Machine TEST and then press +/FORWARD and -/BACK to display "t-04".
- 2. Press READY.
- 3. Rotate the pulley clockwise and the screen will display encoder angle. No lamp will turn on.


◆ CAUTION ▶

No change in value means encoder-related errors including connector.

4. Press SELECT to end the test.



(6) Testing Synchronizer




- 1. Run the Machine TEST and then press +/FORWARD and -/BACK to display "t-05".
- 2. Press READY.
- Rotate the pulley manually. The screen will display the rotation number and the No. lamp will display synchro signal.

◆ CAUTION ▶

No change in value after more than one rotation means synchro-related errors including connector.


4. Press **SELECT** to end the test.

7) Testing Pedal Input




- 1. Run the Machine TEST and then press +/FORWARD and -/BACK to display "t-06".
- 2. Press READY.
- Press pedal to 1st step and No. lamp will turn on. Press to 2nd step and you will see X-scale lamp be lit.
 Pressing Aux 1 switch will turn on Y-scale lamp and Aux 2 switch on speed lamp.
- 4. Press SELECT to end the test.

8) Testing Auxiliary Output



- 1. Run the Machine TEST and then press +/FORWARD and -/BACK to display "t-07".
- 2. Press READY.
- Press READY to light on all of the 8 auxiliary output (J11 on digital circuit board). Press READY again to turn off all of them.
- 4. Press SELECT to end the test.

(9) Testing Auxiliary Input




- 1. Run the Machine TEST and then press +/FORWARD and -/BACK to display "t-08."
- 2. Press READY.
- 3. Relevant lamps will be turned on according to the 8 auxiliary input signals (J9 on the digital circuit board).
- 4. Press SELECT to end the test.

◆ CAUTION ▶

Inputting air pressure reduction only applies to pneumatic type.

(10) Clamp motor motion test




- 1. Run the Machine TEST and then press +/FORWARD and -/BACK to display "t-09".
- 2. Press READY.
- 3. Press SELECT to set the delay times for clamp moving up and down. Use +/FORWARD and -/BACK keys to change the delay time.
- 4. Press RESET to end the test.



4) Other Functions

(1) Initializing Memory Switch

You can initialize the memory switch back to the default condition.



- Turn on the power pressing +/FORWARD and -/BACK at the same time.
- Memory switch will be initialized with the screen like below.
- 3) You will soon see the initial screen.


◆ CAUTION ▶

Memory switch initialization will remove all of your memory switch set-ups.

(2) Inertia Tuning

The controller performs an automatic inertia tuning suitable to the machine load.

Do not perform this function unless tracking of the sewing speed is too slow or the machine stops at one stitch later.




- 1) Press READY and -BACK at the same time to turn the power on.
- 2) The following screen appears.
- 3) Press the foot pedal until it moves to Step 2. The inertia tuning is automatically conducted.

◆ CAUTION ▶

After inertia tuning, the needle bar is stopped at a random position. Therefore, place the needle bar at the origin position, and turn off the power. Soon after, turn on the power again.

(3) Formatting Scalable Memory

You can turn the memory (where you downloaded patterns) to the default status.



- 1) Turn: on the power pressing —/BACK and P3 at the same time.
- 2) Memory will be formatted with the screen like below.

◆ CAUTION ▶

All of your downloaded patterns will be erased.

(4) Checking Program Version

 The following screen will appear for around 0.5 seconds after turning on the power. bH represents machine model and 16 its version.


b H 16

| Classification | | Presser foot Pneumatic | | Pneumatic | Maximum speed [spm] | Upgrade version dispaly |
|----------------|--------------------|------------------------|----------------------------|-----------|----------------------|-------------------------|
| | | error | use error maximum speed [s | | maximum specu [spin] | Direct |
| B1201HA | Pneumatic | × | 0 | 0 | 2,700 | EA02 |
| B1201H | Heavy | 0 | × | × | 3,200 | EHO2 |
| B1201M | Ordinary | 0 | × | X | 3,200 | EN02 |
| B1201MHP | Hole fixing device | 0 | × | × | 3,200 | EP02 |
| B1201L | Light | 0 | X | × | 2,500 | EL02 |
| B1201K | Knitwear | 0 | × | × | 2,500 | Eh02 |
| B1202 | Buttoning | 0 | × | X | 2,700 | Eb02 |

[Differences in programs and functions by type]

7-5) Installing and Replacing ROM


- (1) ROM Types and Classification
 - ① Scalable pattern ROM: This ROM contains sewing patterns made according to user's request and is not installed as a default. It is issued and installed for use at every request from the user.



- Sticker: Usually 8 digits, but may be different according to design.
 - Ex) bc000928, bj000930 ...



② Program ROM: This ROM contains essential programs for operating the sewing machine and is installed as a default. But it should be replaced or updated for adding or changing functions.



■ Sticker: 4-digits. Ex) b005, b006, b = 07...


| Name | Туре | Display on digital board | ROM type | No. of pins |
|----------------------|------|--------------------------|----------|-------------|
| 0 111 | | Direct | PDA | PDA |
| Scalable pattern ROM | E | U7 | 28C010 | 32 |
| Program ROM | E | U6 | 27C010 | 32 |

< ROM Type and Installation Location >

(2) Location of ROM Installation and Precautions



- 1) Make sure the power is OFF and the screen is blank before installing/replacing ROM.
- 2) Wrong mark of direction may damage ROM.
- 3) Make sure the pin is installed accurately on the socket.
- 4) When removing the existing ROM, be careful not to damage the board by using IC removing device or small (-) shape screw.



Location of ROM installation

(3) Using Scalable Pattern ROM

- ① Installing Scalable Pattern ROM
 - 1) Take the cover off the Bartack control box.
 - 2) As shown in the previous page, install the scalable design ROM onto the "U9" location on the digital board. Make sure to align the direction with the indication on the board (so the direction mark is on the left). Pin should go into the socket accurately.
- ② Using Scalable Pattern



- If the pattern number is set up by default as call impossible, change the set-up of the pattern to call possible.
- 2) Check the pattern shape and confirm that the needle and the presser plate do not conflict.

(for BS(BR)1201 series)

- Ex) Changing the scalable pattern No.33 and No.34 to call possible
- A. Turn on the power, pressing READY and RESET at the same time.

 Press A and then +FORWARD to display "A-03" on the screen.
- **→** A 03

- B. Press READY to display the present set-up value.
 - (a) part : pattern number, (b) part : 0 : call impossible, 1 : call possible
- **→** 01-1

- C. Press SELECT to change @ "1" to "33".
- D. Press +/FORWARD to change (b) "0" to "1".
- E. Press SELECT to change @ "33" to "34".
- F. Press +/FORWARD to change 6 "0" to "1".
- G. Press READY to register.
- H. Turn off the power and back on again. Select your desired number.

- → 33-0
- **→** 33-1
- **→** 34-0
- **→** 34-1
- **→** A 03



(For BS(BR)1202 series)

- Ex) Changing scalable pattern No.34 and No.35 to call possible.
- A. Turn on the power, pressing READY and RESET at the same time. Press A and then +/FORWARD to display "A-03" on the screen.
- **→** A 03
- B. Press READY to display the present set-up value.

 (a) part : pattern number, (b) part : 0 : call impossible, 1 : call possible
- **→** 01-1

C. Press SELECT to change @ "1" to "34".

→ 34-0

D. Press +/FORWARD to change © "0" to "1".

→ 34-1

E. Press SELECT to change @ "34" to "35".

→ 35-0

F. Press +/FORWARD to change (b) "0" to "1".

→ 35-1

G. Press READY to register.

- **→** A 03
- H. Turn off the power and back on again. Select your desired number.

(4) Using Hole Fixing Device

- SUB machine type
 - Direct connection type: SPS/E-BS(BR)1201M(HP)
- Parameter changes and default values for using electronic wiper and hole fixing device

| Parameter | Electronic wiper | | Hole fixing device | | |
|-----------|--|---------|---|---------|--|
| Group No. | Content | Default | Content | default | |
| A-18 | Electronic wiper ON time | 100[ms] | Pin attach descending time | 100[ms] | |
| A-23 | Electronic wiper full ON time | 100[ms] | Pin solenoid full ON time | 100[ms] | |
| A-27 ` | Electronic wiper duty value | 20[%] | Pin solenoid duty value | 20[%] | |
| A-30 | Electronic wiper OFF time | 40[ms] | Pin attach ascending time | 100[ms] | |
| A-34 | Pin attach use Yes/No (0: NO 1: YES) | 0 | Pin attach use Yes/No (0: NO 1: YES) | 1 | |



- 1) Electronic wiper cannot be used with the hole-fixing device.
- 2) Initializing to the hole-fixing device version will look like the above table. To use the patterns in the scalable ROM, you must set YES/NO for the pattern data calling possibility as shown below.
- 3) For SPS/E-BS1201M(HP) or SPS/E-BR1201M(HP), exclusive scalable pattern is provided. (No.33 ~ No. 92)
- How to Use

First set the possibility/impossibility of the pattern data call

- Ex) Changing exclusive scalable pattern No.33-92 to call possible
- A. Turn on the power, pressing READY and RESET at the same time. Press A and then +/FORWARD to display "A-03" on the screen.
- B. Press READY to display the present set-up value.
 - ② part : pattern number, ⑤ part : 0 : call impossible, 1 : call possible
- C. Press SELECT to change @ "1" to "33".
- D. Press +/FORWARD to change (b) "0" to "1".
- E. Repeat C and D steps to get (a) "91"
- F. Press SELECT to change @ "91" to "92"
- G. Press +/FORWARD to change (b) "0" to "1".
- H. Press READY to register.
- I. Turn off the power and back on again. Select your desired number

- **→** A 03
- **→** 01-1
- **→** 33-0
- **→** 33-1
- **→** 91-0
- **→** 92-0
- **→** 92-1
- **→** A 03



If pin hole cannot come up or go down, Er11 will occur. Turn OFF the power, fix the problem and turn on the power again.



7-6) Pattern download from PDA (or PC)

How to download patterns

- A. Turn on the power, while press Communication and Serial Download at the same time. The screen displays "Prog".
- Prog

B. Press READY and the screen displays "r-33".

r-33

C. Use +/FORWARD to change "r-33" to "r-40".

- D. Press READY. The screen displays "doUn" and then the download standby mode.
- r-40

* Pattern transfer from PDA (or PC)

- doUn
- E. When pattern transfer is completed, the screen displays "End".
 - - **◆ CAUTION** ▶ Whenever one package transfer is completed, a beep sound is issued.
- End

- F. Press RESET, and the screen displays "r-40".

 - In order to continue to download other patterns, repeat the procedures above from B to E.
- r-40
- G. Press SELECT, and the screen displays the sewing mode.
- XX

◆ CAUTION ▶

◆ CAUTION ▶

The screen displays the pattern numbers stored in the memory.

- H. Use -BACK or +FORWARD to select downloaded pattern numbers.
 - 40
- I. Press READY and conduct sewing by stepping on the pedal.
- The total number of stitches and beep sounds, when patterns are downloaded from PDA(or PC) to the machine

| Туре | Total No. of Stitches Downloaded (Number of packages) | Number of beep sounds | |
|-------------------------|---|-----------------------|--|
| SPS/E-BS(BR)1201 Series | 500 stitches | _ | |
| SPS/E-BS(BR)1202 Series | (4 packages) | 4 | |

^{* 1} package = 125 stitches

7-7) Pattern download from CF card

How to download patterns

A. Turn on the power, while pressing Communication and CF Card Download at the same time. The screen displays "CF--".

| _ | CE | |
|---|-----|---|
| 7 | CF- | _ |

B. Select the mode conversion key.

| Mode | Description | Screen display | | |
|------|---|----------------|--------------|--|
| Key | | Normal status | Error status | |
| P1 | Check whether there is a CF card | CF. OK | CF. Er | |
| P2 | Check the machine type | MC. bt | MC. Er | |
| P3 | Check the directory where patterns are stored | B L 0 5 | BL. Er | |
| P4 | Check patterns in the chosen directory | 05.10 | 05. Er | |
| P6 | Execute downloading | doUn | - | |

- C. Use "P1" to check whether CF is properly operating.
 - If there is no error, the screen displays "CF.OK" and then "Mode".
 - If there is an error, the screen displays "CF.Er". Check CF and then press "P1" again to find out whether it is properly operating.
- ◆ CF. OK

ModE

- D. If CF is properly operating, press "P3" and examine the folder where patterns are stored.
 - Press "P3" once, and the screen automatically displays the initial position where the folder exists.
- **→** BLO5
- Press "P3" again, and the screen displays the next folder.
- Choose the desired folder and press READY to store the folder location. Then the screen displays "Mode".

How to create a folder (directory) in the CF (CF reader is needed)

- 1) Create a folder named "Bbtk" for bartack-type machine in the CF card.
- 2) Create the pattern block folders (up to 96 folders can be created).
- 3) Create a folder name by entering Blk first, followed by a two-digit number, such as Blk00, Blk01, Blk02, ..., Blk95.

If the naming rule is not followed, the folder name cannot be displayed on the screen.

- 4) If there are no patterns within a folder, "BL.Er" is displayed on the screen.
- 5) A CF reader shall be additionally purchased by a user.



- E. Press "P4" and the chosen folder is examined for pattern files.
 - Press "P4" once, and the initial position of the pattern file within the chosen folder is displayed.
 - (a) Folder name
- (b) Pattern file name
- Press "P4" again, and the next pattern file position is displayed.
- Choose the desired pattern file and then press READY to store the location of the pattern file. The screen displays "Mode".

| • | 05. | 10 |
|---|-----|------------|
| _ | (a) | (b) |



How to create pattern files (in case of SSP-WE/2.0)

- 1) Up to 96 pattern files can be stored within a folder.
 - 2) Create a folder name by entering a two-digit number followed by extension ".btk" such as 00.btk, 01.btk, 02.btk, \cdots , 95.btk .

If the naming rule is not followed, the folder name cannot be displayed on the screen.

- 3) If there are no patterns within a folder, "FL.Er" is displayed on the screen.
- F. Press "P6", and the screen displays "r-33".
- G. Use +/FORWARD and change "r-33" to "r-40".
- H. If READY is pressed, the screen displays "doUn", and then the standby mode.
- I. When <u>CF Card Download</u> is pressed, it is checked whether CF is existing. If no error is found, pattern data are transferred. When the transfer is completed, the screen displays "End".
 - When an error occurs displaying "CF.Er" on screen, examine the CF card and press "P1". The screen displays "doUn", and the patterns are automatically transferred.

◆ CAUTION ▶

Whenever one package transfer is completed, a beep sound is issued.

- J. Press RESET, and the screen displays "CF--".
 - In order to continue to download other patterns, repeat the procedures above from E to I.
 - If the pattern download is desired from other folder, repeat the procedures above from D to I.
- K. Press SELECT, and the screen displays the sewing mode.

◆ CAUTION ▶

The screen displays the pattern number stored in the memory.

- L. Use —/BACK or +/FORWARD to select the downloaded pattern number.
- M. Press READY, and conduct sewing by stepping on the pedal.

→ r-33

→ r-40

→ doUn

→ CF.OK

→ End

→ CF--

→ 40


Error List

| No. | Display | Description | |
|-----|--------------------------|---|------------|
| | | | Error tone |
| 1 | Er01 | Pattern call is set "impossible" | × |
| 2 | Er02 | Error in scale function | × |
| . 3 | Er03 | Error in needle bar position | × |
| 4 | Er04 | Error in drive limit | × |
| 5 | Er05/Err55 | Error in clamp position | × |
| 6 | Er06 | Unable to move to X original point in given time | × |
| 7 | Er16 | Unable to move to Y original point in give time | × |
| 8 | Er36 | Original point cable is missing /XY original point sensor failure | × |
| 9 | Er07 | For pneumatic type (HA), if pneumatic is below standard | × |
| 10 | Er08 | Error in ROM version against new digital board | × |
| 11 | Er10 | Alarm that counter is "0" | × |
| 12 | Er11 | Pin hole cannot go down or move up | × |
| 13 | Er12 | No or bad scalable ROM | × |
| 14 | Er13 | Formatting incomplete | × |
| 15 | Er14 | SPMS fan failure | 0 |
| 16 | Er15 | Error in recognizing main motor type | × |
| 17 | 60, 61 | Synchronizer contact error | 0 |
| 18 | 126 | Error in operating sequence of the main shaft motor | 0 |
| 19 | Er70 | X-MOTOR SERVO OFF ERROR | 0 |
| 20 | Er71 | Y-MOTOR SERVO OFF ERROR | 0 |
| 21 | Er72 | P-MOTOR SERVO OFF ERROR | 0 |
| 22 | 127 | Encoder AB error | 0 |
| 23 | 128 | Encoder RST error | 0 |
| 24 | 129 | Main shaft motor overload | 0 |
| 25 | 130 | Error in synchronizer signat - | 0 |
| 26 | 9999 | Main shaft type error | 0 |
| 27 | EEPr | EEPROM error | 0 |
| 28 | CE17, LC18 BC20, AC19 | Communication failure in internal circuit of CPU board | 0 |
| 29 | oPEN | Laying the head on the side for direct-connection type | 0 |
| 30 | orLd | Overvoltage | 0 |


^{*} Error alarm \circ : Buzzer sound, \times : No buzzer sound



* Connecting Connector to Control Box (direct connection) (E-Series)




[Rear Cover of Control Box]



[Left Side Cover of Control Box]

| Cable | Machine | Control box | |
|----------------------------|---------|-------------|--|
| External power input cable | 2 | - | |


| Cable | Machine | Control box |
|---|---------|-------------|
| Presser plate solenoid cable (not used) | - | CN7 |
| Trimmer solenoid cable | 17 | CN10 |
| Wiper solenoid cable (not used) | - | CN13 |
| Main shaft motor cable | 16 | CN26 |
| X-axis encoder | 1 | CN25 |
| Y-axis encoder | 2 | CN38 |
| P-axis encoder | 3 | CN8 |
| Foot plate jumper cable | (4) | CN33 |
| Foot plate switch entry cable | (13) | CN35 |
| Head safety switch cable | 22 | CN29 |
| Pneumatic pressure output and auxiliary input cable | 2 | CN32 |
| X,Y Sensor Cable | 10 | CN36 |
| When the laser pointer is used | - | CN30 |
| Q-axis motor (to be used) | - | CN18 |
| P-axis motor power | - | CN14 |
| X-axis motor power | - | CN30 |
| Y-axis motor power | - | CN30 |



[Right Side Cover of Control Box]

| Cable | Machine | Control box |
|--|---------|-------------|
| Main shaft encoder (Sanyo) input cable | (15) | CN26 |
| OP box connection cable | 7 | CN27 |
| Synch input cable (only for Belt-type) | - | Unused |

▶ SPS/E-BS(R)12XX Series Block Diagram





9

How Select the Sewing Pattern List and the Sewing Lange

9-1) BS(R)1201 Series

| pplication | No. | Pattern | Stitch Number | Range o X (mm) | Sewing Y (mm) |
|-----------------------|-----|--|------------------|-------------------|------------------|
| * | 1 | MWW | 28 | 10 | 2 |
| | 2 | M | - 26 | 16 | 2.5 |
| | 3 | WWW. | 36 | 10 | 2 |
| | 4 | MWWW. | J | 16 | 2.5 |
| For Heavy and | 5 | M | | 10 | 2 |
| General Vaterials | 6 | MWWWWW. | 42 | 16 | 2 |
| | 7 | WWW. | | 16 | 2.5 |
| | 8 | MWWW | | 24 | 3 |
| | 9 | PHWWWWW. | 56 | 24 | 3 |
| | 10 | ************************************* | 64 | 24 | 3 |
| | 11 | } | 21 | 6 | 2.5 |
| For Thin Materials | 12 | WWW | 28 | 6 | 2.5 |
| | 13 | MWWM | 36 | 6 | 2.5 |
| | 14 | | 14 | 8 | 2 |
| For Knit | 15 | \mathbb{W}^{\times} | 21 | 8 | 2 |
| | 16 | WWWW | 28 | 8 | 2 |
| Straight Line | 17 | | 21 | 10 | 0 |

| Application | | Pattern | Stitch | Range of Sewing | | |
|------------------|-----|--|-------------|-----------------|--------|--|
| | NO. | Fattern | Number | X (mm) | Y (mm) | |
| | 18 | | — 28 | 10 | 0 | |
| | 19 | | | 25 | 0 | |
| Straight Line | 20 | *************************************** | 36 | 25 | 0 | |
| | 21 | ••••• | 41 | 25 | 0 | |
| | 22 | \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ | 44 | 35 | 0 | |
| Şemi Circle | 31 | MANNAN . | 42 | 11 | 7 | |
| | 32 | WWW X | 42 | 11 | 7 | |

| Vertical Vertical | | | | | | | | | | | |
|-------------------|----|---------|----|----|--|--|--|--|--|--|--|
| No. | 23 | 24 | 25 | 26 | | | | | | | |
| Pattern | | MANAMAM | | | | | | | | | |
| Stitch Number | 28 | 36 | 42 | 56 | | | | | | | |
| Range of X (mm) | 4 | 4 | 4 | 4 | | | | | | | |
| Sewing Y (mm) | 20 | 20 | 20 | 20 | | | | | | | |

| | Lin | ear Vertical | | |
|-----------------|-----|--------------|----|----|
| , No. | 27 | 28 | 29 | 30 |
| Pattern | 2.5 | | | |
| Stitch Number | 18 | 2 | 1 | 28 |
| Range of X (mm) | 0 | 0 | 0 | 0 |
| Sewing Y (mm) | 20 | 10 | 20 | 20 |

9-2) BS(R)1202 Series

| Pattern | | No. of | Range of Sewing | | | | | | |
|---------|------------|---------|-----------------|--------|--|--|--|--|--|
| No. | Pattern | Threads | X (mm) | Y (mm) | | | | | |
| 1 | | 6-6 | 3.4 | 3.4 | | | | | |
| 2 | | 8-8 | 3.4 | 3.4 | | | | | |
| 3 | | 10-10 | 3.4 | 3.4 | | | | | |
| 4 | | 12-12 | 3.4 | 3.4 | | | | | |
| 5* | | 6-6 | 3.4 | 3.4 | | | | | |
| 6* | | 8-8 | 3.4 | 3.4 | | | | | |
| 7* | | 10-10 | 3.4 | 3.4 | | | | | |
| 8* | | 12-12 | 3.4 | 3.4 | | | | | |
| 9 | (K) | 6-6 | 3.4 | 3.4 | | | | | |
| 10 | Z | 8-8 | 3.4 | 3.4 | | | | | |
| 11 | (K) | 10-10 | 3.4 | 3.4 | | | | | |
| 12 | X | 6-6 | 3.4 | 3.4 | | | | | |
| 13 | × | 8-8 | 3.4 | 3.4 | | | | | |
| 14 | × | 10-10 | 3.4 | 3.4 | | | | | |
| 15* | (X) | 6-6 | 3.4 | 3.4 | | | | | |
| 16* | X | 8-8 | 3.4 | 3.4 | | | | | |
| 17* | × | 10-10 | 3.4 | 3.4 | | | | | |

| Pattern | D. H. | No. of | Range of Sewing | | | | | | |
|----------|------------|---------|-----------------|--------|--|--|--|--|--|
| No. | Pattern | Threads | X (mm) | Y (mm) | | | | | |
| 18 | 0 | 6 | 3.4 | 0 | | | | | |
| 19 | (1) | 8 | 3.4 | 0 | | | | | |
| 20 | 1 | 10 | 3.4 | 0 | | | | | |
| 21 | 1 | 12 | 3.4 | 0 | | | | | |
| 22 | 1 | 16 | 3.4 | 0 | | | | | |
| 23 | (1) | 6 | 0 | 3.4 | | | | | |
| 24 | (1) | 10 | 0 | 3.4 | | | | | |
| 25 | (1) | 12 | 0 | 3.4 | | | | | |
| 26 | 1 | 6-6 | 3.4 | 3.4 | | | | | |
| 27 | 11 | 10-10 | 3.4 | 3.4 | | | | | |
| 28 | 11 | 6-6 | 3.4 | 3.4 | | | | | |
| 29 29 | (11) | 10-10 | 3.4 | 3.4 | | | | | |
| 30 | V | 5-5-5 | 2.9 | 2.5 | | | | | |
| 31 | V | 8-8-8 | 2.9 | 2.5 | | | | | |
| 32 | (A) | 5-5-5 | 2.9 | 2.5 | | | | | |
| 33 | (A) | 8-8-8 | 2.9 | 2.5 | | | | | |
| | | | | | | | | | |

- ** The magnifying and reduction range (X and Y) of standard sewing shown above is 100%. 66 patterns including 33 patterns can be additionally provided.
- ** In case of the pattern of "*" mark of Sewing Pattern No., a thread is trimmed after finish of first sewing to remove a line through sewing patterns. In case of SPS/E-BS(R)1202-01 and 02, press the pedal once more after finish of first sewing, or continuously press and release the pedal until second sewing begins. In case of SPS/E-BS(R)1202-03, just one time pressing of the pedal will do.
- A. If the central distance between use buttonholes does not conform for the standard sewing range of Sewing Pattern No., magnify or reduce the sewing range to adjust it.
- B. After the Sewing Pattern Number and the sewing range (X, Y) are changed, don't forget to check if the needle-point conforms to the buttonhole with regard to [Checking Pattern Shape].
- C. Rate of magnifying and reduction according to the sewing range.

| Sewing Area X,Y(mm) | 2.4 | 2.6 | 2.8 | 3.0 | 3.2 | 3.4 | 3.6 | 4.0 | 4.3 | 4.5 | 4.7 | 5.2 | 5.6 | 6.0 | 6.2 | 6.4 |
|---------------------------|------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Expansion & Reduction (%) | . 71 | 76 | 82 | 88 | 94 | 100 | 106 | 118 | 126 | 132 | 138 | 153 | 165 | 176 | 182 | 188 |

10. BASIC MANUAL

SPS/SUNSTAR/SPS/SUNSTAR/SPS/SUNSTAR/2000

SPS/E-Series

General Sewing: Sew by setting the sewing pattern, extension and

Use of Using Program: Conveniently call the sewing pattern that you reduction rate and sewing speed. frequent use. Use of combined function: Sew by combining the sewing pattern in the order that you want. Sewing Pattern Confirming: Confirm whether the sewing pattern and presser plate are interfered.

Reference: Turn the power on while pressing the switch.

1. User Program Registration

2. Use of Combined Function

3. Parameter Change


4. Parameter Initialization

P2 + P3 P1 +


6. Inertia Tuning

5. Machine Test


7. Formatting Scalable Memory



Use of Using Program: Conveniently call the sewing pattern that you frequent use.



Use of combined function: Sew by combining the sewing pattern in the order that you want.



Sewing Pattern Confirming: Confirm whether the sewing pattern and presser plate are interfered.







SUNSTAR MACHINERY CO., LTD.

HEAD OFFICE # 178-212, GAJWA - DONG, SEO - KU, INCHON, KOREA TEL: (82 - 32) 580 - 5600 ~ 4 FAX: (82 - 32) 584 - 3020

TRADE OFFICE # 178-212, GAJWA - DONG, SEO - KU, INCHON, KOREA TEL: (82 - 32) 580 - 5740 ~ 60 FAX: (82 - 32) 584 - 3025 ~ 6

WEB-SITE

http://www.sunstar.co.kr

E-MAIL" sunstar@sunstar.co.kr swftrade@sunstar.co.kr fortuna@sunstar.co.kr

OVERSEAS NETWORK

SUNSTAR MACHINERY (SHANGHAI) CO.,LTD. TEL: 86 21 6957 6311 FAX: 86 21 6957 6312 SUNSTAR MACHINERY (SHANGHAI) CO.,LTD. SHANGHAI BRANCH TEL: 86 21 6353 2233 FAX: 86 21 6353 8640 TEL: 86 532 482 2396 SUNSTAR NANJING BRANCH TEL: 86 25 464 7389 SUNSTAR HANGZHOU BRANCH TEL: 86 571 8704 4709 SUNSTAR TIANJIN BRANCH TEL: 86 22 2445 8882 SUNSTAR HONGKONG LTD. TEL: 852 2729 7078 SUNSTAR GUANGDONG BRANCH TEL: 86 769 249 1610 IEL: 86 769 249 1610
SUNSTAR FLUIAN BRANCH
TEL: 86 595 8859 8871
SUNSTAR IU.S.A. INC.
TEL: 3 05 591 9596
SUNSTAR HOCHIMINH BRANCH OFFICE
TEL: 84 8 592 3703 (883 3596)
SUNSTAR HANOI BRANCH OFFICE
TEL: 84 4 783 1446 SUNSTAR JAKARTA BRANCH OFFICE TEL: 62 21 4586 5839

SUNSTAR QINGDAO BRANCH TEL: 86 532 482 2236

FAX: 86 25 464 7389 FAX: 86 571 8601 6046 FAX: 86 22 2445 2400 FAX: 852 2729 7573

FAX: 86 769 234 4042 FAX: 86 595 8859 8872 FAX: 1 305 591 0661

FAX: 84 8 592 3704

FAX: 86 532 481 1262

FAX: 84 4 783 1447 FAX: 62 21 4586 5840

SUNSTAR MACHINERY(SINGAPORE) TEL: 008 65 6341 5015 SUNSTAR SAO PAULO OFFICE TEL: 55 11 3362 3434, 3337 2194 TEL: 55 11 3962 3434, 3337 2194
SUNSTAR MACHINERY EUROPE G.M.B.H
TEL: 43 2236 660 229
SUNSTAR NEW DELHI OFFICE
TEL: 91 124 280 3006
SUNSTAR BANGALORE OFFICE
TEL: 91 80 5126 3677
SUNSTAR CHENNAI OFFICE
TEL: 91 44 5232 1189 SUNSTAR MACHINERY (THAILAND) CO., LTD. TEL: 66 2 683 0088 FAX: 66 2 683 0089

AGENT:

May 2007 Printed in Kores