


PARTS LIST OF MODEL **DDW-126**

HIGH SPEED, SINGLE NEEDLE, LOCK STITCH, INDUSTRIAL SEWING MACHINE




AM - LOJA

HOW TO MAKE USE OF THIS PARTS LIST

1. This is a consolidated PARTS LIST of Model DDW-126
2. This list is divided, as a principle, into various sections according to the functions of parts and also contains illustrations to assist you visually.

For example, if you want some parts for the Needle Bar Components, just refer to the section on "NEEDLE BAR & MAIN SHAFT COMPONENTS" etc.

3. Numbers in the first column are reference numbers only, and merely indicate the position of the part in the illustration. Reference numbers should never be used in ordering parts. Always use the part number listed in the second column.
4. On bits and pieces parts such as screws, etc. the illustration shows only a representative one and so for the required amount of these parts, refer to the "Amt. Req." column on the list.
5. At the back of the list will be found a numerical index of all the parts shown in this list. This will facilitate locating the illustration and description when only the part number is known.



CONTENTS


1. FRAME & MISCELLANEOUS COVERS COMPONENTS.....	1
2. NEEDLE BAR & MAIN SHAFT COMPONENTS	2
3. HOOK SHAFT, UPRIGHT SHAFT & FEED SHAFTS COMPONENTS	3
4. STITCH REGULATING MECHANISM COMPONENTS	4
5. PRESSER BAR & LIFTING ROCK SHAFT COMPONENTS	5
6. OIL LUBRICATION MECHANISM COMPONENTS	6
7. OIL RESERVOIR & KNEE LIFTER COMPONENTS	7
8. HEAD COVER & THREAD TENSION COMPONENTS	8
9. NUMERICAL INDEX OF PARTS	9

HOW TO MAKE USE OF THIS PARTS LIST

1. This is a consolidated PARTS LIST of Model DDW-126
2. This list is divided, as a principle, into various sections according to the functions of parts and also contains illustrations to assist you visually.

For example, if you want some parts for the Needle Bar Components, just refer to the section on "NEEDLE BAR & MAIN SHAFT COMPONENTS" etc.


3. Numbers in the first column are reference numbers only, and merely indicate the position of the part in the illustration. Reference numbers should never be used in ordering parts. Always use the part number listed in the second column.
4. On bits and pieces parts such as screws, etc. the illustration shows only a representative one and so for the required amount of these parts, refer to the "Amt. Req." column on the list.
5. At the back of the list will be found a numerical index of all the parts shown in this list. This will facilitate locating the illustration and description when only the part number is known.



CONTENTS

1. FRAME & MISCELLANEOUS COVERS COMPONENTS.....	1
2. NEEDLE BAR & MAIN SHAFT COMPONENTS	2
3. HOOK SHAFT, UPRIGHT SHAFT & FEED SHAFTS COMPONENTS	3
4. STITCH REGULATING MECHANISM COMPONENTS	4
5. PRESSER BAR & LIFTING ROCK SHAFT COMPONENTS	5
6. OIL LUBRICATION MECHANISM COMPONENTS	6
7. OIL RESERVOIR & KNEE LIFTER COMPONENTS	7
8. HEAD COVER & THREAD TENSION COMPONENTS	8
9. NUMERICAL INDEX OF PARTS	9


1. FRAME & MISCELLANEOUS COVERS COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.
1	B-1142-125-000	Eslen tube	1
2	B-1143-125-000	Eslen tube holder	1
3	NS-5700420-SP	... Nut	1
4	SS-8110410-SP	Screw, for three-hole thread eyelet	1
5	B-1165-012-000	Plug	1
6	B-1115-155-000	Three-hole thread eyelet	1
7	SS-7080410-SP	Screw, nozzle holder	2
8	B-1145-125-000	Nozzle holder	2
9	B-1146-125-000	Eslen nozzle	1
10	NS-5080210-SP	Nut, for nozzle holder	1
11	B-1144-125-000	Nozzle connection	1
12	B-1141-125-000	Eslen wick	1
13	SS-2110920-SP	Screw, for throat plate	2
14	B-1109-012-A00	Throat plate	1
15	B-1110-012-000	Bed slide	1
16	B-1111-012-000	Bed slide spring	1
17	SS-6060210-SP	... Screw	2
18	B-1105-122-000	Bed screw stud (B)	1
19	B-1104-122-000	Bed screw stud (A)	1
20	B-1139-125-000	Eslen reservoir cap screw	1
21	B-1138-125-000	Eslen reservoir cap	1
22	B-1137-125-000	Eslen reservoir	1
23	B-1140-125-000	Eslen reservoir holder	2
24	SS-3090610-SP	Screw, for frame thread guide	2
25	B-1114-155-000	Frame thread guide	1
26	SS-4080610-SP	Screw, for nozzle connection	1
27	B-1147-125-000	Thrust ring, for Eslen wick	1
28	B-1108-122-000	Feed driving shaft stay plate	1
29	SS-6092420-SP	... Screw	2
30	B-1107-122-000	Feed rock shaft stay plate	1
31	SS-3091510-SP	... Screw	2
32	B-1113-155-OA0	Needle thread guide pin assembly	1

Ref. No.	Part No.	Description	Amt. Req.
33	B-1113-125-000	Top cover	1
34	B-1116-125-000	Top cover gasket	1
35	NS-5090310-SP	Nut, for Eslen reservoir holder	1
36	SS-7090710-SP	Screw, for Eslen reservoir holder	1
37	SS-7111120-SP	Screw, for side/top cover	5
38	B-1118-125-000	Side cover	1
39	B-1119-125-000	Side cover gasket	1
40	B-1101-125-OA0	Machine arm & bed complete	1
41	B-1159-041-000	Medallion	1
42	B-1123-126-000	Model plate	1
43	B-1161-012-000	Set pin, for model/number plate	4
44	B-1199-126-000	Number plate	1
45	B-1169-122-000	Plug screw	1
46	B-1170-122-000	... Gasket	1
47	B-1171-122-000	... Oil seal sponge	1
48	B-1166-122-000	Plug	1
49	B-1106-122-000	Bed leg	1
50	NS-6150310-SP	... Nut	2


2. NEEDLE BAR & MAIN SHAFT COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.
1	B-1414-125-000	Plug screw, for upper bushing	1
2	RO-0681901-00	• • • Rubber ring	1
3	B-1207-126-000	Needle bar crank	1
4	B-1402-144-000	Needle bar upper bushing	1
5	B-1401-144-B00	Needle bar (DB)	1
6	B-1406-125-000	Needle bar connection	1
7	SS-7110720-TP	• • • Screw	1
8	B-1403-155-000	Needle bar lower bushing	1
9	SS-8110310-SP	• • • Screw	1
10	B-1419-012-000	Pig tail thread guide	1
11	B-1422-155-000	Needle bar oil reservoir	1
12	SS-7080510-SP	Needle set screw	1
13	B-1410-125-000	Needle bar thread guide	1
14	MDB-100#1400	Needle	1
15	B-1206-126-000	Counterweight	1
16	SS-7681750-TP	• • • Screw (A)	1
17	B-1236-125-OA0	Needle bearing assembly	1
18	B-1408-122-000	Needle bar link	1
19	TA-0691001-RO	Plug, for main shaft bushing	5
20	SS-8151150-SP	Screw, for main shaft bushing	3
21	B-1414-012-000	Needle bar slide block	1
22	B-1415-125-000	Needle bar slide block guide	1
23	SS-7111410-SP	• • • Screw	2
24	B-1411-125-000	Needle bar crank oil splasher	1
25	SS-6090510-SP	• • • Screw	2
26	PT-0251800-SH	Tapered pin, for counterweight	2
27	B-1213-012-000	Oil felt retainer	1
28	B-1212-012-000	Oil felt, for retainer housing	2
29	B-1211-012-000	Feed eccentric retainer housing	1
30	SS-8681650-TP	Screw (B), for counterweight	1
31	B-1203-124-000	Main shaft center bushing	1
32	B-1204-155-000	Main shaft front bushing	1
33	B-3542-155-000	• • • Oil wick	1
34	TA-0300503-RO	• • • Plug	1


Ref. No.	Part No.	Description	Amt. Req.
35	B-1201-125-000	Main shaft	1
36	SS-8150710-TP	Screw, for feed eccentric	2
37	B-1208-125-000	Feed eccentric	1
38	SS-8660810-TP	Screw, for gear/pinion	4
39	B-1305-012-000	Gear	1
40	B-1306-012-000	Pinion	1
41	B-1204-122-000	Main shaft rear bushing	1
42	B-1235-122-000	• • • Gasket	1
43	SS-8150410-TP	Screw, for thrust collar	2
44	CS-1471012-SH	Main shaft thrust collar	1
45	B-1219-012-000	Oil felt, for rear bushing	1
46	SS-8152080-SP	Screw, for counterweight	2
47	B-1213-125-000	Counterweight	1
48	RO-1331701-00	• • • Rubber ring	1
49	B-1233-012-000	• • • Adjusting screw	1

3. HOOK SHAFT, UPRIGHT SHAFT & FEED SHAFTS COMPONENTS




Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	SS-4080620-TP	Screw, for feed dog	2	28	B-1801-122-000	Hook shaft	1
2	B-1613-012-A00	Feed dog (A)	1	29	B-1862-012-000	Hook shaft center bushing	1
3	B-1604-012-000	Feed bar shaft	1	30	SS-6111110-SP	... Screw	1
4	B-1602-002-000	Feed bar	1	31	B-1641-122-D00	Oil wick, rear, for feed driving shaft	1
5	SS-8620610-TP	Screw, for feed bar shaft	1	32	B-1641-12-B00	Oil wick, rear, for feed rock shaft	1
6	B-1601-122-000	Feed rock shaft	1	33	B-1607-122-000	Feed rock shaft	1
7	NS-6740510-SP	Nut, for plug screw	4	34	CS-0721216-SH	Hook shaft thrust collar	1
8	B-1113-012-000	Plug screw, for feed rock shaft/ feed driving shaft	4	35	B-1304-012-A00	Oil felt, for hook shaft rear bushing	1
9	B-1830-012-OA0	Sewing hook assembly	1	36	B-1304-012-B00	Oil wick, for hook shaft rear bushing	1
10	B-1839-155-OA0	Bobbin case assembly	1	37	B-1802-012-000	Hook shaft rear bushing	1
11	B-9117-155-000	Bobbin	1	38	B-1301-122-000	Upright shaft	1
12	B-1633-122-OA0	Feed driving shaft crank block assembly	1	39	B-1302-122-000	Upright shaft upper bushing	1
13	B-1706-012-000	Feed driving shaft crank	1	40	B-1318-122-000	... Oil wick	1
14	SS-7111410-SP	... Clamp screw	1	41	B-1303-122-000	Upright shaft lower bushing	1
15	CS-0640863-SH	Feed bar shaft thrust collar	1	42	B-1315-012-000	Oil wick	1
16	SS-8110510-SP	... Screw	2	43	SS-8151150-SP	Screw, for upright shaft bushing	2
17	B-1641-122-000	Oil wick, for feed rock shaft	1	44	B-1307-012-A00	Mitre gear (large)	1
18	B-1803-122-000	Oil wick, Hook shaft front bushing	1	45	SS-8660910-TP	... Screw	4
19	TA-0300503-RO	... Plug	1	46	B-1307-012-B00	Mitre gear (small)	1
20	B-1802-122-000	Hook shaft front bushing	1				
21	SS-7110810-SP	... Screw	1				
22	B-1835-012-000	Bobbin case holder positioning finger	1				
23	SS-6111620-SP	... Screw	1				
24	B-1641-122-C00	Oil wick, front, for feed driving shaft	1				
25	B-1703-125-000	Feed driving shaft	1				
26	SS-7111410-TP	Clamp screw, for feed driving shaft crank	1				
27	B-1863-013-000	Oil wick, for hook shaft center bushing	1				

4. STITCH REGULATING MECHANISM COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	B-1622-122-000	Stitch regulator	1	27	SD-1020861-SP	Hinge screw, for forked rod	2
2	SS-5661110-SP	Screw	1	28	B-1613-125-000	Feed rock shaft connecting forked rod	1
3	B-1633-122-0A0	Stitch regulating lever stud assembly	1	29	SS-8110520-TP	Screw, for lever shaft thrust collar	2
4	B-1627-122-000	Stitch regulating lever shaft crank	1	30	CS-0791016-SH	Stitch regulating lever shaft thrust collar	1
5	SS-5121210-SP	• • • Clamp screw	1	31	B-1702-012-000	Oil felt, for connecting rod	1
6	B-1623-122-000	Stitch regulating lever shaft	1	32	SS-6121610-SP	Clamp screw, for connecting rod	2
7	B-1646-122-000	Spring	1	33	B-1701-125-000	Feed driving shaft connecting rod	1
8	B-1648-122-000	Spring catch (B)	1	34	NS-5680410-SP	Nut, for hinge screw	3
9	WP-0371016-SD	• • • Washer	1	35	B-1642-122-000	Gasket, for lever shaft bushing	1
10	SS-4091010-SP	• • • Screw	1	36	B-1631-122-000	Stitch regulating lever shaft bushing	1
11	SD-1020851-SP	Screw stud, for stitch regulator	1	37	SS-7151210-SP	Clamp screw, for stitch regulating lever	1
12	B-1619-012-000	Stitch regulator connecting link	1	38	SS-6620730-PP	Screw, for stitch regulating lever	1
13	B-1621-012-B00	• • • Tapered screw	1	39	A-1626-001-000	Washer, for stitch regulating lever	1
14	RO-0742401-00	Rubber ring (small)	2	40	SS-7620750-SL	Adjusting screw, for lever shaft	1
15	RO-1342401-00	Rubber ring (large)	2	41	B-1621-125-000	Stitch regulating lever	1
16	B-1631-122-000	Stitch regulating screw bushing	1				
17	B-1634-122-000	Stitch regulating screw	1				
18	SS-8150710-SP	Screw (A), for lever shaft bracket	1				
19	B-1647-122-000	Stitch regulating lever shaft bracket	1				
20	B-1621-012-C00	Tapered stud, for connecting link	1				
21	SS-2090710-SP	Screw, for stitch regulating screw bushing	6				
22	B-1148-012-000	Spring, for screw bushing notch pin	1				
23	B-1147-012-000	Stitch regulating screw bushing notch pin	1				
24	B-1648-012-000	Stitch length indicating dial stopper	1				
25	B-1623-125-000	Stitch length indicating dial	1				
26	SS-6121050-SP	• • • Screw	1				


5. PRESSER BAR & LIFTING ROCK SHAFT COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.
1	B-1505-125-000	Presser spring	1
2	B-1507-125-000	Hand lifter connecting link	1
3	SD-0600271-SP	... Hinge screw	1
4	B-1512-125-000	Presser bar thread guide	1
5	SS-2090710-SP	... Screw	1
6	SS-8150710-SP	Screw, for hand lifter pin	1
7	B-1514-155-0A0	Presser spring regulator assembly	1
8	B-1505-155-000	Presser adjusting spring	1
9	SD-0600402-SP	Hinge screw, for hand lifter connecting link	1
10	SS-1091520-TP	Clamp screw, for presser bar connection	1
11	B-1504-125-000	Presser bar connection	1
12	B-1510-155-000	Presser bar bushing	1
13	SS-8110310-SP	... Screw	1
14	B-1512-012-000	Hand lifter	1
15	B-1501-155-000	Presser bar	1
16	B-1502-155-000	Presser bar joint rod	1
17	B-1512-155-000	Presser bar rubber cap	1
18	B-1515-012-000	Hand lifter pin	1
19	B-1524-012-0A0	Presser foot assembly	1
20	SS-7091110-SP	... Screw	1
21	B-3405-155-000	Lifting rock shaft	1
22	B-3406-125-000	Lifting rock shaft front crank	1
23	PT-0301600-S0	... Knock pin	1
24	B-3401-122-000	Bell crank bracket	1
25	SS-7120910-SP	... Screw	2
26	B-3403-012-000	... Pin	1
27	B-3402-122-000	Bell crank	1
28	SS-8080950-SP	Screw, for bell crank	1
29	SD-0600401-SD	Hinge screw, for connecting rod joint	1
30	B-3409-155-000	Lifting rock shaft connecting rod	1


Ref. No.	Part No.	Description	Amt. Req.
31	SS-7111110-TP	Clamp screw, for rear crank	1
32	B-3407-155-000	Lifting rock shaft rear crank	1
33	B-3416 012 000	Lifting rock shaft connecting rod joint	1
34	B-3404-122-000	Lifting rock shaft connecting rod spring	1
35	WP-0312516-SD	... Retaining washer	1

6. OIL LUBRICATION MECHANISM COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	SS-7111410-SP	Screw, for oil tube connecting screw	1	32	B-3528 122 000	Regulator adjusting screw indicator	1
2	B-3532-012-000	Oil tube connecting screw	1	33	SS-7091310 SP	Screw, for adjusting screw base	2
3	B-3536-122-000	Oil tube holder	2	34	B-3526 122 000	Oil quantity regulator valve	1
4	SS-7090710-SP	• • • Screw	3	35	NS-6150320-SP	Nut, for regulating screw	1
5	SS-6090510-SP	Screw, for return oil tube holder	1	36	B-3521-122-000	Oil regulating screw	1
6	B-3542-125-0A0	Return oil tube assembly	1	37	SS-7111120-SP	Screw, for oil distributor	3
7	B-3550-122-000	Return oil tube	1	38	B-3515-122 000	Main shaft oil distributor	1
8	B-3549-122-000	Return oil tube holder	1	39	B-3535-122-B00	Oil tube (B)	1
9	B-3552-125-000	Return oil nozzle	1	40	B-3546-125-000	Oil tube, for main shaft center bushing	1
10	B-3546-125-000	Return oil wick	1	41	B-3532-122-000	Gasket, for oil sight window	1
11	B-3542-125-000	Oil felt clamp	1	42	B-3531-122-000	Oil sight window	1
12	B-3543-125-000	Head oil felt	1	43	B-3533-122-000	Oil sight window base	1
13	B-3554-122-000	Return oil nozzle coupling	1	44	SQ-1110401-MZ	Oil sight window oil tube connecting screw	1
14	B-3545-125-000	Head oil returning felt	1	45	SS-4091010 SP	Screw, for oil sight window base	1
15	B-3525-122-000	Oil quantity regulator	1	46	B-3535-122-D00	Oil tube (D)	1
16	B-3534-012-000	Washer (gasket), for connecting screw	13	47	B-3530-122-000	Oil sight window oil tube holder	1
17	SQ-1110402-MZ	Oil tube connecting screw	13	48	B-3513-122-000	Main shaft oil supply pipe	1
18	B-3535-122-F00	Oil tube (F)	1	49	B-3512-122-00	• • • Clamping nut	1
19	B-3535-122-G00	Oil tube (G)	1	50	B-3511-122-000	• • • Clamping sleeve	1
20	B-3537-122-000	Oil wick holder	1	51	B-3501-125-000	Oil pump body	1
21	SS-7090510-SP	• • • Screw	1	52	SQ-1150451-MZ	Connecting screw, for oil tube	1
22	B-3536-155-000	Plug screw, for head oil siphon	1	53	SS-7111260-SP	Screw, for oil pump body	3
23	RO-1542401-00	• • • Rubber ring	1	54	B-3507-122-000	Oil pump impeller	1
24	B-1214-038-000	Head oil siphon plunger spring	1	55	SS-6080610-TP	• • • Screw	1
25	B-3534-155-000	Head oil siphon plunger	1	56	B-3505-122-000	Oil pump adapter	1
26	B-3535-122-A00	Oil tube (A)	1	57	B-3503-122-000	Oil pump screen frame (A)	2
27	B-3535-122-C00	Oil tube (C)	1	58	B-3504-155-000	Oil pump screen, upper	1
28	B-3535-122-E00	Oil tube (E)	1	59	B-3545-122-000	Oil pump oil guard	1
29	RO-0442401-00	Rubber ring, for oil quantity regulator valve	1	60	B-3506-125-000	Oil pump screen, lower	1
30	B-3537-122-000	Regulator adjusting screw base	1	61	B-3502-122-000	Oil pump cover	1
31	B-3527-122-000	Screw, for oil quantity regulator	2	62	SS-6081210-SP	• • • Screw	3


8. HEAD COVER & THREAD TENSION COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	B-3102-129-000	Rotary thread take-up cover	1	33	B-3107-012-000	Pig tail thread guide	1
2	SS-4060410-SP	. . . Screw	4	34	NS-6060350-SP	. . . Nut, front	1
3	SD-0600271-SP	Hinge screw, for cover plate	1	35	SS-2060310-SP	Screw, for face plate thread guide	1
4	B-3125-155-000	Disc spring, for cover plate	1	36	B-3109-155-000	Face plate thread guide	1
5	B-3122-155-000	Rotary thread take-up cover plate	1	37	SS-8621150-SP	Screw, for tension stud socket	1
6	SS-8090870-SP	. . . Stop screw	1	38	B-3106-155-000	Indicator	1
7	SS-7111810-SP	Screw, for take-up cover	1	39	SS-7060610-SP	. . . Screw	1
8	B-3104-199-000	Hinge screw, for take-up cover	1	40	WP-0250516-SD	. . . Washer	1
9	PT-0251800-SH	Knock pin, for take-up cover	2	41	B-3110-125-000	Face plate gasket	1
10	B-3105-155-000	Thread retainer housing	1				
11	SS-2080810-SP	Screw, for thread trimmer	2				
12	B-3107-125-000	Thread take-up thread trimmer	1				
13	SS-2090710-SP	Screw, for take-up cover frame	1				
14	B-3103-129-000	Rotary thread take-up cover frame	1				
15	PT-0100800-SO	Thread guide pin	1				
16	B-3126-012-000	Tension disc	2				
17	B-3132-012-000	Tension releasing disc	1				
18	B-3129-012-000	Tension spring	1				
19	B-3120-125-000	Tension nut grommet	1				
20	B-3116-125-000	Tension nut	1				
21	B-3128-012-000	Take-up spring	1				
22	SS-8090670-SP	Screw, for tension stud	1				
23	B-3127-012-000	Tension release pin	1				
24	B-3115-155-000	Tension stud	1				
25	B-3111-126-000	Tension stud socket	1				
26	B-3101-125-000	Face plate	1				
27	WP-0460556-SD	. . . Washer	3				
28	SS-7111120-SP	. . . Screw (A)	3				
29	SS-2110930-SP	. . . Screw (B)	1				
30	B-1905-126-BAO	Rotary thread take-up disk (B)	1				
31	SS-2110930-SP	. . . Screw	3				
32	NS-6060310-SP	Nut, for pig tail thread guide	1				

9. NUMERICAL INDEX OF PARTS

Part No.	Page	Ref. No.	Part No.	Page	Ref. No.	Part No.	Page	Ref. No.	Part No.	Page	Ref. No.	Part No.	Page	Ref. No.
EXCLUSIVE PARTS														
1626-001-000	4-39		B-1410-125-000	2-13		B-3115-155-000	8-24		B-8218-125-000	7-2		SS-4091010-SP	6-45	
1101-125-0A0	1-40		B-1411-125-000	2-24		B-3116-125-000	8-20		B-8221-012-000	7-20		SS-6060210-SP	1-17	
1104-122-000	1-19		B-1414-012-000	2-21		B-3120-125-000	8-19		B-8222-012-000	7-19		SS-6080610-TP	6-55	
1105-122-000	1-18		B-1414-125-000	2-1		B-3122-155-000	8-5		B-8223-122-000	7-17		SS-6081210-SP	6-62	
1106-122-000	1-49		B-1419-022-000	2-10		B-3125-255-000	8-4		B-8226-125-000	7-14		SS-6090510-SP	2-25	
1107-122-000	1-30		B-1422-155-000	2-11		B-3126-012-000	8-16		B-8227-125-000	7-13		SS-6090510-SP	6-5	
1108-122-000	1-28		B-1501-155-000	5-19		B-3127-012-000	8-23		B-8228-125-000	7-15		SS-6090810-SP	6-31	
1109-012-A00	1-14		B-1502-155-000	5-16		B-3128-012-000	8-21		B-8229-125-000	7-16		SS-6091510-SP	1-31	
1110-012-000	1-15		B-1504-125-000	5-11		B-3129-012-000	8-18		B-9117-155-000	3-11		SS-6092420-SP	1-29	
B-1111-012-000	1-16		B-1504-125-000	5-11		B-3132-012-000	8-17					SS-6111110-SP	3-30	
1113-012-000	3-8		B-1505-125-000	5-1		B-3401-122-000	5-24		THRUST COLLAR			SS-6111620-SP	3-23	
B-1113-125-000	1-33		B-1505-155-000	5-8		B-3402-122-000	5-27		CS-0640863-SG	3-15		SS-6121050-SP	4-26	
1113-155-0A0	1-32		B-1507-125-000	5-2		B-3403-012-000	5-26		GS-0721216-SH	3-34		SS-6121210-SP	4-5	
B-1114-155-000	1-25		B-1510-155-000	5-12		B-3404-122-000	5-34		CS-0791016-SH	7-30		SS-6121610-SP	4-32	
1115-155-000	1-6		B-1512-012-000	5-14		B-3405-155-000	5-21		CS-1471012-SH	2-44		SS-6620730-SP	4-38	
B-1116-125-000	1-34		B-1512-125-000	5-4		B-3406-125-000	5-22					SS-6661110-SP	4-2	
B-1118-125-000	1-38		B-1512-155-000	5-17		B-3407-155-000	5-32		NEEDLE			SS-7060610-SP	8-39	
1119-125-000	1-39		B-1514-155-0A0	5-7		B-3409-155-000	5-30		MDB-100-1400	2-14		SS-7080410-SP	1-7	
B-1123-126-000	1-42		B-1515-012-000	5-18		B-3416-012-000	5-33					SS-7080510-SP	2-12	
1137-125-000	1-22		B-1524-012-0A0	5-19		B-3419-125-0A0	7-3		NUT			SS-7090510-SP	6-21	
B-1138-125-000	1-21		B-1601-122-000	3-6		B-3418-012-000	7-9		NS-6070210-SP	1-10		SS-7090710-SP	6-4	
1139-125-000	1-20		B-1602-012-000	3-4		B-3419-122-000	7-12		NS-5060310-SP	8-32		SS-7090710-SP	6-4	
B-1140-125-000	1-23		B-1604-012-000	3-3		B-3420-122-000	7-8		NS-6060350-SP	8-34		SS-7091110-SP	5-20	
1141-125-000	1-12		B-1607-122-000	3-33		B-3425-122-000	7-4		NS-6090310-SP	1-35		SS-7091310-SP	6-33	
B-1142-125-000	1-1		B-1613-012-A00	3-2		B-3426-122-000	7-7		NS-6150310-SP	1-50		SS-7110720-TP	2-7	
B-1144-125-000	1-2		B-1613-125-000	4-28		B-3427-122-000	7-10		NS-6150320-SP	6-35		SS-7110310-SP	3-21	
1143-125-000	1-11		B-1619-012-000	4-12		B-3429-122-000	7-5		NS-6680410-SP	4-34		SS-7111110-TP	5-31	
B-1144-125-000	1-8		B-1621-012-B00	4-13		B-3501-125-000	6-51		NS-5700420-SP	1-3		SS-7111120-SP	1-37	
1145-125-000	1-9		B-1621-012-C00	4-20		B-3502-122-000	6-61		NS-6740510-SP	3-7		SS-7111120-SP	6-37	
B-1146-125-000	4-23		B-1621-125-000	4-41		B-3503-122-000	6-57					SS-711120-SP	8-28	
1147-012-000	1-27		B-1622-122-000	4-1		B-3504-155-000	6-58		TAPER PIN			SS-7111260-SP	6-53	
B-1147-125-000	4-22		B-1623-122-000	4-6		B-3505-122-000	6-56		PT-0100800-SO	8-15		SS-7111410-SP	2-23	
B-1148-012-000	1-41		B-1623-125-000	4-25		B-3506-125-000	6-60		PT-0251800-SH	2-26		SS-7111410-SP	3-14	
1159-041-000	1-43		B-1627-122-000	4-4		B-3507-122-000	6-54		PT-0251800-SH	8-9		SS-7111410-TP	3-26	
B-1161-012-000	1-5		B-1631-122-000	4-36		B-3511-122-000	6-50		PT-0301600-SO	5-23		SS-7111410-SP	6-1	
1165-012-000	1-48		B-1633-122-0A0	3-12		B-3512-122-000	6-49					SS-7111810-SP	8-7	
B-1166-122-000	1-45		B-1633-122-0A0	4-3		B-3513-122-000	6-48		RUBBER RING			SS-7120910-SP	5-25	
1169-122-000	1-46		B-1634-122-000	4-17		B-3515-122-000	6-38		RO-0442401-00	6-29		SS-7151210-SP	4-37	
B-1170-122-000	1-47		B-1636-122-000	4-16		B-3521-122-000	6-36		RO-0681901-00	2-2		SS-7620750-SL	4-40	
1171-122-000	1-44		B-1641-122-000	3-17		B-3525-122-000	6-15		RO-0742401-00	4-14		SS-7681750-TP	2-16	
B-1199-126-000	2-35		B-1641-122-B00	3-32		B-3526-122-000	6-34		RO-1242401-00	7-18		SS-8080950-SP	5-28	
1201-125-000	2-31		B-1641-122-C00	3-24		B-3527-122-000	6-30		RO-1331701-00	2-48		SS-8090670-SP	8-22	
B-1203-125-000	2-41		B-1641-122-D00	3-31		B-3528-122-000	6-32		RO-1342401-00	4-15		SS-8090870-SP	8-6	
1204-122-000	2-32		B-1642-122-000	4-35		B-3530-122-000	6-47		RO-1542401-00	6-23		SS-8110310-SP	2-9	
B-1205-126-000	2-15		B-1646-122-000	4-7		B-3531-122-000	6-42					SS-8110310-SP	5-13	
1207-126-000	2-3		B-1647-122-000	4-19		B-3532-012-000	6-2		HINGE SCREW			SS-8110410-SP	1-4	
B-1208-125-000	2-37		B-1643-012-000	4-24		B-3532-122-000	6-41		SD-0600271-SP	5-3		SS-8110510-SP	3-16	
1211-012-400	2-29		B-1648-122-000	4-8		B-3533-122-000	6-43		SD-0600271-SP	8-3		SS-8110520-TP	4-29	
B-1212-012-000	2-28		B-1701-125-000	4-33		B-3534-012-000	6-16		SD-0600401-SD	5-29		SS-8150410-TP	2-43	
1213-012-000	2-27		B-1702-012-000	4-31		B-3534-155-000	6-25		SD-0900402-SP	5-9		SS-8150710-SP	4-18	
B-1213-125-000	6-24		B-1703-125-000	3-25		B-3535-122-A00	6-26		SD-1020851-SP	4-11		SS-8150715-SP	5-6	
1214-038-000	2-45		B-1706-012-000	3-13		B-3535-122-B00	6-39		SD-1020961-SP	4-27		SS-8150710-TP	2-36	
B-1218-012-000	2-49		B-1801-122-000	3-28		B-3535-122-C00	6-27					SS-8151150-SP	2-20	
1233-012-000	2-17		B-1802-012-000	3-37		B-3535-122-D00	6-46		CONNECTING SCREW			SS-8151150-SP	3-43	
B-1236-125-0A0	2-42		B-1802-122-000	3-20		B-3535-122-E00	6-28		SQ-1110401-MZ	6-4		SS-8152080-SP	2-46	
1301-122-000	3-38		B-1803-122-000	3-18		B-3535-122-F00	6-18		SQ-1110402-MZ	6-1		SS-8620610-TP	3-5	
B-1302-122-000	3-39		B-1830-012-0A0	3-9		B-3535-122-G00	6-19		SQ-1150451-MZ	6-52		SS-8621150-SP	8-37	
1303-122-000	3-41		B-1835-012-000	3-22		B-3536-122-000	6-3					SS-8660810-TP	2-38	
B-1304-012-A00	3-35		B-1839-155-0A0	3-10		B-3536-155-000	6-22		SCREW			SS-8660810-TP	3-45	
1304-012-B00	3-36		B-1862-012-000	3-29		B-3537-122-000	6-20		SS-1091520-TP	5-10		SS-8681650-TP	2-30	
B-1305-012-000	3-40		B-1863-012-000	3-27		B-3542-125-000	6-11		SS-2060310-SP	8-35		SS-9182010-SN	7-6	
1307-013-A00	3-44		B-1905-126-BA0	8-30		B-3541-125-0A0	6-6		SS-2080810-SP	8-11		SS-9201810-SN	7-11	
B-1307-012-B00	3-45		B-3101-125-000	8-26		B-3542-155-000	2-33		SS-2090710-SP	4-21				
1315-012-000	3-42		B-3102-125-000	8-1		B-3543-125-000	6-12		SS-2090710-PP	5-5		PLUG		
B-1318-122-000	3-40		B-3103-125-000	8-14		B-3545-122-000	6-59		SS-2110920-SP	8-13		TA-0300503-RO	2-34	
1401-155-B00	2-5		B-3104-155-000	8-8		B-3546-125-000	6-10		SS-2110930-SP	8-29		TA-0300503-RO	3-19	
B-1402-155-000	2-4		B-3105-155-005	8-10		B-3546-125-000	6-40		SS-2110930-SP	8-31		TA-0691001-RO	2-19	
1403-155-000	2-8		B-3107-012-000	8-32		B-3549-122-000	6-8		SS-3090610-SP	1-24				
B-1406-125-000	2-6		B-3107-125-000	8-12		B-3550-122-000	6-7		SS-4060410-SP	8-2		WASHER		
1408-122-000	2-18		B-3109-155-000	8-36		B-3552-125-000	6-9		SS-4080610-SP	1-26		WP-0250516-SD	8-40	
			B-3110-125-000	8-41		B-3554-122-000	6-13		SS-4080620-TP	3-1		WP-0371016-SD	4-9	
			B-3111-126-000	8-25		B-8217-125-000	7-1		SS-4091010-SP	4-10		WP-0460556-SD	8-27	
												WP-0612516-SD	5-35	



TOKYO JUKI INDUSTRIAL CO., LTD.

SECOND
EDITION