


DT6-B925



Please clarify Ref. No. and
Parts No. as well as parts name
When you place an order.

**EDIÇÃO
03**

I 2120084

INDEX


B925-1

Parts-No.	Ref. No.	Remark	Parts-No.	Ref. No.	Remark	Parts-No.	Ref. No.	Remark	Parts-No.	Ref. No.	Remark
00013-0-03	C-45		101554-0-01	A-43		105074-0-01	B-43		105148-0-00	C-3	
00072-0-04	C-43		101555-0-01	B-9		105075-0-01	B-37		105149-0-00	C-17	
00032-0-01	A-42		101557-0-01	A-45		105076-0-01	B-35		105150-0-00	C-18	
00058-0-01	C-64		101558-0-01	C-32		105077-0-00	B-36		105152-0-01	C-25	
00062-0-04	C-59		101559-0-01	C-31		105078-0-01	B-39		105153-0-00	C-23	
	C-74		101560-0-01	A-31		105079-0-01	B-40		105154-0-01	C-26	
00064-0-01	C-40		101561-0-01	C-80		105081-0-01	B-28		105155-0-01	C-30	
00064-0-03	A-19		101564-0-01	"		105082-0-01	B-26		105156-0-02	C-1	
"	B-34		101629-0-02	B-8		105083-0-01	B-27		105158-0-01	C-8	
"	D-67		"	D-32		105086-0-01	B-32		105159-0-00	C-9	
00086-0-03	C-79		101800-0-01	A-73		105087-0-16	B-33		105160-0-03	C-12	
0134-0-01	D-5		101940-0-01	A-43		105088-0-01	B-43		105161-0-02	C-11	
0242-0-01	A-15		101941-0-01	B-9		105089-0-01	B-3		105162-0-01	C-13	
"	D-23		101943-0-01	A-45		105091-0-01	B-1		105163-0-01	C-10	
0242-0-02	D-55		101944-0-01	C-32		105093-0-01	B-4		105164-0-00	C-7	
0242-0-04	A-5		101945-0-01	C-31		105094-0-01	B-10		105165-0-01	C-4	
0251-0-01	B-45		101949-0-00	C-80		105095-0-01	B-16		105166-0-00	C-6	
"	C-5		102716-0-01	C-14		105096-0-01	B-11		"	C-16	
0257-0-08	A-3		102716-0-03	C-19		105100-0-01	B-13		105167-0-01	C-76	
"	D-69		102843-0-03	A-6		105102-0-01	B-12		105168-0-01	C-77	
0260-0-01	B-2		102921-0-02	B-19		105103-0-01	B-18		105169-0-01	C-73	
"	B-7		103847-0-02	D-56		105104-0-01	B-17		105170-0-01	C-75	
"	B-25		104449-0-01	A-8		105105-0-01	B-20		105171-0-01	C-72	
"	B-29		105053-0-01	A-10		105106-0-01	B-21		105172-0-01	A-45	
"	C-70		105054-0-00	B-60		105113-0-01	A-60		105173-0-03	A-44	
0287-0-03	A-93		105055-0-00	B-49		105114-0-01	B-9		105174-0-01	C-15	
0287-0-04	D-38		105056-0-00	B-48		105123-0-01	D-6		105175-0-01	C-68	
0289-0-03	A-28		105057-0-00	B-50		105128-0-01	C-83		105176-0-01	C-35	
0366-0-01	C-58		105058-0-01	B-54		105129-0-01	C-82		"	C-46	
0368-0-02	C-78		105059-0-00	B-53		105130-0-01	C-81		"	C-67	
0368-0-03	B-41		"	C-24		105131-0-01	B-61		105177-0-01	C-66	
0388-0-04	D-13		105060-0-00	B-52		105132-0-01	B-62		105178-0-00	C-69	
0393-0-01	D-25		105061-0-00	B-51		105133-0-00	B-57		105179-0-01	C-71	
0393-0-05	A-22		"	C-22		105134-0-01	B-56		105180-0-01	C-41, 47~56	
"	D-19		105062-0-01	A-91		"	C-27		105181-0-01	C-56	
"	D-35		"	B-55		105136-0-00	C-28		105182-0-01	C-50	
0522-0-02	B-5		105063-0-01	B-59		105137-0-01	A-67		105183-0-01	C-51	
0541-0-01	C-62		105064-0-01	B-65		105138-0-01	A-65		105184-0-00	C-52	
1091-0-01	A-78		105065-0-01	B-69		105140-0-01	A-69		105185-0-01	C-41	
1488-0-01	C-80		105066-0-01	B-68		105141-0-01	A-68		105186-0-01	C-55	
1491-0-01	B-9		105067-0-01	B-70		105142-0-02	A-70		105187-0-01	C-53	
1492-0-01	C-32		105068-0-01	B-64		105144-0-01	A-74		105188-0-01	C-54	
1493-0-01	C-31		105071-0-01	B-63		105146-0-01	A-71		105189-0-01	C-57	
1497-0-01	C-80		105072-0-01	B-46		"	A-77		105190-0-01	C-47	
1531-0-02	D-29		105073-0-01	B-47		105147-0-01	C-2				

INDEX

B925-2

Parts-No.	Ref. No.	Remark	Parts-No.	Ref. No.	Remark	Parts-No.	Ref. No.	Remark	Parts-No.	Ref. No.	Remark
105191-0-01	C-49		105238-0-01	A-14		105296-0-01	D-71		111025-0-01	B-6	
105193-0-01	C-36~40 42~46		105239-0-01	A-11		105297-0-01	D-68		111026-0-01	A-94	
105194-0-01	C-38		105242-0-01	A-21		105298-0-01	C-20		111027-0-01	A-2	
105195-0-01	C-37		105243-0-01	A-23		105299-0-02	C-21		111028-0-01	A-1	
105196-0-01	C-39		105244-0-00	A-24		105300-0-01	A-49		111032-0-01	A-4	
105197-0-01	C-36		105245-0-01	A-25		105301-0-01	A-27		111033-0-01	A-7	
105198-0-00	C-42		105247-0-03	A-18		105302-0-01	A-31		111039-0-01	A-75	
105199-0-01	C-44		105248-0-01	A-16		105303-0-01	A-26		111040-0-01	A-72	
105200-0-01	C-61		105249-0-01	D-26		105304-0-01	A-30		111071-0-01	A-95	
105201-0-00	C-65		105250-0-01	D-28		105305-0-01	A-29		111084-0-01	A-13	
105202-0-00	C-60		105251-0-01	D-31		105306-0-01	A-53		111086-0-01	B-14	
105203-0-01	C-32		105255-0-01	D-33		105307-0-01	A-52		111188-0-01	A-12	
105204-0-01	C-31		105256-0-01	D-34		105308-0-01	A-51		111193-0-01	B-66	
105205-0-01	C-33		105257-0-01	D-37		105309-0-01	A-50		111194-0-01	B-67	
105206-0-01	C-34		105260-0-01	D-36		105310-0-01	A-39		111809-0-01	A-17	
105209-0-01	C-63		105262-0-01	D-42		105313-0-01	A-40		112817-0-01	A-62	
105210-0-01	A-55		105268-0-01	D-40		105315-0-01	A-35		112820-0-01	A-20	
105211-0-01	A-54		105269-0-01	D-41		105318-0-01	A-36		115995-0-01	B-58	
105214-0-01	A-59		105270-0-01	D-45		105319-0-00	A-34		"	C-29	
105215-0-01	A-61		105274-0-01	D-43		105320-0-00	A-38		116231-0-01	A-64	
105216-0-01	A-56		105275-0-01	D-49		105321-0-01	A-33		117948-0-01	C-48	
"	D-27		105276-0-01	D-48		105322-0-01	A-90		143259-0-01	A-63	
105217-0-01	A-47		105277-0-01	D-44		105332-0-01	A-92		144105-0-00	D-2	
105218-0-01	A-48		105278-0-00	D-47		105333-0-01	B-22		180051-0-01	C-7~13	
105219-0-04	D-30		105279-0-01	D-46		105337-0-02	A-79		180052-0-01	C-14~16	
"	D-39		105281-0-01	D-51		105341-0-01	A-76		181074-0-01	B-31	
105220-0-01	D-20		105282-0-02	D-52		105363-0-01	A-9		181075-0-01	"	
105221-0-01	D-18		105283-0-01	D-72		"	B-24		181076-0-01	"	
"	D-24		105284-0-01	D-66		"	B-38		181077-0-01	"	
105222-0-01	D-22		105285-0-01	D-59		105367-0-01	B-15		181966-0-01	C-4~6	
105223-0-01	D-21		105286-0-01	D-58		105403-0-01	A-43		181980-0-01	B-63~70	
105224-0-01	D-17		105287-0-01	D-54		105404-0-01	A-45		181982-0-01	B-56, 57	
105225-0-01	D-7		105288-0-00	A-37		106159-0-01	A-43		181983-0-01	B-45~47	
105226-0-01	D-8		105288-0-01	A-41		106160-0-01	B-9		181985-0-01	C-20, 21	
105227-0-01	D-3		105288-0-02	D-53		106169-0-01	A-45		181987-0-01	C-57, 58	
105229-0-01	D-4		"	D-70		106170-0-01	A-31		181999-0-01	B-45~47	
105230-0-01	D-1		105289-0-01	D-57		107308-0-01	A-66		182304-0-01	A-15~25	
105231-0-00	D-9		105291-0-01	D-60		108721-0-01	D-6				
105232-0-01	D-16		105291-0-04	A-46		108896-0-01	B-44				
105233-0-01	D-15		105292-0-01	D-63		109407-0-01	B-46				
105234-0-01	D-14		105293-0-01	D-62		110427-0-01	C-31~35				
105235-0-01	D-12		105294-0-01	D-65		110428-0-01	"				
105236-0-01	D-10		105295-0-02	D-64		110429-0-01	"				
105237-0-02	D-11		105295-0-03	A-22		110430-0-01	"				
						111024-0-01	B-30				




PARTS LIST for DT6-B925

B925-A-2

Ref. No.	Name of Parts	Q'ty	Parts-No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts-No.	Assembly No.
A-1	Face Plate Upper	1 pce.	111028-0-01		A-43	Needle Plate 5/32 MH	1 pce.	101940-0-01	
A-2	Face Plate Upper Hinge	1 "	111027-0-01		"	" 3/16 MH	1 "	105403-0-01	
A-3	Set Screw for A-2	4 pcs.	100257-0-08		"	" 1/4 MH	1 "	101554-0-01	
A-4	Stopper Spring for A-1	1 pce.	111032-0-01		"	" 1/4 H	1 "	106159-0-01	
A-5	Set Screw for A-4	2 pcs.	100242-0-04		A-44	Fastening Screw for A-45	1 "	105173-0-03	
A-6	Set Screw for A-7	1 pce.	102843-0-03		A-45	Feed Dog 1/8 MH	1 "	105172-0-01	
A-7	Stopper Plate for A-4	1 "	111033-0-01		"	" 5/32 MH	1 "	101943-0-01	
A-8	Cap Screw for Thread Take-up Crank	1 "	104449-0-01		"	" 3/16 MH	1 "	105404-0-01	
A-9	Wick 12 X 12 for A-10	3 pcs.	105363-0-01		"	" 1/4 MH	1 "	101557-0-01	
A-10	Oil Cap (large)	4 "	105053-0-01		"	" 1/4 H	1 "	106169-0-01	
A-11	Thread Guide for Upper Thread Take-up Lever	1 pce.	105239-0-01		A-46	Set Screw for A-47	4 pcs.	105291-0-04	
A-12	Washer for A-11	1 "	111188-0-01		A-47	Cap Plate for Lower Shaft Ball Bearing Left	1 pce.	105217-0-01	
A-13	Set Screw for A-11	1 "	111084-0-01		A-48	Packing for A-47	1 "	105218-0-01	
A-14	Upper Thread Guide on Arm	1 "	105238-0-01		A-49	Lower Thread Feed Tube	1 "	105300-0-01	
A-15	Set Screw for A-14	1 "	100242-0-01		A-50	Set Screw for A-51	2 pcs.	105309-0-01	
A-16	Washer for A-17	1 "	105248-0-01		A-51	Thread Cutter Outside Plate	1 pce.	105308-0-01	
A-17	Lower Thread Guide	1 "	111809-0-01		A-52	Thread Cutter	1 "	105307-0-01	
A-18	Set Screw for A-17	1 "	105247-0-03		A-53	Thread Cutter Inside Plate	1 "	105306-0-01	
A-19	Set Screw for A-20	1 "	100064-0-03		A-54	Packing for A-55	1 "	105211-0-01	
A-20	Upper Thread Take-up Lever	1 "	112820-0-01		A-55	Toward Arm Cover Assembly	1 set.	105210-0-01	
A-21	Thread Guide for A-20	1 "	105242-0-01		A-56	Set Screw for A-55	16 pcs.	105216-0-01	
A-22	Set Screw for A-20	1 "	100393-0-05		A-59	Oil Gauge Rod	1 pce.	105214-0-01	
A-23	Thread Checker for A-20	1 "	105243-0-01	182304-0-01	A-60	Fastening Screw for A-59	1 "	105113-0-01	
A-24	Spring for A-20	1 "	105244-0-00		A-61	Packing for A-59	1 "	105215-0-01	
A-25	Stud Screw for A-24	1 "	105245-0-01		A-62	Arm-bed	1 "	112817-0-01	
A-26	Fastening Screw for A-31	1 "	105303-0-01		A-63	Model Plate	1 "	143259-0-01	
A-27	Looper Thread Guide Bracket	1 "	105301-0-01		A-64	Model Plate Pin	2 pcs.	116231-0-01	
A-28	Set Screw for A-27	1 "	100289-0-03		A-65	Belt Cover	1 pce.	105138-0-01	
A-29	Fastening Screw for A-30	1 "	105305-0-01		A-66	Set Screw for A-65	2 pcs.	107308-0-01	
A-30	Looper Thread Guide	1 "	105304-0-01		A-67	Timing Belt	1 pce.	105137-0-01	
A-31	Looper Thread Guide Arm 1/8 5/32 3/16 MH	1 "	105302-0-01		A-68	Packing for Cover Plate	1 "	105141-0-01	
"	Looper Thread Guide Arm 1/8 MH	1 "	101560-0-01		A-69	Cover Plate	1 "	105140-0-01	
"	Looper Thread Guide Arm 1/8 MH	1 "	106170-0-01		A-70	Set Screw for A-69	2 pcs.	105142-0-02	
A-22	Set Screw for A-33	1 "	105295-0-03		A-71	Set Screw for A-72	2 "	105146-0-01	
A-33	Side Cover Stopper	1 "	105321-0-01		A-72	Pulley Cover	1 pce.	111040-0-01	
A-34	Side Cover Spring	1 "	105319-0-00		A-73	Metal Sheet for A-72	2 pcs.	101800-0-01	
A-35	Looper Side Cover Left Assembly	1 "	105315-0-01		A-74	Fixing Bolt for A-75	2 "	105144-0-01	
A-36	Plate Spring for A-35	1 "	105318-0-01		A-75	Pulley Cover Base	1 pce.	111039-0-01	
A-37	Fastening Screw for A-36	1 "	105288-0-00		A-76	Base Cushion	2 pcs.	105341-0-01	
A-38	Taper Pin 2 X 7 for A-39	2 pcs.	105288-0-00		A-77	Set Screw for A-79	2 "	105146-0-01	
A-39	Looper Side Cover Right Assembly	1 set.	105310-0-01		A-78	Set Screw 6.2 X 26 for A-79	2 "	101091-0-01	
A-40	Plate Spring for A-39	1 pce.	105313-0-01		A-79	Cushion Assembly	2 sets	105337-0-02	
A-41	Fastening Screw for A-40	1 "	105288-0-01		A-90	Spool Stand Base Socket	1 pce.	105322-0-01	
A-42	Needle Plate Flat Screw	3 pcs.	100032-0-01		A-91	Fastening Screw for A-90	2 pcs.	105062-0-01	
A-43	Needle Plate 1/8 MH	1 pce.	105088-0-01		A-92	Set Screw 6.2 X 40 for A-90	3 "	105332-0-01	
					A-93	Set Screw for A-94	2 pcs.	100287-0-03	
					A-94	Face Plate Lower	1 pce.	111026-0-01	
					A-95	Face Plate Lower Packing	1 "	111071-0-01	


B



PARTS LIST for DT6-B925

B925-B 5

Ref. No.	Name of Parts	Q'ty	Parts-No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts-No.	Assembly No.
B-1	Presser Bar Upper Bushing	1 pce.	105091-0-01		B-40	Needle Bar Guide	1 pce.	105079-0-01	
B-2	Set Screw for B-1	1 "	100260-0-01		B-41	Set Screw for B-40	2 pcs.	100268-0-03	
B-3	Presser Bar Assembly	1 set.	105089-0-01		B-43	Needle Bar Crank	1 pce.	105074-0-01	
B-4	Presser Bar Bracket	1 pce.	105093-0-01		B-44	Wick 12 X 12 for B-43	1 "	108896-0-01	
B-5	Fastening Screw for B-4	1 "	105022-0-02		B-45	Set Screw for B-46	2 pcs.	100251-0-01	181983-0-01
B-6	Presser Bar Lower Bushing	1 "	111025-0-01		B-46	Thread Take-up Crank for MH	1 pce.	105072-0-01	
B-7	Set Screw for B-6	1 "	100260-0-01		B-47	Fastening Screw for B-46	2 pcs.	105073-0-01	
B-8	Set Screw for Presser Foot Assembly	1 "	101629-0-02		B-45	Set Screw for B-46	2 pcs.	100251-0-01	
B-9	Presser Foot Assembly 1/8 MH	1 "	105114-0-01		B-46	Thread Take-up Crank for 1/4 H	1 pce.	109407-0-01	181999-0-01
"	" 5/32 MH	1 "	101941-0-01		B-47	Fastening Screw for B-46	2 pcs.	105073-0-01	
"	" 3/16 MH	1 "	101491-0-01		B-48	Upper Shaft Ball Bearing (left)	1 pce.	105056-0-00	
"	" 1/4 MH	1 "	101555-0-01		B-49	Ball Bearing Receiver (left)	1 "	105055-0-00	
"	" 1/4 H	1 "	106160-0-01		B-50	Oil Stopper for B-48	1 "	105057-0-00	
B-10	Presser Plate Spring (A)	1 "	105094-0-01		B-51	Fixing Screw Ring for B-52	1 "	105061-0-00	
B-11	Presser Plate Spring (B)	1 "	105096-0-01		B-52	Collar for B-53	1 "	105060-0-00	
B-12	Presser Adjusting Wing Nut	1 "	105102-0-01		B-53	Ball Bearing Receiver (right)	1 "	105059-0-00	
B-13	Guide Washer for B-11	1 "	105100-0-01		B-54	Housing for B-53	1 "	105058-0-01	
B-14	Presser Adjusting Screw	1 "	111086-0-01		B-55	Set Screw for B-54	1 "	105062-0-01	
B-15	Nut for B-14	1 "	105367-0-01		B-56	Side Ring for B-57	2 pcs.	105134-0-01	181982-0-01
B-16	Presser Plate Spring (A) Pin	1 "	105095-0-01		B-57	Tinning Belt Wheel Upper	1 pce.	105133-0-00	
B-17	Stud Screw for B-18	1 "	105104-0-01		B-58	Fastening Screw for B-57	2 pcs.	115995-0-01	
B-18	Presser Bar Lifter	1 "	105103-0-01		B-59	Upper Shaft Oil Cap	1 pce.	105063-0-01	
B-19	Stud Screw for B-20	1 "	102921-0-02		B-60	Upper Shaft	1 "	105054-0-00	
B-20	Knee Lifter Lever	1 "	105105-0-01		B-61	Pulley	1 "	105131-0-01	
B-21	Knee Lifter Spring	1 "	105106-0-01		B-62	Set Screw for B-61	2 pcs.	105132-0-01	
B-22	Presser Foot Lifter Chain Assembly	1 set.	105333-0-01		B-63	Oil Receiver Packing	1 pce.	105071-0-01	
B-24	Wick 12 X 12 for B-26	1 "	105363-0-01		B-64	Fastening Screw for B-70	4 pcs.	105068-0-01	
B-25	Set Screw for B-24	1 "	100260-0-01		B-65	Oil Receiver	1 pce.	105064-0-01	
B-26	Needle Bar Upper Bearing	1 "	105082-0-01		B-66	Cap Screw for Oil Inlet	1 "	111193-0-01	181980-0-01
B-27	Oil Felt for B-26	1 "	105083-0-01		B-67	Packing for B-66	1 "	111194-0-01	
B-28	Needle Bar	1 "	105081-0-01		B-68	Packing for B-69	1 "	105066-0-01	
B-29	Fastening Screw for B-28	1 "	100260-0-01		B-69	Oil Gauge Window	1 "	105065-0-01	
B-30	Needle Bar Lower Bearing	1 "	111024-0-01		B-70	Oil Gauge Flange	1 "	105067-0-01	
B-31	Needle Clamp 1/8 MH	1 "	181076-0-01						
"	" 5/32 MH	1 "	181075-0-01						
"	" 3/16 MH	1 "	181077-0-01						
"	" 1/4 MH & 1/4 H	1 "	181074-0-01						
B-32	Needle Clamp Screw	2 pcs.	105086-0-01						
B-33	Needle (TV X 1)	2 "	105087-0-16						
B-34	Set Screw for B-35	1 pce.	100064-0-03						
B-35	Needle Bar Bracket	1 "	105076-0-01						
B-36	Washer for B-35	1 "	105077-0-00						
B-37	Needle Bar Crank Rod	1 "	105075-0-01						
B-38	Wick 12 X 12 for B-37	1 "	105363-0-01						
B-39	Needle Bar Guide Slide Block	1 "	105078-0-01						




PARTS LIST for DT6-B925

B925-C 7

Ref. No.	Name of Parts	Q'ty	Parts-No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts-No.	Assembly No.
C-1	Fastening Screw for C-2	1 pce.	105156-0-02		C-31	Looper (long) 1/4	1 "	101559-0-01	
C-2	Lower Shaft	1 "	105147-0-01		C-32	Looper (short) 1/4	1 "	101558-0-01	
C-3	Ball Bearing	1 "	105148-0-00		C-33	Fastening Screw for C-31 & C-32	1 "	105205-0-01	110430-0-01
C-4	Feed Lifting & Looper Eccentric	1 "	105165-0-01		C-34	Looper Holder	1 "	105206-0-01	MH & H
C-5	Set Screw for C-4	2 pcs.	100251-0-01	181966-0-01	C-35	Set Screw for C-34	1 "	105176-0-01	
C-6	Square Sleeve for C-4	1 pce.	105166-0-00		C-36	Looper Toggle Joint	1 "	105197-0-01	
C-7	Square Sleeve for C-8	1 "	105164-0-00		C-37	Looper Toggle Link Upper Cap	1 "	105195-0-01	
C-8	Feed Eccentric	1 "	105158-0-01		C-38	Looper Toggle Link	1 "	105194-0-01	
C-9	Feed Eccentric Bracket	1 "	105159-0-00		C-39	Looper Toggle Link Lower Cap	1 "	105196-0-01	
C-10	Fastening Screw for C-9	2 pcs.	105163-0-01	180051-0-01	C-40	Fastening Screw for C-39	4 pcs.	100064-0-01	
C-11	Washer for C-12	1 pce.	105161-0-02		C-42	Washer for C-36	1 pce.	105198-0-00	105193-0-01
C-12	Fastening Screw for C-9	1 "	105160-0-03		C-43	Nut for C-36	1 "	100022-0-04	
C-13	Feed Eccentric Adjusting Screw	1 "	105162-0-01		C-44	Looper Shaft Holder	1 "	105199-0-01	
C-14	Set Screw for C-15	2 pcs.	102716-0-01		C-45	Set Screw for C-44	1 "	100013-0-03	
C-15	Looper Feed Eccentric	1 pce.	105174-0-01	180052-0-01	C-46	Set Screw for C-47	1 "	105176-0-01	
C-16	Square Sleeve for C-15	1 "	105166-0-00		C-41	Looper Lever	1 "	105185-0-01	
C-17	Ball Bearing	1 "	105149-0-00		C-47	Looper Lever Shaft	1 "	105190-0-01	
C-18	Ball Bearing Bushing	1 "	105150-0-00		C-48	Looper Lever Shaft Packing	1 "	117948-0-01	
C-19	Set Screw for C-18	2 pcs.	102716-0-03		C-49	Set Screw for C-41	1 "	105191-0-01	
C-20	Lower Thread Take-up Disc.	1 pce.	105298-0-01		C-50	Looper Link	1 "	105182-0-01	
C-21	Set Screw for C-20	2 pcs.	105299-0-02	181985-0-01	C-51	Looper Link Shaft	1 "	105183-0-01	105180-0-01
C-22	Fixing Screw Ring for C-23	1 pce.	105061-0-00		C-52	Fastening Screw for C-51	1 "	105184-0-00	
C-23	Collar for C-24	1 "	105153-0-00		C-53	Stud Screw for C-55	1 "	105187-0-01	
C-24	Ball Bearing	1 "	105059-0-00		C-54	Packing for C-55	1 "	105188-0-01	
C-25	Housing for C-24	1 "	105152-0-01		C-55	Looper Connecting Square Sleeve	1 "	105186-0-01	
C-26	Set Screw for C-25	1 "	105154-0-01		C-56	Looper Connector	1 "	105181-0-01	
C-27	Side Ring for C-28	2 pcs.	105134-0-01		C-57	Looper Connector Guide Plate	1 "	105189-0-01	181987-0-01
C-28	Timing Belt Wheel Lower	1 pce.	105136-0-00		C-58	Set Screw for C-57	2 pcs.	100366-0-01	
C-29	Set Screw for C-28	2 pcs.	115995-0-01		C-59	Set Screw for C-60	1 pce.	100062-0-04	
C-30	Cap Screw for C-28	1 pce.	105155-0-01		C-60	Looper Shaft Metal (rear)	1 "	105202-0-00	
C-31	Looper (long) 1/8	1 "	105204-0-01		C-61	Looper Shaft	1 "	105200-0-01	
C-32	Looper (short) 1/8	1 "	105203-0-01		C-62	Set Screw for C-63	1 "	105411-0-01	
C-33	Fastening Screw for C-31 & C-32	1 "	105205-0-01	110427-0-01	C-63	Looper Shaft Set Collar	1 "	105209-0-01	
C-34	Looper Holder	1 "	105206-0-01	MH	C-64	Set Screw for C-65	1 "	100058-0-01	
C-35	Set Screw for C-34	1 "	105176-0-01		C-65	Looper Shaft Metal (front)	1 "	105201-0-00	
C-31	Looper (long) 5/32	1 "	101945-0-01		C-66	Looper Feeding Shaft	1 "	105177-0-01	
C-32	Looper (short) 5/32	1 "	101944-0-01		C-67	Fastening Screw for C-68	1 "	105176-0-01	
C-33	Fastening Screw for C-31 & C-32	1 "	105205-0-01	110428-0-01	C-68	Looper Feeding Fork	1 "	105175-0-01	
C-34	Looper Holder	1 "	105206-0-01	MH	C-69	Looper Feeding Shaft Receiver	1 "	105178-0-00	
C-35	Set Screw for C-34	1 "	105176-0-01		C-70	Set Screw for C-69	1 "	100260-0-01	
C-31	Looper (long) 3/16	1 "	101493-0-01		C-71	Fastening Screw for C-69	1 "	105179-0-01	
C-32	Looper (short) 3/16	1 "	101492-0-01		C-72	Packing for C-73	1 "	105171-0-01	
C-33	Fastening Screw for C-31 & C-32	1 "	105205-0-01	110429-0-01	C-73	Feed Bar Eccentric Shaft	1 "	105169-0-01	
C-34	Looper Holder	1 "	105206-0-01	MH	C-74	Set Screw for C-73	1 "	100062-0-04	
C-35	Set Screw for C-34	1 "	105176-0-01		C-75	Forced Feed Bar Square Sleeve	1 "	105170-0-01	

C-76	Forced Feed Bar	1 pce.	105167-0-01	
C-77	Feed Lifting Fork	1 "	105168-0-01	
C-78	Fixing Screw for C-77	1 "	100368-0-02	
C-79	Fixing Screw for C-77	1 "	100086-0-03	
C-80	Lapper 1/8 MH Assembly	1 "	101488-0-01	
"	Lapper 5/32MH Assembly	1 "	101949-0-00	
"	Lapper 3/16MH Assembly	1 "	101497-0-01	
"	Lapper 1/4 MH Assembly	1 "	101561-0-01	
"	Lapper 1/4 H Assembly	1 "	101564-0-01	
C-81	Fastening Screw for C-80	1 "	105130-0-01	
C-82	Lapper Guide Plate Washer	2 pcs.	105129-0-01	
C-83	Lapper Guide Plate	1 pce.	105128-0-01	

D



PARTS LIST for DT6-B925

B925-D 10

Ref. No.	Name of Parts	Q'ty	Parts-No.	Assembly No.	Ref. No.	Name of Parts	Q'ty	Parts-No.	Assembly No.
D-1	Upper Thread Tension Adjusting Screw	2 pcs.	105230-0-01		D-46	Set Screw for D-45	1 pce.	105279-0-01	
D-2	Upper Washer for D-3	2 "	144105-0-00		D-47	Lower Thread Tension Bracket	1 "	105278-0-00	
D-3	Upper Thread Tension Spring	2 "	105227-0-01		D-48	Lower Thread Tension Screw Assembly	1 "	105276-0-01	
D-4	Lower Washer for D-3	2 "	105229-0-01		D-49	Lower Thread Tension Cap Screw	1 "	105275-0-01	
D-5	Tension Disc	2 "	100134-0-01		D-50	Thread Take-up Lever Cover	1 "	105280-0-01	
D-6	Tension Disc	4 "	108721-0-01		D-51	Plate Spring for D-50	1 "	105281-0-01	
D-7	Upper Thread Tension Stud Screw	2 "	105225-0-01		D-52	Set Screw for D-51	2 pcs.	105282-0-02	
D-8	Tension Bracket Thread Guide	2 "	105226-0-01		D-53	Set Screw for D-54	1 pce.	105288-0-02	
D-9	Upper Thread Release Pin	2 "	105231-0-00		D-54	Guide Plate for D-58	1 "	105287-0-01	
D-10	Thread Release Connecting Bar	1 pce.	105236-0-01		D-55	Fastening Screw for D-57	1 "	100242-0-02	
D-11	Stud Screw for D-10	2 pcs.	105237-0-02		D-56	Round Washer 4 X 8 X 1.2 for D-57	1 "	103847-0-02	
D-12	Thread Release Crank	1 pce.	105235-0-01		D-57	Lower Thread Guide (right)	1 "	105289-0-01	
D-13	Set Screw for D-12	1 "	100388-0-04		D-58	Lower Thread Take-up Lever Base	1 "	105286-0-01	
D-14	Nut for D-15	1 "	105234-0-01		D-59	Lower Thread Take-up Lever Cover Shaft	1 "	105285-0-01	
D-15	Guide Screw for D-16	1 "	105233-0-01		D-60	Lower Thread Take-up Lever Guide	2 pcs.	105291-0-01	
D-16	Thread Release Shaft	1 "	105232-0-01		D-61	Set Screw for D-60	2 "	105123-0-01	
D-17	Upper Thread Tension Bracket	1 "	105224-0-01		D-62	Washer for D-60	1 pce.	105293-0-01	
D-18	Upper Thread Guide	2 pcs.	105221-0-01		D-63	Lower Thread Guide Plate	1 "	105292-0-01	
D-19	Set Screw for D-18	4 "	100393-0-05		D-64	Fastening Screw for D-65	1 "	105295-0-02	
D-20	Upper Thread Guide Retainer	1 pce.	105220-0-01		D-65	Lower Thread Guide (left)	1 "	105294-0-01	
D-21	Fastening Screw for D-20	1 "	105223-0-01		D-66	Lower Thread Take-up Lever Frame	2 pcs.	100064-0-03	
D-22	Thread Hanger for D-20	1 "	105222-0-01		D-67	Set Screw for D-66	1 pce.	100064-0-03	
D-23	Fastening Screw for D-20	1 "	100242-0-01		D-68	Lower Thread Guide Plate	2 pcs.	105297-0-01	
D-24	Lower Thread Guide	2 pcs.	105221-0-01		D-69	Set Screw for D-68	1 pce.	100257-0-08	
D-25	Fastening Screw for D-24	4 "	100393-0-01		D-70	Set Screw for D-71	1 "	105288-0-02	
D-26	Lower Thread Guide Retainer	1 pce.	105249-0-01		D-71	Lower Thread Guide	1 "	105296-0-01	
D-27	Fastening Screw for D-26	1 "	105216-0-01		D-72	Set Screw for D-50	1 "	105283-0-01	
D-28	Lower Thread Guide Supporter	1 "	105250-0-01						
D-29	Set Screw for D-28	1 "	101531-0-02						
D-30	Set Screw for D-28	1 "	105219-0-04						
D-31	Inclined Guide Tube Assembly	1 set.	105251-0-01						
D-32	Set Screw for D-31	2 pcs.	101629-0-02						
D-33	Lower Thread Cover	1 pce.	105255-0-01						
D-34	Plate Spring for D-33	1 "	105256-0-01						
D-35	Fastening Screw for D-34	2 pcs.	100393-0-05						
D-36	Lower Thread Guide Hinge Assembly (right)	1 set.	105260-0-01						
D-37	Lower Thread Guide Hinge Assembly (left)	1 "	105257-0-01						
D-38	Set Screw for D-37	2 pcs.	100287-0-04						
D-39	Set Screw for D-40	1 pce.	105219-0-04						
D-40	Horizontal Tubular Guide Plate Spring	1 "	105268-0-01						
D-41	Position Plate for D-40	1 "	105269-0-01						
D-42	Horizontal Tubular Guide Assembly	1 set.	105262-0-01						
D-43	Lower Thread Tension Adjusting Screw	1 pce.	105274-0-01						
D-44	Lower Thread Tension Plate	1 "	105277-0-01						
D-45	Lower Thread Tension Bracket Assembly	1 set.	105270-0-01						