MITSUBISHI SEWING MACHINE PARTS CATALOG


Model.....DY-253

INDEX


=

1.本 体 部 分··································	G 23- 1
2.針棒、天びん部分Needle bar & thread take up lever mechanism	G 23- 5
3.上 軸 部 分········Upper shaft mechanism ·······	······ G23- 7
4.竪 軸 部 分·······Vertical shaft mechanism ·······	G23- 9
5.カマ、送り機構Rotating hook & feed mechanism	G23-11
6.下 軸 部 分······Lower shaft mechanism·····	G 23-13
7.上部送り機構Upper feed mechanism	
8.返し縫い機構Reverse lever mechaism	G23-17
9.押工上げ機構Presser foot mechanism	G23-21
10.給油機構Oil lubrication mechanism	G23-23
11.付 属• 品··················Accessories····································	G23-25

MITSUBISHI ELECTRIC CORPORATION




DY-253形 本体部分 ARM BED



					備考
Fig.	サービス部品コード 資材コード	部 品 名	Name of Part		Remarks
No.	Part No. Code No.	平 ネ ジ 11/64(40)×8	Saraw		
1	M9 1110 002 W500294		Screw Face plate		
2	MG 23C0 830 W220613-01	124	Arm thread guide(middle)		
3	MG 23C0 181 W461009-01	糸カケ(アーム中)	Screw for Fig.3		
4	M9 1103 011× W502941	丸 皿 ネ ジ 11/64(40)×7	Sub upper thread tension regulator assembly		1
901	MG 23C1 210 W456596	副上糸調節器(組)	Tension stud		Fig.No.901二含厶
5	MG 23C0 553 W502017	糸調子棒(後) 	Screw for Fig.7		11g.140.301= BA
6	M9 1109 002 W500511	平 ネ ジ 11/64(40)×7			
7	MG 23C1 181 W461022	糸カケ(アーム上)	Arm thread guide(upper) Tension disc		Fig. No. 001 = 4
8	MG 23C0 555 W502732	調子皿	Screw for Fig.12		Fig.No.901二含厶
9	M9 1110 002 W500294	平 ネ ジ 11/64(40)×8			Fig. No. 001 = 会 /
10	MG 23C0 245 W502733	糸調子バ ネ (4/40)	Tension spring Tension regulating thumb screw		Fig.No.901二含厶
11	M9 1604 046× W501027-02	糸調子ナット 1/4(40)	5 5		"
12	MG 23C0 880 × W459356-01	横 ブ タ	Arm side cover		
13	MG 23C0 188 W502793	糸 立 台	Thread spool stand		
14	MG 23C0 186 × W459374-01	※ 立 棒	Thread spool pin		
15	M9 1105 045 B 503845	ナット 11/64(40)×5	Nut		
16	W450620	社 名 板	Name plate		
17	M9 5001 062 × W461746	ネジビョウ	Screw for Fig.16	+	
18		アームベッド(組)	Arm bed assemby		
19	M9 5401 002 × W460506	平 ネ ジ M22×18	Screw	++++	
20	MG 23C0 143 ★ W502925-01	油管(上)	Oil pipe(upper)		
21	MG 23C0 144 > W502925-02	油 管(下)	Oil pipe(lower)		
22	MF 60A0 251× W469101	オイルカップ	Oil cap		
23	W451064-47	形 名 板	Model plate		
902	MG 23C0 210 W456591	上 糸 調 節 器(組)	Upper thread tension regulator assembly		F: N 000 = A /
24	W501027-02	糸調子 ナット	Tension regulating thumb nut		Fig.No.902二含厶
25	MG 23C1 557 📈 W461079-1	糸調子バネ	Tension releasing lever spring		"
26	MG 23C0 556 × W461065	皿 押 工	Tension releasing disc		"
27	W502707	座	Tension washer		"
28	MG 23C1 555 W502709	調子皿	Tension disc(2)		11
29	MG 23C2 555× W502708	調子皿	Tension disc(1)		"
30	W502716	フェルト	Washer(felt)		JI .
31	MG 23C1 553× W456592-01	調子棒	Tension screw stud		"
32	W502710	調節ブッシュ	Tension regulating bushing		11
33	MG 23C0 187 W456593-01	糸 取 り バ ネ	Tension spring		11
34	MG 23C0 557 W456597-01	ネジリコイルバネ	Spring		11
37	W456594-01	ブ ッ シ ュ	Tension regulating bushing		"
38	M9 1508 001 / B 509088	頭ナシ止メネジ 15/64(28)×8	Screw		
39	W502388-03	糸ユルメピン	Tension releasing pin		Fig.No.902二含厶


_____DY-253

DY-253形 本体部分 ARM BED




			•			備 考
Fig. No.	サービス部品コード 資材コード Part No. Code No.	部	品 名	Name of Part		Remarks
35	MG 23C0 474 X W457517-01	スベリ板(右))	Slide plate(right)		
36	M9 1207 002 🖍 W461723	平 ネ ジ	3/16(28)×8	Set screw		
40	MG 23C0 216 × W457530-01	上 糸 案 内	3	Upper thread guide		
41	MG 23CO 101 × W457515-01	針 板		Throat plate		
903	MG 23E0 470 X W474365-G01			Slide plate(left)complete		
42	M9 0602 002 🗡 W501567	平 ネ ジ	3/32(56)×3	Screw		Fig.No.903二含厶
43	MG 23C0 471 × W502711	スベリ板バネ		Spring for slide plate		
44	M9 1207 002 X W461 223	平 ネ ジ	3/16(28)×8	Screw		
45	MG 23C0 473 X W457516-01	ス ベ リ 板(左))	Slide plate(left)		Fig.No.903二含厶
46	M9 1113 002 / W500182	平 ネ ジ	11/64(40)×15	Screw for Fig.2		Tig.ivo.ooo=g.z
	\$ -0 ·					
	50					
. 16						
						1
Carlo I			N. Committee			
		1111				
		•				
	Y					
			100000000000000000000000000000000000000			
	· V	_				
	·					
		•				
					+	1
						1.
,		,			1	
			The second secon			

DY-253形 針棒、天びん部分 NEEDLE BAR & THREAD TAKE UP LEVER MECHANISM




つ `		LEVER MECH	ANISM	備考
Fig. No.	サービス部品コード 資材コード . Part No. Code No.	部 品 名	Name of Part	Remarks
47	MG 23C0 662 > W456582-01	針棒クランクガイド	Needle bar crank guide	
48	M9 1110 002 / W500294	平 ネ ジ 11/64(40)×8	Set screw for Fig.47	
49	M9 0906 002 W500791	平 ネ ジ 9/64(40)×4.5	Set screw for Fig.51	•
50	M9 1501 003 🔀 B 508963	丸 平 ネ ジ 15/64(28)×10	Set screw for Fig.53	
51	MG 23C2 181 X W502730	糸カケ(針止メ用)	Needle clamp thread guide	
52	W465212	針 DD×1 #25	Needle DD×1(#25)	•
53	MG 23C0 679 X W456584	針 止 メ	Needle clamp	
54	MG 23C0 664 × W502705	針棒メタル(下)	Needle bar bushing(lower)	
55	M9 1108 001 / B 503846	頭ナシ止メネジ 11/64(40)×5.5	Set screw for Fig.54	Χ
56	MG 23C0 325 × W502717	角 駒	Needle bar connecting block	
904	MG 23E0 582 ×	天 ビ ン(組)	Thread take up lever assembly	
57	W456581-01	針棒ダキ	Needle bar holder	Fig.No.904二含厶
58	M9 1251 002 × W20466-A	平 ネ ジ 3/16(32)×12	Set screw for Fig.57	ıı ıı
59	MG 23C0 660 × W456580-01	針 棒	Needle bar	
60	W456583-01	針棒クランクロット	Needle bar connecting link	Fig.No.904二含厶
61	M9 1210 002 / W501247	平 ネ ジ 3/16(28)×10	Set screw for Fig.72	
62	M9 1181 003 × W502725	丸 平 ネ ジ(左) 11/64(40)×13.5		Fig.No.904二含厶
63	W456588-01	天ビンクランク	Thread take up lever link	"
64	M9 2001 001 × W502218	頭ナシ止メネジ 5/16(24)×8	Set screw for Fig.72	
65	M9 0511 063 × W502731 **	特殊ピン	Thread take up lever hinge pin	
66	W502706	天ビン支工軸	Thread take up lever link hinge pin	Fig.No.904二含厶
67	W456585	天ビンダエ軸	Thread take up lever	// // // // // // // // // // // // //
68	M9 1513 001 B 509060	頭ナシ止メネジ 15/64(28)×11	Set screw for Fig.70	
69	M9 1106 001 × B 509266	頭ナシ止メネジ 11/64(40)×4.3*		
	MG 23C0 663 × W456579-01	針棒メタル(上)	Needle bar bushing(upper)	
71	MG 23C0 740 × W502203	フェルト	Felt	
72	MG 23C0 383 × W456589-01	$\begin{array}{cccccccccccccccccccccccccccccccccccc$	Needle bar crank	
	M9 0601 002 × W502723			Fig.No.904二含厶
74	M9 1802 006 B 503851		Set screw for Fig.72	119.140.304= 8.2
75	M9 1513 001 B 509060	棒 先 平 ネ ジ 9/32(28)×14	Set screw for Fig.72	
76	MG 23C0 232 × W45 659-01	頭ナシ止メネジ 15/64(28)×11	Set screw for Fig.76	
	MG 23C1 740 × W502486	上軸メタル(左)	Arm shaft bushing(left)	
//	WIG 2301 740 ~ W502486	フェルト・	Felt	

DY-253形 上軸部分 UPPER SHAFT MECHANISM



								備考
Fig. No.	サービス部品コード 資材コ Part No. Code	No. 部	品	名	Name of Part			Remarks
78	MG 23C0 230X W3227		車由		Arm shaft			
79	MG 23C0 331 × W4565	98-01 傘 歯	車(上軸)		Bevel gear for arm shaft			
80	M9 1602 002 X W5027	03 平 才	ジ 1/4(40)×9	Set screw for Fig.79			
905	MG 23E0 490 ×	水平送り割	節体(組)		Feed cam assembly			,
81	M9 1107 002 X W5000		ジ 11/6	64(40)×5.5	Set screw for Fig.85			Fig.No.905二含厶
82	M9 1504 002 X B 5089		ジ 15/6	64(28)×10	Set screw for Fig.85			// ig.ivo.3000 含在
83	W4652	17 座	金		Washer for Fig.82			n n
84	M9 1203 004 X W5004		調節ネジ 3/16	6(28)×24	Thumb screw for feed cam			"
85	W4605	76-01 水平送り	調節体		Feed cam regulator			"
86	W4605		リカム		Feed cam			"
87	MG 23C0 352 W4593	62 カラ	_		Collar			"
88	M9 1516 001 / W50000		メネジ 15/6	64(28)×15	Set screw for Fig.87			
89	M9 1504 002 X B 50896	63 平 ネ		34(28)×10	Set screw for Fig.91			
90	M9 1513 001 X B 50906	30 頭ナシ止	メネジ 15/6	64(28)×11	Set screw for Fig.93			
91	MG 23C0 461 × W45931	18-01 上下送	りカム		Feed lifting cam			
92	MG 23C1 740 X W50248	36 フェ			Felt			
93	MG 23C0 233 × W45932	22-01 上軸メタ	7 ル(右)		Arm shaft bushing(right)		-	
94	M9 1802 002 × W46289	96 平 ネ		(28)×16	Set screw for Fig.95			
95	MG 23C0 682 X W32276	86-01 ハ ズ	ミ車		Balance wheel			
96	M9 2202 003 X W50024	16 丸 平	ネ ジ 11/3	2(28)×17	Set screw for Fig.95			
97	MF 60A0 700 X W50083	36 ×	ネ		Spring for Fig.98			
98	MG 23C2 740 × W50073	88-02 フェ	ル・ト		Felt for Fig.101	460	A101 100	
99	MF 60A0 700 / W50083	86 バ	ネ		Spring for Fig. 100	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	119	(71)
00	MG 23C2 740 × W50073	88-02 フェ			Felt for Fig. 102		23 3 40	
01	MG 23C0 385 X W32277	0-01 クランクロッ		•	Feed rock shaft connecting rod(front)			
02	MG 23CO 386 X W32276	7-01 クランクロッ			Feed rock shaft connecting rod(back)			
03	M9 1602 002 X W50270	3 平 ネ		0)×9	Screw for Fig.115		63 68	
04	MG 23C0 521 X W45753	8-01 竪軸メタ			Feed lifting rock shaft bushing(upper)			/
05	MG 23C0 520 W45750	1-01 竪	軸		Feed lifting rock shaft			(1)
06	M9 1602 002 × W50270	3 平 ネ	ジュ1/4(4	0)×9	Screw for Fig.112			2
07	M9 1513 001 B 50906		メネジ 15/64	1/28\ × 11	Screw for Fig.112 Screw for Fig.110			
08	M9 1602 002 W50270	3 平 ネ	ジ 1/4(4		Screw for Fig.110 Screw for Fig.109			
09	MG 23C0 334 X W45750	3-01 傘 歯 車(玄神上)	0,73				1
10	MG 23C0 522 X W45937	1-01 竪軸メタ			Bevel gear(lower)			
11	MG 23C3 740 X W50004	3-02 フェ			Feed lifting rock shaft bushing(lower)			
12	MG 23C1 352 X W50200	1-02 b 5	_		Felt			
	70200	1-02 /			Collar			


DY-253形 竪軸部分 VERTICAL SHAFT MECHANISM



					備考
Fig. No.	サービス部品コード Part No.	Code No.	部 品 名	Name of Part	Remarks
113	MG 23C3 740	W500043-02	フェルト	Felt	
114	M9 1513 001 /	B 509060	フェルト 頭ナシ止メネジ 15/64(28)×11	Screw for Fig.104	
115	MG 23C0 333X	W457502-01	傘 歯 車(竪軸上)	Bevel gear(upper)	
_					
					,
		1			
	1	1			
	·	76			
				\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	
		* *			
			16.		
				3	
		- 4		·	
		19			
			•		
	, c				
				A A	
	0		** 4		
	*		1		(
			w /		
			F		
1					

=DY-253=


DY-253形 カマ、送り機構 ROTATING HOOK & FEED MECHANISM



	, ,					Remarks
Fig.	サービス部品コード	資材コード	部品名	Name of Part		Homarks
No.	Part No.	Code No.				
116	MG 23E0 121 🔨		外 ガ マ(組)	Rotating hook assembly		
906	MG 23E0 616		カマ押エ(組)	Rotating hook positioner assembly		
117	MG 23C0 781 🗶		カマ押エ台	Rotating hook positioner		Fig.No.906二含ム
118	MG 23C0 285 🗶		送り軸メタル	Feed lifting rock shaft bushining		,
119	M9 1502 002 🖊		平 ネ ジ 15/64(28)×12	Screw for Fig.118		
120	M9 2051 003 📈		丸 平 ネ ジ 5/16(24)×26	Screw for Fig.117		
121	M9 1505 002 🗙 '		平 ネ ジ 15/64(28)×14	Screw for Fig.122		
122			送り腕(上下左)(組)	Feed lifting rock shaft crank		*1
123	M9 1108 002 🗶	B 509289	平 ネ ジ 11/64(40)×7	Screw for Fig.126		Fig.No.906二含厶
124			角駒	Square block		Fig.No.122二含厶
125	M9 0606 063 🗶 '		コ ロ 軸	Square block set pin		n e
126	MG 23C0 192 X		板 バ ネ	Spring		Fig.No.906二含ム
127	M9 1506 001 /		頭ナシ止メネジ 15/64(28)×7	Screw for Fig.117		11
128	MG 23C0 257 ⊀	W457545	カマ押エ腕	Rotating hook positioner crank		II .
129	M9 0709 063 X	W502720	平 ピ ン	Set pin for Fig.128	,	11
130	M9 0402 063 ×	W502721	カシメピン	Set pin for Fig.132		<i>1</i> 1
131	M9 0909 003 /	W501901	丸 平 ネ ジ 9/64(40)×6	Screw for Fig.132		11
132	MG 23C0 258 🛩	W457546	押 エ 板 バ ネ	Rotating hook positioner spring		II .
133	M9 1502 002 /	W500509-02	平 ネ ジ 15/64(28)×12	Screw for Fig.134		
134	MG 23C0 285 🗲	W457554-01	送り軸メタル	Feed rock shaft bushing(left)		
135	MG 23C0 278 ×	W459308-01	送り腕(水平、左)	Feed rock shaft crank(left)		
136	M9 1603 003 /	W501009	丸 平 ネ ジ 1/4(24)×16	Screw for Fig.135		
137	M9 1204 003 🗙 I	B 508978	丸 平 ネ ジ 3/16(28)×12	Screw for Fig.138		
138	MG 23CO 229 🖈	W457542-01	内ガマ止メ・	Rotating hook positioner		
139	MG 23C0 283 🗶	W502779	送り台支エ軸	Feed bar shaft		
140	M9 1108 002 📈 I	B 509289	平 ネ ジ 11/64(40)×7	Screw for Fig.135		
	M9 1506 001 / I		頭ナシ止メネジ 15/64(28)×7	Screw for Fig.146		- /
142	MG 23C2 352X	B 422844-02	カラー	Collar for Fig.139		
143	M9 0906 002 / V	W500791	平 ネ ジ 9/64(40)×4.5	Screw for Fig.135		
144	MG 23C0 104 🔀	W322769-01	送り	Feed dog		•
145		W500713	平 ネ ジ 9/64(40)×8.5	Screw for Fig.144		
146	MG 23C0 281 🖈		送り台	Feed bar		4
147			カマセットネジ	Screw for Fig.116		Fig.No.116二含厶
				2.		
-						


=DY-253=

DY-253形 下軸部分 LOWER SHAFT MECHANISM



			. *						備考
ig. lo.	サービス部品コード 資材コード Part No. Code No.	部 品 名	Name of Part						Remarks
	M9 1513 001 B 509060	頭ナシ止メネジ 15/64(28)×11	Screw for Fig.150	+			+		
	MF 60A0 740 / W500042	フェルト	Felt	+		\top	+		
	MG 23C0 451 × W459371-02	下軸メタル(左)	Rotating hook shaft bushing(left)			-		\dashv	
51	MG 23C0 450 × W457506-01	下軸	Rotating hook shaft	+	\vdash	\top		_	
52	MG 23C0 491 × W461012	水平送り軸	Feed rock shaft				++		
	M9 1603 003 - W501009-01	丸 平 ネ ジ 1/4(24)×16	Screw for Fig. 156	\top					
	M9 1111 001 X B 503852	頭ナシ止メネジ 11/64(40)×10	Screw for Fig.155	+		_	1		
	MG 23C0 453 × W502718	下軸メタル(中)	Rotating hook shaft bushing(middle)			_	1		χ
	MG 23C1 465 × W457550-02	上部水平送り腕(右)	Feed lifting connecting crank(right)						
57	M9 1203 002 X B 509178	平 ネ ジ 3/16(28)×15	Screw for Fig.156	\top					
158	MG 23C0 279 × W459372-01	送 り 腕(水平右)	Feed rock shaft(right)						
	M9 1603 003 × W501009	水 平 ネ ジ 1/4(24)×16	Screw for Fig.158						
	MG 23C0 285 X W457554-01	送り軸メタル	Feed rock shaft crank bushing				11		
61	M9 1502 002 / W500509-02	平 ネ ジ 15/64(28)×12	Screw for Fig.160						
162	MG 23C1 352 > W502001-02	л э —	Collar for Fig.151						
63	MG 23C3 740 × W500043-02	フェルト	Felt for Fig.165	\top					
164	M9 1602 002 X W502703	平 ネ ジ 1/4(40)×9	Screw for Fig.162						
165	MG 23C0 452 X W457538-02	下軸メタル(右)	Rotating hook shaft bushing(right)						
166	M9 1513 001 🔀 B 509060	頭ナシ止メネジ 15/64(28)×11	Screw for Fig 165						
167	MG 23C0 332 × W457507-01"	傘 歯 車(下軸)	Bevel gear for lower shaft						
	M9 1602 002 🗡 W502703	平 ネ ジ 1/4(40)×9	Screw for Fig.167						
69	M9 0902 060 🔀 W501107	ピ ン 9.53 <i>ø</i> ×18	Set pin for Fig.170						
170	MG 23C0 277 × W462645	送 り 腕(上下右)	Feed lifting rock shaft crank(right)						
71	M9 1502 002 / W500509-02	平 ネ ジ 15/64(28)×12	Screw for Fig.170						
172	M9 1502 002 / W500509-02	平 ネ ジ 15/64(28)×12	Screw for Fig.173						
173	MG 23C0 285 X W457554-01	送り軸メタル	Feed lifing rock shaft crank bushing(right)						
74	M9 1108 002 B 509289	平 ネ ジ 11/64(40)×7	Screw for Fig.169						
75	MG 23C0 460 × W461013	上下送り軸	Feed lifting rock shaft						
		,							

DY-253形 上部送り機構 UPPER FEED MECHANISM




				11=1			
							備 考 Remarks
Fig. No.	サービス部品コード 資材コード Part No. Code No.	部 品 名	Name of Part				Homarks
178	M9 1601 045 / W501989	ナ ッ ト 1/4(24)×3.5	Nut for Fig.193				
179	M9 0607 050 W462759	座 金 M6	Washer for Fig.178				
180	MG 23C0 464 X W464054	送り腕(上部水平左)	Feed rock shaft crank(left)				
	MG 23C0 296 × W502715	送り足支工案内	Walking foot guide link				
182	W502794	ブッシュ	Walking foot guide bushing			e e e	
	MG 23C0 294 × W457549	送 り 足	Walking foot			1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
184	MG 23C0 295 X W324527	送り足支工	Walking foot guide supporter			1	
	M9 1108 002 B 509289	平 ネ ジ 11/64(40)×7	Screw for Fig.183				
	MG 10B0 910 / W457552-01	リンク	Walking foot guide link				
	M9 1602 015 × W501245	段 付 平 ネ ジ 1/4(24)×18	Screw for Fig.186	10		1	
	M9 1601 045 W501989	ナ ッ ト 1/4(24)×3.5	Nut for Fig.191			1 4	
89	M9 1110 002 W500294	平 ネ ジ 11/64(40)×8	Screw for Fig.181				
90	M9 1503 045 × W501843	ナ ッ ト 15/64(28)×5.5	Nut for Fig.194				
91	M9 1602 015 X W501245	段 付 平 ネ ジ 1/4(24)×18	Screw for Fig.186				
92	M9 5005 063 / W464052	コロ軸	Feed connecting rod				
93	MG 30B0 411 W443980	¬	Slide block				
194	M9 1507 015 / W466842	段 付 平 ネ ジ 15/64(28)×23.5	Screw for Fig.195				
95	MG 23C0 950 X W459317-01	レバー	Feed connecting rod				
96	MG 23C0 226 X W502714	受 ケ 金	Prop up washer Fig.199			134	
97	W502412	案 内 金	Bell crank pin clamp			Fig.N	o.199二含厶
98	M9 1213 015 × W501569 "	段 付 平 ネ ジ 3/16(28)×14.5	Bell crank screw				
99	MG 23C0 157 📈 W502712	案 内 棒	Bell crank pin			N	
200	M9 1210 002 / W501247	平 ネ ジ 3/16(28)×10	Screw for Fig.202	-		5 2 6	
201	M9 1210 002 W501247	平 ネ ジ 3/16(28)×10	Screw for Fig.202				
202	MG 23CO 910 📈 W457526	リンク・	Feed lifting rock shaft link				
203	MF 40A1 572 X W446379-01	ツル巻キバネ	Bell crank spring				
	MG 23C0 763 🗸 W457527-01	ベルクランク	Bell crank				
	MG 23C0 462 W457525-01	送り腕(上部上下左)	Upper feed lifting rock shaft crank(left)				/-
	M9 1110 002 / W500294	平 ネ ジ 11/64(40)×8	Screw for Fig.207				
	MG 23C0 261 X W4575-01	押工調節台	Presser regulating bracket				
	M9 2402 045 X B 509118	ナ ッ ト 3/8(28)×5	Nut for Fig.209				
209	M9 2401 035 × W457536-01	調 節 ネ ジ 3/8(28)×50	Feed regulating thumb screw				
210	M9 0401 061 / W501209	テーパーピン 4 ø×23×1/50	Taper pin for Fig.205				4
211	M9 1508 001 × B 509088	頭ナシ止メネジ 15/64(28)×8	Screw for Fig.212				
	MG 23C1 285 X W457554-02	送り軸メタル	Upper feed lifting rock shaft bushing(left)				. "
	M9 1508 001 X B 509088	頭ナシ止メネジ 15/64(28)×8	Screw for Fig.214				

=DY-253=

.


MAZ HI THIS IVY

DY-253形 上部送り機構 UPPER FEED MECHANISM



								備	考
ig.	サービス部品コード 資材コード Part No. Code No.	部 品 名	Name of Part	No.				Remarks	
4	M9 0901 060 / W501107	ピ ン 9.53 <i>ϕ</i> ×25	Set pin						
5	M9 1502 002 / W500509	平 ネ ジ 15/64(28)×12	Screw for Fig.218						
6	MG 23C0 285 W457554-01	送り軸メタル	Upper feed lifting rock shaft bushing						
7	M9 1108 002 X B 509289	平 ネ ジ 11/64(40)×7	Screw						
8	MG 23C1 277 × W462646-01	送 り 腕(上下右)	Upper feed lifting rock shaft crank(right)						
	MG 23E0 384 X W457522-01	クランクロット・	Feed connecting crank rod				•		
	MG 23C0 760 X W457523-01	偏 心 輪	Feed lifting eccentric						
	M9 1504 002 X B 508963	平 ネ ジ 15/64(28)×10	Screw for Fig.220						
	M9 1508 001 / B 5090\$8	頭ナシ止メネジ 15/64(28)×8	Screw for Fig.224						
	M9 1603 003 / W501009-01	丸 平 ネ ジ 1/4(24)×16	Screw for Fig.225						
4	MG 23C0 285 X W457554-01	送り軸メタル	Feed driving shaft bushing(right)					*	
	MG 23C0 465 × W457550-01	上部水平送り腕(右)	Connecting rod hinge screw	111					
	M9 1803 015 / W454870-01	段 付 平 ネ ジ 9/32(28)×26.1	Screw						_
	MG 23C0 910 × W322772-01	リンク	Feed dring connecting link						
	M9 1802 045 / B 508961-01	ナット 9/32(28)×4	Nut for Fig.226					3 Marie 10 10 10 10 10 10 10 10 10 10 10 10 10	
	M9 1803 015 / W454870-01	段 付 平 ネ ジ 9/32(28)×26.1	Connecting rod hinge screw						
	M9 1802 045 / B 508961-01	ナ ッ ト 9/32(28)×4	Nut for Fig.229						
	MG 23C1 460 × W461014	上部上下軸	Feed lifting rock shaft(upper)						
	MG 23C0 467 × W457553-01	上部水平送り軸	Feed driving rock shaft(upper)	4.4	40	5 .10			
33	MG 23C0 285 × W457554-01	送り軸メタル	Feed driving shaft bushing(left)	1	1		36	¥1	
34	M9 0401 061 / W501209	テーパーピン 4 <i>ø</i> ×23×1/50	Taper pin for Fig.233						
35	M9 1508 001 / B 509088	. 頭ナシ止メネジ 15/64(28)×8	Screw for Fig.233						
П		•							
		-	:						
	•						\perp		
	*					7/ 1	\perp		
		*/							
			, and a second s						
								1	

DY-253形 返し縫い機構 REVERSE LEVER MECHAISM




KTY)25つ用》をプロ水準) JEVOFJO JEVOFJ (DE DI JA JI JA)

		備考
Fig. サービス部品コード 資材コード 部 品 名 No. Part No. Code No. 部 品	Name of Part	Remarks
236 M9 0903 002 B 509065 平 ネ ジ 9/64(40)×6.	5 Screw for Fig.241	
237 M9 0703 060メ W502921 ピ ン 7.94 ϕ ×29	Pin	
238 M9 0604 060 / W502791 $^{\circ}$ $\sim 6.35 \phi \times 20$	Pin for Fig.241	6
239 M9 1101 030 × W502032 バネ掛ケピン 11/64(40)×1	9 Spring guide pin	
240 MG 23C0 572× W461011 ツル巻バネ	Spring	
241 MG 23C0 322 ➤ W4610 PO 返シ縫イテコ	Reverse stitch lever	
242 M9 1502 045 M501883 ナット 15/64(28)×4	Nut	
243 MG 23C0 953メ W459357-01 連 結 板	Reverse stitch lever connecting Plate	*
244 M9 1506 015 / W501246 段付平ネジ 15/64(28)×1	6 Screw	
245 M9 1202 045 / W500001 ナット 3/16(28)×4	Nut	-
246 MN 15AO 321 🗸 W459355-O1 返シ縫 イ板	Reverse stitch lever plate	
247 M9 1201 010 🗡 W501934 🔳 ネ ジ 3/16(28)×10	Lever plate screw	
248 M9 1506 001 / B 509087 頭ナシ止メネジ 15/64(28)×7	Screw	
249 MM 11A0 352メ W446142-01 カ ラ ー	Collar	
250 MG 23C0 320メ W459373-01 返シ縫 イ軸	Reverse stitch shaft	
251 M9 0507 065 / W465218 E 形止メ輪 7	E shape stop ring	
252 MG 23C0 454 × W502780 軸	Pin for Fig.254	
253 M9 1506 001 / B 509087 頭ナシ止メネジ 15/64(28)×7	' Screw	
254 MN 15AO 323× W461018-01 返シ縫 イ腕	Reverse stitch crank(right)	
255 MN 15AO 886 × W46O582 括動腕	Bell crank	
256 MN 15AO 323 メ W461018-01 返 シ 縫 イ 腕	Reverse stitch crank (left)	
257 M9 1109 001 / W500985 頭ナシ止メネジ 11/64(40)×6	6.6 Screw for Fig.255	
258 M9 1202 001 × W500151 頭ナシ止メネジ 3/16(28)×6	Screw for Fig.256	
259 M9 0903 060 ★ W461064 ピ > 9.53¢×22	Pin for Fig.256	
260 MN 15AO 910 W460584 リンク	Connecting link	
261 M9 0707 063 ★ W501015 ピ ン 7.94¢×22.5	Pin for Fig.260	Z
262 油 ヒ モ	Oil wick	
		1
· .		
· ·		

=DY-253====

DY-253形 押え上げ機構 PRESSER FOOT MECHANISM




								備考
ig. No.	サービス部品コード Part No.	資材コード Code No.	部品	名	Name of Part			Remarks
263	M9 1551 016 /	B 503843	段付丸平ネジ 15/	64(24)×30	Screw for Fig.265			
264	MG 23C0 729 🗡	W459375-01	ヒネリバネ		Spring for Fig.265			
265		W322771-01	ヒキ上ゲテコ		Knee lifter lifting lever link		A	
266		B 509176-02	段付丸平ネジ 15/	64(28)×10	Screw for Fig.269			į,
267		B 509177-02	ナット3/1	6(32)×3	Nut for Fig.266			
268	MG 23C0 591×	W461007-01	テコ接手		Knee lifter rock shaft			
269			ナ ッ ト 3/1	6(32)×3	Nut for Fig.270			
270	MG 23CO 593 X	W457521-01	テコ引キ棒		Lifting lever connecting rod			
271	M9 0605 060 ×	W461006-01	ヒキ上ゲピン 60>	< 60	Knee lifter lever pin			N.
272	MG 23CO 720 📈	W502926	ヒキ上ゲ板		Knee lifting lever plate	,		
	MG 23CO 220 🔀		上糸ュルメ		Thread tension releasing guide			
274	MF 10A2 245 X	B 409092-01	円錐バネ		Spring for Fig.273			
275	M9 0903 033 X	W459391	ピンネジ9/6	4(40)×12	Screw for Fig.273			
276	M9 1508 001	B 509088	頭ナシ止メネジ 15/	64(28)×8	Set screw for Fig.278			
277	M9 0704 063 🗙	B 503977-02	押工上ゲピン 7 ø×1	9	Presser bar lifter pin			
278	MG 23C0 252 X		押ェ上ゲ		Presser bar lifter			
279	M9 1112 002 /		平 ネ ジ 11/	64(40)×12	Screw for Fig.280			
280	MG 23CO 256 X	W457548-01	押 工 足	-	Presser foot			*
281	MG 23CO 262 ×	W457528-01	押 工 棒		Presser bar			
282	M9 1106 045 🔀	W500698	ナ ッ ト 11/0	64(40)×3	Nut for Fig.279			
283	MG 23C0 475×		スベリ上ゲ		Presser bar lifter bracket			
284	M9 1203 002 X			6(28)×15	Screw for Fig.289			
285	M9 1251 015 ×		段 付 平 ネ ジ 3/10		Screw for Fig.283			
286		W501247		6(28)×10	Screw for Fig.289			
287	M9 1111 001 X	B 503852	頭ナシ止メネジ 11/0		Screw for Fig.289			
288	M9 1103 045 × 1	W501528		64(40)×3	Nut for Fig.287			
	MG 23CO 265 ×		押工棒ダキ		Presser bar holder			
	M9 4001 035 🗡		押工調節ネジ 5/8(28)×49	Presser regulating thumb screw			
	M9 4001 045 × 1		ナット5/8(Nut for Fig.290			
292	MG 23C0 259 X		押ェバネ		Presser spring			* 3 3
293		W502726	摺 動 子		Presser bar slide			
294	M9 0304 060 /		ピ ン 3 ϕ ×	12	Pin for Fig.296			
		W500294		16(40)×8	Screw for Fig.296			,
			押工棒ダキ案内	,, -	Presser bar holder guide			
		3 509088	頭ナシ止メネジ 15/0	64(28)×7	Screw for Fig.265	9		

イワイをつうまり	"冷汁料槽"	711	JIEJIJA	(1(17	MIKANTER
		, ,			

.) •				備 考 Remarks
Fig. No.	サービス部品コード 資材コード Part No. Code No.	部 品 名	Name of Part	Homarka
298	W444134	毛	Oil wick	
99	MF 10A0 731 / W446232	ビニールパイプ	Oil pipe	
00	M9 1110 002 / W500294	平 ネ ジ 11/64(40)×8	Screw for Fig.301	*
	MG 23C0 689 X W461024	パイプホルダ	pipe holder	
02	M9 0906 011 X B 509269	丸 皿 ネ ジ 9/64(40)×7	Screw for Fig.304	
03	MF 60A4 740 X W500905	フェルト	Oil felt	. ¢
04	MG 23C0 742 × W4456 19	フタ	Oil reservoir cover	
05	MF 10E2 148 × W464039	油 ヒ モ 2.5 <i>ϕ</i> ×100	Oil wick	
06	M9 1852 002 X W501146	平 ネ ジ 9/32(20)×16	Screw for Fig.307	Fig.No.907二含厶
07	MG 23E0 711×	歯 車 箱 上(組)	Arm shaft bevel gear box complete(upper)	
07	W456599	歯 車 箱(上左)	Arm shaft bevel gear box(left)	Fig.No907二含厶
80	M9 1503 002 X B 504000	平 ネ ジ 15/64(28)×5	Screw for Fig.307	
09		丸 血 ネ ジ 9/64(40)×7	Screw for Fig.312	
10	W457500	歯 車 箱(上右)	Arm shaft bevel gear box(right)	Fig.No.907二含厶
11		フェルト	Oil felt	
	MG 23C0 742 X W445619	フタ	Oil reservoir cover	
	MG 23C0 139 X W447200-2	油 タ ン ク	Oil reservoir	
14		油 ヒ モ 2.5 <i>ϕ</i> ×100	Oil wick	
	MF 60A1 689 🗡 W444233	パイプホルダー	Oil pipe holder	
16	M9 1110 002 / W500294 "	平 ネ ジ 11/64(40)×8	Screw for Fig.315	
80		歯 車 箱 下(組)	Hook shaft bevel gear box complete(lower)	
17		平 ネ ジ 9/32(20)×16	Set screw for Fig.319	Fig.No.908二含厶
18		平 ネ ジ 15/64(28)×5	Set screw for Fig.319	
19	W457505	歯 車 箱(下右)	Hook shaft bevel gear box(right)	Fig.No.908二含厶
20	W457504	歯 車 箱(下左)	Hook shaft bevel gear box(left)	II .
21		ビニールパイプ	Oil pipe	
22	M9 1110 002 / W500294	平 ネ ジ 11/64(40)×8	Set screw for Fig.323	
	MF 10A0 689 X W444230	パイプホルダー	Oil pipe holder	
24		油 ヒ モ 2.5 <i>ϕ</i> ×240	Oil wick	
25		パッキン	"O"ring	
26		平 ネ ジ 11/64(40)×10	Set screw for Fig.327	
	MG 23C0 250★ W502927	オイルゲージ	Oil gauge	4
28		フ タ	Cover	· ·
29		油 ヒ モ 2.5 <i>ϕ</i> ×240	Oil wick	
	M9 1110 002 / W500294	平 ネ ジ 11/64(40)×8	Set screw for Fig.331	
	MF 10A0 689 X W444230	パイプホルダー	Oil pipe holder	
32	MF 10A0 731 / W446232	ビニールパイプ	Oil pipe	
	MF 10A0 148 🗶 W444138	油 ヒ モ 2. ¢×240	Oil wick	
34	MG 23C0 147X W461023	油ヒモ支エ	Oil pipe holder	

_____DY-253

DY-253形 付属品(付属品箱) ACCESSORIES BOX



) ,	77571777	馬马(对馬.)) (((((((((((((((((((+		1	7	備	-	考
Fig. No.	サービス部品コード Part No.	Code No.	部 品 名	Name of Part		F					Remark	s '
	MF 60A0 749 X		付属品箱	Accessories box								
801	MB 02A0 608 X	P 842003X01	ドライバー(中)	Driver(medium)					4			
802	MB 02A1 608 🔀	P 842002X01	ドライバー(小)	Driver(small)			•					ć
803	MG 23CO 128 🗙		針 DD×1#25	Needle #DD×1 #25								
804	MG 23CO 123 X		ボービーン	Bobbin								
	MF 60A0 137 🗶		油 差 シ	Oil bottle								
306	MG 23CO 739 X	W502124	ヒンジ	Table hinge								
	MM 10A0 376 🗡		鎖 1.006mm	Chain							ĸ	
	MF 60A0 608 🗡		ドライバー(大)	Driver(large)								
	MG 23CO 131 🗶	W220633	油 受	Oil guard								
822	MG 23E0 190 🗶		糸 巻 仕 掛 132K	Bobbin winber								
823	MG 23C0 748 🗴	W219080	踏板	Treadle plate								
								\perp				
	3											
								\perp				
				/								
								+				
		- 40										
		**						+	-			
				**	4			-				
								\perp	_			
								\perp	_			
						\blacksquare			_			
								+	\perp			
			_						-			
R.					++	\perp		-	-			
					\perp				-			
		14 F	•/					-	-			
								+	+			
		4			++			\perp	-	1		
			·		++				-			
				,	+-+	+		++				
•				1	++	-		+	_			
					+-	-		+	+			
					1	1						

G23-26

DY-253