Automatic 2-needle Belt-loop Attaching Machine

MOL-254

- The new machine head specifically developed for belt-loop attaching machines runs at a maximum sewing speed of 2,500rpm and is equipped with a direct-drive system that improves start up performance and shortens sewing time.
- The belt-loop feeding device is now provided with a halfway standby capability for subsequent belt-loops, and its faster belt-loop supply action shortens the time required for supplying belt-loops and helps speed up the machine time to 1.2 seconds per belt-loop (with 28 stitches).
- Belt-loops are fed out by the conventional gear-roller feeding mechanism and also drawn out by the new drawing mechanism on the clamp device.
 Supported by these two mechanisms, the folding fork catches "curled" or "creased" belt-loops every time and supplies them to the head.
- The machine preliminarily detects each splice in the belt-loops and efficiently disposes them. This means that even when the machine carries out the splice-disposal procedure, the belt-loop feeding device can complete its belt-loop supply action and supply the next belt-loop well before the machine starts to sew. As a result, the operator can perform rhythmical and efficient sewing work with no delay in cycle time.
- The number of stitches to sew a belt-loop can be switched between; 28-, 36- and 42-stitches, and the bartacking size can be easily changed through the operating panel. What's more, the user can create his/her own original sewing patterns in addition to the standard ones using JUKI's PGM-20 programming software developed for computer-controlled sewing machines.




MOL-254



SPECIFICATIONS


Model name	MOL-254	
Machine head	Computer-controlled, 2-needle, lockstitch bartacking machine	
Max. sewing speed 2,500rpm		
Thread take up	Link type	
Needle bar stroke	45.7mm	
Thread	Spun thread, cotton thread #50 ~ #30, B33 ~ B46, Nm=120/3 ~ 60/3	
Needle (at the time of delivery)	DP × 17 (#21) #19 ~ #21	
Hook	Horizontal-axis 1.8 fold-capacity shuttle hook	
Lift of the presser foot	21mm	
Number of stitches	28, 36, 42 (selectable on the operating panel)	
Needle gauge	40 ~ 70mm (1-37/64" ~ 2-3/4")	
Bartacking length	7 ~ 22mm (9/32" ~ 55/64") adjustable in increments of 0.1mm	
Bartacking width	1 ~ 3.2mm (3/64" ~ 1/8") adjustable in increments of 0.1mm	
Number of pieces of bartacking data that can be stored in memory	9 (99 patterns if optional ROM is added)	
Belt-loop width	9 ~ 20mm (23/64" ~ 25/32")	
Finished length of belt-loop	48 ~ 78mm (1-57/64" ~ 3-5/64")	
Machine time	1.2 sec./belt-loop (28 stitch)	
Positioning of the front hook	Driven by motor (the distance between the hook can be established in increments of 0.01mm)	
Bobbin winder	Electric type (provided as standard)	
Lubrication	Centralized oil wick lubrication (machine head)	
Lubricating oil	JUKI New Defrix Oil No.2 (equivalent to ISO VG32)	
Power requirement and power consumption	Single-/3-phase, 350VA	
Compressed air and air consumption	0.5MPa (5kgf/cm²), 32NQ/min	
Total weight	230kg	
Dimensions	1,200mm (W) × 800mm (D) × 1,350mm (H: in its lowest end)	
Height of the top surface of the throat plate as from the floor surface	920 ~ 1,250mm (provided with the adjustable stand capability)	



^{*} Enter codes of required options in alphabetical order.

FINISHED BELT-LOOP STITCH SIZE

- The applicable loop width for the cross-cutting device is increased. In this model, both the cross-cutting device and the straight-cutting device can now cut loop up to 20mm width.
- *The machine is factory-equipped with cross-cutting device at the time of delivery.




OPTIONS

Part No.	Description	Feature
G5700-254-0A0	Belt-loop tension releasing (fullness)	The device slackens the belt-loop when attaching it on the garment body.
G5730-254-0A0	Belt-loop feeding device (belt-loop slackener)	The cylinder type belt-loop feeding device supports the belt-loop feeding of the main unit.
G5760-254-0A0	Air gun assembly	
G5770-254-0A0	Needle cooler	The device cools the frictional heat generated by the needle during sewing.
G5780-254-0A0	Needle thread breakage detector	The device detects breakages in the needle thread by means of a thread take-up spring. If a needle thread breakage is detected, the device halts the sewing of the next loop.


MAJOR SPARE PARTS

Part No.	Description	Remarks
G5412-254-000	Upper knife (loop cut knife)	Exclusive to MOL-254
B1818-210-D0B	Shuttle, H type	Also used with the AMS-210D
B1817-210-DAC	Shuttle race ring complete, C type	Also used with the AMS-210D
138-82501	Needle hole guide	Also used with the MOL-154
138-81255	Moving knife junction	Also used with the MOL-154
138-81008	Lower plate blank	Also used with the MOL-154
HL-0084230-00	EP-ROM for data	Also used with the LK-1900




NOL-254 1. HACHINE FRANE & HISCELLANEOUS COMPONENTS

No note	Parts No.	DESCRIPTION	a
1	144-00055	HEAD COVER A ASM.	
Z	144-00006	HEAD COVER A	ſ
3	55-6111140-5P	3CREW11/64-40 L=11	ſ
4	MB002-430-000	21OFFER	ſ
5	144-00204	HEAD COVER FIXED PLATE	1
6	100-04109	GROUND MARX	
7	144-01400	FACE GASKET	1
В	54-0040801-50	SCREW	
9	144-02002	HEAD FIXED SHAFT	
10	55-81 50822-1P	SCREW 15/64-28 L=8	
11	144-01301	FACE PLATE	
12	110-00403	PLATE	
13 01	55-4110/15-5P	3CREW 11/64-40 L=/	
14	CM-3002001-01	ZOPETY LOBEL, 1 (SMOLL).	
15	CM-3002001-A1	ZOPETY LOBEL (SMALL).	
16	144-00105	HEAD COVERB	
17	55-4110815-5P	SCREW 11/64-40 L=8	
18	MB002-430-000	\$10PPER	
19	HX-0015000-0C	CABLE CUP	
za	55-4110615-5P	SCREW 11/64-40 L=6	
21	G8515-286-QAQ	BR EARTH CORD ASM.	
22	22-4110/15-3P	SCREW 11/64-40 L=/	
23 01	EA-9500B01-00	CABLE BAND	1
24 GZ	EA-9500B02-00	CABLE BAND 150	
25	CM-2005000-85	LAMEL(ZS).	
26	CM-3002000-02	CAUTION LABEL(25)	
2/	BSG 23- 2 \ 2-GGG	1HREAD GUIDE NO.1	
28	22-4150/15-3P	3CREW 15/64-28 L=/	
29	55-4151215-5P	SCREW 15/64-28 L=12	
20	22-/110840-3P	SCREW 11/64-40 L=/.8	
31	144-01509	BED COVER A	
22	144-01508	BED COVER B	
22		SCREW11/64-40 L=6	
	22-8110810-1P	SCREW11/64-40 L=6	
34	22-8110810-1P		
22	55-4151215-5P	3CREW 15/64-28 L=12	
26	1A-1250406-R0	RuBBER PLUG D=12.5 L=4	
21	1A-14/0/04-R0	RUBBER PLUG	
28	51-4041291-50	3CREW M4 L=12	
29	1A-1050504-R0	RUBBER PLUG	
40	PJ-0252000-01	RUBBER PLUG	
41	138-/1/GZ	BALANCE COVER	
4Z	55-4120615-5P	3CREW 3/16-28 L=6	
45	138-70902	BALANCE THREAD GUIDE.C	
44	139-22208	1AKE-UP THREAD GUIDE B	
45	55-61 20620-1P	SCREW	
46	WP-0641600-30	WASHEW 6:4X1 2:5X1.6	
4/	MAZ-12665000	MAGNET FITTING BASE COLLAR	
48	144-01806	WIFER CYLINDER BASE (A)	
49	138-72007	WIFER CYLINDER BASE. B	
sa	138-72304	WIPER CYLINDER BASE. (C)	
51	128-/9902	WIFER CYLINDER BASE (D)	
52	22-1110110-25	3CREW11/64-40 L=/	
2.2	WP-0480856-3P	WASHER 4.8X8.4X0.8	
54	22-8121040-2P	3CREW15/64-28 L=10	
55	138-/2106	WIFER	
36	138-/2205	WIPER PRESSER	
57	22-8080410-2P	3CREW1/8-44 L=4	
58	PJ-3040405-04	ELBOW UNION	
59	PA-1004001-A0	AIR CYLINDER	
6a	B1111-232-000	1HREAD GUIDE PLATE	
61	55-4150/15-5P	SCREW 15/64-28 L=/	
62	141-00309	10P COVER	
6.2	144-01/0/	BOBBIN COVER	
64	55-61111140-5P	30REW11/64-40 L=11	




No	note	Parts No.	DESCRIPTION	Qt
1		55-6151210-5P	SCREW 15/64-28 L=12	4
Z		B1223-//1-000	NEEDLE ROD CRANK WASHER	1
3		144-02960	LINK BALANCE ASM.	1
4		144-02952	LINK BALANCE COMPL.	(1)
5		144-03000	BALANCE CRANK	(1)
6		81903-552-000	LEF1 SCREW	(1)
7		D1203-L/V-V00	MEEDLE BOR CRONK, HEAVY	(1)
В		144-03109	NEEDLE BAR CRANK ROD	(1)
9	01	81905-541-000	NEEDLE BUZHING	(1)
10	01	B1905-541-A00	NEEDLE BEARING, A	(1)
11	01	81905-541-800	NEEDLE BEARING	(1)
12	01	B1905-541-C00	NEEDLE BEARING	(1)
13	01	B1905-541-D00	NEEDLE BEARING	(1)
14	01	B1411-B04-000	NEEDLE DRIVING LEVER BEARING	(1)
15	01	B1411-B04-A00	BEARING (A)	(1)
16	01	81411-804-800	NEEDLE DRIVING LEVER BEARING B	(1)
17	01	B1411-B04-C00	MEEDLE DRIVING LEVER BEARING C	(1)
18	01	B1411-B04-D00	BEARING (D)	(1)
19		144-00303	MOTOR WIRE HARNESS RELAY BASE	1
za		32-4041091-50	3CREW M4 L=10	2
21		144-04305	IDLERPOLLEY	1
22		SB-112000/-00	E LARING	z
23		RC-1200001-KP	C-SHAPED SHAP RING	1
24		MM-6120001-CP	Nu1 M1Z	i
25		WS-1220002-KP	SPRING WASHER	1
26		140-23303	YPACER .	1
2/		D1904-L/V-V00	LINK TAKE-UP LEVER PIN . HEAVY	1
28		55-7151120-5P	3CREW 15/64-28 L=11	1
29		144-03612	NEEDLE ROD	1
20		144-03/11	NEEDLE ROD SUPPORT SHAFT	1
31		144-03208	NEEDLE ROD LOWER METAL A	i
32		81402-280-000	NEEDLE ROD METAL	1
22		144-03307	NEEDLE ROD LOWER METAL B	i
34		144-03406	NEEDLE ROO UPPER METAL A	1
22		144-04016	NEEDLE ROD BASE	1
26		144-04800	WEEDLE IN STALLING BASE	
37		144-03802	NEEDLE ROD HOLDER A	1
28		22-8030810-1b	3CREW 9/64-40 L=/.5	1
23		22-/110840-3P	3CREW 11/64-40 L= /.8	
40		55-6110820-1P	3CREW 11/64-40 L= 8	1
41		3M-6850502-1N	3CREW M Z.5 L= 5	2
42	az	MDP-1/081900	NEEDLE DPX1 / #19	2
43	02	MDP-17082100	NEEDLE DPX1 / #21	2
44		D1906-L/V-V00	32.1 3CREW	1
45	a 1	B1414-232-000	200 NEE BLOCK	1
45	a1	B1414-232-000	CRANK SLIDE BLOCK	1
47	a1	B1414-232-008	GUIDE ROLLER	1
48	91	83035-280-000	ZAFE IV PLATE SLIDE BLOCK	1
49		144-03901	NEEDLE ROD HOLDER B	1
49 50		ZZ-6090810-1P	SCREW 9/64-40 L=7.5	1
51		22-8110250-1b		1
52		22-8110320-1P	SCREW 11/64-40 L= 4.5	1
			SCREW 15/64-28 L= 4./	
53		HX-0015000-0N	CABLE CUP	1
54		51-4041091-50	SCREW M4 L=10	1
55		144-04404	IDLER PULLEY SHAF1	1






	1. HAIL 2-A I CONTONIA I I					
No	note	Parts No.	DESCRIPTION	Qty		
1		PS-0400142-KH	SPRING PIN 4X14	Z		
Z		144-02/05	MAIN 54-AFT	1		
2		144-03505	MAIN SHAFT FRONT METAL	1		
4		141-02305	MAIN 34AF1 BU3HING, MIDDLE	1		
5		22-8110210-2P	SCREW11/64-40 L= 5	Z		
6		22-8110210-2P	30REW 11/64-40 L= 2.8	Z		
- 7		265-00306	HAND PULLEY SHAFT	1		
B		141-02800	HAND PULLEY GEAR B	1		
9		141-02/01	HAND PULLEY GEAR A	1		
10	•	400-59353	SERVO MOTOR	1		
11		B1231-210-D00	COUPLING	1		
12		144-02804	COUNTER WEIGHT	1		
13		144-04206	11MING BEL.1	1		
14		144-04107	DRIVING SPROCKET	1		
15		3M-8060802-1P	SCREW Mis L=8	Z		
16		55-6151412-1P	3CREW 15/64-28 L=14	1		
17		22-6681712-1P	3CREW 9/32-28 L=16.5	1		
18		22-3881520-Cb	3CREW 1/4-40 L=12	1		
19		22-8660610-1P	3CREW 1/4-40 L= 6	1		
za		CS-14/121A-SH	1HRUS1 COLLAR ASM D=14.72 W=12	1		
21		G1216-8/0-000	UPPER SHAFT REAR BEARING	1		
ZZ		3M-8060612-1P	2CREW Mis IT-8	Z		
23		3M-8061612-1P	SCREW MEXTE	Z		
24		RO-1542401-00	RUBBER RING	1		
25		144-0250/	MOTOR INSTALLING BRACKET	1		
26		55-2110920-1P	SCREW 11/64-40 L=8.5	4		
27		55-6151220-5P	SCREW 15/64-28 L=11.5	2		
28		94-6052002-1P	SCREW MS L=20	4		
29		WP-0531000-5D	WASHERMS	4		
20		WS-051000Z-KP	SPRING WASHER 5.1X9.2X1.3	4		
31		55-7110840-5P	3CREW 11/64-40 L=7.8	1		
32		A1230-500-000-A	HANDWHEET ZE 12CLEW	1		
22		81144-210-000	REVOLVING DIRECTION LABEL	1		
34		B1212-210-D00	PULLEY	1		
35		GAF-0100/000	SHING SHIP	1		

4. HOOK DRIVING SHAFT COMPONENTS




No	note	Parts No.	DESCRIPTION	Qty
1		141-03402	OSCILLATOR	1
Z		B1814-210-D00	24011FE	1
2		81813-980-000	SHUTTLE NEEDLE OUTER RING	1
4		262-31100	SHUTTLE LUBRICATING PLATE	1
5		83504-280-000	SHU11LE FEL1	1
6		22-8090440-3P	SCREW 9/64-40 L= 4.0	Z
7		WP-0952616-5D	WASHER 9.5X14.8X2.6	1
В		CO-2522000-00	OIL WICK	1.5
9		B1820-210-D00	SHUTTLE OIL FELT A	Z
10		BP-3000000-00	VINYL PIPE	1
11		B1821-210-D00	SHUTTLE OIL FELT B	1
12		B1 B2G- 21 S-PAG-A	INNER HOOK PRESSER ASM.	2
13		B1 B22-215-P00	INNER HOOK PRESSER SPRING	z
14		RE-0300000-K0	E-RING 3	2
15		B1817-210-DAC	SHUTTLE RACE RING ASMC	1
16		105-23504	WASHER	1
17		B1836-210-D00	OSCILLATING ECCENTRIC SHAFT	1
18		B1802-210-D00		
19		B1815-210-000	CRANK ROD	1
za		B1818-210-00B	INNER HOOK UPPER SPRING	1
21			SHUTTER	1
		22-6151220-3P	SCREW 15/64-28 L=11.5	1
ZZ		55-81 50 8 2 2 - 1P	SCREW 15/64-28 L=8	2
23		ZZ-/111110-1P	SCREW 11/64-40 L=10.5	Z
24		135-08403	LOWER SHAFT REAR METAL	1
25		144-0/951	LOWER SHAFT GEAR COMPL.	1
26	01	B1411-B04-A00	BEARING (A)	
27	01	81411-804-800	NEEDLE DRIVING LEVER BEARING B	3
28	a 1	B1411-B04-C00	MEEDLE DRIVING LEVER BEARING C	3
29	a 1	B1411-B04-D00	BEARING (D)	3
20		81808-980-000	LOWER SHAFT THRUST WASHER	1
31		144-05005	3-UTILE DRIVER	1
3 Z		22-9151515-1b	SCREW 3/16-28 L=12/0	1
22		144-0/506	ROTARY BOLL SPLINE	1
34		144-07605	FOLLOWER SPROCKET	1
35		144-07704	SPROCKET BASE	1
36		144-07803	BEL1 GUIDE	1
37		B1806-210-D00	BOBBIN	1
28		B1828-21Q-DAA	BOBBIN CASE ASM.	1
29		B1828-210-D0A	BOBBIN CASE	(1)
40		B1808-210-D00	SPRING	(1)
41		C2-080081C-24	1HRUZ1 COLLAR A3M, D=8.0 W=8	1
42		C2-0800818-24	1HRUS1 HOLDER D= 8 W= 8	(i)
43		55-8110520-1P	SCREW 11/64-40 L= 4.5	(2)
44		CZ-1000811-ZP	1HRUS1 COLLAR	1
45		C2-1201010-24	1HRUST COLLER ASM, D=12 W=10	i
43 46				(1)
		C2-1201011-24	1HRUS1 COLLAR D=1 2 W=10	
47		22-8660610-1P	SCREW1/4-40 L=6	(2)
48		55-8110520-1P	30REW 11764-40 L= 4.5	2
49		WZ-8880420-2b	Nu11/4-40	1
sa		RE-0900000-K0	E-RNG 9	1
51		50-0801021-1P	HINGE SCREW D= 8H=10.2	1
52		22-8080410-1P	5CREW 5/32-56 L= 3.5	Z
53		22-6110480-3P	SCREW 11/64-40 L=4.3	1
54		262-22208	SHUTTLE RACE ADJUSTING SHAFT	1
55		52-6041492-1M	2CKEW	6
56		5M-6051202-1P	3CREW M5X0.8 L=12	6
57		94-6053502-1P	8001	6
58		WS-051000Z-KP	SPRING WASHER 5.1X9.2X1.5	6

G1...SELECTIVE PARTS /






No	note	Parts No.	DESCRIPTION	Qty
1		144-11201	CROSSFEED ARM	1
Z		144-11805	CROSSFEED GEAR	1
- 2				
		144-11/06	LENGTHWISE FEED ARM	1
4		144-10401	LENGTHWISE FEED SHAFT	1
5		141-1040/	LENGTHWISE FEED GEAR	1
- 6		144-10203	X FEED STEPPING MOTOR	1
- /		144-10104	Y FEED STEPPING MOTOR	1
8		144-11409	CKOZZEED ZEVZOK ZTI	1
9		144-11508	ZMSOR INSTALLING BAZE	1
10		141-36402	LENGTHWISE FEED SENSOR SUT	1
11		141-11801	ZEN SOR IN STALLING BASE	1
12		3M-6051602-1P	3CREW M 5X0.8 L=16	2
13		34-6051002-1P		
		144-10/08	SCREW MSX0.8 L=10	1
14			CLOTH FEED BASE	1
15		144-12209	CLOTH FEED PLATE BASE A	1
16		144-12308	CLOTH FEED PLATE BASE B	1
17		138-80505	BOLL HOLDING BASE	1
18	a 1	B1414-232-000	200 NASE BLOCK	Z
19	01	B1414-232-00A	CRANK SLIDE BLOCK	Z
ZO	01	81414-232-008	GUIDE ROLLER	2
21		144-11904	CROSSFEED SUPPORT ARM	1
22		144-12001		1
23		BZ509-704-000	LENGTHWISE FEED SUPPORT ARM	
			BUSHING. REAR	2
24		144-1160/	LENGTHWISE FEED BASE	1
25		34-804050Z-1P	SCREW M4X0.7 L= 5	1
26		135-1890/	SUPPORT PLATE	1
27		55-4110715-5P	SCREW 11764-40 L=7	1
28		144-11300	FEED DRIVING ARM SHAFT	1
29		82548-280-000	BALL RE LAIMER	1
20		82549-280-000	WORK CLAMP FOOT MOUNTING BASE	7
31		138-80406	CLOTH PRESER LOWER PLATE	1
32		144-11102	XY 1AH.E	1
22		144-1080/	FROM 1 PREZZER FOOT BASE	
				1
34		144-10906	CLOIH PRESSER BASE COVER	2
22		138-80604	WASHER	Z
2.6		138-80/03	CYLINDER PIN	Z
21		144-11003	CLOTH PRESSER CYLINDER SHAFT	Z
28		22-8150/40-2b	S0REW 3/16-28 L= /	1
29		138-/5612	CLOTH PREZZER FOOT	2
40		PA-1002507-A0	AIR CYLINDER	2
41		PJ-3040405-04	ELBOW UNION	4
42		RE-0300000-K0	E-Ring 3	2
43				8
		3M-6041 202-1N	3CREW M4X0./ L=12	
44		24-9040602-20	SCREW M4 L=6	2
45		3L-6040892-1M	8011	1
46		2M-E0208E0-2b	2CME/M	Z
47		5M-6051802-1P	2005W W2 F=18	2
48		5M-6052502-1P	SCREW M 5X0.8 L= 25	1
49		5M-6051602-1P	SCREW M \$30.8 L=16	Z
50		55-8110422-1P	30REW11/64-40 L=4	2
51		5M-6061202-1N	80.1	Z
52		22-6110810-1P	SCREW 11/54-40 L=8	2
2.2		55-6152212-5P	SCREW 15/64-28 L=22.0	2
54		22-8151510-2P	SCREW 3/16-28 L=12	2
55		RC-0560/11-KP	RETAINING RING	1
56		3M-8060602-1P	2CREW MEXE	2
57		3M-8060602-1P	SCREW MEXE	Z
58		22-8660212-1P	SCREW 1/4-40 L= 5	2
29		HD-0005700-0A	PHOTO SENSOR	1
60		HD-0005/00-0A	PHOTO SENSOR	1
61		37-4021531-20	SCREW M 3X1 2	1
62		SL-4031291-SC	SCREW M3X12	1
6.2		55-4110715-5P	SCREW 11/64-40 L=/	1
64		22-4110/15-3P	3CREW 11/64-40 L=/	1
65		3M-6041202-1P	3CREW M4X0./ L=12	4
66		3M-6041202-1P	SCREW M4X0.7 L=12	2
6/				
		WP-0430800-3D	WASHER M4	3
68		W5-041000Z-KP	SPRING WASHER	2
69		WP-0430800-3D	WASHER M4	4
70		W5-0410002-KP	SPING WASHER	4
71		22-51 10350-1b	SCREW 11/64-40 L=8.5	2
72		38-4080001-00	BEARING	2
7.3		22-8110810-1P	SCREW11/64-40 L=6	1
74		22-4110313-3P	SCREW 11/64-40 L= 5	1
75		144-10005	X MOTOR INSTALLING BASE	1
76		144-1030Z	Y MOTOR IN ZTALLING BASE	1
77		55-6151412-1P	3CREW 15/64-28 L=14	1
78		3M-6052002-1P		
78			SCREW MS L=20	3
		WP-0531000-3D	WASHERMS	2
BO		W5-051000Z-KP	SPRING WASHER 5.1X9.2X1.3	2
81		22-8111010-1P	SCREW 11764-40 L= 9.5	Z
82		22-1110840-3P	SCREW 11/64-40 L=7.8	2
82		WP-0550800-3P	WASHERS.SX10X0.8	6
		WP-0621016-3H	WASHER	2
84		RE-0400000-K0	E-Ring 4	2
84 85			3CREW 3/16-28 L= /	Z
85		32-8120/40-3P		
85 86		55-8120740-5P		
85 86 87		HX-0015000-0F	CABLE CLIP	1
85 86				




No	note	Parts No.	DESCRIPTION	Qty
91		144-10559	Y SENSOR CABLE ASM.	1
92		229-13503	WASHER	Z
93		82222-980-000	OIL WICK PIPE STOPPER	1
94		G5560-254-000	CLOTH FEED PLATE GUIDE	1
95		GSS61-254-000	Support Guide	1
96		27-8020885-1M	80.1	Z
97		138-7/816	PREZZER FOOT (FOR FULL NEZZ)	Z

Underheidt ...FORUSEIN JAPAN / 02...FOREXPORT / 01...SELECTIVE PARTS / 01...SELECTIVE PARTS / 01...SELECTIVE PARTS / 02...FORUSEIN JAPAN / 03...FOREXPORT / 03...FOREXPORT / 01...FORUSEIN JAPAN / 02...FOREXPORT / 03...FOREXPORT HIGH VOLTAGE / 01...FORUSEIN JAPAN (200V) / 02...FOREXPORT (LOW VOLTAGE 200—240 / 01...FORUSEIN JAPAN (200V) / 04...FOREXPORT (LOW VOLTAGE 200—240 / 01...FORUSEIN JAPAN (200V) / 05...FOREXPORT (LOW VOLTAGE 200—240 / 04...FOREXPORT / 05...FOREXPORT (LOW VOLTAGE 200—240 / 04...FOREXPORT / 05...FOREXPORT / 0






No	note	Parts No.	DESCRIPTION	Qty
1		265-01205	CAM FOLLOWER STOPPER	1
z		141-08500	SOLENOID ARM	i
2		141-08609	CONNECTING ROD	1
4		144-12902	CONNECTION PLATE A	1
5		144-13009	CONNECTION PLATE B	1
6		141-08955	THREAD TRIMMING SOLENOID ASM.	1
7		141-0880/	20/EVOID IN 21 VITING BYZE	in
8		141-08906	SOLENOID FOR THREAD TRIMMING	(1)
9		110-43304	SOLEMOID RUBBER	(1)
10		M2-8660410-24		(1)
11		NM-6040000-3N	Nu1	
12		NZ-6660430-3P	Nu1M4	(2)
			Nu11/4-40	(1)
13		WP-0450000-3D	WASHER4.5X8X0.5	(2)
14		HK-0346100-20	Z-POLE NYLON PLUG	(1)
15		HK-0346400-00	PIN CONTACT	(2)
16		B1652-704-000	SHING SHIP	(1)
17		141-09250	CAM FOLLOWER ASM.	1
18		141-09300	THREAD TRIM LINK SPRING	1
19		B2401-210-D00	1HREAD IRIMMER CAM	1
za		82408-210-D00	THREAD TRIMMER SHAFT	1
21		5M-8022002-1P	2CKEM WR F= 20	1
ZZ		110-4300/	SOLENOID PIN	1
23		B1223-//1-000	NEEDLE ROD CRANK WASHER	1
24		81116-804-000	CLOTH PLATE WASHER	1
25		81649-161-000	TEN SION SPRING ADJUSTING SCREW	1
26		144-12803	1HREAD CU11ING LINK	1
27		55-7110740-1P	SCREW11/64-40 L=/	Z
28		144-12506	MEEDLE PLATE	1
29	01	82423-280-00A	MOVING KNIFE WASHER A	1
20	01	B2423-280-00B	MOVING KNIFE WASHER B	1
31	01	B2423-280-00C	MOVING KNIFE WASHER C	1
32	Q1	B2423-280-00D	MOVING KNIFE WASHERD	1
22	01	BZ4Z3-Z8Q-QQE	MOVING KNIFE WASHERE	
34	01			1
22		82423-280-00F 82423-280-00G	MOVING KNIFE WASHERF MOVING KNIFE WASHERG	1
	a 1			1
26		138-82105	MOVING KNIFE LINK	1
21		B2424-210-000	COUNTERKNIFE	1
28		138-81255	MOVING KNIFE JUNC 110N	1
29		138-82501	NEEDLE HOLE GUIDE	1
40		22-1080510-1b	3CREW 3/32-36 L= 2.2	2
41		22-1030410-2b	3CREW 9764-40 L= 3.5	2
42		B2417-210-000	MOVING KNIFE HINGE SCREW	1
43		144-12654	1HREAD CU 11ING LEVER COMPL.	1
44		D2587-L8W-B00	ROLLER	1
45		D2588-L8W-B00	ROLLER SHAF1	1
46		NM-6050001-3P	NU1M5	1
47		MS-6110420-SP	NU1 11/64-40	1
48		NS-6110420-5P	Nu1 11/64-40	Z
49		WZ-8150210-25	NU13/16-28	1
SO		RE-a Saaaaa-Ka	E-RING	1
51		WP-0501016-3D	WASHERSX10.5X1	1
52		3D-0500803-1P	HINGE SCREW D= 5 H= 8	Z
22		3D-0650305-1P	HINGE SCREW D= 6.5H= 3	1
54		SD-0/90311-1P	HINGE SCREW D= 7.94 H= 3.1	1
55		3D-1100301-1P	HINGE SCREW H=11 W=3	1
56		22-6110610-1P	30REW11/64-40 L=6	4
57		22-6110640-3P	SCREW 11/64-40 L=6	1
58		22-\110\10-2b	SCREW11/64-40 L=/	1
59		22-/110840-3P	SCREW 11/64-40 L= 7.8	2
60		22- E1 S G B 2 G - 2b	SCREW 3/16-28 L=9	2
61		128-81909	THREAD CUTTING LINK ROLLER	1
62		138-82006	1HREAD CU11ING LEVER 3HAF1	1
6.2		55-81 50822-1P	SCREW 15/64-28 L=8	1
64		55-8661012-1P	SCREW	Z
65		WP-0553216-3D	WASHER	1
66		141-0/601	THREAD RELEASE ARM	1
67		B2312-210-D00	TENTION RELEASE NOTCH	1
68		141-0/809	TENSION RELEASE ARM PIN	1
69		C2-080081C-24	1HRUS1 COLLAR ASM, D=8.0 W=8	1
70		W2-8120310-2P	MU115/64-28	i
71		3M-6040602-1P	30REW M4 L=6	Z
72		BZ617-771-000	IRIPPING LEVER IENSION SPRING	1





No	note	Parts No.	DESCRIPTION	Qty
1		141-0/502	21OPPER	1
Z		141-07700	CONNECTING BAR	1
3		82304-210-000	TENSION RELEASE LINK	1
4		265-00900	TENSION RELEASE ADJUSTING ARM	Z
5		144-13512	DYZK RIZING ROD	1
6		135-13304	THREAD TENSION ARM	1
7		82545-280-000	PREZZURE ZPRING	1
В		WP-0482086-3D	WASHER 4.8X11.5X2	1
9		C2-100081A-3P	1HRUS1 COLLAR ASM.	1
10		144-13603	DISK RISING COLLAR	1
11		265-00405	CONNECTING SHAFT	1
12		113-15108	COLLAR	2
13		55-4121615-5P	3CREW 3/16-28 L=16	Z
14		138-83905	L- 1YPE, 1HREAD GUIDE	1
15		NS-6120310-SP	Nu13/16-28	1
16		144-13165	THREAD TENSION ASM.	1
17		144-13157	THREAD TENSION PLATE COMPL.	m
18		106-9/603	THREAD TAKE-UP SPRING STUD	(1)
19		144-13306	1AKE-UP SPRING SPRING A	(1)
za		83137-527-GAG	1AKE-UP SPRING GUIDE ASM.	(2)
21		B3142-52/-000	1AKE-UP SPRING GUIDE PLATE	(1)
zz		83139-527-000	COLLAR	(1)
23		144-13405	1AKE-UP SPRING SPRING B	(1)
24		83138-527-000	ADJUZTING PLATEB	(1)
25		226-1/609	THREAD TENSION POST	(1)
26		226-17/08	1AKE-UP SPRING GUIDE	(1)
27		83141-527-000	PRESSER COLLAR	(1)
28		226-1/80/	Nu1	
29 29		83143-527-000	1AKE-UP SPRING GUIDE STUD	(1)
20		226-18201	TENNON RELEASE PIN. A	(1)
31	-	226-18300	TENSON RELEASE PIN. B	- m
32	-	B3126-012-000	THREAD TENSION DISK	(1)
				[4]
22		226-1/906	THREAD TENSION DISK PRESSER	(2)
34		B3129-012-A00	JENZON ZRING	(2)
22		B3112-/04-000	JEVZOV ZASVE BRZHIVE	(2)
26		119-568GZ	THREAD TENSION KNOB. BLUE	(2)
3/	-	226-181GZ	TENTION RELEATE LEVER	(1)
28		22-1030210-2b	3CREW 9/64-40 L= 4.6	m
23	-	226-18904	32.1 3CREW	<u>m</u>
40		226-18904	五1 20년M	- m
41		3D-04/0281-3P	HINGE SCREWD=4./ H= 2.8	(2)
4Z	-	101-24204	THREAD TENSION POST. A	<u>m</u>
43		101-24303	THREAD TENSION POST, B	<u>m</u>
44		WZ-8110210-2b	Nu1 11/64-40	(2)
45		107-41106	FIRST THREAD TENSION PLATE	[4]
46		110-2200	THREAD TENTION SPRING	(2)
47		110-/2402	IHREAD IEN SON NU I	(2)
48		144-1320/	ADJUSTING PLATE A	- in
49		22-4090E12-2P	3CREW 9/64-40 L=6	- in
sa		WP-0450801-3D	WASHER 4.5X10X0.8	m
51		144-14106	DIZK BIZNE NA	1
52		83413-552-000	272-EV-20V-20VEM	1
22		2D-0220551-2b	HINGE SCREW D= 5.3H= 2.2	1
54		50-0720321-1P	HINGE SCREW	1
55		50-0640391-1P	HINGE SCREW D= 6.35 H= 3.9	1
56		3D-0640482-3P	HINGE 30REW D= 6.35 H= 4.8	1
57		22-6110810-1P	SCREW 11/64-40 L=8	2
58		22-4090315-2P	30REW 9764-40 L=5	Z
29		22-1111150-2P	30REW 11/64-40 L=10.5	1
60		WZ-8150210-2b	Mu13/16-28	1
61		WP-0651056-3D	WASHER 6.5X1 1X1	1









MOL-254 II. 1H/READ PRESSER COMPONENTS

No	note	Parts No.	DESCRIPTION	Qty
1		144-1400/	1HREAD PRESSER	1
Z		144-13/02	THREAD PRESSER FITTING PLATE	1
3		B1-0400251-EB	URETHANE HOSE, BLACK	0.1
4		PA-0601015-00	AIR CYLINDER	1
5		22-4120915-3P	3CREW 3/16-28 L=9	2
6		138-70902	BALANCE 1HREAD GUIDE, C	1
7		139-22208	1AKE-UP 1HREAD GUIDE B	2
В		22-1110210-2P	3CREW11/64-40 L=5	1
9		22-1110220-2b	SCREW 11/64-40 L= 3.5	Z
10		WP-0450801-3P	WASHER	Z
11		144-13900	CYLINDER INSTALLING PLATE	1
12		55-4110615-5P	SCREW 11/64-40 L=6	Z
13		22-4041091-30	30REW M4 L=10	1
14		2M-0020801-2C	208EM W 2 X B	1
15		WW-8030001-30	MU1M2	1
16		PV-0100140-00	OUICK EXHAUST VALVE	1
17		144-13801	THREAD PRESSER PLATE LINK	1
18		250-02809	THREAD TENSION STUD	Z
19		250-02908	THREAD TENSION NUT	4
za		81136-850-000	JEN 20N ZHANG B	Z
21		HX-0015000-0D	CABLE CLIP	1
ZZ		55-4110615-5P	3CREW 11/64-40 L=6	1




	9. HOOK BASE COMPONENTS(1)					
No	note	Parts No.	DESCRIPTION	Qty		
1	a 1	144-18305	LOWER SHAFT GEAR A	1		
Z	a 1	144-18404	LOWER SHAFT GEAR B	1		
2	a 1	144-18503	LOWER SHAFT GEAR C	1		
4	a1	144-18602	LOWER SHAFT GEAR D	1		
5		128-19606	HOOK CRANK METAL B	1		
6		128-82208	METAL	1		
- /		112-/2408	1HRUS1 COLLAR	2		
В		169-92604	1HRUS1 WASHER	4		
9		138-85454	1HREAD CU11ING LEVER ASM.	1		
10		144-1/802	HOOK BASE	1		
11		144-18206	LOWER SHAFT B	1		
12		144-1810/	HOOK BASE CRANK GEAR	1		
13		144-1/901	HOOK BASE CRANK	1		
14		144-18008	HOOK BASE CRANK ROD	1		
15		144-19501	REMOVING SHAF1 CRANK	1		
16		138-8/005	THRUST WASHER	4		
17		138-8/104	THREAD CUTTING CAM. B	1		
18		138-8/203	REMOVING SHAFT CRANK BASE	1		
19		138-8/450	THREAD CUTTING ARM ASM.	1		
za		138-8/401	1HREAD CU11ING ARM	(1)		
21		138-74300	1HREAD CUTTING ARM PIN	(1)		
22		55-7111120-1P	SCREW	(1)		
23		WZ-8090310-3P	Nu 19/64-40	(1)		
24		144-20004	∑MNG	1		
25		144-20103	SMING RACK A	i		
26		110-41100	ROLLER	i		
27	a 1	B1411-B04-A00	BEARING (A)	1		
28	<u>a1</u>	B1411-804-B00	NEEDLE DRIVING LEVER BEARING B	i		
29	Q1	B1411-B04-C00	NEEDLE DRIVING LEVER BEARING C	1		
20	01	B1411-B04-D00	BEARING (D)	i		
31		144-05005	SHUTTLE DRIVER	1		
32		81812-980-000	SHUTTLE NEEDLE OUTER RING	1		
22		B1815-210-000	INNER HOOK UPPER SPRING			
34		B1903-55Z-000	LEF1 2CREW	1		
35	a 1	B1905-541-A00	NEEDLE BEARING, A	2		
36	a1	B1905-541-B00	MEEDLE BEARING	2		
37	a1	B1903-341-C00	MEEDLE BEARING	2		
28	a1		MEEDLE BEARING	2		
	u i	B1905-541-D00				
29		22-2030210-2b	3CREW9/64-40 L=6	5		
40		144-18800	BMETAL THRUST HOLDER PLATE	Z		
41		825/9-229-000	CYLINDER SHAFT THRUST HOLDER	1		
42		144-17604	CONNECTING COLLAR	1		
43		22-8080410-1P	3CREW 3/32-56 L= 3.5	2		
44		22-8660610-1P	30REW174-40 L=6	4		
45		55-6110420-1P	3CREW 11/64-40 L=4.8	1		
46		144-18/01	LOWER SHAFT BMETAL	1		
47		3B-1120002-00	ELARING	2		
48		38-6120001-00	BE-ARING	Z		
49		22-8151515-1b	SCREW 3/16-28 L=12.0	1		
sa	a 1	28- 20 E000 \-0 \	BEARING	1		
51	a 1	28-2020001-08	BEARING	1		
52	a 1	28- 20 E000 \-0C	BEARING	1		
2.2	01	28: 20 E000 \-0D	BEARING	1		
54		22-/111120-1P	SCREW	2		
55		22-8880220-2b	3CREW1/4-40L= 3.0	Z		
56		RE-0300000-K0	E-RING 3	Z		
57		22-8110210-3P	30REW 11764-40 L= 5	1		
58		22-8660615-1b	30REW 1/4-40 L=6	Z		
59		22-8661012-1P	2CHEM	1		
60		55-8661212-1P	2CREW	1		
61		22-61 10820-1P	3CREW 11/64-40 L=8	1		
62		WP-0952616-3D	WASHER 9.5X14.8X2.6	1		
63		B1 B2G-21 5-PAG-A	INNER HOOK PRESSER ASM.	Z		
64		81828-21G-DAA	BOBBIN CASE ASM.	1		
65		81828-210-DOA	BOBBIN CASE	(11)		
66		81808-210-000	SHING SHING	(11)		
67		138-8/906	HOOK BASE COVER, LEFT	1		
68		138-86205	PACKING	1		
69		1A-1250406-R0	Rubber Plug D=12.5 L=4	1		
70		B1822-215-P00	INNER HOOK PRESSER SPRING	Z		
71		144-18909	2-01ILE B	1		
72		128-86106	HOOK COVER MAGNET, A	i		
/3		22-5111140-25	3CREW 11/64-40 L=11	3		
74		3M-4030455-3A	SCREW	2		
75		B1806-210-D00	BOBBN	1		
76		144-1/505	HOOK BYZ INZIATTING ZHAŁI	1		
77		B1817-210-DAC				
		B1818-210-D0B	SHUTTLE RACE RING ASMC	1		
		a. a ra- c ru-uud	SHUTTER	1		
78		22-7111120-1P	SCREW	1		




Nο	note	Parts No.	DESCRIPTION	Qty
1		144-19451	MAGNET INSTALLING PLATE ASM.	Z
Z		2M-0020801-20	2085M W2 X 8	4
3		81-0600401-EF	10 E .	1.5
4		55-1060210-1P	30REW 37 32-56 L= 2.2	Z
5		22-6121840-3P	SCREW 3/16-28 L=18	1
6		138-86304	1HROA1 PLA1E. B	1
7		144-19303	HOOK CONNECTING PLATE	1
В		22-6120160-24	30REW 15/64-28 L=6.5	Z
9		22-6120110-2P	2CMEAN	Z
10		138-8/302	MOVING KNIFE LINK. B	1
11		144-20202	SPRING RACK B	1
12		144-19006	HOOK COVER, LEF1	1
13		144-19105	HOOK COVER, RIGH1	1
14		22-8152010-2b	30REW 3/16-28 L=30.0	2
15		144-19600	HOOK BASE COVER	1
16		55-6110610-1P	30REW11/64-40 L=6	4
17		138-88803	PACKING	1
18		EA-9500B01-00	CABLE BAND	Z
19		55-6111052-1P	2CHEM	Z
za		B2417-210-000	MOVING KNIFE HINGE SCREW	1
21		1A-1050504-R0	RUBBER PLUG	1
zz	01	82423-280-00A	MOVING KNIFE WASHER A	1
23	01	B2423-28G-GGB	MOVING KNIFE WASHER B	1
24	01	B2423-280-00C	MOVING KNIFE WASHER C	1
25	01	82423-280-00D	MOVING KNIFE WASHER D	1
26	01	82423-280-00E	MOVING KNIFE WASHER E	1
2/	01	82423-280-00F	MOVING KNIFE WASHER F	1
28	01	82423-280-00G	MOVING KNIFE WASHER G	1
29		B2424-21G-GGG	COUNTERKNIFE	1
20		144-17703	HOOK COVERHINGE	
31		22-1090410-2P	30REW 9764-40 L= 3.5	2
32		MM-6050001-5P	NUTMS	1
22		PA-1501515-A0	AIR CYLINDER	1
34		PJ-0460540-02	HOZE ELBOW	
35		D2112-555-B00	CORD HOLDER, LARGE	1
26		22-7110840-2P	30REW 11/64-40 L=7.8	1
37		22-9090410-1b	2CMEM	Z
28		22-a0a1010-25	30REW 9764-40 L=10	Z
29		B1444-180-006	ADJUSTING WASHER	Z
40		138-81255	MOVING KNIFE JUNC 110N	1
41		138-82501	NEEDLE HOLE GUIDE	1
42		144-19204	ZENSOR INSTALLING BAZE	1
43		55-4111015-5P	3CREW 11/64-40 L=10	1
44		D2063-772-B00	LOCKING CAM PLATE HOLDER	1
45		WW-8020001-20	NOT M2	4
46		WP-0320500-30	WASHER M3	4
47		W3-031000Z-KR	SMING WASHER 3.1XS.9X0./	4
48		3M-4860601-30	SCREW MZ.6 L=6	2
49		144-00451	HOOK COVER SENSOR CABER ASM.	1
49 Sa	az	CM-3002000-BZ	LABEL(25).	1
51	02	CM-3002000-02	CAUTION LABEL(25)	1
52	93	WP-0501016-3D	WASHERSX10.5X1	1

G1...SELECTIVE PARTS / G2..FOR USE IN JAPAN / G3..FOR EXPORT /




NOL-254 11. 2ND HOOK NOVE COMPONENTS


No	note	Parts No.	DESCRIPTION	Qty
1		144-22604	COUPLING	1
Z		144-22/03	CROSS ROLLER UPPER	1
3		144-22505	BOLL SCREW	1
4		144-23107	BALL SCREW SUPPORT BASE	1
5		144-22802	SLIDER ARM	1
6		144-22901	ERMOVING BASE	1
- 7		144-23008	SLICE BOR	1
В		144-23206	SENSOR DETECTOR PLATE	1
9		144-23305	SENSOR INSTALLING PLATE	1
10		144-23453	SENSOR SUIT ASM.	1
11		G5230-254-000	FEED-OUT MOTOR	1
12		122-92504	HORIZON TALL DRIVING SHAFT	Z
13		28-1062201-00	BEARING .	1
14		38-4060001-00	THRUST BEARING	Z
15		5M-6031002-1P	HEXAGONAL BOLT M3 X 10	6
16		%L-6041292-1N	SCREW	6
17		57-4021581-20	SCREW MISKI 2	1
18		WP-0611626-5P	WASHER 15X6X1.6	Z
19		22-8030\10-2b	3CREW9/64-40 L= 7.0	2
za		3D-0/90433-1P	HINGE SCREW D= 7.94 H= 4.3	1
21		55-6151712-1P	SCREW 15/64-28 L=16.5	z
22		NM-6060001-30	NU1M6	Z
23		WP-0612066-5P	WASHER 6.1X11X2	1
24		94-6041202-1P	30REW M4X0.7 L=12	4
25		55-6151440-5P	3CREW15/64-28 L=14	Z
26		55-6121610-1P	3CREW 3/16-28 L=15.5	Z
27		5M-804080Z-1P	SCREW M4X8	Z
28		94-805060Z-1P	30REW MS L= 6	Z
29		94-6041202-1P	3CREW M4X0./ L=12	4
20		WP-0430800-3D	WASHER M4	4
31		WS-0410002-KP	SPRING WASHER	4
32		51-4041091-50	3CREW M4 L=10	Z
2.2		5M-8030302-1P	2CBEM W2 F=2	Z
34		51-4030691-50	2CBEM W 2XB	Z
35		144-23651	HOOK REMOVAL SENSOR 1	1
36		HD-0005/00-0A	PHO10 32N 30R	1
37		55-6151210-5P	SCREW 15/64-28 L=12	1






No	note	Parts No.	DESCRIPTION	Qty
1		141-14102	OIT 24IETD	1
Z		141-14201	OIT 24IETD	1
2		138-88607	OIL FEL1	1
4		110-2160/	TUBE HOLDER (UPPER)	2
5		22-4110313-2P	30REW 11/64-40 L=5	Z
6		W2-8110210-2P	Nu1 11/64-40	Z
7		22- 81 SQ 3 2 Q - 2P	5CREW 3/16-28 L=9	1
В		83509-210-000	OL FEL1	1
9		135-29003	ONCE THROUGH OIL FELT	0.56
10		83501-210-000	OIL GAUGE	Z
11		81419-026-000	OIL WICK PRESSER	5
12		83506-280-000	OIL WICK PRESSER	1
13		144-24006	FACE FEL1	1
14		EA-9500B01-00	CABLE BAND	4
15		83508-280-000	BALANCE LUBRICATING PLATE	1
16		83509-280-000	NEEDLE ROD CRANK LUBRICATING	4
17		83518-280-000	BALANCE LUBRICATING	Z
18		BP- 3000000-00	VINYL PIPE	2.7
19		BP-6000000-00	VINYL PIPE	1.5
za		BP-5000000-00	VINYL PIPE	1.1
21		CO-200000-00	OIL WICK	2
ZZ		CO-2522000-00	OL WICK	0.6
23		E8/60-452-M00	1UEE.	Q.1
24		22-8095150-2P	30REW 9/64-40 L=21.2	1
25		262-31605	CRANK ROD LUBRICATING PLATE	Z
26		83523-280-000	OIL TUBE HOLDER	1
27		83520-210-000	OIL FELT SUPPORTING PLATE	1
28		55-4120615-5P	30REW 3/16-28 L=6	4
29		55-4090515-5P	30REW 9/64-40 L= 5	1
20		55-4120615-5P	SCREW 3/16-28 L=6	1
31		55-4090615-5P	30REW 9/64-40 L=6	1
32		83523-220-000	OL FEL1	1
2.2		83504-280-000	ZHU 1 ILE FEL 1	1
34		262-31100	SHUTTLE LUBRICATING PLATE	1
3.5		22-8030440-2b	30REW 9764-40 L= 4.0	Z
36		81820-210-000	SHUTTLE OIL FELT A	2
37		81821-210-000	SHU11LE OIL FEL1 B	1
28		CO-2520000-00	OL WICK	2.5
29		81821-210-000	SHUTTLE OIL FELT B	1
40		55-4111015-5P	SCREW 11/64-40 L=10	Z






No	note	Parts No.	DESCRIPTION	Qty
1		400-49/98	ZOFE IY PLATE BASE	1
Z		138-8940/	ZOFETYPLATE	1
2		55-4110615-5P	SCREW 11/64-40 L=6	Z
4		WP-0450801-3D	WASHER 4.5X10X0.8	2
5		55-1110640-1P	SCREW 11/64-40 L= 5.5	Z






No	note	Parts No.	DESCRIPTION	Qty
1		G5001-254-000	UNIT SERVO MOTOR	1
Z		GS002-254-000	LOOP SUPPLY GUIDE SHAFT	1
3		G5003-254-000	LOOP SUPPLY CAM	1
4		G5004-254-000	LOOP SUPPLY CAM ROTARY SHAFT	1
5		G5005-254-000	LOOP SUPPLY SLIDE GUIDE	1
6		G5006-254-000	DRIVING SPROCKET SHAFT	1
7		GS007-254-000	DRIVING GEAR	1
В		G5008-254-000	FOLLOWER GEAR	1
9		G5009-254-000	MOTOR INSTALLING PLATE	1
10		GS010-254-000	SUPPLY SENSOR FITTING PLATE	1
11		G5011-254-000	LOOP SUPPLY SENSOR SLI I	1
12		G5012-254-000	CAM MAINTENANCE PLATE	1
13		G6014-880-000	LINK 1HRUS1 HOLDER	1
14		135-18105	LIFTING LEVER SHAFT	1
15		123-08300	METAL FRONT	1
16		E1022-/60-000	SPIRAL TUBE	0.7
17		81632-180-000	FEED ADJUSTING JOIN 1	1
18		B2509-210-D00	BEL1 RECEIVER	1
19		B2512-210-D0A	X TIMING BELTIEXTENTION)	1
za		B2513-210-D00	DRIVE SPROCKET	1
21		B2514-210-D00	DRIVEN SPROCKET	1
22		B2528-215-000	34AF1	1
23		B2/40-//1-000	THRUST WASHER	3
24		C2-100101D-2H	1HRUS1 COLLAR ASM.	1
25		C2-1201010-24	1HRUS1 COLLAR ASM, D=12 W=10	1
26		RE -0600000-КО	E-RING 6	1
27		3B-1080003-00	RAZNAL BEARING	4
28		3B-1120001-00	BEARING D=12X32	2
29		Z-6020895-1M	SCREW	2
20		3L-6041 292-1M	SCREW	2
31		Z-6051292-1M	BOL1	4
32		3L-6051292-1N	BOL1	4
22		Z-6051292-1M	BOLI	4
34		3L-6051292-IN	BOL1	2
22		3L-6051642-1N	BOL1	1
26		3M-6041002-1P	3CREW M4 L=10	Z
37		3M-6052002-1P	3CREW M3 L= 20	1
28		3M-8040502-1P	SCREW M4X0./ L= 5	Z
29		3M-8040502-1P	3CREW M4X0./ L= 5	1
40		3M-8050602-1P	SCREW MS L=6	2
41		3M-8060802-1P	2CREW MB L=8	Z
42		3M-8060802-1P	3CREW M6 L= 8	2
43		3M-8060802-1P	2CREW M6 L=8	Z
44		22-61 10630-1P	3CREW11/64-40 L=6	1
45		WP-0531000-3D	WASHERMS	1
46		WP-0561616-50	WASHER 5.6X1 6X1.6	1
47		WP-0820526-3D	WASHER 8.2X14X0.5	1
48		WP-1221016-3P	WASHER	i
49		MM-6050001-3D	Nu1 MSX0.8	1
50		PA-1602006-B0	AIR CYLINDER	1
51		PC-0103080-00	SPEED CONTROLLER	2
52		G5013-254-000	WASHER	1
32		HX-0018900-00	SPIRAL TUBE	0.5
54		GSG14-254-000	MOTOR GUIDE PIN	1
55		EA-9500B01-00	CABLE BAND	2
35		SL-4041291-SC	SCREW M4 L=12	1
57		HD-0055200-00	SUNEW MR LE 12 PHO10 3EN 3OR	1



NOL-254 15. BEL1 LOOP FOLDING COMPONEN 15


No	note	Parts No.	DESCRIPTION	Qty
1		GSGS1-254-000	BENDING SHAFT METAL	Z
Z		G5G52-254-000	BENDING SHAFT METAL BRACKET	Z
2		GSGS3-254-000	SUPPLY CAM LEVER SHAFT	1
4		22-8121520-2P	30REW15/64-28 L=12	Z
5		WP-0450801-3D	WASHER 4.5X1 0X0.8	2
6		GSGS6-254-GGG	LOOP SUPPLY SLIDE BYZ	1
7		GSGS7-254-000	FROM 1 BENDING SHAFT ROTOR BASE	1
В		GSGS8-254-GGG	REAR BENDING SHAFT ROTOR BASE	1
9		NS-6150540-5P	NU115/64-28	Z
10		G\$060-254-000	BENCING SHAFT PRESSER SPRING	Z
11		GSG61-254-GGG	FOLDING SHAFT ROTOR	Z
12		G5062-254-000	LOOP BENDING CONNECTING PLATE	1
13		G5063-254-000	FORK WIDTH SCALE PLATE	1
14		P1-0320590-06	BARB JOIN 1	a
15		225-85/0/	34AF1	1
16		138-60606	PIN	Z
17		81853-512-00E	HOOK SHAFT WASHER	Z
18		400-09143	ROLLER	1
19		WP-0820526-5D	WASHER 8.2X14X0.5	a
za		RE -0 6000000-K0	E-RING 6	a
21		RE-0/00000-K0	E-RING /	1
ZZ		%-6041292-1N	2CMEAN	4
23		92-6041292-1N	2CMEAN	4
24		3M-8050602-1P	SCREW MS L=6	Z
25		PJ-3080400-02	OUICK COUPLING	Z
26		22-8111010-1P	30REW 11/64-40 L= 9.5	3
27		22-8111010-1P	30REW 11764-40 L= 9.5	Z
28		22-1080210-2b	208EM 2125-28 F=2	Z
29		3M-804080Z-1P	SCREW M4X8	Z
20		G5G54-254-QAG	FROM 1 BENDING SHAFT ASM.	1
31		G5054-254-000-A	FRON 1 BENDING SHAF1	(1)
32		GSGS9-254-000	LOWER FOLDING DOG	(z)
22		3M-6850502-1N	3CREW M 2.5 L= 5	(1)
34		WP-0250501-30	WASHER 2.5X6.5	(1)
22		G5G55-254-GAG	REAR BENDING SHAFT ASM.	1
36		G5055-254-000-A	REAR BENDING SHAFT	m
37		G5059-254-000	LOWER FOLDING DOG	(z)
28		94-6850502-1N	SCREW M 2.5 L= 5	(II)
29		WP-0250501-50	WASHER 2.5X6.5	(1)






No	note	Parts No.	DESCRIPTION	Qty
1		GS101-254-000-A	LOOP PRESSER UNIT BASE	1
Z		G5102-254-000-A	LOOP PRESSER SUPPORT BASE	1
2		G5103-254-000-A	LOOP PRESSER REMOVING BASE	1
4		G5104-254-000-A	LOOP CATCH FRONT	1
5		G5105-254-000-A	LOOP CATCH REAR	1
6		G\$106-254-000	LOOP GATHER BRACKET, FROM 1	1
7		G\$107-254-000	LOOP GATHER BRACKET, REAR	1
В		G\$108-254-000	LOOP DRAWING CLICK A. FRON 1	1
9		G\$109-254-000	LOOP DRAWING CLICK A. REAR	1
10		G5110-254-000	LOOP DRAWING CLICK B	Z
11		G5063-254-000	FORK WIDTH SCALE PLATE	1
12		84127-352-000	BOTTOM GUIDE	1
13		263-03404	PLATE A	Z
14		81449-526-000	REPOSITIONING LEVER SPRING	Z
15		81632-180-000	FEED ADJUSTING JOIN 1	1
16		81606-210-000	ROLLER	1
17		%L-6082092-1M	80.1	Z
18		94-6061002-1P	2085W WP F=10	2
19		30-0/00312-30	HINGE SCREW D= /H= 3.13	3
za		W2-8110210-2P	Nu111/64-40	2
21		WS-0441040-KP	976NG WASHER 4.4X7.4X1	3
ZZ		55-6110610-1P	30REW11/64-40 L=6	1
23		30-0550212-1P	HINGE SCREW D= 5.5 H= 2.1	1
24		22-6110610-1P	30REW 11/64-40 L= 6	4
25		92-6052042-1M	2CHEW	1
26		22-6110610-1P	30REW11/64-40 L=6	Z
27		30-0500481-1P	HINGE SCREW D= SH= 4.8	Z
28		3M-8030402-1P	30REW M 3X0.5 L=4	Z
29		3M-8030802-1P	SCREW M 5X0 .5 L= 8	Z
30		22-1080210-2b	SOREW 3/32-56 L= 3	Z
31		PA-1602005-A0	AIR CYLINDER	1
32		PJ-3040405-06	ELBOW UNION	Z
2.2		PC-0124060-00	SPEED CON IROLLER	Z
34		PA-1005501-A0	CYLINDER	Z
35		PJ-3040405-04	ELBOW UNION	4
36		PC-0124060-00	SPEED CON IROLLER	1
37		PJ-3080400-02	QUICK COUPLING	Z
28		G5112-254-000	LOOP SWEEPING PLATE FRONT	1
29		G5113-254-000	LOOP SWEEPING PLATE REAR	1
40		3L-6041292-1M	SCREW	4
41		G5114-254-000	LOOP CATCH SENSOR BK 1. FRON 1	1
42		G5115-254-000	LOOP CATCH SENSOR BK 1. REAR	1
43		G5116-254-000	LOOP CATCH SENSOR FITTING BR 1.	1
44		D2587-L8W-B00	ROLLER	1
45		D2588-L8W-B00	ROLLER SHAFT	1
46		9M-6030402-1P	30REW M 3X0.5 L=4	1
47		3M-4860601-30	30REW M Z .6 L= 6	Z
48		HX-0015000-00	CUP	1
49		EA-9500B01-00	CABLE BAND	5
50		5M-6030402-1P	30REW M3X0.5 L=4	1
51		M8522-610-0A0	LOOP GATHER DESCENT SENSOR ASM	1






No	note	Parts No.	DESCRIPTION	Q
1		G5201-254-000	LOOP BINDER B	1
Z		34-0040801-30	3CREW	1
3		G5202-254-000	LOOP WIDTH GUIDE	1
4		82549-372-000	CLAMP SCREW A	- 2
5		106-32511	PLUNGER PIN	1
6		G5203-254-000	LOOP BINDER A	1
7		5M-0040801-50	SCREW	- 2
В		RE-0400000-K0	E-RING 4	1
9		G5204-254-000	FEED ROLLER SHAF1	1
10		81618-804-000	WASHER	- 2
11		G5231-254-080	FEED ROLLER ASM.	1
12		G5207-254-000	ROLLER SHAFT	1
13		94-8040602-1P	SCREW M4X0.7 L=6	- 1
14		G5208-254-0A0	FEED ROLLER ASM.	
15		140-45306	ADJJ 71PM	
16		MM-6040003-30	Nu1 M4	
17		94-6043052-1N	SCREW M4 L= 30	
18		WP-0430801-3E	WAS-ER 4.5X9X0.8	
19		G5209-254-000	LOOP FEED BASE	1
za		28-1060003-00	BE ARING	
21		G5210-254-000	FEED ROLLER LEVER	-
zz		G5211-254-000	LOOP GUIDE A	-
23		3M-6031202-1P	SCREW M330.5 L=12	
24		G5212-254-000	FEED ROLLER SPRING	
25		G5213-254-000	FEED ROLLER SPROCKE1	
26		34-8040602-1P	3CREW M4X0.7 L=6	
27		G5214-254-000	FEED 1IMING BEL1	
28		%L-6062092-1N	3CREW M6 L=20	
29		RE-0300000-K0	E-Ring 3	
2a		WZ-0430200-KH	WAVED WASHER	
31		G5215-254-000	FEED MOTOR BRACKET	
32		3M-6041 202-1P	3CREW M4X0./ L=12	
22		400-21803	SENSOR PLATE	
34		27-4041031-20	3CREW M4 L=10	
22		G5230-254-000	FEED-OUT MOTOR	
26				
37		G5217-254-000-A	FEED-OUT MOTOR SPROCKET	
28		94-8040602-1P	SCREW M4X0.7 L=6 GEAR	1
29		400-21805		
40		3M-803040Z-1P G5219-254-000-A	50REW M 3X0.5 L=4 5NAF 1 GEAR	
41			25.1 2CREW M4 F=4	
41 42		3M-804041 Z-1P		
		400-21806	BEARING COLLAR	
43		G5236-254-000	THRUST RING	
44		GS220-254-000	S-AF1 S-MANG	
45		GSZZ1-ZS4-000	DEJECTOR PLATE	
46		3M-6030602-1P	3CREW M3X0.5 L=6	
47		400-21804	SHAF1	
48		RE-0400000-K0	E-RING 4	
49		28-6062201-00	BE_ARMG	
sa		G5227-254-000	LOOP GUIDE.	
51		400-21802	GEAR PLAIE	
52		5M-6041002-1P	SCREW M4 L=10	
53		G5224-254-000	LOOP ROLLER 3HAF1	
14		5M-8050602-1P	SCREW MS L= 6	
55		G5225-254-000	LOOP ROLLER	
6 6		G5226-254-000	ROLLER LEVER 34 AF 1	
5/		5M-804060Z-1P	SCREW M4X0.7 L=6	
68		229-0/802	HAND LIFTER	
19		51-4041281-50	SCREW M4X0.7 L=12	
ia		5M-6043052-1N	3CREW M4 L= 30	
i 1		NM-6040000-3N	Nu IM4	
iZ		G5228-254-000-A	GUIDE ROLLER CATCH A	
13		27-4041031-20	SCREW M4 L=10	
4		E3/05-/15-000	VCS SPACER	
15		102-08/00	WIPER LINK SHAFT	
6 6		G5229-254-000	GUIDE ROLLER CATCH B	
67		51-4041091-50	30REW M4 L=10	
68		WP-0430801-3E	W-Z-S- P-Z-A-Z-A-Z-A-Z-A-Z-A-Z-A-Z-A-Z-A-Z-A-Z-	
69		NM-6040000-3N	NU1M4	
ra		3M-6031402-1P	2CBEW	
ri .		WW-8020001-2C	NOT M2	
72		28-1090002-00	BE ARING	
73				
74		28-1060002-00	ELARING PORTING	
		34-8030412-1P 81618-804-000	SCREW WASHER	





No note	Parts No.	DESCRIPTION	Oty
1	G5301-254-000-A	LOOP CLAMP LEVER	1
Z	GS302-254-000	LOOP CLAMP BASE PLATE	1
2	5L-6041092-1M	2CKEM	Z
4	G5303-254-000	LOOP CLAMP LEVER SHAF1	1
5	RE-030000-KO	E-RING 3	Z
6	GS305-254-000	LOOP CLAMP DETECTOR PLATE	1
7	27-8020835-JW	2CMEAN	Z
В	G5306-254-000	LOOP CLAMP FEED SHAF1	1
9	PA-1001025-A0	PIN CYLINDER	1
10	PA-9000340-00	JOIN1	1
11	38-7100002-00	SLIDE BEARING	1
12	RC-1900001-KP	C-RING	Z
13	WZ-2200300-KP	WAVED WASHER	1
14	WP-2103001-3E	PLAIN WASHER	1
15	123-08409	ME1AL, REAR	1
16	5M-8060602-1P	208EM WEXE	1
17	81811-205-000	LOWER 3-AF1	1
18	5M-8040602-1P	SCREW M4X0./ L=6	Z
19	GS307-254-000	CLAMP FEED GUIDE PLATE	1
za	5L-6041092-1N	2CKEM	2
21	51-4041291-50	5CREW M4 L=12	1
22	G5010-254-000	SUPPLY SENSOR FITTING PLATE	1
23	5L-6041092-1N	2CMEAN	Z
24	GS308-254-000	CLAMP END SENSOR BRACKET	1
25	5L-6041092-1N	2CKEM	Z
26	G5230-254-000	FEED-OUT MOTOR	1
27	5M-6041202-1P	SCREW M4X0.7 L=12	4
28	G\$309-2\$4-000	CLAMP FEED MOTOR GEAR	1
29	34-8050602-1P	SCREW MS L=6	Z
20	HX-0018900-00	SPIRAL TUBE	0.5
31	HD-0023000-00	ZN 208	1
22	3M-6850802-1N	SCREW MZ.S L=B	1




lo note	Parts No.	DESCRIPTION	C
1	140-06506	COLLAR	
Z	3M-6041 602-1P	SCREW M4X0./ L=16	
3	G5401-254-000	KNIFE CYLINDER BRACKET	
4	3L-6062092-1N	SCREW M6 L=20	
5	G5420-254-000	BLOW PIPE	
6	34-4040801-34	SCREW M4 L=B	
7	PA-3201503-A0	AIR CYLINDER	
8	PJ-3040651-01	ELBOW UNION 6XP1178	
9	G5421-254-QAQ	KNIFE LOWERING SENSOR ASM.	
a	G5402-254-000	KNIFE SHAFT JOINT	
1	B1853-512-00A-A	HOOK SHAFT WASHER, A	
Z	WS-GBZGGGZ-KM	SPRING WASHER MB	
2	3M-6081802-1P	SCREW	
4	G5403-254-000	FIXING KNIFE POSITION BRACKET	
5	3M-6052502-1P		
6	G5404-254-000	SCREW MSX0.8 L=25 KNIFE BASE BRACKET	
7	3L-6062092-1M		
8	PC-022403F-00	SCREW MS L= 20	
9	22-5030 \ 10-1b	INTERNATIONS	
:a		SCREW 9/64-40 L=/.2	
:u :1	G6014-880-000	TINK THRUST HOLDER	
2	3M-6064002-1R G5405-254-000	SCREW M6L=40	
		KNIFE DEVICE BRACKET	
:2	G5406-254-000	MOVING KNIFE 3HAF1	
4	G5407-254-000-A	FIXING KNIFE BASE	
15	G5408-254-000	KNIFE BASE LOOP GUIDE	
6	3M-4030401-3C	3CREW M3X0.5 L=4	
27	G5409-254-000-A	FIXING KNIFE	
8	3M-1041001-3C	3CREW M4X0.7 L=10	
9	G5410-254-000	MOVING KNIFE GUIDE	
ia	2M-4020822-2A	2045M W2 F= 810	
i1	G5411-254-000	MOVING KNIFE BASE	
iZ	3M-8050602-1P	SCREW MS L=6	
12	G5412-254-000	UPPER KNIFE	
i4	112-1/213	ROLLER	
15	22-4080610-3P	30REW 178-44 L=6.4	
6	G5413-254-000	KNIFE PRESSER SPRING	
17	GPK-26004000	SWITCH PEDAL GUIDE COLLAR	
i 8	B2423-280-00E	MOVING KNIFE WASHERE	
19	22-8092420-2P	SCREW 9764-40 L=23.5	
ıa 📗	GS414-254-000	ROD END	
11	9M-6041402-1P	30REW M4 L=14	
ız	PA-1004513-A0	AIR CYLINDER	
13	PJ-3040405-04	ELBOW UNION	
14	GS415-254-000	CYLINDER ADJUSTING COLLAR	
15	94-6041002-1P	30REW M4 L=10	
16	94-8040602-1P	30REW M4X0.7 L=6	
17	G5416-254-000	CYLINDER PIN	
18	G5417-254-000	CLOTH CUT SUPPORT	
19	3M-6030402-1P	SCREW M 3X0.5 L=4	
a	2F-8082035-1W	ZCREW	
11	32-4030631-30	2CREW W 2X8	
Z	G5418-254-000	LOOP GUIDE B	
.3	WP-0320501-3D	WASHER	
14	94-6030502-1P	BOLT MIXXS	
5	G5419-254-000	KNIFE UNI 1 GUIDE RAIL	
6	27-8082035-1W	SCREW	
7	G5422-254-000	LOOP WIDTH KNIFE POSITION SEAL	
	225-/1400	CAM ROLLER, D	
9	34-608/002-1N	SCREW MB L= / 0	
ia			
il i	W5-082000Z-KN	SPRING WASHER MB	
iZ	WP-0841601-30	WASHER 8.4X1 / .4X1 .5	
	G5063-254-000	FORK WIDTH SCALE PLATE	
i3 i4	DZ\$88-L8W-900	ROLLER SHAFT	
	D2587-L8W-B00	ROLLER	




NOL-254 20. SUPPLYING DEVICE BASE COMPONENTS

No	note	Parts No.	DESCRIPTION	Qty
1		GSS01-254-000	BAX PLATE	1
Z		B1104-280-000	VIERATION-PROOF RUBBER PAD	3
3		34-608/002-1N	30REW M8 L= / 0	6
4		WP-0841601-50	WASHER 8.4X1 / .4X1.6	6
5		WP-0852086-50	WASHERMB	6
6		WS-082000Z-KN	SPRING WASHER MB	6
7		NM-6080001-30	NU1 MBX1.25	6
В		G5506-254-000	FRAME FIXING HINGE	1
9		3L-6062042-1N	B0L1	Z
10		GSS07-254-000	BAZE PLATE BUZH	Z
11		G5503-254-000	CLAMP FEED BASE PLATE	1
12		GSS04-254-000	CLAMP FEED PLATE FRONT	1
13		GSSGS-254-000	CLAMP FEED PLATE REAR	1
14		3M-6061202-1R	HOLED BOL1	6
15		27-8082035-1W	2CMEAN	4
16		G5502-254-000	LOOP SUPPLY FRAME	1
17		32-6084092-1N	B0L1	4
18		GSS08-254-000	ZWITCH INSTALLING PLATE	1
19		92-4041291-90	30REW M4 L= 12	Z
ZO		22-8111010-2P	30REW 11/64-40 L= 9.5	1
21		WP-0450801-50	WASHER 4.5X10X0.8	1
ZZ		WS-0451040-KP	SPRING WASHER 4.5X8.5X1	1
23		CO-2522000-00	OIL WICK	1.5
24		PS-0300102-K0	SPRING PIN 3.0X10	8











No	note	Parts No.	DESCRIPTION	Qty
1		GSSS1-2S4-000	CHIP COVER	1
Z		32-4041091-30	30REW M4 L=10	2
2		400-21/93	GEAR COVER	1
4		32-4041091-30	30REW M4 L=10	5
5		G5553-254-000-A	CLOIH WAZIE 2/PPORT	1
6		51-4051291-50	SCREW M 500.8 L=12	4
7		168-70206	GRAVITY SEAL	1
B		G5554-254-000	CLOTH WAZIE 20PPORT ZTAY	1
9		5K-3412001-50	WOOD SCREW D=4.1 L=20	Z
10		WP-0501046-50	WASHER 5 X 1 3 X 1	2
11		G5555-254-000	SUPPLY FRAME COVER	1
12		32-4041091-30	30REW M4 L=10	2
13		G5556-254-000	CHIP BOARD	1
14		51-4051291-50	SCREW M5X0.8 L=12	Z
15		GSSS7-254-000	CLAMP FEED BRACKET COVER	1
16		32-4041091-30	30REW M4 L=10	2
17		G1015-192-000	CLAMP	1
18		GSSS8-254-000	OPERATION PANEL RUBBER	1
19		3L-6062092-1M	SCREW MB L=20	2
za		3M-606/332-1P	HEXAGONAL-HOLE BOL1 MB L= 75	Z
21		3M-6062002-1P	SCREW M6 L= 20	1
ZZ		WP-0612516-5D	WASHER6.1X15.2X2.5	2
23		112-80856	FRAME SUPPORT BAR ASM.	1
24		G5559-254-000	PLAIE	1
25	az	CM-3002000-01	ATTEM TION SEAL	6
26	01	CM-3002000-A1	CAUTION LABEL(16)	5
27	01	CM-3002000-C1	CAUTION LASEL	1
28		WP-0501046-50	WASHER 5 X 1 3 X 1	3
29		WP-0501046-50	WASHER 5 X 1 3 X 1	1
20		HX-0015000-0N	CABLE CUP	1
31		32-4041091-30	30REW M4 L=10	1
32		3M-6085002-1N	B0L1	1
22		WP-0841601-30	WASHER 8.4X1 / .4X1.6	1
34		MM-8080001-50	NU1 M8X1.25	1
35		GSS63-254-000	CLOTH WASTE FRONT CATCH	1
36		51-4041291-50	30REW M4 L=12	Z
37	az	CM-3002000-02	CAUTION LABEL(25)	1
28	01	CM-3002000-B2	LOREL(ZS).	1
39	01	G5562-254-000	五吋	1
40		81140-761-000	OILING LABEL	9
41	0.2	СМ-6001001-01	WEEE MARK LABEL 5	1
42		31-4041091-50	30REW M4 L=10	8
43		WP-0501046-50	WASHER 5 X 1 3 X 1	1


G1...FOR USE IN JAPAN / G2...FOR EXPORT / G3...FOR JE /



No no	te Parts No.	DESCRIPTION	C
1	PA-3201503-A0	AIR CYLINDER	
z			
	PA-1004513-A0	AIR CYLINDER	
2	GSG61-254-000	FOLDING SHAFT ROTOR	
4	PA-1602006-A0	AIR CYLINDER	
	PA-1602005-A0	AIR CYLINDER	
	PA-1001025-A0		
		PIN CYLINDER	
	PA-1005501-A0	CYLINDER	
	PA-1005501-A0	CYLINDER	
	PA-1003003-A0	PEN CYLINDER	
1			
	PA-2015005-A0	AIR CYLINDER	
	PA-1501515-A0	AIR CYLINDER	
	PA-1002507-A0	ARCYLINDER	
_			
i	PA-0601015-00	AIR CYLINDER	
	PA-1004001-A0	AIR CYLINDER	
	PJ-3040405-04	ELBOW UNION	
_			
i	PC-01050B0-00	SPEED CONTROLLER	
	PC-01030/0-00	SPEED CONTROLLER	
1	PJ-3080400-02	CUICK COUPLING	
1	PV-0100140-00	OUICK EXHAUST VALVE	
	PC-0151080-00	SPEED CONTROLLER	
	PC-0124050-00	SPEED CON IROULER	
	PJ-0460540-02	HOZE ELBOW	
	PJ-3040405-06	ELBOW UNION	
_			
	P1-0250280-08	BARB JOIN 1	
	PJ-3040651-01	ELBOW UNION 6XP1178	
	32-4041091-30	SCREW M4 L=10	
	3L-6051292-1N	BOL1	
	3L-6051292-1N	90L1	
	GS601-254-0A0	SOLENOID VALVE A ASM.	
_			
	GS602-254-0A0	SOLENOID VALVE BIASM.	
	PV-1502090-00	5 PORT SOLENOID VALVE	
	PX-5000140-00	PLUG	
_			
	GS604-254-0A0	FILTER REGULATER ASM.	
	PJ-3080852-02	UNIONY	
	PJ-3050800-01	PIPE IEE	
	PX-9500010-00	PLUG	
	161-11403	AIRGUN	
	P#3010651-03	HALF UNION EXP11/8	
	G5458-116-000	CURLED TUBE	
	B1-0800501-EB	VINYL TUBE	
			-
	B1-0600401-EB	1UBE.	
	B1-0600401-EF	1UEE	
	B1-0400251-EB	URE THANE HOSE, BLACK	
	G5421-254-0A0	KNIFE LOWERING SENSOR ASM.	
	180-33006	CABLE MARK NO.1	
	180-35105	WIRE MARK (2)	
	180-35204	WIRE MARK (3)	
	180-25202	WIRE MARK (4)	
	180-35402	WIRE MARK (S)	
	180-35501	WIRE MARK (6)	
	180-35600	WIRE MARK (7)	
	180-35/09	WIRE MARK (B)	
_	180-35808	WIRE MARK (9)	
	180-35907	WIRE MARK (10)	
	180-36004	WIRE MARK	
	180-36103	WIRE MARK (12)	
	180-36202	WIRE MARK (13)	
			-
	180-26201	WIRE MARK (14)	
	180-36400	WIRE MARK (15)	
	180-36509	WIRE MARK (16)	
	180-36608	WIRE MARK (17)	
	180-36/0/	WIRE MARK (18)	
	180-36806	WIRE MARK (19)	
	180-36903	WIRE MARK (20)	
		WIRE MARK (21)	
	180-37002		
	180-3/002		
	180-3/101	WIRE MARK (22)	
		WIRE MARK (23)	
	180-3/101 180-3/200	WIRE MARK (23)	
	180-2\200 180-2\200 180-2\101	WIRE MARK (23) WIRE MARK (24)	
	180-2/408 180-2/203 180-2/200	WIRE MARK (25) WIRE MARK (25)	
	180-2\200 180-2\200 180-2\101	WIRE MARK (23) WIRE MARK (24)	
	180-3/101 180-3/209 180-3/200	WIRE MARK (25) WIRE MARK (25) WIRE MARK 26	
	180-2/206 180-2/200 180-2/200 180-2/200	WIRE MARK (23) WIRE MARK (24) WIRE MARK (25) WIRE MARK (26)	
	180-3/101 180-3/209 180-3/200	WIRE MARK (23) WIRE MARK (24) WIRE MARK (25) WIRE MARK 26 WIRE MARK 27 WIRE MARK (28)	
	180-2/206 180-2/200 180-2/200 180-2/200	WIRE MARK (23) WIRE MARK (24) WIRE MARK (25) WIRE MARK (26)	
	180-3/101 180-3/200 180-3/200 180-3/200 180-3/200	WIRE MARK (23) WIRE MARK (24) WIRE MARK (25) WIRE MARK 26 WIRE MARK 27 WIRE MARK (28) WIRE MARK (28)	
	180-2/804 180-2/804 180-2/402 180-2/408 180-2/408 180-2/408 180-2/408	WIRE MARK (23) WIRE MARK (24) WIRE MARK (25) WIRE MARK (26) WIRE MARK (26) WIRE MARK (27)	
	180-28000 180-27804 180-27806 180-27408 180-27408 180-27200 180-2700	WIRE MARK (23) WIRE MARK (24) WIRE MARK (25) WIRE MARK 26 WIRE MARK 27 WIRE MARK (28) WIRE MARK (28)	
	180-2/804 180-2/804 180-2/402 180-2/408 180-2/408 180-2/408 180-2/408	WIRE MARK (23) WIRE MARK (23) WIRE MARK (25) WIRE MARK (26) WIRE MARK (26) WIRE MARK (27) WIRE MARK (27) WIRE MARK (27)	
	180-28000 180-28000 180-27002 180-27002 180-27002 180-2700 180-2700 180-2700	WIRE MARK (23) WIRE MARK (24) WIRE MARK (26) WIRE MARK (26) WIRE MARK (27) WIRE MARK (31) WIRE MARK (31)	
	180-28508 180-28000 180-28000 180-28002 180-28004 180-28009 180-2800 180-2800 180-2800 180-2800	WIRE MARK (22) WIRE MARK (23) WIRE MARK (24) WIRE MARK (21) WIRE MARK (23) WIRE MARK (31) WIRE MARK (32) WIRE MARK (32) WIRE MARK (32)	
	180-28000 180-28000 180-27002 180-27002 180-27002 180-2700 180-2700 180-2700	WIRE MARK (23) WIRE MARK (24) WIRE MARK (26) WIRE MARK (26) WIRE MARK (27) WIRE MARK (31) WIRE MARK (31)	
	180-2820/ 180-28208 180-28000 180-27903 180-27904 180-27904 180-27904 180-27904 180-3700 180-3700	WIRE MARK (24) WIRE MARK (25) WIRE MARK (26) WIRE MARK (27) WIRE MARK (28) WIRE MARK (31) WIRE MARK (31) WIRE MARK (32) WIRE MARK (32) WIRE MARK (31) WIRE MARK (32) WIRE MARK (33)	
	180-28304 180-28304 180-28300 180-28300 180-28000 180-2400 180-2400 180-2400 180-2400 180-2400 180-2400	MISE WARK (22) MISE WARK (24) MISE WARK (25) MISE WARK (26) MISE WARK (27) MISE WARK (26) MISE WARK (26) MISE WARK (26) MISE WARK (27) MISE WARK (27) MISE WARK (28) MISE WARK (28)	
	180-2820/ 180-28208 180-28000 180-27903 180-27904 180-27904 180-27904 180-27904 180-3700 180-3700	WIRE MARK (24) WIRE MARK (25) WIRE MARK (26) WIRE MARK (27) WIRE MARK (28) WIRE MARK (31) WIRE MARK (31) WIRE MARK (32) WIRE MARK (32) WIRE MARK (31) WIRE MARK (32) WIRE MARK (33)	
	180-28304 180-28304 180-28300 180-28300 180-28000 180-2400 180-2400 180-2400 180-2400 180-2400 180-2400	WIRE MARK (25) WIRE MARK (24) WIRE MARK (24) WIRE MARK (25) WIRE MARK (26) WIRE MARK (27) WIRE MARK (31) WIRE MARK (31) WIRE MARK (32) WIRE MARK (32) WIRE MARK (33) WIRE MARK (33) WIRE MARK (34) WIRE MARK (35)	
	180-28904 180-28905 180-28906 180-28900 180-28900 180-28000 180-28004 180-28004 180-28004 180-28004 180-28004 180-28004 180-28004	MIRE MARK (25) MIRE MARK (25) MIRE MARK (26) MIRE MARK (26) MIRE MARK (27) MIRE MARK (27) MIRE MARK (27) MIRE MARK (28) MIRE MARK (29) MIRE MARK (29) MIRE MARK (26) MIRE MARK (27)	
	180-28402 180-28604 180-28505 180-28506 180-28506 180-28506 180-27606 180-27606 180-27507 180-27507 180-27507	MIRE MARK (25) MIRE MARK (25) MIRE MARK (26) MIRE MARK (26) MIRE MARK (27) MIRE MARK (28) MIRE MARK (28) MIRE MARK (28) MIRE MARK (31) MIRE MARK (35) MIRE MARK (36) MIRE MARK (36) MIRE MARK (36)	
	180-28904 180-28905 180-28906 180-28900 180-28900 180-28000 180-28004 180-28004 180-28004 180-28004 180-28004 180-28004 180-28004	MIRE MARK (25) MIRE MARK (25) MIRE MARK (26) MIRE MARK (26) MIRE MARK (27) MIRE MARK (27) MIRE MARK (27) MIRE MARK (28) MIRE MARK (29) MIRE MARK (29) MIRE MARK (26) MIRE MARK (27)	
	180-28402 180-28402 180-28503 180-28508 180-28508 180-28508 180-28508 180-28508 180-28504 180-28504 180-27002 180-27002 180-27002 180-37004 180-37004 180-37004	WIRE MARK (28) WIRE MARK (21) WIRE MARK (23) WIRE MARK (23) WIRE MARK (23) WIRE MARK (23) WIRE MARK (33) WIRE MARK (33) WIRE MARK (33) WIRE MARK (34) WIRE MARK (35) WIRE MARK (35) WIRE MARK (36)	
	180-28901 180-28902 180-28903 180-28904 180-28202 180-28204	MISE WARK (23) MISE WARK (24) MISE WARK (24) MISE WARK (25) MISE WARK (26) MISE WARK (26) MISE WARK (26) MISE WARK (26) MISE WARK (27) MISE WARK (28)	
	180-28402 180-28402 180-28503 180-28508 180-28508 180-28508 180-28508 180-28508 180-28504 180-28504 180-27002 180-27002 180-27002 180-37004 180-37004 180-37004	WIRE MARK (28) WIRE MARK (21) WIRE MARK (23) WIRE MARK (23) WIRE MARK (23) WIRE MARK (23) WIRE MARK (33) WIRE MARK (33) WIRE MARK (33) WIRE MARK (34) WIRE MARK (35) WIRE MARK (35) WIRE MARK (36)	
	180-28901 180-28902 180-28903 180-28904 180-28202 180-28204	MISE WARK (23) MISE WARK (24) MISE WARK (24) MISE WARK (25) MISE WARK (26) MISE WARK (26) MISE WARK (26) MISE WARK (26) MISE WARK (27) MISE WARK (28)	
	180-28008 180-28001 180-28802 180-28804 180-28806 180-28200	WIRE MARK (23) WIRE MARK (24) WIRE MARK (24) WIRE MARK (25) WIRE MARK (26) WIRE MARK (26) WIRE MARK (27) WIRE MARK (26) WIRE MARK (31) WIRE MARK (31) WIRE MARK (32) WIRE MARK (35) WIRE MARK (35) WIRE MARK (36) WIRE MARK (36)	




No	note	Parts No.	DESCRIPTION	Qt
1		1/0-//058	TABLE & STAND ASM.	1
Z		1/0-//009	LOWER STAND RIGHT	ſı
2		1/0-//108	LOWER STANDLEFT	i ii
4		1/0-//20/		(1
			UPPER STAND RIGHT	
5		1/0-//306	UPPER STANDLEF I	[1
6		1/0-//405	UPPER SUPPORT	ſZ
7		1/0-//504	GEAR	ſz
В		1/0-//603	WORM WHEEL SHAFT	f1
9		1/0-///10	GEAR BOX	ſı
10		170-77801	GEAR BOX COVER	ín.
11		1/0-//900	WORM	ſı
12		1/0-/800/	WORM SHAFT	ſ1
13		1/0-/8114	WORM 24AF1	i i
14		1/0-/8213		
			HANDLE	(1
15		1/0-/8304	GUIDE BAR	ſZ
16		1/0-/8/00	TOROUE RIMITER	(1
17		1/0-/8502	RACK	ſz
18		88206-552-COO	ZIDE ZIBO I	f1
19		88307-220-000	LOWER STRUT A	ſı
za		GHP-0321/000	SHAFT HOLDER.	in the second
21		E4087-172-000	COLLAR	ſz
22		38-11/0002-00	ROLLING BEARING	íz
23		E4087-172-000	COLLAR	12
24		1/8-22628	ADJUSTING BOLT ASM.	[4
25		88150-221-000	CASTER	[4
26		202-43200	Z1AND CAP. W	[4
27		1A-2351305-R0	Russer Plug	ſz
28		Z-3081632-Z	HEXAGON SCREW WITH WASHER	(B
29		Z-9081692-Z	HEXAGON SCREW WITH WASHER	(B
5a		27-3081832-2E	HEXAGON SCREW WITH WASHER	(B
51		94-8061242-1P	SCREW	(2
52		27-3081832-2E	HEXAGON SCREW WITH WASHER	(4
22			BOLT WITH WASHER	
		27-8085282-2E		ſZ
34		2M-80E1502-2E	SCREW M6 L=12	(1)
22		32-6102042-1M	2CLEM	(1
26		5L-6081242-1N	BOL1	(B
21		5M-8082012-1N	2CMEW WB L= 50	ſz
28		9M-8061212-1P	SCREW M6X12	(4
29		94-8061212-1P	SCREW M6X1 Z	l (1
40		94-8040612-1P	3CREW M4 L= 6	ſı
41		94-8061242-1P	SCREW	ſ1
4Z		34-8040612-1P	SCREW M4 L= 6	ĺ1
43		3M-8050842-1P	Z 13CREW	ſz
44		3M-8050612-1P	SCREW MSXE	[4
15		3M-8050612-1P	2CKEM W 2XE	ſZ
46		3L-4041081-3C	3CREW M4 L=10	f1
47		GBR-2210/000	SPACER .	ſz
48		W5-061000Z-KN	SPRING WASHER 6.1X1 2.2X1.5	ĺ11
19		1/0-/9500	START SW PLATE	1
ia l		1/0-/9609	START SW BRACKET A	1
51		1/0-/9/08	START SW BRACKET B	1
52		1/0-/980/	ZIARI ZWITCH RETURN ZPRING	2
3		1/0-/9906	START SW FULCRUM SHAFT	
4		1/0-80110	E POWER SW BRACKET	
15		111-56056	SMALL CASTINGS CASE ASM.	1
6		88202-205-000	OIL MANAGEMEN1	1
7		ZK-2211801-ZE	WOOD SCREW D= 3.1 L= 16	4
8		89121-012-000	OILCAN	1
9		5M-6085002-1N	BOL1	
ia		WP-0850002-50	WASHER 8.5X1 8X1.6	1
i1		WW-8080001-20	NU1 MBX1.25	
iz			SPRING WASHER, MB	
		WS-082000Z-KR		l l
3		52-4051485-5E	BAY PLATE Y 150REW	
14		9L-6041092-1N	2CKEM	2
i5		5M-605080Z-1N	BOL1	
6		SL-6051292-1N	8001	ā
7		1/0-/8601	1ABLE	1
iB		3M-6040602-1N	BOL1	
9			SHING NN 2.0X10	
		PS-030010Z-K0		
a		3M-6052002-1N	BOL1	
1		MM-8030001-30	NU1MS	1
Z		HX-0015000-00	CUP	1
.2		32-4040891-30	2CKEM W4 F=8	1
		GSS64-254-000	DIRECTION IN ZIRUCTION REAL	1




No	note	Parts No.	DESCRIPTION	Qty
1	•	400-59340	MAIN PCB ASSY	1
z	٠.	400-22269	ZDC PCB VZZA	1
3	101	M8604-590-0C0	POWER CIRCUIT BOARD ASM.	1
4	,02	M8604-590-AC0	POWER CIRCUIT BOARD A ASM.	i
5		M8605-580-0A0	PMDC CIRCUIT BOARD ASM.	1
6		M1001-581-000	CONTROL BOX	i
7		M1GGZ-SBG-GAG	CONTROL BOX COVER ASM.	i
		м1001-610-000	CON TROL BOX PANEL	1
9		M1013-610-000	MAIN CIRCUIT BOARD PLATE	1
10		M1004-581-000	VENTILATION COVER	<u> </u>
11	•	400-59338	TRANSFORMER BIASM.	i
12		M8540-580-0A0	FAN ASM.	1
13		HM-0008600-10	FAN FILTER	1
14		E9567-319-000	EARTH MARK	2
15		HK-0542500-40		
16		HX-0014/00-00	TERMINAL BASE. SPACER	2 4
17		HX-0022300-0D		
18		HX-0040700-00	PACER	4
19		HX-0041000-00	8.34	2
70 20			8/34 CORD (13/1/46 PLA) 25	1
2u 21		1/8-45009 HX-0012300-08	CORD FITTING PLATE CABLE CUP	Z
				1
ZZ		EA-9500B01-00	CABLE BAND	11
23		HX-0022300-00	ZIUD	4
24		HX-0014/00-0C	SPACER	3
25		2-4040881-3F	SCREW M4 L= 8	4
26		27-4020891-20	2005M W 2XB	4
2/		27-4020881-20	2005M W 2XB	4
28		3L-4041281-3F	SCREW M4 L=12	4
29		3L-4051081-3F	SCREW MS L=10	4
20		3L-4040681-3C	COMBINATION SCREW M4 X B	,
31		3M-4031851-3R	2CME/A	4
3 Z		M2-0210\05-K2	SPRING WASHER	4
22		27-40410à1-20	2CREW M4 L= 10	4
34		27-40408à1-20	2CREW M4 F=8	6
22		27*4041031*2C	2CREW W4 L=10	
36		2M-1022001-2C	2CME/W	2
37		WW-8020002-20	WO1W2	2
28		27-4041031-20	3CREW M4 L=10	4
29		NM-3040520-3F	FLANGE NU1 M4	4
40		M8599-610-0A0-A	ACCESSORE PART ASM.	1
41		M3001-140-000	LAREL	(11)
4Z		HF-0084063-P0	FUX	(2)
43		HX-0001300-0B	WIRE HARNESS PART	0.5
44		EA-9500B0Z-00	CABLE BAND 150	5
45		EA-9502B04-00	CABLE CLIPE	1
46		HX-0015000-0F	CABLE CLIP	2
47		HX-0015000-0D	CABLE CLIP	2
48		HX-0015000-00	CUP	2
49	a 1	CM-3001001-01	DANGER LABEL (SMALL)	1
sa	0.2	CM-3001000-01	LAREL	1
51		E9567-319-000	EARTH MARK	4
52		2K-22B5001-2E	30REW D= 3.8 L= 20	2
53		MM-8080001-30	NU1 ME	3
54		9M-3065052-1C	2CLE.M	4
55		WP-0612056-3E	WASHER 6.1X18.5XZ	4
56		W5-0610002-KN	SPRING WASHER 6.1X12.2X1.5	4
57		51-4040891-50	2085M W4 F= 8	9
58		MAO-11532000	CORD STAPLE	Z
59	04	HA-0042500-00	ZMIJCH	1
60	az	HA-0058200-00	ZMIJCH	i
61	04	3K-3512001-3F	WOOD ZOLEM	Z
62		WP-0450826-30	WASHER 4.5X10X0.8	2
63	az	N-4051485-X	BASE PLATE SETSCREW	2
64	az	3K-3482001-3E	WOOD SCREW D=4.8 L=20	4

01 ...FOR USE IN JAPAN (200V) / 02...FOR JE-HIGH VOLTAGE / ...(220 -400V) / 03...FOR EXPORT / ...(LOW VOLTAGE 220 -400V), / ...FOR JE-HIGH VOLTAGE / ...(220 -400V) (200V), / ...FOR EXPORT (LOW VOLTAGE 200 -240 /




MOL-254 25. OPERATION BOX COMPONENTS

No	note	Parts No.	DESCRIPTION	Qty
1	•	400-29929	OPERATION PANEL ASM.	1
z		HX-0022100-0E	B1.2+	m
2		м1001-060-000	PLUG	(1)
4	•	400-59350	PANEL FROM 1 COVER	(1)
5		37-4020891-20	SCREW MISKS	(4)
6		G1013-192-000	REAR PLATE	(1)
7		G1014-192-000	ZWITCH COVER	(1)
В		G6010-003-000	KNOB SCREW	(z)
9		G1015-192-000	CLAMP	(1)
10		G1016-192-000	CLAMP BOTTOM PLATE	(z)
11		3M-6062002-1N	SCREW M6 L= 20	(z)
12		WP-0641601-30	WASHER	(2)
13		W5-061000Z-KN	SPRING WASHER 6.1X12.2X1.5	(z)
14	•	400-29926	PANEL PCB ASSY	(1)
15		37-4020881-20	2CKEM W 2 F= 8	(1a)
16	•	KG-0000001-40	LCD	(1)
17	•	400-59352	LCD COVER	(1)
18		CM-3001000-01	LAREL	(1)
19	•	400-609/2	PANEL CABLE ASM.	(1)
za		1A-0800504-R0	PLUG D=8 L=4.5	(z)




N-		ZE. WIRING DIAG		Otto
No	note	Parts No.	DESCRIPTION	Qty
2		MBS15-610-0A0	START SWITCH ASM.	1
3	-	400-59335	LOOP SENSOR C ASM.	1
4		MB598-610-0A0	HED DETECT TW ATM.	1
5		M8591-610-0A0	AV208	+ !-
6		HD-0013500-00	KNIFE BRACKET SENSOR ASM.	1
-		MB592-610-0A0	ZN20K	1
8		144-00451	LOOP CLAMP DETECT SENSOR ASM.	1
9			HOCK COVER TENTOR CARER ATM.	1
10		144-00451	HOOK COVER SENSOR CABER ASM.	1
11		144-23651 HD-0005/00-0A	HOOK REMOVAL SENSOR 1	1
			PHOTO SEASOR	1
12		HD-0005/00-0A	PH-010 32/450R	1
14		HD-0005/00-0A	PHOTO SEASOR	1
		M8516-610-0A0 M8510-610-0A0	1HREAD BREAK AGE DE 1EC 1 CABLE	1
15			LOOP LOCK DETECT SWITCH ASM.	1
17		144-10203 144-10104	XFEED STEPPING MOTOR	1
18			Y FEED STEPPING MOTOR	1
19		G5230-254-000	FEED-OUT MOTOR	1
		G5230-254-000	FEED-OUT MOTOR	1
Za		G5230-254-000	FEED-OUT MOTOR	1
21		138-/0266	BOREN THREAD WINDING DEVICE	1
22		141-08906	SOLENOID FOR THREAD TRIMMING	1
23		G5001-254-000	UNIT SERVO MOTOR	1
24	-	400-59353	YERVO MOTOR	1
25	•	M9002-580-0A0	SERVO POWER CORD ASM. B	1
26		G\$602-254-0A0	SOLEMOID VALVE BASM.	1 (1)
2/		PV-1502092-00	S-PORT SOLENOID VALVE	(1)
28		PV-1502090-00	5 PORT SOLENOID VALVE	(1)
29		PV-1502091-00	SOLEMOID VALVE	(1)
20		PV-1502090-00	5 PORT SOLENOID VALVE	(1)
31		PV-1502090-00	S PORT SOLEMOID VALVE	(1)
22		PV-1502090-00	S PORT SOLEMOID VALVE	(11)
2.2		PV-1502100-00	SDC CIRCUIT BOARD AA ASM.	(1)
34		PV-1502090-00	S PORT SOLENOID VALVE	(1)
22		PV-1502090-00	S PORT SOLEMOID VALVE	(1)
26		PV-1502090-00	S PORT SOLEMOID VALVE	(11)
21		GS601-254-0A0	SOLENOID VALVE A ASM.	1 (1)
28		PV-1502090-00	S PORT SOLEMOID VALVE	(1)
2.9		PV-1502090-00	S PORT SOLEMOID VALVE	(1)
40		PV-1502090-00	S PORT SOLEMOID VALVE	(1)
41		PV-1502090-00	S PORT SOLEMOID VALVE	(1)
42		PV-1502090-00	S PORT SOLEMOID VALVE	m
43		G\$604-254-0A0	FILTER REGULATER ASM.	1
44		G5421-254-0A0	KNIFE LOWERING SENSOR ASM.	1
45		G\$603-254-0A0	SOLENOID VALVE CABLE ASM.	1
46		M8562-610-0A0	XY MOTOR RELAY CABLE ASM.	1
47	-	400-59340	MAIN PCB ASSY	1
48	÷	400-59356	MMDC DCB V22A	1
49		400-59355	ZIC bcg vzz.	1
sa	*01	M8604-590-0C0	POWER CIRCUIT BOARD ASM.	1
51	*az	M8604-590-AC0	POWER CIRCUIT BOARD A ASM.	1
52	0.2	HA-0042500-00	ZMICH	1
2.2	04	HA-0020200-0A	ZMICH	1
54	•	400-59338	TRANSFORMER BIASM.	1
55		M8540-580-0A0	FAN ASM.	1
56	0.2	M9017-580-0A0	POWER CABLE ASM.	1
57	04	GB512-298-QAQ	POWER CABLE ASM.	1
58		M8512-610-0A0	SUPPLY DEVICE SENSOR CABLE	1
59		MB511-610-0A0	LOOP CLAMP SENSOR RELAY CABLE	1
60		MB514-610-0A0	HOOK SENSOR RELAY CABLE ASM.	1
61		144-10658	X SANSOR CABLE ASM.	1
62		144-10559	Y SENSOR CABLE ASM.	1
E.3		MB50B-610-0A0	20/ENOID ANTAE METAL CHIEF VZM	1
64		M8507-610-0A0	PMDC I/F CABLE ASM.	1
65		M8504-610-0A0	STEPPING MOTOR RELAY CABLE ASM	1
66		M8506-610-0A0	BOREN WINDER RELAY CARLE ASM.	1
67		M8503-610-0A0	1HREAD 1RIM MAGNET RELAY CABLE	1
68		M8502-610-0A0	FORK MOTOR RELAY CABLE ASM.	1
69		400-59336	SICLIF CABLE ASM.	1
70	,02	400-59500	AC POWER CABLE ASM. D	1
/1	- :	M9003-580-0A0	MP POWER CORD ASM.	1
/2	÷	400-59337	SERVO POWER CORD B ASM.	1
/3	-	400-39939	OPERATION PANEL ASM.	1 (2)
74	-	KG-0000001-40	LCD	(1)
		400-39936	PAHEL PCB AZZY	(1)
75		400-59501	AC POWER CABLE ASM. E	1
76	*04			
76	04	HN-0014900-00	CLAMP FILTER(L)	1
76 77 78	04 04	HN-0014900-00 HN-001/900-00	FERRITE CLAMP	Z
76 77 78 79	04	HN-0014900-00 HN-001/900-0C HA-0048600-10	SWITCH CLAMP	2
76 77 78 79 80	04 04 04	HN-0014900-00 HN-001/900-00 HA-0048600-10 M8522-610-0A0	FERRITE CLAMP SWITCH CLAMP LOOP GATHER DESCENTISEN, ASM.	2 1 1
76 77 78 79	04 04	HN-0014900-00 HN-001/900-0C HA-0048600-10	SWITCH CLAMP	2



MOL-254 27. 1HREAD STAND COMPONENTS


No	note	Parts No.	DESCRIPTION	Qty
1		D3301-772-1AB	THREAD STAND ASM.	1
Z		83319-704-L00	1HREAD GUIDE	(2)
3		3M-8081810-30	30REW M 6 L= 1 6	(2)
4		83318-704-L00-A	THREAD GUIDE ARM JOINT	(2)
5		83311-/04-000	SPOOL REST ROD CAP	(1)
6		111-85204	SPOOL REST ROD/LIPPER	(ii)
7		B3305-/04-000-A	SPOOL REST ROD JOIN 1	(1)
В		NM-6050001-5E	Nu1MS	(2)
9		5M-4051405-5E	30REW MS L=14	(2)
10		111-85501	SPOOL RETAINER	(2)
11		83320-/04-L00-A	SPOOL PIN	(2)
12		83311-012-000	25/00F MEZJ C/1/24/04	(2)
13		119-66504	25/00F1872.J	(2)
14		111-85105	SPOOL REST ROD LOWER	(1)
15		119-69508	SPOOL REST ARM A	(2)
16		83317-704-000	Nu1	(1)
17		WP-1612616-5E	WASHER 16X3GX2.6	(2)
18		83321-/04-L00	SPOOL REST ARM SUPPORT. A	(1)
19		MAC-11532000	CORD ZIAPLE	(2)
za		3M-4061201-3E	30REW M 6 L= 1 2	(1)
21		NM-6050001-5E	NU1MS	(2)
ZZ		NM-6060001-5E	NU1M6	(1)
23		2K-2285001-2E	30REW D= 3.8 L= 20	(1)
24		269-10059	THREAD GUIDE ARM ASM.	1
25		131-6/903	THREAD STANDING THREAD GUIDE	(1)
26		131-68000	1HREAD GUIDE BASE, LOWER	(1)
27		131-68109	THREAD GUIDE ARM BASE	(1)
28		131-68208	THREAD GUIDE ARM BASE	(1)
29		3M-4041001-30	3CREW M4X0.7 L=10	(2)
20		NM-6040002-5E	Nu1 M4x0.7	(z)
31		9M-4041201-30	3CREW M4 L=12	(1)
32		94-4042001-90	3CREW M4 X 20	(1)
2.2		NM-6040002-5E	Nu1 M4X0.7	(2)




No	note	Parts No.	DESCRIPTION	Qty
1		22-2680/40-2P	30REW9/32-28 L= 6.8	1
Z		GS641-254-000	UPPER FOLDING DOG. 4MM WID1H	Z
3		G5642-254-000	UPPER FOLDING DOG. 2.5MM WID1H	Z
4	01	MDP-17081902	NEEDLE DPX17#19-2	Z
5	az	MDP-17082102	NEEDLE DFX1/#21-2	Z
6		138-70266	BOBBIN THREAD WINDING DEVICE	1
7		128-89951	BOBBIN GUIDE ASM.	1
В		B2612-3/2-QQQ	STOP MOTION TRIP LEVER BRACKET	m
9		83107-352-000	NEEDLE 1HREAD GUIDE	m
10		83108-352-000	NEEDLE 1HREAD 1ENSON POST	m
11		83125-012-000	THREAD TENSION NUT	m
12		83126-012-000	THREAD TENSION DISK	(z)
13		83129-//1-000	1EN SION SPRING	(ii)
14		NS-6150430-5N	NU115/64-28	(z)
15		5K-3412001-50	WOOD 50REW D=4.1 L=20	Z
16		WP-0501016-50	WASHERSX10.5X1	Z
17		5K-3412001-50	WOOD SCREW D=4.1 L=20	Z
18		WP-0501016-50	WASHERSX10.5X1	Z
19		118-51102	2CLEW AMENCH	1
za		138-81008	LOWER PLATE BLANK	1
21		89101-490-000	DRIVER	1
ZZ		81806-210-000	BOBBN	Z
23		89101-552-000	ACCESSORY BOX	1
24		J10/1-000-000	SCREW DRIVER	1
25		89109-555-000	SCREW DRIVER, LARGE	1
26		B9110-012-000	SCREW DRIVER, MIDDLE	1
27		B9111-012-000	SCREW DRIVER, SMALL	1
28		260-34/02	WRENCH (14X11)	1
29		B9113-012-000	WRENCH (9X10)	1
20		89143-3/2-000	WRENCH (7.1 X 8.1)	1
31		G9101-116-0A0	L-SHAPED WRENCH ASM.	1
32		89204-804-000	TWEETERS	1
2.2		WP-0820526-3D	WASHER 8.2X14X0.5	4
34		MAL-01129000	MAGNE1	1
35		PJ-3095200-01	20CKE1	1
36		PB-0000100-00	HOSE BAND	1
37		B9121-220-0A0	OILER (CONTAINING NO.2 OIL)	1
28	0.2	CM-6001002-01	WEEE INFORMATION SHEET	1

G1...FOR USE IN JAPAN / G2...FOR EXPORT / G5...FOR JE /






No	note	Parts No.	DESCRIPTION	Qty
1		G5700-254-0A0	FULLNESS DEVICE ASM.	1
Z		G5/01-254-000	FULLMEZZ BASE	m
2		G5/02-254-000	FULLNESSLEVER	m
4		G5/03-254-000	FULLINESS BELT PRESSER FROM 1	m
5		G5/04-254-000	FULLMESS BEL1 PRESSER REAR	m
6		138-77816	CLOTH PRESSER FOOT	(2)
1		22-81111140-2P	30REW11/64-40 L=11	(2)
В		3D-0640271-1P	HINGE SCREW	(2)
9		22-6110610-1P	50REW11/64-40 L=6	(4)
10		PA-9000340-00	JOIN1	(1)
11		GNP-01330000	CON IROL PIN	m
1 Z		C2-0310/18-2D	THRUST COLLAR ASM. SMM	m
13		PA-1003003-A0	PEN CYLINDER	m
14		PC-01050/0-00	SPEED CON TROLLER	m
15		PV-1502090-00	5 PORT SOLENOID VALVE	(1)
16		PX-5000140-00	PLUG	(1)
17		B1-0400251-EB	URE THANE HOSE, BLACK	(0.5)
18		180-35808	WIRE MARK (9)	(4)
19		EA-9500B01-00	CABLE BAND	(2)



MOL-254 SG. NEEDLE COOLER COMPONENTS (OPTION)

No	note	Parts No.	DESCRIPTION	Qty
1		G5770-254-0A0	NEEDLE COOLER MASASM.	1
Z		G5771-254-QAQ	NC BASE A ASM.	m
2		G5773-254-QAQ	NC BASE BIASMI.	(1)
4		22-/110840-3P	50REW 11/64-40 L=7.8	(1)
5		22-7110840-3P	50REW 11/64-40 L=7.8	(n)
6		PV-1502090-00	S PORT SOLENOID VALVE	(1)
7		PX-5000140-00	PLUG	(1)
В		PJ-3080400-02	OUICK COUPLING	(1)
9		PC-0124060-00	SPEED CON IROLLER	(1)
10		B1-0400251-EB	URE THANE HOSE, BLACK	(z)
11		EA-9500B01-00	CABLE BAND	(5)
12		180-36400	WIRE MARK (15)	[4]
13		180-38604	WIRE MARK (37)	(4)
14		180-38/03	WIRE MARK (38)	(4)









d	MOL-254 51. THREAD BREAKAGE DETECT DEVICE COMPONENTS (OPTION)								
No	note	Parts No.	DESCRIPTION	Qty					
1		GS780-254-0A0	THREAD BREAKAGE SENSOR ASM.	1					
Z		GS/81-254-000	THREAD TAKE-UP SPRING PLATE B	m					
2		GS/82-254-000	THREAD TAKE-UP SPRING PLATE C	m					
4		M8516-610-0A0	1HREAD BREAK AGE DE1EC1 CABLE	(1)					
5		G3197-116-000	INSULATING BUSHING	(z)					
6		22-8080550-2b	SCREW 3/32-56 L= 2/0	(z)					
- 7		WP-0250516-50	WASHER 2.5X6X0.5	(2)					
В		W1-0320001-KM	WASHER	m					
9		EA-9500B01-00	CABLE BOND	m					
10		HX-0015000-0A	CABLE CLAMP	(2)					
11		55-4110715-5P	SCREW 11/64-40 L=7	(2)					
12		55-6060440-1P	30REW 3732-56 L= 3.5	(11)					







No	note	Parts No.	DESCRIPTION	Qty
1		GS/91-254-000	MEEDLE BAR 1HREAD GUIDE	Z
Z		5M-6850402-1N	B0L1 M Z.5 L=4	Z
2		G5/92-254-000	MEEDLE BAR 1HREAD GUIDE B	1
4		3M-6850402-1N	B0L1 M Z.5 L=4	1
5		WP-0280500-30	WASHER	1
6		G5/93-254-000	SHUTTLE H (SM TERED)	1
- 7		G5/94-254-000	CARBOE TIP DRIVER	1






MOL-254 53. AIR GUN COMPONENTS (OPTION)

No	note	Parts No.	DESCRIPTION	Qty
1		GS760-254-0A0	AIR GUN ASM.	1
Z		161-11403	AIRGUN	(11)
2		PJ-3010651-03	HALF UNION 6XP1178	(11)
4		G5458-116-000	CURLED TUBE	(11)
5		MA1-81163100	CORD HOLDER	(1)







MOL-254 S4. LOOP PULL-OUT DEVICE COMPONENTS (OPTION)

No	note	Parts No.	DESCRIPTION	Qty
1		G5/30-254-0A0	LOOP DRAWER DEVICE ASM.	1
Z		G5/31-254-000	LOOP DRAWER DEVICE BASE	(1)
3		G5/32-254-000	LOOP GUIDE PIN	(2)
4		GS/33-254-000	LOOP FROM 1 SUPPORT PLATE	(1)
5		GS/34-254-000	LOOP REAR SUPPORT PLATE	(1)
6		G5/35-254-000	LOOP FASIEN PIC	(2)
7		GS/36-254-000	LOOP GUIDE METAL FITTING	(1)
В		G5/3/-254-000	LOOP APPLY METAL	(1)
9		G5/38-254-000	LOOP STOPPER SPRING	(2)
10		G5/39-254-000	GUIDE PLATE SPRING	(1)
11		G5/40-254-000	LOOP DRAWER CYLINDER METAL	(1)
12		G5/41-254-000	LOOP DRAWER ROLLER	(1)
13		GNP-01330000	CON TROL PIN	(1)
14		88231-092-000	BACK PLATE	(1)
15		G5/44-254-000	LOOP LOWER SUPPORT PLATE	(1)
16		G\$/45-254-000	LOOP GUIDE PLATE	(1)
17		MB510-610-0A0	LOOP LOCK DETECT SWITCH ASM.	(ii)
18		G6022-8/0-000	FOLDING STEPSCREW	(1)
19		G6022-8/0-000	FOLDING STEPSCREW	(2)
za		G9 20 2- 8 80-000	BuSh D= 5	(2)
21		PS-0400202-KH	SPRING PIN 4X20	m
ZZ		PA-2015005-A0	AIR CYLINDER	(1)
23		PC-01510B0-00	SPEED CON IROLLER	(2)
24		PV-1502090-00	S PORT SOLENOID VALVE	m
25		B1-0400251-EB	URE THANE HOSE, BLACK	(0.5)
26		180-35907	WIRE MARK (10)	(4)
27		180-38901	WIRE MARK (40)	(4)
28		EA-9500B01-00	CABLE BAND	(4)
29		5L-6041092-1N	2CMEAN	(2)
20		5L-6041092-1N	2CMEAN	(z)
31		3M-804046Z-1P	2CMEAN	(z)
2.5		5L-6041092-1N	2CMEAN	(z)
22		27-4021881-20	2CMEW W2 X 1 B	(z)
34		5M-8040462-1P	2CMEAN	(z)
22		5M-6053502-1P	BOL1	(2)
26		5L-6041092-1N	2CMEAN	(2)
21		3M-608500Z-1N	B0L1	(2)
28		WP-085000Z-SC	WASHER 8.5X1 8X1.6	[4]
29		WS-08Z000Z-KR	SPRING WASHER, MB	(2)
40		WW-8080001-3C	NU1 MBX1.25	(2)
41		W2-8150210-2P	NU13/16-28	(1)
42		W2-8150210-2P	NU13/16-28	(2)
43		5L-6041092-1N	2CMEAN	(2)
44		GAK-33032000	SOLEMOID RUBBER, B	(2)

As to the place changed, refer to the corresponding Rev. No. When previous parts (Obsoleted part) and new parts (Added parts) are not interchangeable with each other:

In this case, even obsoleted parts (D.) can be ordered with the obsoleted part number, so select the parts with changed dates and place your orders.

変更箇所は、該当Rev.No.版をご参照ください。 部品の互換性がない変更の場合は、削除された品番でも、ご注文できます。

29330404

No. 1265-04 · · · Rev. No.

*A: Added parts 資加部品/D: Obsoleted parts 削減部品/E: Erratum即正

- /	A: Ado	ied p	parts	遊加部品/D: Obsoleted	ра	rtsg	月年部品/	E: Er	ratumII止
(Page		Parts No.			Page		
	No.	Ā	No.	A #		No.	Ā	No.	S 8
D	03	6	1	141-02404					
D	03	6	5	144-04602		_			
D	03	6	6	144-04750		<u> </u>			
D	03	6	10	M6001-610-AA0	Α	04	6	10	400-59353
D	03	6	24	SM-6850602-TN					
D	03	6	2.5	WS-0270002-KN					
D	03	6	26	SM-4060801-SE					
D	03	6	2 7	WS-0610002-KN					
D	03	6	4 1	144-02606					
D	03	6	43	SM-8050812-TP					
D	03	48	1	M8601-610-AA0	.A	0 4	4.8	1	400-59340
D	03	48	2	M8610-610-AAA-A	Α	0.4	4.8	2	400-22269
D	03	48	3	M8620-610-AAA	А	0.4	4.8	3	M8604-590-0C0
D	0.3	48	4	M8620-610-BAA	Α	0.4	4.8	4	M8604-590-AC0
D	03	48	11	M8901-610-0A0	Α	04	4.8	11	400-59338
D	03	5 0	1	M8580-610-0A0	А	0.4	5 0	1	400-39939
D	03	5.0	2	M1100-610-000					
D	03	50	3	NM-6030001-SC					
D	03	50	4	G1012-192-000	Α	0.4	5 0	4	400-59350
D	0.3	50	1.4	G8602-195-0A0	А	0.4	5 0	14	400-39936
D	03	5 0	16	G8525-192-0A0	А	0.4	5 0	16	KG-0000001-40
D	03	5.0	17	G1018-192-000	A	0.4	5 0	17	400-59352
D	0.3	5.0	18	G8533-192-0A0					
D	03	5.0	19	G8522-195-0A0	Α	0.4	5.0	19	400-60972
D	03	52	2	400-22521	Α	0.4	5 2	2	400-59335
D	03	52	2 4	M6001-610-AA0	Α	0.4	5.2	2 4	400-59353
D	0.3	52	2.5	144-04750					
					Α	0.4	5.2	2.5	M9002-580-0A0
D	0.3	5.2	47	M8601-610-AA0	A	0.4	5.2	47	400-59340
D	0.3	5.2	4.8	M8605-580-0A0	А	0.4	5.2	4.8	400-59356
D	03	5.2	49	M8610-610-AAA-A	А	0.4	5.2	4.9	400-59355
D	03	52	5.0	M8620-610-AAA	A	0.4	5 2	5.0	M8604-590-0C0
D	03	52	5 1	M8620-610-BAA	A	0.4	5 2	5 1	M8604-590-AC0
D	03	52	5.4	M8901-610-0A0	A	0.4	5 2	5.4	400-59338
D	03	52	6.9	M8519-610-0A0	A	0.4	5 2	69	400-59336
D	03	5.2	7.0	M8530-610-AA0	A	0.4	5 2	7.0	400-59500
	0.0	0.2	7.0	WA 2 2 0 - 0 10 - VVO	_^	0 7	9.6	1.0	400-0000

		Page	Ref.	Parts No.		Rev.	Page	Ref.	Parts No. ≗ ≛
D	No.	页 52		≗ # M8505-610-0A0	A		Ĭ.	NO.	™ # M9005-580-0A0
D	03	52	72	M8544-610-0A0	+^	04	32	- / 1	M3003-300-0V0
_		0.2		moorr- oro- oro	A	0.4	5 2	7 2	400-59337
D	0.3	5.2	7.3	M8580-610-0A0	A	0.4	5 2	7.3	400-39939
D	03	52		G8525-192-0A0	A	0.4	5 2	7.4	KG-0000001-40
D	03	52	_	G8602-195-0A0	A	0.4	5.2	7.5	400-39936
D	0.3	5.2		M8530-610-CA0	A	0.4	5.2	7.6	400-59501
					A	0.4	5 2	8 1	400-59354
					A	0.4	5 2		M9020-580-AA0
					-				
					\vdash				
					-	-			
_					\vdash				
					-				
					+				
					+				