

JUKI®

model **LU-562·3**

High Speed Single Needle Lockstitch Unison Feed
Industrial Sewing Machine

PARTS * BOOK

REVISION No. 3




TOKYO JUKI INDUSTRIAL CO., LTD.

HOW TO MAKE USE OF THIS PARTS BOOK

- 1. This is a consolidated PARTS BOOK of Model LU-562-563.
- 2. This book is divided, as a principle, into various sections according to the functions of parts and also contains illustrations to assist you visually.
For example, if you want some parts for the SEWING HOOK SHAFT COMPONENTS, just refer to the section on "SEWING HOOK SHAFT COMPONENTS" etc.
- 3. The figures on the illustrations indicate the corresponding numbers on the BOOK.
- 4. On bits and pieces parts such as screws, etc. the illustration shows only a representative one and so for the required quantity of these parts, refer to the BOOK.
- 5. Parts marked with * on the "Ref. No." column, mean these parts are one complete assembly unit.
- 6. The parts under "Amt. Req." column circled by ○ are parts included in the one assembly unit which is marked with * just above these parts.
- 7. When placing your order, please specify your order by the assembly unit number marked with * under the "Ref. No." column. However, parts whose "Ref. No." column are not circled by ○ can be sold as a single part unit even though the "Amt. Req." column figure is circled by ○ .

FOR EXAMPLE


Ref. No.	Part No.	Description	Amt. Req.	
*1	B-1111-111-0A0	Name of part	1	Means one assembly unit
2	B-1111-111-000	" "	①	Means this is included in the above B-1111-111-0A0 assembly unit. (This part can be sold as a single unit)
③	B-1112-111-000	" "	①	Means this part is included in the above B-1111-111-0A0 assembly unit. (This part can not be sold as a single unit)



CONTENTS

1. MAIN FRAME & MISCELLANEOUS COVER COMPONENTS	1
2. UPPER MAIN SHAFT & SAFETY CLUTCH MECHANISM COMPONENTS	2
3. SEWING HOOK SHAFT COMPONENTS	3
4. NEEDLE BAR FRAME COMPONENTS	4
5. PRESSER BAR & KNEE LIFTER COMPONENTS	5
6. REVERSE FEED CONTROL LEVER	6
7. EXCLUSIVE PARTS FOR LU-563	7
8. NUMERICAL INDEX OF PARTS	8


1. MAIN FRAME & MISCELLANEOUS COVER COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
①	B-1101-562-000	Frame	1	29	B-3137-051-0A0	Take-up spring guide asm.	①
2	B-3101-053-000	Face plate	1	30	SS-4080610-SP	... Screw	①
3	B-3106-019-000	... Screw	1	33	B-3136-051-000	Thread tension disc	②
4	B-1140-051-000	Thread take-up oil splasher	1	34	B-3132-051-000	... Presser	①
5	SS-3090610-SP	... Screw	1	35	B-3129-053-000	Thread tension spring	①
6	B-1129-051-000	Frame thread guide, upper	1	36	B-3125-012-000	Thread tension stud nut	②
7	SS-2090710-SP	... Screw	2	37	B-3121-051-000	Thread controller base	①
8	B-1103-051-000	Face plate pin	1	39	B-3134-051-000	Thread release lever	①
9	B-1112-053-000A	Bed slide, left	1	40	SD-0470281-SP	... Screw	②
10	B-1113-053-000A	Bed slide, right	1	41	B-3122-053-000	Thread release lever pushing bar	①
(11)	B-1105-051-000	... Pin (obsoleted)	(1)	38	SS-7110720-SP	Screw	1
(12)	B-1106-051-000	... Spring (obsoleted)	(1)	27	B-3138-051-000	Take-up spring adjusting plate	1
13	B-1109-562-000	Throat plate	1	28	SS-7090520-SP	... Screw	1
14	SS-2110920-TP	... Screw	2	42	B-1128-051-000	Three-hole thread eyelet	1
15	B-1839-053-000	Oil receiving cover	1	43	SS-8110510-SP	... Screw	1
16	B-1841-053-000	Oil drip felt	1	(44)	B-1102-562-000	Bed	1
17	SS-711-410-SP	Screw, for cover	2	(45)	B-1160-562-000	Model plate	1
18	B-1130-051-000	Frame thread guide, middle	1	(46)	A-1161-001-00B	... Pin	2
19	SS-2090710-SP	... Screw	1	47	B-3501-051-000	Oil filter sleeve, front bushing	1
20	B-1131-562-000	Frame thread guide, lower	1	48	B-1155-053-000	Oil cup	1
21	SS-3090610-SP	... Screw	1	49	B-1509-051-000	Pressure regulating thumb screw	1
22	B-1157-009-0A0	Bed oil cup	2	50	B-1114-051-000	Needle thread guide pin	1
23	SS-8111251-SP	Screw, take-up spring stud	1	51	B-1150-051-000	Top cover	1
24A	B-3121-053-0A0	Thread tension asm.	1	52	B-1152-051-000	... Washer	1
24	B-3128-051-000	Take-up spring	①	53	SD-0630241-SD	... Screw	1
25	B-3123-051-000	Stud	①	54	B-3542-581-000	Hook shaft front bushing felt	1
26	B-3127-051-000	Thread release pin	①				



27 B-3138-051-00
28 SS-7090520-SP

2. UPPER MAIN SHAFT & SAFETY CLUTCH MECHANISM COMPONENTS




Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	B-1905-053-000	Take-up lever	1	7B	SS-7681750-TP	... Screw (A)	1
2	SS-8151150-SP	Screw, take-up lever pin	1	31	B-1303-055-A00	Sprocket wheel lower	1
4	CQ-505000000	... Oil wick	1	32	B-1301-051-000	Timing belt	1
5	B-1206-051-000	Counterweight	1	33	B-1216-051-000	Upper main shaft rear bushing (1)	1
6	SS-8680540-SP	Screw (1), crank pin	1	19	SS-8151350-SP	... Screw	1
7A	SS-7681750-TP	Screw (S), counterweight	1	34	D-1201-055-B00	Upper main shaft	1
8A	SS-8681650-TP	Screw, counterweight	1	35	B-1217-051-000	Upper main shaft rear bushing (2)	1
9	B-1210-051-000	Needle bar crank pin	1	36	SS-8150710-SP	... Screw	2
4	CQ-505000000	... Oil wick	1	37	B-1219-051-000	Upper main shaft rear bearing	1
11	SS-8680730-SP	... Screw (2)	1	38	B-1218-051-000	... Retaining collar	1
12	B-1408-051-000	Needle bar crank rod	1	39	B-1227-053-000	Hand wheel	1
4	CQ-505000000	... Oil wick	1	40	B-1233-012-000	... End screw	1
15	B-1207-051-000	Plug screw, upper main shaft	1	41	SS-8151780-SP	... Screw (S)	1
4	CQ-505000000	Oil wick	1	42	B-1311-055-000	Safety clutch body	1
17	B-1202-051-000	Upper main shaft front bushing	1	43	B-1316-055-000	... Screw	2
18	B-1205-051-000	... Thrust washer	1	44	B-1309-055-000	Safety clutch counter-hook spring	1
19	SS-8151350-SP	... Screw	1	45	B-1305-055-000	Safety clutch spring	1
20	B-1203-051-000	... Oil felt	1	46	SD-0640322-TP	... Hinge screw	1
4	CQ-505000000	... Oil wick	1	47	B-1307-055-000	Safety clutch hook	1
22	D-1450-055-B00	Feed eccentric	1	48	B-1310-055-000	Safety clutch small link	1
23	SS-8660570-TP	... Screw A	1	49	SD-0640322-TP	Hinge screw, safety clutch hook	1
24	SS-8660970-TP	... Screw B	1	50	B-1308-055-000	Safety clutch counter-hook spring	1
25	B-1220-562-000	Stitch graduator	1	51	SS-8090710-SP	Positioning screw, safety clutch spring	1
26	SS-8151230-SP	... Screw	2	52	B-1314-055-000	Pin, small link	1
27	B-1302-051-000	Sprocket wheel, upper	1	53	SS-8152030-SP	Screw, hand wheel	1
28	B-1214-019-000	... Ring	3				
8B	SS-8681650-TP	... Screw (B)	1				

3. SEWING HOOK SHAFT COMPONENTS




Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	CQ-505000000	Oil wick, crank pin	1	35	B-1627-562-000	Needle bearing	1
2	B-1823-051-000	Bobbin case opening lever crank pin	1	36	B-1702-012-000	Oil supply felt	1
3	B-9117-051-000	Bobbin	1	37	B-1213-012-000	Retainer	1
4	B-1830-055-0A0	Vertical-axis sewing hook asm.	1	*38	B-1620-562-0AX	Feed adjusting body asm.	1
5	B-1820-051-000	Bobbin case opening lever link	1	39	B-1623-057-000	Feed eccentric	①
6	B-1814-051-000	Hook driving shaft upper bushing	1	41	B-1622-057-000	Friction plate	2
7	SS-8151150-SP	Screw	1	42	B-1642-057-000	Screw	2
8	B-1822-051-000	Bobbin case opening lever crank	1	43	NS-6080210-SP	Nut	2
9	B-1824-051-000	Bobbin case opening lever	1	44	SS-8151780-SP	Screw B, eccentric body	1
10	WP-0371016-SD	Washer	1	45	SS-8151770-SP	Screw A, eccentric body	1
11	SS-6090620-SP	Screw	1	46	B-1626-562-000	Feed eccentric guide	1
12	B-1820-051-000	Crank screw stud	1	47	B-1636-055-000	Adjusting knob	1
13	CQ-505000000	Oil wick	1	48	B-1637-055-000	Bushing	1
14	NS-6110420-SP	Nut	1	49	RE-0500000-K0	Snap ring	1
15	B-1811-051-000	Hook driving shaft saddle	1	50	B-1639-051-000	Spring	1
16	SS-7762840-SP	Screw	1	51	B-1314-057-000	Safety clutch ratchet gear	1
17	B-1812-051-000	Washer	1	52	SS-8151780-SP	Screw (A)	1
18	SS-8150710-SP	Screw, crank	1	53	SS-8152080-SP	Screw (B)	1
19	SS-6153040-SP	Clamp screw, saddle	1	54	B-1313-055-000	Safety clutch knob sleeve	1
20	B-1816-051-000	Hook shaft gear	1	55	B-1639-051-000	Spring, for knob	1
21	B-1831-055-000	Screw	2	56	PS-0200102-KH	Pin, for knob	1
22	B-1817-051-000	Hook driving shaft gear	1	57	B-1312-055-000	Safety clutch knob	1
23	SS-8660530-TP	Screw	1	58	B-1625-057-000	Retaining collar, for eccentric body spring	1
24	SS-8660670-SP	Screw	1	59	SS-8110510-SP	Screw (A)	1
25	B-1818-051-800	Thrust washer gear	1	60	SS-8110750-SP	Screw (B)	1
26	B-1815-051-000	Lower bushing, shaft	1	61	B-1624-055-000	Feed eccentric body spring	1
27	SS-8150710-SP	Screw	1	62	B-1806-051-000	Hook shaft timing indicator	1
28	B-1802-053-000	Hook shaft front bushing	1	63	SS-7090520-SP	Screw	2
29	SS-8152030-SP	Screw	1	64	B-1809-051-000	Bearing retaining collar	1
30	B-1804-051-000	Hook shaft intermediate bushing	1	65	SS-8090530-TP	Screw	3
31	SS-8151550-SP	Screw	1	66	B-1219-051-000	Hook shaft bearing	1
32	B-1807-512-000	Intermediate bushing (B)	1	67	B-1808-051-000	Hook shaft rear bushing (2)	1
34	B-1614-562-000	Crank connecting rod	1	68	SS-8150750-SP	Screw	2
				69	B-1807-051-000	Hook shaft rear bushing (1)	1
				70	SS-8152030-SP	Screw	1
				71	B-1801-562-000	Hook shaft	1
				72	B-1840-051-000	Feed driving eccentric	1
				73	SS-8150580-SP	Screw	1

4. NEEDLE BAR FRAME COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	B-1420-053-000	Needle bar frame	1	33	B-1466-053-000	Walking bar	1
2	B-1421-051-000	. . . Taper stud	1	34	B-1470-053-000	Walking foot	1
3	B-1411-053-000	Needle bar connection	1	35	SS-6110710-TP	. . . Clamp screw	1
4	B-1412-051-000	Oil felt	1	36	B-1467-053-00A	Spring pole, for walking bar	1
5	SS-7090910-SP	. . . Screw	1	37	B-1468-053-000	Spring, for walking bar	1
6	B-1423-051-000	Needle bar frame guide	1	38	B-1467-053-00B	Retaining collar, for spring	1
7	SS-9111010-SP	. . . Screw	1	39	B-1467-053-00C	. . . Pin	1
8	WP-0480856-SP	. . . Washer	1	40	B-1469-053-000	Adjusting thumb screw, walking foot	1
9	B-1401-053-000	Needle bar	1	41	D-1453-055-B00	Upper feed rod	1
10	MDI-300B2301	Needle D1x3(29x3) #23	1	42	D-1454-055-B00	Upper feed spring rod	1
11	B-1419-053-000	Needle bar thread guide	1	43	D-1455-055-B00	Wing screw bolt bushing	1
12	SS-7060310-SP	. . . Screw	1	44	D-1456-055-B00	Wing screw bolt	1
13	SS-7080510-SP	Screw, for needle	1	45	D-1457-055-B00	Wing screw washer	1
14	B-1425-051-000	Needle bar frame slide block	1	46	B-1702-012-000	Oil felt	1
16	B-1428-051-000	Shaft front crank	1	47	B-1213-012-000	. . . Retainer	1
17	PT-0301600-S0	. . . Knock pin	1	48	D-1458-055-B00	Wing screw	1
18	B-1437-051-000	. . . Oil wick retainer	1	49	SS-7161640-SP	Screw, for upper feed spline rod	1
19	B-1438-051-000	. . . Oil wick	1	50	B-1456-053-000	Walking bar rock shaft	1
20	NS-6620310-SP	Lock nut, for slide block stud	1	51	B-1555-053-000	. . . Bushing	2
21	B-1429-051-000	Needle bar frame rock shaft	1	52	B-1457-055-000	Screw stud, for rock shaft connecting link	1
22	B-1431-051-000	. . . Rear crank	1	53	NS-6660430-SP	Nut	1
23	SS-6151440-SP	 Screw	1	54	B-1458-053-000	Walking bar rock shaft connecting link	1
24	SD-0790801-SP	 Hinge screw	1	55	B-1459-053-00A	L shaped link	1
25	NS-6160520-SP	 Nut	1	56	B-1459-053-00B	Screw stud, for crank	1
26	B-1434-051-000	. . . Driving rod	1	57	NS-6110310-SP	. . . Nut	1
27	SD-0950801-SP	Hinge screw, for driving rod crank	1	58	B-1465-053-000	Walking bar driving link	1
28	CQ-505000000	Oil wick	1	59	SS-6111140-SP	Screw, for L shaped link	1
29	NS-6700420-SP	Nut, for driving rod crank	1	60	SS-8151160-SP	Screw, for taper stud	1
30	B-1435-051-000	Driving rod crank	1				
31	SS-6151920-SP	. . . Clamp screw	1				
32	CQ-505000000	Oil wick	1				

5. PRESSER BAR & KNEE LIFTER COMPONENTS




Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	B-1507-051-000	Presser bar connection	1	32	SS-9151440-CP	Screw	①
2	SS-7090910-SP	...Screw	1	33	WS-0651510-KP	Washer	①
3	B-1503-051-B00	Presser bar bushing B	1	30	B-1605-051-000	Oil supply felt	1
4	SS-8151150-SP	...Screw	1	31	SS-5080710-SP	Screw	1
5	B-1501-040-000	Presser bar	1	34	B-1603-051-000	Feed bar shaft	1
6	B-1525-053-000	Presser foot	1	35	SS-8110510-SP	...Screw	2
7	SS-6090910-TP	...Screw	1	36	B-1601-562-000	Feed rock shaft	1
8	B-1505-053-000	Presser bar adjusting plate spring	1	37	B-1607-051-000	...Front bushing	1
9	SD-0801601-SP	Screw stud, for plate spring	1	38	SS-8151150-SP	Screw	1
10	SD-0800481-SP	Hinge screw, for bracket	1	39	CS-1401012-SC	...Thrust collar	2
11	B-1502-051-000	Presser bar guide sleeve	1	40	SS-8150410-SP	Screw	4
12	SS-8151150-SP	...Screw	1	41	B-3409-053-000	Knee lifter front lever	1
13	B-1503-051-A00	Presser bar bushing A	1	42	SD-0790361-SP	...Hinge screw	1
14	SS-8151150-SP	...Screw	1	43	B-3410-051-000	Knee lifter rear lever	1
15	B-1504-051-000	Presser bar connection	1	44	SD-0790361-SP	...Hinge screw	1
16	SS-7090910-SP	...Screw	1	45	B-3413-053-000	Rear lifting bar	1
17	B-1460-053-00A	Hand lifter mounting bracket	1	46	PD-0231100-0B	...Cotter pin	1
18	B-1460-053-00B	...Connecting pin	1	47	CS-0510713-SC	...Spring retaining collar	1
19	SS-7111310-SP	...Clamp screw	1	48	SS-7110540-SP	Screw	1
20	PT-0201200-S0	...Pin	1	49	B-3414-051-000	...Spring	1
21	B-1512-051-000	Hand lifter	1	50	B-3416-051-000	...Roller holder	1
22	B-1515-051-000	Shaft	1	51	B-3417-051-000	...Roller	1
23	B-1462-053-000	Thread release spring	1	52	SD-0550801-SP	...Screw stud	1
24	B-1461-053-0A0	Thread release guide	1	53	SS-7110510-SP	...Screw	1
26	B-1613-053-000	Feed dog	1	54	B-1609-051-000	Feed rock shaft rear bushing	1
27	B-1611-055-000	...Screw	2	55	SS-8152030-SP	...Screw	1
*28	B-1602-055-0A0	Feed bar	1	56	B-8217-053-000	Drip pan	1
29	B-1604-051-000	...Fork	①	57	B-3401-027-0A0	Knee lifter assembly	1

6. REVERSE FEED CONTROL LEVER

Exploded view diagram of the Reverse Feed Control Lever assembly. The diagram shows the lever mechanism with various components labeled with reference numbers. A small inset shows the lever installed in the sewing machine head.

Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	B-1647-562-000	Feed regulating forks link	1	37	SS-7090540-TP	Screw, for slide block	1
2	B-1664-562-000	... Needle bearing	1	38	B-1652-562-000	Feed changing shaft base (A)	1
3	B-1646-562-000	Feed regulating link shaft	1	39	SM-6081542-CP	... Screw	2
4	CQ-3030000-00	Oil wick	1	40	B-1654-562-000	Feed changing arm	1
5	B-1659-562-000	Tension spring suspension (B)	1	41	SS-7151120-SP	... Screw (B)	1
6	B-2007-232-000	Tension spring	1	42	SS-8151280-SP	... Screw (A)	1
7	SS-4091010-SP	Screw, for suspension (B)	1	43	B-1657-562-000	Feed regulating rod	1
8	WP-0371016-SD	Washer	1	44	SD-0600271-SP	... Hinge screw (B)	1
9	B-1667-562-000	Feed limiting plate	1	45	B-1656-562-000	Feed changing shaft (B)	1
10	SS-9121340-CP	... Screw	2	46	SS-8150710-SP	... Screw	1
10A	WP-0480856-SP	... Washer	2	47	B-1655-562-000	Feed changing shaft base (B)	1
11	SS-9111820-SP	... Adjusting screw	1	48	SM-6081542-CP	... Screw	2
12	NS-6110530-SP	... Adjusting nut	1	49	SS-6121030-SP	End screw, for feed changing shaft (B)	1
13	B-1644-562-000	Feed regulating pin	1	50	B-1624-555-000	Reverse feed control lever	1
14	CQ-3030000-00	Oil wick	1	51	SS-8660970-TP	... Screw (A)	1
15	B-1647-122-000	Tension spring suspension (A)	1	52	SS-9660720-SP	... Screw (B)	1
16	SS-8150710-SP	... Screw	1	53	SS-7620750-SP	End screw, for lever	2
17	B-1645-562-000	Feed regulating link	1	54	B-1660-562-000	Reverse feed control lever shaft	1
18	B-1641-562-000	Feed regulating arm shaft	1	55	B-1658-562-000	Tension spring regulating arm	1
19	SS-8110750-SP	Screw, for link shaft	1	56	SS-8150710-SP	... Screw	1
20	B-1640-562-000	Feed regulating arm	1	57	B-1666-562-000	Tension spring (B)	1
21	SS-8110750-SP	Screw (A), for feed regulating pin	1	58	SD-0400201-SD	Hinge screw, for tension spring bracket	1
22	SS-8110750-SP	Screw (B)	1	59	SS-6121210-SP	Clamp screw, for spring regulating arm	1
23	B-1642-562-000	Feed regulating arm pin	1	60	B-1663-562-000	Feed control lever stopper	1
24	SS-8110520-TP	... Screw	1	61	SS-9151440-CP	... Screw	1
25	B-1643-562-000	Bushing, for arm shaft	1	62	WP-0621016-SD	... Washer	1
26	SS-8110510-SP	... Screw	1	63	PS-0500202-KP	Feed control stopper pin (A)	1
27	B-1414-155-000	Slide block, for feed regulating pin	1	64	PS-0500202-KP	... Pin (B)	1
28	B-1651-562-000	Feed changing fork	1	65	B-1662-562-000	Collar, for feed control lever	1
29	SS-9151540-SP	... Screw	1	66	SS-9111820-SP	Limiting screw	1
30	B-1653-562-000	Feed changing shaft (A)	1	67	NS-6110530-SP	... Nut	1
31	PS-0300201-KP	Knock pin, for feed changing arm shaft	1	68	SD-0600321-SP	Hinge screw, (A), for feed regulating rod	1
32	B-1616-562-000	Feed rock shaft crank	1	69	WZ-0641510-KP	... Washer	1
33	SS-7111410-SP	... Clamp screw	2	70	SS-7151210-SP	Clamp screw, for feed regulating arm	1
34	B-1648-562-000	... Connecting shaft	1				
35	CQ-3030000-00	Oil wick	1				
36	SS-8110520-TP	... Screw, for connecting shaft	2				

7. EXCLUSIVE PARTS FOR LU-563



Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
①	B-1101-563-OZO	Machine frame	1	19	B-1839-563-000	Oil receiving cover, for saddle	1
②	B-1102-563-OZO	Machine bed	1	20	B-1841-563-000	. . . Oil drip felt	1
3	B-1158-563-000	Thread take-up lever cover	1	21	B-1129-563-000	Frame thread guide, upper	1
4	SS-7150940-SP	. . . Screw	2	22	B-3502-563-000	Oil gauge	1
5	B-1905-563-0A0	Thread take-up lever assembly	1	23	SS-7110510-SP	Screw, for oil shield	4
6	B-9117-563-000	Bobbin	1	24	B-1613-563-000	Feed dog	1
7	B-1830-563-0A0	Vertical-axis sewing hook assembly	1				
	B-1830-563-BA0	 For extreme thick thread	(1)				
8	B-1814-563-000	Hook driving shaft upper bushing	1				
9	B-1815-563-000	. . . Lower bushing	1				
10	B-1811-563-000	Hook driving shaft saddle	1				
11	B-1822-563-000	Bobbin case opening lever crank	1				
12	B-1824-563-000	Bobbin case opening lever	1				
13	B-1843-563-000	Oil adjusting screw	1				
14	NS-6110420-SP	. . . Nut	1				
⑬	B-1160-563-000	Model plate	1				
16	B-1838-563-000	Oil shield, (A) for saddle	1				
17	B-1844-563-000	Oil shield, (B) for saddle	1				
18	B-1846-563-000	. . . Oil drip felt	1				

8. NUMERICAL INDEX OF PARTS

Part No.	Page	Ref. No.	Part No.	Page	Ref. No.	Part No.	Page	Ref. No.	Part No.	Page	Ref. No.	Part No.	Page	Ref. No.
EXCLUSIVE PARTS			B-1435-051-000	4-30		B-1656-562-000	6-45		B-3413-053-000	5-45		SD-0630241-SD	1-53	
A-1161-001-00B	1-46		B-1437-051-000	4-18		B-1657-562-000	6-43		B-3414-051-000	5-49		SD-0640322-TP	2-49	
B-1101-562-000	1-1		B-1438-051-000	4-19		B-1658-562-000	6-55		B-3416-051-000	5-50		SD-0640322-TP	2-46	
B-1101-563-020	7-1		B-1456-053-000	4-50		B-1659-562-000	6-5		B-3417-051-000	5-51		SD-0790361-SP	5-42	
B-1102-562-000	1-44		B-1457-055-000	4-52		B-1660-562-000	6-54		B-3501-051-000	1-47		SD-0790361-SP	5-44	
B-1102-563-020	7-2		B-1458-053-000	4-54		B-1662-562-000	6-65		B-3502-563-000	7-42		SD-0790801-SP	4-24	
B-1103-051-000	1-8		B-1459-053-00A	4-55		B-1663-562-000	6-60		B-3542-581-000	1-54		SD-0800481-SP	5-10	
B-1105-051-000	1-(11)		B-1459-053-00B	4-56		B-1664-562-000	6-2		B-8217-053-000	5-56		SD-0801601-SP	5-9	
B-1106-051-000	1-(12)		B-1460-053-00A	5-17		B-1666-562-000	6-57		B-9117-051-000	3-3		SD-0950801-SP	4-27	
B-1109-562-000	1-13		B-1460-053-00B	5-18		B-1667-562-000	6-9		B-9117-563-000	7-6		SM-6081542-CP	6-48	
B-1112-053-000A	1-9		B-1461-053-00A	5-24		B-1702-012-000	3-36		D-1201-055-B00	2-34		SM-6081542-CP	6-39	
B-1113-053-000A	1-10		B-1462-053-000	5-23		B-1702-012-000	4-46		D-1450-055-B00	2-22		SS-2090710-SP	1-7	
B-1114-051-000	1-50		B-1465-053-000	4-58		B-1801-562-000	3-71		D-1453-055-B00	4-41		SS-2090710-SP	1-19	
B-1128-051-000	1-42		B-1466-053-000	4-33		B-1802-053-000	3-28		D-1455-055-B00	4-43		SS-2110920-TP	1-14	
B-1129-051-000	1-6		B-1467-053-00A	4-36		B-1804-051-000	3-30		D-1456-055-B00	4-44		SS-3090610-SP	1-5	
B-1129-563-000	7-21		B-1467-053-00B	4-38		B-1806-051-000	3-62		D-1457-055-B00	4-45		SS-3090610-SP	1-21	
B-1130-051-000	1-18		B-1467-053-00C	4-39		B-1807-051-000	3-69		D-1458-055-B00	4-48		SS-4080610-SP	1-30	
B-1131-562-000	1-20		B-1468-053-000	4-37		B-1807-512-000	3-32		D-1454-055-B00	4-42		SS-4091010-SP	6-7	
B-1140-051-000	1-4		B-1469-053-000	4-40		B-1808-051-000	3-67					SS-5080710-SP	5-31	
B-1150-051-000	1-51		B-1470-053-000	4-34		B-1809-051-000	3-64		THRUST COLLAR			SS-6090620-SP	3-11	
B-1152-051-000	1-52		B-1501-040-000	5-5		B-1811-051-000	3-15		CS-0510713-SC	5-47		SS-6090910-TP	5-7	
B-1155-053-000	1-48		B-1502-051-000	5-11		B-1811-563-000	7-10		CS-1401012-SC	5-39		SS-6110710-TP	4-35	
B-1157-009-0A0	1-22		B-1503-051-A00	5-13		B-1812-051-000	3-17					SS-6111140-SP	4-59	
B-1158-563-000	7-3		B-1503-051-B00	5-3		B-1814-051-000	3-6		OIL WICK			SS-6121030-SP	6-49	
B-1160-562-000	1-45		B-1504-051-000	5-15		B-1814-563-000	7-8		CQ-3030000-00	6-4		SS-6121210-SP	6-59	
B-1160-563-000	7-15		B-1505-053-000	5-8		B-1815-051-000	3-26		CQ-3030000-00	6-14		SS-6151440-SP	4-23	
B-1202-051-000	2-17		B-1507-051-000	5-1		B-1815-563-000	7-9		CQ-3030000-00	6-35		SS-6151920-SP	4-31	
B-1203-051-000	2-20		B-1509-051-000	1-49		B-1816-051-000	3-20		CQ-5050000-00	2-4		SS-6153040-SP	3-19	
B-1205-051-000	2-18		B-1512-051-000	5-21		B-1817-051-000	3-22		CQ-5050000-00	3-13		SS-7060310-SP	4-12	
B-1206-051-000	2-5		B-1515-051-000	5-22		B-1818-051-B00	3-25		CQ-5050000-00	4-32		SS-7080510-SP	4-13	
B-1207-051-000	2-15		B-1525-053-000	5-6		B-1820-051-000	3-5		CQ-5050000-00	2-4		SS-7090520-SP	1-28	
B-1210-051-000	2-9		B-1555-053-000	4-51		B-1821-051-000	3-12		CQ-5050000-00	2-4		SS-7090520-SP	3-63	
B-1213-012-000	4-47		B-1601-562-000	5-36		B-1822-051-000	3-8		CQ-5050000-00	3-1		SS-7090540-TP	6-37	
B-1213-012-000	3-37		B-1602-055-0A0	5-28		B-1822-563-000	7-11		CQ-5050000-00	2-4		SS-7090910-SP	5-2	
B-1214-019-000	2-28		B-1603-051-000	5-34		B-1823-051-000	3-2		CQ-5050000-00	2-4		SS-7090910-SP	4-5	
B-1216-051-000	2-33		B-1604-051-000	5-29		B-1824-051-000	3-9		CQ-5050000-00	4-28		SS-7090910-SP	5-16	
B-1217-051-000	2-35		B-1605-051-000	5-30		B-1824-563-000	7-12					SS-7110410-SP	1-17	
B-1218-051-000	2-28		B-1607-051-000	5-37		B-1830-055-0A0	3-4		NUT			SS-7110510-SP	5-53	
B-1219-051-000	2-37		B-1609-051-000	5-54		B-1830-563-0A0	7-7		NS-6080210-SP	3-43		SS-7110510-SP	7-23	
B-1219-051-000	3-66		B-1611-055-000	5-27		B-1830-563-BA0	7-(7)		NS-6110310-SP	4-57		SS-7110540-SP	5-48	
B-1220-562-000	2-25		B-1613-053-000	5-26		B-1831-055-000	3-21		NS-6110420-SP	3-14		SS-7110720-SP	1-38	
B-1227-053-000	2-39		B-1613-563-000	7-24		B-1838-563-000	7-16		NS-6110420-SP	7-14		SS-7111310-SP	5-19	
B-1233-012-000	2-40		B-1614-562-000	3-34		B-1839-053-000	1-15		NS-6110530-SP	6-12		SS-7111410-SP	6-33	
B-1301-051-000	2-32		B-1616-562-000	6-32		B-1839-563-000	7-19		NS-6110530-SP	6-67		SS-7150940-SP	7-4	
B-1302-055-000	2-27		B-1620-562-0AX	3-*38		B-1840-051-000	3-72		NS-6160520-SP	4-25		SS-7151120-SP	6-41	
B-1303-055-A00	2-31		B-1622-057-000	3-41		B-1841-053-000	1-16		NS-6620310-SP	4-20		SS-7151210-SP	6-70	
B-1305-055-000	2-45		B-1623-057-000	3-39		B-1841-563-000	7-20		NS-6660430-SP	4-53		SS-7161640-SP	4-49	
B-1307-055-000	2-47		B-1624-055-000	3-61		B-1843-563-000	7-13		NS-6700420-SP	4-29		SS-7620750-SP	6-53	
B-1308-055-000	2-50		B-1624-555-000	6-50		B-1844-563-000	7-17					SS-7681750-TP	2-7A	
B-1309-055-000	2-44		B-1625-057-000	3-58		B-1846-563-000	7-18		NEEDLE			SS-7681750-TP	2-7B	
B-1310-055-000	2-48		B-1626-562-000	3-46		B-1905-053-000	2-1		MDI-300B2301	4-10		SS-7762840-SP	3-16	
B-1311-055-000	2-42		B-1627-562-000	3-35		B-1905-563-0A0	7-5					SS-8090530-TP	3-65	
B-1312-055-000	3-57		B-1636-055-000	3-47		B-2007-232-000	6-6		TAPER PIN			SS-8090710-SP	2-51	
B-1313-055-000	3-54		B-1637-055-000	3-48		B-3101-053-000	1-2		PD-0231100-0B	5-46		SS-8110510-SP	1-43	
B-1314-055-000	2-52		B-1639-051-000	3-50		B-3106-019-000	1-3		PS-0200102-KH	3-56		SS-8110510-SP	6-26	
B-1314-057-000	3-51		B-1639-051-000	3-55		B-3128-051-000	1-24		PS-0300201-KP	6-31		SS-8110510-SP	3-59	
B-1316-055-000	2-43		B-1640-562-000	6-20		B-3121-051-000	1-37		PS-0500202-KP	6-64		SS-8110510-SP	5-35	
B-1401-053-000	4-9		B-1641-562-000	6-18		B-3122-053-0A0	1-24A		PS-0500202-KP	6-63		SS-8110520-TP	6-36	
B-1408-051-000	2-12		B-1642-057-000	3-42		B-3122-053-000	1-41		PT-0201200-S0	5-20		SS-8110520-TP	6-24	
B-1411-053-000	4-3		B-1642-562-000	6-23		B-3123-051-000	1-25		PT-0301600-S0	4-17		SS-8110750-SP	6-22	
B-1412-051-000	4-4		B-1643-562-000	6-25		B-3125-012-000	1-36					SS-8110750-SP	3-60	
B-1414-155-000	6-27		B-1644-562-000	6-13		B-3127-051-000	1-26		"E" RING			SS-8110750-SP	6-21	
B-1419-053-000	4-11		B-1645-562-000	6-17		B-3129-053-000	1-35		RE-0500000-K0	3-49		SS-8110750-SP	6-19	
B-1420-053-000	4-1		B-1646-562-000	6-3		B-3132-051-000	1-34					SS-8111251-SP	1-23	
B-1421-051-000	4-2		B-1647-122-000	6-15		B-3134-051-000	1-39		SCREW			SS-8150410-SP	5-40	
B-1423-051-000	4-6		B-1647-562-000	6-1		B-3136-051-000	1-33		SD-0400201-SD	6-58		SS-8150580-SP	3-73	
B-1425-051-000	4-14		B-1648-562-000	6-34		B-3137-051-0A0	1-29		SD-0470281-SP	1-40		SS-8150710-SP	6-16	
B-1428-051-000	4-16		B-1651-562-000	6-28		B-3138-051-000	1-27		SD-0550801-SP	5-52		SS-8150710-SP	6-46	
B-1429-051-000	4-21		B-1652-562-000	6-38		B-3401-027-0A0	5-57		SD-0600271-SP	6-44		SS-8150710-SP	2-36	
B-1431-051-000	4-22		B-1653-562-000	6-30		B-3409-053-000	5-41		SD-0600321-SP	6-48		SS-8150710-SP	6-56	
B-1434-051-000	4-26		B-1654-562-000	6-40		B-3410-051-000	5-43					SS-8150710-SP	3-18	
			B-1655-562-000	6-47										

Part No.	Page	Ref. No.
SS-8150710-SP	3-27	
SS-8150750-SP	3-68	
SS-8151150-SP	5-14	
SS-8151150-SP	5-38	
SS-8151150-SP	5- 4	
SS-8151150-SP	5-12	
SS-8151150-SP	2- 2	
SS-8151150-SP	3- 7	
SS-8151160-SP	4-60	
SS-8151230-SP	2-26	
SS-8151350-SP	2-19	
SS-8151280-SP	6-42	
SS-8151350-SP	2-19	
SS-8151550-SP	3-31	
SS-8151770-SP	3-45	
SS-8151780-SP	3-44	
SS-8151780-SP	3-52	
SS-8151780-SP	2-41	
SS-8152030-SP	3-70	
SS-8152030-SP	5-55	
SS-8152030-SP	3-29	
SS-8152030-SP	2-53	
SS-8152080-SP	3-53	
SS-8660530-TP	3-23	
SS-8660530-TP	2-23	
SS-8660670-SP	3-24	
SS-8660970-TP	6-51	
SS-8610970-TP	2-24	
SS-8680540-SP	2- 6	
SS-8680730-SP	2-11	
SS-8681650-TP	2-8A	
SS-8681650-TP	2-8B	
SS-9111010-SP	4- 7	
SS-9111820-SP	6-11	
SS-9111820-SP	6-66	
SS-9121340-CP	6-10	
SS-9151440-CP	5-32	
SS-9151440-CP	6-61	
SS-9151540-SP	6-29	
SS-9660720-SP	6-52	

WASHER

WP-0371016-SD	3-10
WP-0371016-SD	6- 8
WP-0480856-SP	4- 8
WP-0480856-SP	6-10A
WP-0621016-SD	6-62
WZ-0641510-KP	6-69
WS-0651510-KP	5-33



TOKYO JUKI INDUSTRIAL CO.,LTD.

Head Office & Plant, 2-1, 8-chome, Kokuryo-cho, Chofu-shi, Tokyo, Japan
Business Office: 23, Kabuki-cho, Shinjuku-ku, Tokyo, Japan
Cable Address: JUKI TOKYO Telex: 232-2301 JUKI SHINJUKU TOK