


PARTS LIST OF MODEL

MS-19

High Speed, Chain Stitch, Two-needle, Feed-Off-The-Arm, Lap Seam Felling Industrial Sewing Machine



JM - ORIGINAL


HOW TO MAKE USE OF THIS PARTS LIST

1. This is a consolidated PARTS LIST of Model MS-19
2. This list is divided, as a principle, into various sections according to the functions of parts and also contains illustrations to assist you visually.
3. Number in the first column are reference numbers only, and merely indicate the position of the part in the illustration. Reference numbers should never be used in ordering parts. Always use the part number listed in the second column.
4. On bits and pieces parts such as screws, etc. the illustration shows only a representative one and so for the required amount of these parts, refer to the "Amt. Req." column on the list.
5. At the back of the list will be found a numerical index of all the parts shown in this list. This will facilitate locating the illustration and description when only the part number is known.

NOTE: The large Gothic number on the top line of Reference No. are the new, current parts numbers.
The small parts number shown just below this line is now obsolete.

for Example: Ref. No. B-2201-019-000New number
192201Obsolete number


* In ordering the parts, please place the order by the NEW NUMBERS.



CONTENTS



	Page
1. THREAD TAKE-UP & LOOPER THREAD TENSION COMPONENTS	1
2. FRAME & MISCELLANEOUS COVERS COMPONENTS	2
3. FEED & LOOPER DRIVING MECHANISM COMPONENTS.....	4
4. ARM ROTARY SHAFT & BED ROTARY SHAFT COMPONENTS	5
5. THREAD TENSION & PRESSER LIFTER COMPONENTS	6
6. LOOPER MECHANISM COMPONENTS	7
7. PRESSER BAR & NEEDLE BAR COMPONENTS	8
8. NUMERICAL INDEX OF PARTS	9

1. THREAD TAKE-UP & LOOPER THREAD TENSION COMPONENTS




Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	B-2201-019-000 192201	Looper thread take-up stripper plate	1	22	B-2226-019-000 192226	...Locking screw stud	1
2	SS-7090410-SP 0946ph	...Screw	1	23	B-2416-019-000 192416	Looper thread tension regulating screw stud	1
3	B-2202-019-000 192202	...Thread guard	1	24	B-2413-019-000 192413	Looper thread tension plate	3
4	SS-7060310-SP 0622ph	...Screw	2	25	B-2412-019-0A0 192412	Looper thread tension guide	1
5	B-2220-019-000 192220	Looper thread guide (B) cushion	1	26	SS-8151550-SP 1554ph	...Screw	1
6	B-2211-019-000 192211	Looper thread guide (A)	1	27	B-1115-019-000 191115	Hinge connecting pin	2
7	B-2212-019-000 192212	Looper thread guide (B)	1	28	B-2415-019-000 192415	Looper thread tension spring	1
8	B-2213-019-000 192213	Looper thread guide (C)	1	29	B-2414-019-000 192414	Looper thread tension regulating screw stud nut	1
9	B-2215-019-000 192215	Looper thread guide (E)	1	30	SS-5090710-SP 0973ph	Screw, for tension regulating screw stud	1
10	B-2214-019-000 192214	Looper thread guide (D)	1	31	B-1113-019-000 191113	Looper thread tube cover	1
11	SS-7060310-SP 0622ph	...Screw, for (D)	1	32	B-1114-019-000 191114	Looper thread tube cover hinge	2
12	SS-7090520-SP 0921ph	...Screw, for (C) & (E)	2	33	SS-4091010-SP 0926ph	...Screw	2
13	WP-0371016-SP W371p	...Washer, for (A) & (B)	3	34	B-1141-019-000 191141	Looper thread tube cover spring (A)	1
14	SS-7090530-SP 0972ph	...Screw, for (A)	1	35	SS-7060310-SP 0622ph	...Screw	3
15	SS-7090710-SP 0922ph	...Screw, for (B)	2	36	B-2413-026-A00 262413A	Looper thread guide plate (A)	1
16	B-2203-019-000 192203	Looper thread take-up stripper plate bracket	1	37	SS-2060310-SP	...Screw	2
17	SS-3090510-SP 0971ph	...Screw	2	38	B-2413-026-B00 262413B	Looper thread guide plate (B)	1
18	B-2207-026-000 192207	Looper thread take-up cover	1	39	B-2414-026-000 262414	Looper thread guide plate fixing plate	1
19	B-2208-019-000 192208	Looper thread take-up cover spring	1	40	B-1144-019-0A0 191144S	Looper thread tube cover spring reinforcing plate assembly	1
20	SS-6060210-SP 0621ph	...Screw	1	41	B-1143-019-000 191143	Looper thread tube cover spring (B)	1
21	B-2224-019-000 192224	Looper thread take-up cover pin	1	42	SS-3090710-TP 0940ph	...Screw	1

2. FRAME & MISCELLANEOUS COVERS COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.
1	B-1101-019-000 191101	Main frame	1
2	B-1155-019-000 191155	Oil cup	3
3	B-3101-019-000 193101	Face plate, upper	1
4	B-3106-019-000 193106	...Screw	1
5	B-1139-019-000 191139	Oil reservoir plug screw	3
6	B-1140-019-000 191140	...Washer	3
7	B-3104-019-000 193104	Face plate pawl spring	1
8	SS-7060310-SP 0622ph	...Screw	1
9	B-3102-019-000 193102	Face plate, lower	1
10	SS-1090920-SP 0907ph	...Screw	
11	B-3103-019-000 193103	Gasket, for face plate, lower	1
12	B-1148-019-000 191148	Rubber cushion (A)	2
13	SS-6151440-SN	...Screw A	
14	SK-3552000-SC	...Screw B	
15	B-1157-019-000 191157	Looper thread tube (C)	1
16	B-1152-019-000 191152	Rubber cushion (B)	1
17	B-1156-019-000 191156	Rubber cushion (C)	1
18	B-1110-019-000 191110	Sprocket wheel cover	1
19	SS-8660610-TP 6651ph	...Screw	2
20	B-2406-019-000 192406	Looper thread tube (A)	1
21	SS-4091010-SP 0926ph	...Screw	2
22	B-2418-019-000 192418	Looper thread tube cap	4
23	B-1219-019-000 191219	Timing belt	1
24	B-1117-019-000 191117	Sprocket wheel cover gasket	1
25	B-1111-019-000 191111	Sprocket wheel cover plate	1
26	SS-7151210-SP 1522ph	...Screw	2
27	B-1805-019-000 191805	Bed rotary shaft front bushing cover	1
28	SS-6090620-SP 0940ph	...Screw	4
29	B-1806-019-000 191806	...Gasket	1
30	B-1116-019-0A0 191116S	Bed cover assembly	1
31	SS-7090850-SP 0976ph	...Screw	6
32	SS-5091020-SP 0938ph	...Screw	10
33	B-1120-019-000 191120	Bed cover gasket clamping plate	1
34	SS-7060310-SP 0622ph	...Screw	1
35	B-1119-019-000 191119	Bed cover gasket	1
36	B-1134-019-000 191134	Oil gauge stud	1
37	B-1105-019-000 191105	Bed extension	1
38	SS-9284043-CP 2881ph	...Screw	2
39	B-1104-019-000 191104	Belt guard	1
40	SS-6151440-SP 1525ph	...Screw	


3. FEED & LOOPER DRIVING MECHANISM COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	B-2101-019-000 192101	Feed rocker & looper avoid lever	1	22	B-1610-019-000 191610	Feed bar hinge pin slide block	1
2	R0-0952001-00- 0G09520	O ring, for feed rocker slide block pin	1	23	B-1607-019-000 191607	Feed lifting eccentric forked connection slide block	1
3	B-2105-019-000 192105	Feed rocker slide block	1	24	B-1602-019-000 191602	Feed lifting eccentric forked connection	1
4	B-2108-019-000 192108	Feed rocker slide block stopper	1	25	SS-7111110-TP 1137ph	...Screw	2
5	SS-8110510-SP 1151ph	...Screw	2	26	B-1606-019-000 191606	Feed eccentric slide block	1
6	B-2103-019-000 192103	Feed rocker eccentric	1	27	B-1613-019-000 191613	Feed eccentric (adjustable)	1
7	SS-8660610-SP 6651ph	...Screw	2	28	SS-7090610-SK 09210fh	...Screw	1
8	B-2115-019-000 192115	Feed rocker connecting link	1	29	WP-0480856-SP W481ph	...Washer	1
9	B-2116-019-000 192116	Feed rocker connecting link pin	2	30	B-1611-019-000 191611	Feed eccentric adjustor	1
10	B-2117-019-000 192117	...Screw	2	31	SS-8151150-SK 1552fh	...Screw	2
11	B-2106-019-000 192106	Feed rocker slide block pin	1	32	B-1614-019-000 191614	Feed regulating screw	1
12	B-2107-019-000 192107	Feed rocker shaft	1	33	B-2503-019-000 192503	Looper rocker shaft rear bushing	1
13	SS-7110830-SP 1138ph	...Clamp screw	1	34	SS-8150410-SP 1558ph	...Screw	1
14	B-2122-019-000 192122	...Washer	1	35	B-2505-019-000 192505	Looper avoiding eccentric forked connection crank	1
15	SS-8150710-SP 1555ph	...Screw	1	36	SS-7111110-TP 1137ph	...Clamp screw	1
16	B-2102-019-000 192102	Feed rocker	1	37	B-2501-019-000 192501	Looper rocker shaft	1
17	B-2109-019-0A0 192109S	Feed rocker connecting rod assembly	1	38	B-2502-019-000 192502	Looper rocker shaft front bushing	1
18	B-1601-019-000 191601	Feed bar	1	39	SS-8151150-SP 1552ph	...Screw	1
19	B-1608-019-000 191608	Feed bar hinge pin	1	40	B-2001-019-000 192001	Looper avoiding eccentric forked connection bracket shaft	1
20	SS-8151150-SK 1552fh	...Screw	1	41	B-2002-019-000 192002	Looper avoiding eccentric forked connection bracket	1
21	B-1617-019-000 191617	...Washer (gasket)	1	42	SS-6121840-SP 1228ph	...Screw	1

(Continued to page 5)

4. ARM ROTARY SHAFT & BED ROTARY SHAFT COMPONENTS




Ref. No.	Part No.	Description	Amt. Req.
1	B-1204-019-000 191204	Arm rotary shaft ball bearing spacing collar	1
2	B-1205-019-000 191205	Arm rotary shaft ball bearing case nut	1
3	B-1202-019-000 191202	Arm rotary shaft ball bearing, rear	1
4	B-1203-019-000 191203	Arm rotary shaft ball bearing case	1
5	SS-8701140-SP 7051ph	...Screw	1
6	B-1214-019-000 191214	Sprocket ring	3
7	B-1211-019-000 191211	Sprocket wheel (A)	1
8	SS-9150860-SK 1582fh	...Screw	4
9	B-1215-019-000 191215	Hand wheel	1
10	SS-8152030-fh 1556ph	...Screw	2
11	B-3501-019-000 193501	Oil cup body	1
12	B-3502-019-000 193502	Oil cup body cap	1
13	B-3503-019-000 193503	Oil cup body cap gasket	1

4. FEED & LOOPER DRIVING MECHANISM COMP. (Cont.)

43	SS-8150410-SP 1558ph	Screw, for feed rocker slide block pin	1
44	B-2004-019-000 192004	Looper avoiding eccentric forked connection	1
45	SS-7111110-TP 1137ph	...Clamp screw	1
46	B-1607-019-000 191607	Looper avoiding eccentric forked connection slide block	1
47	B-2006-019-000 192006	Looper avoiding eccentric	1
48	SS-8110410-TP 1152ph	...Screw	2
49	B-1613-019-0A0 191613S	Feed eccentric (adjustable) assembly	(1)

Ref. No.	Part No.	Description	Amt. Req.
14	B-3504-019-000 193504	Oil cup body cap retainer	1
15	SS-6092120-SP 0945ph	...Screw	4
16	B-3505-019-000 193505	Oil cup gasket	1
17	SS-5660440-SP 6671ph	Oil cup body oil plug screw	1
18	B-3508-019-000 193508	...Washer	1
19	B-1201-019-000 191201	Arm rotary shaft	1
20	B-1222-019-000 191222	Arm rotary shaft screw washer	1
21	SS-7740740-SP 7421ph	Arm rotary shaft screw	1
22	B-1802-019-000 191802	Bed rotary shaft ball bearing, front	1
23	B-1803-019-000 191803	Bed rotary shaft ball bearing, intermediate	1
24	SS-8110320-SP 1153ph	...Screw	2
25	B-1808-019-000 191808	...Sleeve	1
26	B-2210-019-000 192210	Looper thread take-up	1
27	SS-8660330-SP 6652ph	...Screw	2
28	B-1811-019-000 191811	Bed rotary shaft ball bearing spacing collar	1
29	B-1205-019-000 191205	Bed rotary shaft ball bearing case nut	1
30	B-1202-019-000 191202	Bed rotary shaft ball bearing, rear	1
31	B-1810-019-000 191810	Bed rotary shaft ball bearing case	1
32	SS-7120910-SP 1222ph	...Screw	3
33	B-1212-019-000 191212	Sprocket wheel (B)	1
34	B-1801-019-000 191801	Bed rotary shaft	1
35	SS-7161040-SP 1624ph	Screw, for bed rotary shaft, rear	1
36	SS-7110830-SP 1138ph	Screw, for bed rotary shaft, front	1


5. THREAD TENSION & PRESSER LIFTER COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	B-2326-019-000 192326	Pressure regulating screw nut (B)	1	20	SS-4622340-SP 6222ph	...Screw	1
2	NS-6120310-SP N122ph	Pressure regulating screw nut (A)	1	21	B-2306-019-000 192306	Tension thread guide	2
3	B-2324-019-000 192324	Pressure regulating screw	1	22	B-2310-019-000 192310	Tension releasing pin	2
4	B-2329-019-0A0 192329S	Presser bar spring, upper, assembly	1	23	B-2307-019-000 192307	Tension post	2
5	B-2327-019-000 192327	Presser bar spring	1	24	B-3126-012-000 123126	Tension disc	4
6	B-2328-019-000 192328	Presser bar spring pin	1	25	B-3132-012-000 123132	Tension releasing disc	2
7	B-2319-019-000 192319	Presser bar lifting lever	1	26	B-2313-019-000 192313	Tension spring bushing (B)	2
8	B-3701-019-000 193701	...Hinge screw	1	27	B-2311-019-000 192311	Tension spring	2
9	B-2322-019-000 192322	Presser bar lifting bracket lifter	1	28	B-2312-019-000 192312	Tension spring bushing (A)	2
10	SD-0790431-SP D079414h	...Hinge screw	1	29	B-2314-019-000 192314	Tension regulating thumb nut	2
11	B-2321-019-000 192321	Presser bar lifting lever spring	1	30	B-2402-019-000 192402	Thread guide	4
12	B-2315-019-000 192315	Tension releasing shaft crank connecting link	1	31	SS-5060410-SP 0677ph	...Screw	8
13	SD-0450211-SP D045001h	...Hinge screw	2	32	B-2420-019-000 192420	Thread guide bracket (needle thread)	1
14	B-2317-019-000 192317	Tension releasing shaft crank	1	33	B-2421-019-000 192421	Thread eyelet (needle thread thread)	1
15	SS-7110710.SP 1123ph	...Screw	1	34	SS-7090510-SP 0923ph	...Screw	1
16	B-2303-019-000 192303	Tension releasing shaft	1	35	B-2404-019-000 192404	Thread guide bracket support	1
17	NS-6110310-SP N112ph	...Lock nut	1	36	SS-7090520-SP 0921ph	...Screw	2
18	SS-8111160-SP 1154ph	...Screw	1	37	B-2401-019-000 192401	Thread guide bracket (looper thread)	1
19	B-2301-019-000 192301	Tension bracket (needle thread)	1	38	SS-4091010-SP 0922ph	...Screw	2


(Continued to page 7)

6. LOOPER MECHANISM COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	B-9100-019-0A0 199100S	Lap seam feller assembly	1	8	B-2515-019-000 192515	Looper holder	1
2	B-1137-019-000 191132	Thread cutter holding plate, inner	1	9	SS-7091480-SK 0944fh	Looper clamp screw	1
3	B-1135-019-000 191135	Thread cutter	1	10	B-2516-019-000 192516	Looper support pin	1
4	SS-3060710-SP 0673ph	...Screw	2	11	SS-6111040-SP 1139ph	Looper holder clamp screw	1
5	B-1136-019-000 191136	Thread cutter holding plate, outer	1	12	B-2514-019-000 192514	Looper (B)	1
6	B-1163-019-0A0 191163	Looper cover, left assembly	1	13	B-2513-019-000 192513	Looper (A)	1
7	B-1167-019-000 191167	...Guide pin	1	14	B-2507-019-000 192507	Needle guard	1
6. THREAD TENSION & PRESSER LIFTER COMP. (Cont.)				15	B-2509-019-000 192509	Needle guard holder	1
39	B-1903-019-000 191903	Thread take-up tension lever	1	16	SS-8150410-SP 1558ph	...Screw	1
40	B-1904-019-000 191904	...Washer	1	17	SS-7092360-SP 0943ph	Screw, for needle guard	1
41	SS-7090710-SP	...Screw	1	18	B-2510-019-000 192510	Looper thread eyelet	1
42	B-1146-019-000 191146	Frame thread guide	1	19	SS-6080710-SP 0833ph	...Screw	1
43	SS-4090610-SP 0927ph	...Screw	1	20	B-1166-019-000 191166	Looper cover spring	1
44	B-1414-019-000 191414	Needle bar thread guide	1	21	SS-7110710-SP 1123ph	...Screw	1
45	SS-7090710-SP 0922ph	...Screw	1	22	B-1160-019-0A0 191160	Looper cover, right assembly	1
46	B-1159-041-000 411159	Medallion	1	23	B-1604-019-000 191604	Feed dog	1
47	B-1153-019-000 191153	Model plate	1	24	SS-7621040-SP 6221ph	...Screw	1
48	B-1161-012-000 121161	Rivet, for model plate & number plate	4	25	B-1108-019-000 191108	Throat plate	1
49	B-1199-019-000 191199	Number plate	1	26	SS-2110920-SP 1101ph	...Screw	3

7. PRESSER BAR & NEEDLE BAR COMPONENTS



Ref. No.	Part No.	Description	Amt. Req.	Ref. No.	Part No.	Description	Amt. Req.
1	B-1502-019-000 191502	Presser bar upper bushing	1	21	B-1409-019-000 191409	Needle bar connection	1
2	SS-8150310-SP 1560ph	...Screw, for presser bar	2	22	SS-7090910-SK 0941fh	...Clamp screw	1
3	B-1506-019-000 191506	Presser bar steel ball	1	23	B-1404-026-000 261404	Needle bar lower bushing	1
4	B-1501-019-000 191501	Presser bar	1	24	B-1406-019-000 191406	Needle clamp	1
5	B-1504-019-000 191504	Presser bar lifting bracket	1	25	MTV-100#1600	Needle	2
6	SS-7111110-TP 1137ph	...Clamp screw	1	26	SS-8110310-SP 1156ph	...Screw	2
7	B-1503-019-000 191503	Presser bar lower bushing	1	27	B-1412-038-000 381412	Needle bar connection slide "block guide"	1
8	B-1507-019-0A0 191507S	Presser foot assembly	1	28	SS-7120910-SP 1222ph	...Clamp screw	2
9	SS-7091110-SP 0929ph	...Screw	1	29	B-1411-019-000 191411	Needle bar connection slide block	1
10	B-1402-019-000 191402	Needle bar upper bushing	1	30	B-1408-038-000 381408	Needle bar connecting link	1
11	SS-8150410-SP 1156ph	...Screw, for needle bar bushing	2	31	B-1209-019-000 191209	Needle bar connecting link pin	1
12	B-1906-019-000 191906	Take-up thread eyelet	1	32	TA-0290601-M0 T0292	...Plug	1
13	SS-3060410-SP 0674ph	...Screw	1	33	B-1236-125-0A0 1251236S	Needle roller assembly	1
14	B-1901-019-000 191901	Thread take-up	1	34	B-1207-019-000 191207	Counterweight	1
15	SS-6090620-SP 0940ph	...Clamp screw	1	35	SS-6151220-SK 1524fh	...Screw	2
16	B-1908-019-000 191908	Thread take-up tension plate	1	36	SS-8660610-TP 6651ph	Screw, for needle bar connecting link pin	2
17	SD-0280401-SL D028001h	...Screw stud	1	37	B-1221-019-000 191221	Arm rotary shaft ball bearing oil retainer (B)	1
18	B-1910-019-000 191910	Thread take-up tension spring	1	38	B-1218-019-000 191218	Arm rotary shaft ball bearing, front	1
19	B-1401-019-000 191401	Needle bar	1	39	B-1220-019-000 191220	Arm rotary shaft ball bearing oil retainer (A)	1
20	B-1418-019-000 191418	Needle bar connection oil supply felt	1	40	B-1207-019-0A0 191207S	Counterweight assembly	(1)

8. NUMERICAL INDEX OF PARTS

Part No.	Page	Ref. No.	Part No.	Page	Ref. No.	Part No.	Page	Ref. No.	Part No.	Page	Ref. No.
EXCLUSIVE PARTS			B-1204-019-000	5—	1	B-1611-019-000	4—	30	B-2210-019-000	5—	26
B-1101-019-000	3—	1	191204			191611			192210		
191101			B-1205-019-000	5—	2	B-1613-019-000	4—	27	B-2211-019-000	1—	6
B-1104-019-000	3—	39	191205			191613			192211		
191104			B-1205-019-000	5—	29	B-1613-019-0A0	4—	49	B-2212-019-000	1—	7
B-1105-019-000	3—	37	191205						192212		
191105			B-1207-019-000	8—	34	B-1614-019-000	4—	32	B-2213-019-000	1—	8
B-1108-019-000	7—	25	191207			191614			192213		
191108			B-1207-019-0A0	8—	40	B-1617-019-000	4—	21	B-2214-019-000	1—	10
B-1111-019-000	3—	25				191617			192214		
191111			B-1209-019-000	8—	31	B-1801-019-000	5—	34	B-2215-019-000	1—	9
B-1113-019-000	1—	31	191209			191801			192215		
191113			B-1211-019-000	5—	7	B-1802-019-000	5—	22	B-2220-019-000	1—	5
B-1114-019-000	1—	32	191211			191802			192220		
191114			B-1212-019-000	5—	33	B-1803-019-000	5—	23	B-2224-019-000	1—	21
B-1115-019-000	1—	27	191212			191803			192224		
191115			B-1214-019-000	5—	6	B-1805-019-000	3—	27	B-2226-019-000	1—	22
B-1116-019-0A0	3—	30	191214			191805			192226		
191116S			B-1215-019-000	5—	9	B-1806-019-000	3—	29	B-2301-019-000	6—	19
B-1117-019-000	3—	24	191215			191806			192301		
191117			B-1218-019-000	8—	38	B-1808-019-000	5—	25	B-2303-019-000	6—	16
B-1119-019-000	3—	35	191218			191808			192303		
191119			B-1219-019-000	3—	23	B-1810-019-000	5—	31	B-2306-019-000	6—	21
B-1120-019-000	3—	33	191219			191810			192306		
191120			B-1220-019-000	8—	39	B-1811-019-000	5—	28	B-2307-019-000	6—	23
B-1134-019-000	3—	36	191220			191811			192307		
191134			B-1221-019-000	8—	37	B-1901-019-000	8—	14	B-2310-019-000	6—	22
B-1135-019-000	7—	3	191221			191901			192310		
191135			B-1222-019-000	5—	20	B-1903-019-000	6—	39	B-2311-019-000	6—	27
B-1136-019-000	7—	5	191222			191903			192311		
191136			B-1236-125-0A0	8—	33	B-1904-019-000	6—	40	B-2312-019-000	6—	28
B-1137-019-000	7—	2	1251236S			191904			192312		
191137			B-1401-019-000	8—	19	B-1906-019-000	8—	12	B-2313-019-000	6—	26
B-1139-019-000	3—	5	191401			191906			192313		
191139			B-1402-019-000	8—	10	B-1908-019-000	8—	16	B-2315-019-000	6—	12
B-1140-019-000	3—	6	191402			191908			192315		
191140			B-1404-026-000	8—	23	B-1910-019-000	8—	18	B-2317-019-000	6—	14
B-1141-019-000	1—	34	261404			191910			192317		
191141			B-1406-019-000	8—	24	B-2001-019-000	4—	40	B-2319-019-000	6—	7
B-1143-019-000	1—	41	191406			192001			192319		
191143			B-1408-038-000	8—	30	B-2002-019-000	4—	41	B-2321-019-000	6—	11
B-1144-019-0A0	1—	40	381408			192002			192321		
191144S			B-1409-019-000	8—	21	B-2004-019-000	4—	44	B-2322-019-000	6—	9
B-1146-019-000	6—	42	191409			192004			192322		
191146			B-1411-019-000	8—	29	B-2006-019-000	4—	47	B-2324-019-000	6—	3
B-1148-019-000	3—	12	191411			192006			192324		
191148			B-1412-038-000	8—	27	B-2101-019-000	4—	1	B-2326-019-000	6—	1
B-1152-019-000	3—	16	381412			192101			192326		
191152			B-1414-019-000	4—	44	B-2102-019-000	4—	16	B-2327-019-000	6—	5
B-1153-019-000	6—	47	191414			192102			192327		
191153			B-1418-019-000	8—	20	B-2103-019-000	4—	6	B-2328-019-000	6—	6
B-1155-019-000	3—	2	191418			192103			192328		
191155			B-1501-019-000	8—	4	B-2105-019-000	4—	3	B-2329-019-0A0	6—	4
B-1156-019-000	3—	17	191501			192105			192329S		
191156			B-1502-019-000	8—	1	B-2106-019-000	4—	11	B-2401-019-000	6—	37
B-1157-019-000	3—	15	191502			192106			192401		
191157			B-1503-019-000	8—	7	B-2107-019-000	4—	12	B-2402-019-000	6—	30
B-1159-041-000	6—	46	191503			192107			192402		
411159			B-1504-019-000	8—	5	B-2108-019-000	4—	4	B-2404-019-000	6—	35
B-1160-019-0A0	7—	22	191504			192108			192404		
191160			B-1506-017-000	8—	3	B-2109-019-0A0	4—	17	B-2406-019-000	3—	20
B-1161-012-000	6—	48	191506			192109S			192406		
121161			B-1507-019-0A0	8—	8	B-2115-019-000	4—	8	B-2412-019-0A0	1—	25
B-1163-019-0A0	7—	6	191507S			192115			192412		
191163			B-1601-019-000	4—	18	B-2116-019-000	4—	9	B-2413-019-000	1—	24
B-1166-019-000	7—	20	191601			192116			192413		
191166			B-1602-019-000	4—	24	B-2117-019-000	4—	10	B-2413-026-A00	1—	36
B-1167-019-000	7—	7	191602			192117			262413A		
191167			B-1604-019-000	7—	23	B-2122-019-000	4—	14	B-2413-026-B00	1—	38
B-1199-019-000	6—	49	191604			192122			262413B		
191199			B-1606-019-000	4—	26	B-2201-019-000	1—	1	B-2414-026-000	1—	39
B-1201-019-000	5—	19	191606			192201			262414		
191201			B-1607-019-000	4—	23	B-2202-019-000	1—	3	B-2414-019-000	1—	29
B-1202-019-000	5—	3	191607			192202			182414S		
191202			B-1607-019-000	4—	46	B-2203-019-000	1—	16	B-2415-019-000	1—	28
B-1202-019-000	5—	30	191607			192203			192415		
191202			B-1608-019-000	4—	19	B-2207-026-000	1—	18	B-2416-019-000	1—	23
B-1203-019-000	5—	4	191608			192207			192416		
191203			B-1610-019-000	4—	22	B-2208-019-000	1—	19	B-2418-019-000	3—	22
			191610			192208			192418		

Part No.	Page	Ref. No.	Part No.	Page	Ref. No.	Part No.	Page	Ref. No.	Part No.	Page	Ref. No.
B-2420-019-000 192420	6-32		NS-6120310-SP N122ph	6-2		SS-6151440-SP 1525ph	3-40		SS-7161040-SP 1624ph	5-35	
B-2421-019-000 192421	6-33		RO-0952001-00 OG09520	4-2		SS-7060310-SP 0622ph	1-4		SS-7621040-SP 6221ph	7-24	
B-2501-019-000 192501	4-37		SD-0280401-SL D02800h	8-17		SS-7060310-SP 0622ph	1-11		SS-7740740-SP 7421ph	5-21	
B-2502-019-000 192502	4-38		SD-0450211-SP D04500h	6-13		SS-7060310-SP 0622ph	1-35		SS-8110310-SP 1156ph	8-26	
B-2503-019-000 192503	4-33		SD-0790431-SP D079414h	6-10		SS-7060310-SP 0622ph	3-8		SS-8110320-SP 1153ph	5-24	
B-2505-019-000 192505	4-35		SS-1090920-SP 0907ph	3-10		SS-7060310-SP 0622ph	3-34		SS-8110410-TP 1152ph	4-48	
B-2507-019-000 192507	7-14		SS-2060310-SP	1-37		SS-7090410-SP 0946ph	1-2		SS-8111160-SP 1154ph	6-18	
B-2509-019-000 192509	7-15		SS-2110920-SP 1101ph	7-26		SS-7090510-SP 0923ph	6-34		SS-8150310-SP 1560ph	8-2	
B-2510-019-000 192510	7-18		SS-3060410-SP 0674ph	8-13		SS-7090520-SP 0921ph	1-12		SS-8150410-SP 1558ph	4-34	
B-2513-019-000 192513	7-13		SS-3060710-SP 0673ph	7-4		SS-7090520-SP 0921ph	6-36		SS-8150410-SP 1558ph	4-43	
B-2514-019-000 192514	7-12		SS-3090510-SP 0971ph	1-17		SS-7090530-SP 0972ph	1-14		SS-8150410-SP 1558ph	7-16	
B-2515-019-000 192515	7-8		SS-3090710-TP 0940ph	1-42		SS-7090610-SK 09210fh	4-28		SS-8150410-SP 1156ph	8-11	
B-2516-019-000 192516	7-10		SK-3552000-SC	3-14		SS-7090710-SP 0922ph	1-15		SS-8110510-SP 1151ph	4-5	
B-3101-019-000 193101	3-3		SS-4090610-SP 0927ph	6-43		SS-7090710-SP	6-41		SS-8150710-SP 1555ph	4-15	
B-3102-019-000 193102	3-9		SS-4091010-SP 0926ph	1-33		SS-7090710-SP 0922ph	6-45		SS-8151150-SK 1552fh	4-20	
B-3103-019-000 193103	3-11		SS-4091010-SP 0926ph	3-21		SS-7090850-SP 0976ph	3-31		SS-8151150-SK 1552fh	4-31	
B-3104-019-000 193104	3-7		SS-4091010-SP 0926ph	6-38		SS-7091110-SP 0929ph	8-9		SS-8151150-SP 1552ph	4-39	
B-3106-019-000 193106	3-4		SS-4622340-SP 6222ph	6-20		SS-7090910-SK 0941fh	8-22		SS-8151550-SP 1554ph	1-26	
B-3126-012-000 123126	6-24		SS-5060410-SP 0677ph	6-31		SS-7091480-SK 0944fh	7-9		SS-8152030-fh 1556ph	5-10	
B-3132-012-000 123132	6-25		SS-5090710-SP 0973ph	1-30		SS-7092360-SP 0943ph	7-17		SS-8660330-SP 6652ph	5-27	
B-3501-019-000 193501	5-11		SS-5091020-SP 0938ph	3-32		SS-7110710-SP 1123ph	6-15		SS-8660610-SP 6651ph	4-7	
B-3502-019-000 913502	5-12		SS-5660440-SP 6671ph	5-17		SS-7110710-SP 1123ph	7-21		SS-8660610-TP 6651ph	3-19	
B-3503-019-000 193503	5-13		SS-6060210-SP 0621ph	1-20		SS-7110830-SP 1138ph	4-13		SS-8660610-TP 6651ph	8-36	
B-3504-019-000 193504	5-14		SS-6080710-SP 0833ph	7-19		SS-7110830-SP 1138ph	8-36		SS-8701140-SP 7051ph	5-5	
B-3505-019-000 193505	5-16		SS-6090620-SP 0940ph	3-28		SS-7111110-TP 1137ph	4-25		SS-9150860-SK 1582fh	5-8	
B-3508-019-000 193508	5-18		SS-6090620-SP 0940ph	8-15		SS-7111110-TP 1137ph	4-36		SS-9284042-CP 2881ph	3-38	
B-3701-019-000 193701	6-8		SS-6092120-SP 0945ph	5-15		SS-7111110-TP 1137ph	4-45		TA-0290621-MO T0282	8-32	
B-9100-019-0A0 M9100S	7-1		SS-6111040-SP 1139ph	7-11		SS-7111110-TP 1137ph	8-6		WP-0371016-SP W371p	1-13	
SCREWS & OTHER PARTS			SS-6121840-SP 1228ph	4-42		SS-7120910-SP 1222ph	5-32		WP-0480856-SP W481ph	4-29	
MTV-100 # 1600	8-25		SS-6151220-SK 1524fh	8-35		SS-7120910-SP 1222ph	8-28				
NS-6110310-SP N113ph	6-17		SS-6151440-SN	3-13		SS-7151210-SP 1522Ah	3-26				