



Form 2629w

(240)


PRINTED IN U. S. A.

SINGER


144 w 302



THE SINGER MANUFACTURING COMPANY




120342



120343

225498



225497



41400



225554



Copyright, U. S. A., 1939 and 1940
by The Singer Manufacturing Co.
All Rights Reserved for all Countries

16124 - 3/8

237043

200383C

200429C

202301

237523

200437C

224108

200383C

200256C

201525E

237521

200602E

202253

224104

200327C



202277

201522E

200833C

202330

200049D

200607C

261602



261638

261635

201517E


201171C

202277



16127 - 3/4

261645



201253F

265095


265096

265092

265097

200583H

*265091



265093

261650

261647


261648

261649


200597E

200983F


265089




265090




16/30 - 1/2




16/28 - 5/8




16132 - 1/2






16140 - 1/3





16134









265084

236787

202784

265082

265080

265083

264530

264531

264536

356C

265081

356C

356C

264536

356C

202468

200530C

204126

227980

