


MACHINE PARTS CHART for SINGER*

17U130
17U141
17U142

* A Trademark of THE SINGER COMPANY
© THE SINGER COMPANY 1968

Printed in Japan





CLOTH PLATE
FOR MACHINES 17U130 AND 17U141

PART NO.	DESCRIPTION
547784	Cloth Plate
547785	Cloth Plate Bracket
547858	Cloth Plate Bracket Set Screw
549105 (853)	Cloth Plate Screw (2)
547860	Cloth Plate Slide
547849	Cloth Plate Slide Spring
549148 (832)	Cloth Plate Slide Spring Screw (2)

CLOTH PLATE
FOR MACHINE 17U142

PART NO.	DESCRIPTION
549706	Cloth Plate
547857	Cloth Plate Bracket
547858	Cloth Plate Bracket Set Screw
549105 (853)	Cloth Plate Screw (2)
547860	Cloth Plate Slide
547849	Cloth Plate Slide Spring
549148 (832)	Cloth Plate Slide Spring Screw (2)
549708	Cloth Plate Washer (2)

ROLLER PRESSER
FOR MACHINES 17U130 AND 17U141

PART NO.	DESCRIPTION
547735	Roller with 549061 (810) and 545454 (809)
547736	Roller Arm
504144 (810)	Roller Arm Adjusting Screw
547737	Roller Arm Adjusting Screw 504144 (810) with 545454 (809)
545454 (809)	Roller Arm Adjusting Screw Nut
547738	Roller Arm Bracket
2205	Roller Arm Lock Spring
549060 (810)	Roller Arm Lock Spring Screw
545455 (809)	Roller Arm Lock Spring Screw Nut
549059 (810)	Roller Arm Screw Center (2)
547739	Roller Arm Screw Center 549059 with 545454 (809)
545454 (809)	Roller Arm Screw Center Nut (2)
547740	Roller Presser complete, (7/8" fine roller) Nos. 2205, 545455 (809), 547735, 547736, 547737, 547738, 549060 (810) and two 547739
549061 (810)	Roller Screw
545454 (809)	Roller Screw Nut

ACCESSORIES FOR MACHINE 17U142

PART NO.	DESCRIPTION
547794	Drip Pan
547781	Feed Reverse Lever Chain
547778	Feed Reversing Treadle complete
549071 (809)	Machine Bolt (4)
547766	Machine Bolt 549071 (809) with 545464 (809) and 6055
545464 (809)	Machine Bolt Nut (4)
6055	Machine Bolt Washer (4)
547773	Motor Treadle Lever
2083 (16x2)	Needle (6)
546906	Oiler (filled with Singer Type "B" Oil)
2180	Presser Foot
PN963	Screw Driver (large)
PN964	Screw Driver (small)
2073	Shuttle Bobbin (4)
4918	Wrench (for 545456)
547930	Wrench (for 154981)
547846	Wrench (for 545454 and 545455)

KNEE LIFTER PARTS FOR MACHINES 17U130, 17U141 AND 17U142

PART NO.	DESCRIPTION
47829	Presser Bar Lifter Lever Chain
505397	Rock Shaft
547779	Rock Shaft complete, Nos. 505397, 547832, 547833 and two each 505651, 505398 and four Wood Screws (1 in. No. 10)
505398	Rock Shaft Hanger (2)
547831	Rock Shaft Knee Arm
547832	Rock Shaft Knee Arm complete, Nos. 504510 (809), 547831, 505400 and 505402
504510 (809)	Rock Shaft Knee Arm Clamping Nut
505400	Rock Shaft Knee Arm Hub with 504105 (809)
504105 (809)	Rock Shaft Knee Arm Hub Set Screw
505402	Rock Shaft Knee Plate with 504105 (809)
504105 (809)	Rock Shaft Knee Plate Set Screw
547833	Rock Shaft Lifting Bracket with 6338 and two 504105 (809)
6338	Rock Shaft Lifting Bracket Hook
504105 (809)	Rock Shaft Lifting Bracket Hook Set Screw
504105 (809)	Rock Shaft Lifting Bracket Set Screw
505651	Rock Shaft Stop Dog with 504105 (809)
504105 (809)	Rock Shaft Stop Dog Set Screw (2)









BOBBIN WINDER FOR MACHINES 17U130, 17U141 AND 17U142

PART NO.	DESCRIPTION
547787	Universal Bobbin Winder complete, Nos. 545962, 545963, 545965, 545966, 545968, 545969, 545970, 545971, 545976, 545977, 545978, 545979, 547788, 549200 (819), 549201 (819), 549202 (819), 549203 (819), 549205 and two 545980 with two 5.5x19 Wood Screws

PART NO.	DESCRIPTION
545979	Bobbin Winder and Tension Bracket Base
545977	Bobbin Winder Brake
545978	Bobbin Winder Brake Clamp
549202 (819)	Bobbin Winder Brake Clamp Screw
545966	Bobbin Winder Frame with 545967
549205	Bobbin Winder Frame Hinge Pin
545967	Bobbin Winder Frame Oil Cup
545968	Bobbin Winder Frame Spring
545969	Bobbin Winder Frame Spring Plunger
545962	Bobbin Winder Pulley with 549204 (819)
549204 (819)	Bobbin Winder Pulley Set Screw
547788	Bobbin Winder Spindle
545965	Bobbin Winder Stop Latch
549200 (819)	Bobbin Winder Stop Latch Screw
545970	Bobbin Winder Stop Latch Thumb Lever
545980	Bobbin Winder Stop Latch Thumb Lever Hinge Stud (2)
545963	Bobbin Winder Stop Latch Trip Lever
549203 (819)	Bobbin Winder Stop Latch Trip Lever Hinge Screw
545973	Bobbin Winder Tension Bracket with 545974
545971	Bobbin Winder Tension complete, Nos. 545470 (819), 545972, 545973 and two 545975
549201 (819)	Bobbin Winder Tension Bracket Screw
545976	Bobbin Winder Tension Bracket Screw Washer
545975	Bobbin Winder Tension Disc (2)
545972	Bobbin Winder Tension Spring
545974	Bobbin Winder Tension Stud
545470 (819)	Bobbin Winder Tension Stud Thumb Nut
	Wood Screw 5.5x19 (2)


THREAD UNWINDER FOR MACHINES 17U130, 17U141 AND 17U142

PART NO.	DESCRIPTION
505656	Thread Unwinder (for two spools) complete, Nos. 545465 (856), 545466 (856), 545467 (856), 546727, 546728, 546729, 546730, 546734, 546735, 546736, 546738, 546740, three 549171 and two each 545468 (856), 546732, 546733, 546737, 546739 and 546741
546732	Thread Unwinder Spool Pin (2)
545468 (856)	Thread Unwinder Spool Pin Nut (2)
546739	Thread Unwinder Spool Pin Spring Washer (2)
546741	Thread Unwinder Spool Pin Washer (2)
546738	Thread Unwinder Spool Rest Bushing with 549172 (850)
545466 (856)	Thread Unwinder Spool Rest Bushing Nut
546736	Thread Unwinder Spool Rest Bushing Nut Washer
549172 (850)	Thread Unwinder Spool Rest Bushing Set Screw
546737	Thread Unwinder Spool Rest Felt (2)
546730	Thread Unwinder Spool Rest (for two spools)
546728	Thread Unwinder Spool Rest Rod (lower)
549170 (828)	Thread Unwinder Spool Rest Rod (lower) Set Screw
546729	Thread Unwinder Spool Rest Rod (upper)
545467 (856)	Thread Unwinder Spool Rest Rod (upper) Nut
546727	Thread Unwinder Spool Stand with 549170 (828)
546733	Thread Unwinder Thread Guide (2)
545465 (856)	Thread Unwinder Thread Guide Lock Nut
546740	Thread Unwinder Thread Guide Lock Nut Spring Washer
546734	Thread Unwinder Thread Guide Position Cup
546735	Thread Unwinder Thread Guide Rod Washer
549171	Wood Screw No. 10x1 inch (3)




PARTS ONLY FOR MACHINE

17U130



PARTS ONLY FOR MACHINE




17U142



549703

- 549712
- 547790
- 549709
- 545325
- 549056

549712



NUMERICAL LIST OF PARTS FOR MACHINES 17U130, 17U141 AND 17U142

PART NO.	17U 130	17U 141	17U 142	DESCRIPTION	PART NO.	17U 130	17U 141	17U 142	DESCRIPTION
229 (850)	*	*	*	Face Plate Thread Guard (upper) Screw	545256 (850)	*	*	*	Presser Bar Lifter Lever Hinge Screw
229 (850)	*	*	*	Thread Take-up Spring Regulator Plate	545284 (802)	*	*	*	Arm Shaft Screw
2070	*	*	*	Adjusting Screw	545306 (805)	*	*	*	Throat Plate Holder Screw (2)
2073	*	*	*	Presser Bar Spring Washer	545325 (809)	*	*	*	Shuttle Race Ring Screw (2)
2102	*	*	*	Shuttle Bobbin	545382 (850)	*	*	*	Machine Pulley Set Screw (2)
2105	*	*	*	Tension Disc (2)	545404 (856)	*	*	*	Tension Regulating Thumb Nut
2113	*	*	*	Tension Thread Guard	545454 (809)	*	*	*	Roller Arm Adjusting Screw Nut
2114	*	*	*	Thread Retaining Disc Steady Pin	545454 (809)	*	*	*	Roller Arm Screw Center Nut (2)
2115	*	*	*	Thread Retaining Spring	545454 (809)	*	*	*	Roller Screw Nut
2124	*	*	*	Thread Retaining Stud	545455 (809)	*	*	*	Roller Arm Lock Spring Screw Nut
2127	*	*	*	Thread Take-up Spring	545456 (851)	*	*	*	Pressure Regulating Thumb Screw Lock Nut
2205	*	*	*	Thread Take-up Spring Regulator Plate	545819	*	*	*	Feed Regulating Stud Lock Pin
2308	*	*	*	Roller Arm Lock Spring	545820	*	*	*	Feed Regulating Stud Lock Pin Spring
3045	*	*	*	Presser Bar Spring	547633	*	*	*	Tension Releaser Hinge Pin
12424	*	*	*	Needle Bar Connecting Link	547703	*	*	*	Arm Shaft
16242	*	*	*	Oscillating Shaft Crank Slide Block Cap Screw Washer	547706	*	*	*	Arm Side Cover
32016	*	*	*	Shuttle Race Ring Cover Latch	547707	*	*	*	Crank Connecting Rod with 125044 and two 504071 (833)
52165	*	*	*	Presser Bar Lifter	547709	*	*	*	Face Plate with 2105
2239	*	*	*	Feed Connecting Link	547710	*	*	*	Face Plate complete, Nos. 504029 (833), 549056 (833), 504149 (809), 56870, 547780, 547755, 2127, 547633, 547963, 547751, 547709 and two 229 (809)
56870	*	*	*	Arm Spool Pin and Thread Eyelet	547712	*	*	*	Feed Dog Carrier
5163	*	*	*	Face Plate Thread Guard (upper)	547714	*	*	*	Feed Regulating Stud Head
65169	*	*	*	Presser Foot (narrow toe)	547715	*	*	*	Feed Regulating Stud Head 547714 with two Feed Regulating Stud Head Stop Plate
5170	*	*	*	Shuttle Race Thread Protector	547716	*	*	*	Feed Regulator
99662	*	*	*	Throat Plate	547717	*	*	*	Feed Regulator 547716 with 547782 and 549082 (850)
25044	*	*	*	Feed Reverse Lever Return Spring	547718	*	*	*	Feed Rock Shaft 547775 with 547712
125314	*	*	*	Crank Connecting Rod Oil Pad (felt)	547719	*	*	*	Feed Rock Shaft Crank with 545236 (803)
54759 (850)	*	*	*	Tension Spring	547720	*	*	*	Machine Pulley with two 545382 (850)
54759 (850)	*	*	*	Crank Connecting Rod Hinge Screw	547721	*	*	*	Needle Bar
54759 (850)	*	*	*	Feed Connecting Link Hinge Screw (2)	547722	*	*	*	Needle Bar Connecting Link 3045 with 547723
154777 (850)	*	*	*	Feed Forked Connection Hinge Screw	547723	*	*	*	Needle Bar Connecting Stud with 154777 (850)
54981 (819)	*	*	*	Needle Bar Connecting Stud Set Screw	547725	*	*	*	Oscillating Rock Shaft with 547791
154981 (819)	*	*	*	Crank Connecting Rod Hinge Screw Nut	547726	*	*	*	Oscillating Rock Shaft complete, Nos. 547725 and 547728
154981 (819)	*	*	*	Feed Connecting Link Hinge Screw Nut (2)	547727	*	*	*	Oscillating Rock Shaft Hinge Pin
154981 (819)	*	*	*	Feed Forked Connection Hinge Screw Nut	547728	*	*	*	Oscillating Rock Shaft Hinge Pin 547727 with 504504 (819)
4981 (819)	*	*	*	Needle Bar Connecting Link Hinge Screw Nut	547729	*	*	*	Oscillating Shaft
4002 (850)	*	*	*	Arm Shaft Bushing (intermediate) Set Screw	547730	*	*	*	Oscillating Shaft 547729 with 547774, 547777 and 548170
4002 (850)	*	*	*	Feed Cam Set Screw	547731	*	*	*	Oscillating Shaft Crank
504002 (850)	*	*	*	Feed Regulating Stud Bushing Set Screw	547732	*	*	*	Presser Bar
504004 (852)	*	*	*	Arm Side Cover Thumb Screw	547733	*	*	*	Presser Bar Lifter Bracket with 504056 (830)
504004 (852)	*	*	*	Cylinder Side Cover Thumb Screw	547734	*	*	*	Presser Bar Lifter Lever
504029 (833)	*	*	*	Belt Safety Guard Set Screw (2)	547735	*	*	*	Roller with 549061 (810) and 545454 (809)
504029 (833)	*	*	*	Tension Screw Stud Set Screw	547736	*	*	*	Roller Arm
504056 (830)	*	*	*	Presser Bar Lifter Bracket Set Screw	547737	*	*	*	Roller Arm Adjusting Screw 504144 (810) with 545454 (809)
504063 (810)	*	*	*	Presser Foot Screw	547738	*	*	*	Roller Arm Bracket
504063 (810)	*	*	*	Roller Presser Screw	547739	*	*	*	Roller Arm Screw Center 549059 (810) with 545454 (809)
504064 (805)	*	*	*	Arm Screw (3)	547740	*	*	*	Roller Presser complete, (7/8" fine roller) Nos. 2205, 545455 (809), 547735, 547736, 547737, 547738, 549060 (810) and two 547739
504071 (833)	*	*	*	Crank Connecting Rod Cap Screw (2)	547741	*	*	*	Feed Forked Connection
504074 (850)	*	*	*	Feed Regulating Stud Head Cap Screw					
504080 (851)	*	*	*	Face Plate Screw (3)					
504091 (803)	*	*	*	Feed Dog Screw					
504099 (809)	*	*	*	Feed Reverse Lever Return Spring Bracket Screw					
504101 (833)	*	*	*	Belt Safety Guard Shaft Set Screw					
504144 (810)	*	*	*	Roller Arm Adjusting Screw					
504149 (805)	*	*	*	Face Plate Thread Guard (lower) Screw					
504504 (819)	*	*	*	Oscillating Rock Shaft Hinge Pin Lock Nut					
5001	*	*	*	Arm Dowel Pin (2)					
505008	*	*	*	Arm Spool Pin Washer (felt)					
5055 (833)	*	*	*	Oscillating Shaft Crank Set Screw					
545232 (833)	*	*	*	Arm Shaft Bushing (back) Set Screw					
5222 (833)	*	*	*	Thread Take-up Cam Set Screw					
545256 (850)	*	*	*	Feed Rock Shaft Crank Set Screw					

NUMERICAL LIST OF PARTS FOR MACHINES 170130, 170141 AND 170142

PART NO.	170 130	170 141	170 142	DESCRIPTION	PART NO.	170 130	170 141	170 142	DESCRIPTION
229 (809)	*	*	*	Face Plate Thread Guard (upper) Screw	545256 (850)	*	*	*	Presser Bar Lifter Lever Hinge Screw
229 (809)	*	*	*	Thread Take-up Spring Regulator Plate Adjusting Screw	545284 (802)	*	*	*	Arm Shaft Screw
2070	*	*	*	Presser Bar Spring Washer	545306 (805)	*	*	*	Throat Plate Holder Screw (2)
2073	*	*	*	Shuttle Bobbin	545325 (809)	*	*	*	Shuttle Race Ring Screw (2)
2102	*	*	*	Tension Disc (2)	545382 (850)	*	*	*	Machine Pulley Set Screw (2)
2105	*	*	*	Tension Thread Guard	545404 (856)	*	*	*	Tension Regulating Thumb Nut
2113	*	*	*	Thread Retaining Disc Steady Pin	545454 (809)	*	*	*	Roller Arm Adjusting Screw Nut
2114	*	*	*	Thread Retaining Spring	545454 (809)	*	*	*	Roller Arm Screw Center Nut (2)
2115	*	*	*	Thread Retaining Stud	545454 (809)	*	*	*	Roller Screw Nut
2124	*	*	*	Thread Take-up Spring	545455 (809)	*	*	*	Roller Arm Lock Spring Screw Nut
2127	*	*	*	Thread Take-up Spring Regulator Plate	545456 (851)	*	*	*	Pressure Regulating Thumb Screw Lock Nut
2205	*	*	*	Roller Arm Lock Spring	545819	*	*	*	Feed Regulating Stud Lock Pin
2308	*	*	*	Presser Bar Spring	545820	*	*	*	Feed Regulating Stud Lock Pin Spring
3045	*	*	*	Needle Bar Connecting Link	547633	*	*	*	Tension Releaser Hinge Pin
12424	*	*	*	Oscillating Shaft Crank Slide Block Cap Screw Washer	547703	*	*	*	Arm Shaft
16242	*	*	*	Shuttle Race Ring Cover Latch	547706	*	*	*	Arm Side Cover
52016	*	*	*	Presser Bar Lifter	547707	*	*	*	Crank Connecting Rod with 125044 and two 504071 (833)
52165	*	*	*	Feed Connecting Link	547709	*	*	*	Face Plate with 2105
52239	*	*	*	Arm Spool Pin and Thread Eyelet	547710	*	*	*	Face Plate complete, Nos. 504029 (833), 549056 (833), 504149 (809), 56870, 547780, 547755, 2127, 547633, 547963, 547751, 547709 and two 229 (809)
56870	*	*	*	Face Plate Thread Guard (upper)					
65163	*	*	*	Presser Foot (narrow toe)					
65169	*	*	*	Shuttle Race Thread Protector	547712	*	*	*	Feed Dog Carrier
65170	*	*	*	Throat Plate	547714	*	*	*	Feed Regulating Stud Head
99662	*	*	*	Feed Reverse Lever Return Spring	547715	*	*	*	Feed Regulating Stud Head 547714 with two Feed Regulating Stud Head Stop Plate
125044	*	*	*	Crank Connecting Rod Oil Pad (felt)					
125314	*	*	*	Tension Spring	547716	*	*	*	Feed Regulator
154759 (850)	*	*	*	Crank Connecting Rod Hinge Screw	547717	*	*	*	Feed Regulator 547716 with 547782 and 549082 (850)
154759 (850)	*	*	*	Feed Connecting Link Hinge Screw (2)					
154759 (850)	*	*	*	Feed Forked Connection Hinge Screw	547718	*	*	*	Feed Rock Shaft 547775 with 547712
154777 (850)	*	*	*	Needle Bar Connecting Stud Set Screw	547719	*	*	*	Feed Rock Shaft Crank with 545236 (803)
154981 (819)	*	*	*	Crank Connecting Rod Hinge Screw Nut	547720	*	*	*	Machine Pulley with two 545382 (850)
154981 (819)	*	*	*	Feed Connecting Link Hinge Screw Nut (2)	547721	*	*	*	Needle Bar
154981 (819)	*	*	*	Feed Forked Connection Hinge Screw Nut	547722	*	*	*	Needle Bar Connecting Link 3045 with 547723
154981 (819)	*	*	*	Needle Bar Connecting Link Hinge Screw Nut	547723	*	*	*	Needle Bar Connecting Stud with 154777 (850)
504002 (850)	*	*	*	Arm Shaft Bushing (intermediate) Set Screw	547725	*	*	*	Oscillating Rock Shaft with 547791
504002 (850)	*	*	*	Feed Cam Set Screw	547726	*	*	*	Oscillating Rock Shaft complete, Nos. 547725 and 547728
504002 (850)	*	*	*	Feed Regulating Stud Bushing Set Screw	547727	*	*	*	Oscillating Rock Shaft Hinge Pin
504004 (852)	*	*	*	Arm Side Cover Thumb Screw	547728	*	*	*	Oscillating Rock Shaft Hinge Pin 547727 with 504504 (819)
504004 (852)	*	*	*	Cylinder Side Cover Thumb Screw					
504029 (833)	*	*	*	Belt Safety Guard Set Screw (2)	547729	*	*	*	Oscillating Shaft
504029 (833)	*	*	*	Tension Screw Stud Set Screw	547730	*	*	*	Oscillating Shaft 547729 with 547774, 547777 and 548170
504056 (830)	*	*	*	Presser Bar Lifter Bracket Set Screw	547731	*	*	*	Oscillating Shaft Crank
504063 (810)	*	*	*	Presser Foot Screw	547732	*	*	*	Presser Bar
504063 (810)	*	*	*	Roller Presser Screw	547733	*	*	*	Presser Bar Lifter Bracket with 504056 (830)
504064 (805)	*	*	*	Arm Screw (3)	547734	*	*	*	Presser Bar Lifter Lever
504071 (833)	*	*	*	Crank Connecting Rod Cap Screw (2)	547735	*	*	*	Roller with 549061 (810) and 545454 (809)
504074 (850)	*	*	*	Feed Regulating Stud Head Cap Screw					
504080 (851)	*	*	*	Face Plate Screw (3)	547736	*	*	*	Roller Arm
504091 (803)	*	*	*	Feed Dog Screw	547737	*	*	*	Roller Arm Adjusting Screw 504144 (810) with 545454 (809)
504099 (809)	*	*	*	Feed Reverse Lever Return Spring Bracket Screw	547738	*	*	*	Roller Arm Bracket
504101 (830)	*	*	*	Belt Safety Guard Shaft Set Screw	547739	*	*	*	Roller Arm Screw Center 549059 (810) with 545454 (809)
504144 (810)	*	*	*	Roller Arm Adjusting Screw					
504149 (809)	*	*	*	Face Plate Thread Guard (lower) Screw	547740	*	*	*	Roller Presser complete, (7/8" fine roller) Nos. 2205, 545455 (809), 547735, 547736, 547737, 547738, 549060 (810) and two 547739
504504 (819)	*	*	*	Oscillating Rock Shaft Hinge Pin Lock Nut	547741	*	*	*	Feed Forked Connection
505001	*	*	*	Arm Dowel Pin (2)					
505008	*	*	*	Arm Spool Pin Washer (felt)					
545056 (833)	*	*	*	Oscillating Shaft Crank Set Screw					
545232 (833)	*	*	*	Arm Shaft Bushing (back) Set Screw					
545232 (833)	*	*	*	Thread Take-up Cam Set Screw					
545236 (803)	*	*	*	Feed Rock Shaft Crank Set Screw					