

MACHINE PARTS CHART for SINGER* 188u

* A Trademark of THE SINGER COMPANY
Copyright © 1973 THE SINGER COMPANY
All Rights Reserved Throughout the World

Cavemac



Controle do Acervo de Catálogos	
Identificação	834
Edição	1973
Conteúdo	SINGER 188U


00000834







SINGER



188u








ATTACHMENTS AND ACCESSORIES



BOBBIN WINDER
(FOR MOTOR DRIVE)

BOBBIN WINDER
(FOR TREADLE OPERATION)



NUMERICAL LIST OF PARTS FOR MACHINE 188U

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
229 (807)	Needle Bar Thread Guard Screw	504066 (833)	Arm Shaft (horizontal) Bevel Gear Set Screw (2)
691	Throat Plate Screw (Spec. 1050) (2)	504067 (850)	Clamp Stop Motion Flanged Bushing Set Screw
2102	Tension Disc (2)	504068 (803)	Feed Bar Screw Center (2)
11170	Presser Bar Spring Washer	504069 (833)	Feed and Feed Lifting Eccentric Position Screw
12431-451	Bed Slide (Spec. 1019)	504070 (850)	Feed and Feed Lifting Eccentric Set Screw
32618	Clamp Stop Motion Flanged Bushing	504071 (833)	Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw (2)
32758	Thread Take-up Spring	504072 (803)	Feed Lifting Rock Shaft Screw Center (2)
36555	Thread Cutter and Holder	504072 (803)	Feed Rock Shaft Screw Center (2)
52016	Presser Bar Lifter	504073 (803)	Feed Regulating Stud
52018	Rotating Hook Bobbin Case Holder Position Bracket	504074 (852)	Feed Regulating Stud Head Cap Screw
52022	Thread Take-up Lever	504075 (830)	Feed Reverse Lever Set Screw (2)
52024	Thread Take-up Lever Link	504077 (803)	Needle Bar Connecting Link Adjusting Screw
52454	Thread Retainer	504078 (810)	Needle Bar Connecting Stud Clamping Screw
55623	Rotating Hook Bobbin	504080 (851)	Needle Clamp Screw
56024	Feed Connecting Link	504083 (852)	Pressure Regulating Thumb Screw
56034	Feed Regulating Stud Lock Pin	504084 (810)	Rotating Hook Bobbin Case Holder Position Bracket Screw
56035	Feed Regulating Stud Lock Pin Spring	504086 (806)	Rotating Hook Bobbin Case Tension Regulating Screw
56042	Needle Bar Bushing (upper)	504087 (806)	Rotating Hook Bobbin Case Tension Spring Screw
56046	Presser Bar Spring	504088 (803)	Rotating Hook Section Screw (3)
56056	Tension Releasing Lever	504089 (832)	Rotating Hook Set Screw (2)
56065	Throat Plate (large needle hole)	504090 (803)	Rotating Hook Thread Guard Screw (4)
99601	Feed Dog	504091 (810)	Slack Thread Regulator Adjusting Screw
99646	Arm Shaft (horizontal) Flanged Bushing (back)	504093 (809)	Spool Holder Wire Hinge Screw
99648	Arm Shaft (upright)	504094 (833)	Thread Retainer Set Screw
99649	Arm Shaft (upright) Flanged Bushing (lower)	504095 (850)	Thread Take-up Crank Position Screw
99650	Arm Shaft (upright) Flanged Bushing (upper)	504099 (809)	Feed Regulator Spring Bracket (hook) Screw
99651	Arm Side Cover	504101 (850)	Arm Shaft (upright) Bevel Gear (lower) Set Screw (2)
99654	Arm Top Cover	504101 (850)	Rotating Hook Shaft Bevel Gear Set Screw (2)
99662	Feed Reverse Lever Return Spring	504101 (850)	Thread Take-up Crank Set Screw
99663	Needle Bar (hollow)	504101 (850)	Arm Shaft (upright) Bevel Gear (upper) Set Screw (2)
99665	Presser Bar (hollow)	504120 (850)	Needle Bar Crank Position Screw
99671	Rotating Hook Shaft	504502 (819)	Feed Bar Screw Center Nut (2)
99672	Rotating Hook Shaft Bushing (back)	504504 (819)	Feed Lifting Rock Shaft Screw Center Nut (2)
99674	Slack Thread Regulator	504504 (819)	Feed Rock Shaft Screw Center Nut (2)
99678	Thread Guard (side of arm)	505001	Arm Dowel Pin (2)
99685	Rotating Hook Shaft Bushing (back and front) Oil Pad (felt) (2)	505009	Clamp Stop Motion Clamp Washer
99686	Arm Shaft (horizontal) Flanged Bushing (back and front) Oil Pad (felt) (2)	505151	Tension Releasing Lever Hinge Pin
125314	Tension Spring	505152	Tension Releasing Lever Spring
154756 (851)	Clamp Stop Motion Clamp Stop Screw	505302	Arm Oil Tube for Oiling 505337
154759 (850)	Feed Connecting Link Hinge Screw (2)	505303	Arm Oil Tube for Oiling 505321 and 505322
154759 (850)	Feed Forked Connection Hinge Screw	505307	Arm Shaft (horizontal)
154759 (850)	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw	505308	Arm Shaft (horizontal) Bevel Gear with two 504066
154781 (850)	Presser Bar Lifter Pin Set Screw	505311	Arm Shaft (upright) Bevel Gear (lower) with two 504101
154789 (809)	Bed Slide Spring Screw (2)	505312	Arm Shaft (upright) Bevel Gear (upper) with two 504101
154884	Bed Slide Spring	505313	Arm Shaft (upright) Oil Tube (lower)
154981 (819)	Feed Connecting Link Hinge Screw Nut (2)	505314	Arm Shaft (upright) Oil Tube (upper)
154981 (819)	Feed Forked Connection Hinge Screw Nut	505317-451	Bed Slide complete, Nos. 12431-451, 154884 and two 154789
154981 (819)	Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut	505319	Face Plate
166035	Thread Take-up Lever complete, Nos. 52022 and 52024	505320	Feed Bar
174036	Feed Regulator Spring Bracket (hook)	505321	Feed and Feed Lifting Eccentric with 504069 and 504070
504002 (850)	Arm Shaft (horizontal) Flanged Bushing (front) Set Screw	505322	Feed Forked Connection
504002 (850)	Rotating Hook Shaft Bushing (front) Set Screw	505324	Feed Lifting Rock Shaft with 504751
504002 (850)	Thread Take-up Lever Link Hinge Pin Set Screw	505326	Feed Lifting Rock Shaft Crank with 504019
504002 (850)	Thread Take-up Spring Regulator Set Screw	505327	Feed Lifting Rock Shaft Crank Connecting Rod with two 504071
504004 (852)	Arm Side Cover Thumb Screw	505328	Feed Lifting Rock Shaft Crank Connecting Rod Cap Oil Pad (felt)
504004 (852)	Face Plate Thumb Screw	505329	Feed Regulating Stud Head
504005-451	Clamp Stop Motion Clamp Screw (Spec. 1039)	505330	Feed Regulator with 545045
504007 (830)	Rotating Hook Shaft Retainer Collar Screw (2)	505331	Feed Regulator Hinge Stud
504013 (850)	Belt Cover and Bobbin Winder Tension Bracket Screw	505332	Feed Reverse Lever with two 504075
504013 (850)	Belt Cover Screw	505333	Feed Rock Shaft
504019 (808)	Feed Lifting Rock Shaft Crank Clamping Screw	505335	Feed Rock Shaft Crank with 504019
504019 (808)	Feed Rock Shaft Crank Clamping Screw	505336	Needle Bar Connecting Link with 504077
504028 (850)	Arm Shaft (horizontal) Flanged Bushing (back) Set Screw	505337	Needle Bar Connecting Link 505336 with 505338
504028 (850)	Needle Bar Bushing (lower) Set Screw	505338	Needle Bar Connecting Stud with 504078
504028 (850)	Needle Bar Bushing (upper) Set Screw	505339	Needle Bar Crank with 504095, 504101 and 504120
504028 (850)	Presser Bar Guide Bracket Set Screw	505340	Needle Bar Thread Guard
504028 (850)	Rotating Hook Shaft Bushing (back) Set Screw	505341	Needle Clamp with 504080
504030 (854)	Presser Foot Thumb Screw	505343	Presser Bar Guide Bracket with 504028
504032 (805)	Rotating Hook Bobbin Case Latch Stop Screw	505344	Rotating Hook with two 504089
504047 (830)	Tension Stud Set Screw		
504051 (850)	Feed Dog Screw (2)		
504052 (809)	Face Plate Screw		
504057	Needle Bar Connecting Link Cap Screw (Spec. No. 1015)		

NUMERICAL LIST OF PARTS FOR MACHINE 188U

<u>PART NO.</u>	<u>DESCRIPTION</u>
505347	Rotating Hook 505344 with 505352, 505360, 505364, three 504088 and four 504090
505348	Rotating Hook 505347 with 540770
505351	Rotating Hook Bobbin Case Hinge Nos. 505353, 505354 and 505355
505352	Rotating Hook Bobbin Case Holder
505353	Rotating Hook Bobbin Case Latch
505354	Rotating Hook Bobbin Case Latch Lever
505355	Rotating Hook Bobbin Case Latch Lever Fulcrum Pin
505356	Rotating Hook Bobbin Case Latch Spring
505357	Rotating Hook Shaft Bushing (front)
505360	Rotating Hook Section
505361	Rotating Hook Shaft Bevel Gear with two 504101
505364	Rotating Hook Thread Guard
505365	Spool Holder Base
505367	Spool Holder Wire
505368	Spool Holder complete, Nos. 504093, 505365 and 505367
505369	Tension Releasing Pin
505371	Thread Take-up Crank
505372	Thread Take-up Lever Link Hinge Pin
505373	Thread Take-up complete, Nos. 166035, 504057, 505337, 505371 and 505372
505407	Feed Bar Screw Center 504068 with 504502 (2)
505408	Feed Lifting Rock Shaft Screw Center 504072 with 504504 (2)
505408	Feed Rock Shaft Screw Center 504072 with 504504 (2)
505414	Arm Shaft (horizontal) Flanged Bushing (front) Oil Tube
505420	Needle Bar Bushing (lower)
505427	Rotating Hook Shaft Retainer Collar with two 504007
505428	Arm Shaft (horizontal) Flanged Bushing (front)
505508	Arm Oil Tube (front of arm, back)
505511	Arm Oil Tube (front of arm, front)
505513	Arm Oil Tube Packing (cotton) (4)
505643	Presser Foot (spring hinged)
505658	Presser Bar Lifter Pin
540767	Rotating Hook Bobbin Case Tension Spring
540770	Rotating Hook Bobbin Case with 504032, 504086, 504087, 505351, 505356 and 540767
541786	Hand Wheel (for foot or electric power)
544054 (805)	Arm Screw (4)
545045 (833)	Feed Regulator Hinge Stud Set Screw
545115 (829)	Spool Holder Base Screw
545404-451	Tension Regulating Thumb Nut (Spec. 1019) (2)
545893	Tension Releasing Disc
545898	Tension Stud
545899-451	Tension Stud 545898 with two 545404-451
546927	Thread Take-up Spring Regulator with 504047
546944	Belt Cover
546945	Tension complete, Nos. 32758, 125314, 505369, 545893, 545899-451, 546927 and two 2102
Cat. 2254	Needle (16 x 231 #14)

KNEE LIFTER PARTS (Fitted to Machine)

866	Lifting Lever Hinge Screw (Spec. 1019)
56071	Presser Bar Lifting and Releasing Lever Bracket
56073	Bell Crank Spring
504099 (809)	Bell Crank Bracket Screw (2)
504100 (852)	Lifting Lever Connecting Rod Joint Hinge Screw
504509 (809)	Lifting Lever Connecting Rod Lock Nut
505384	Bell Crank complete, Nos. 56073, 505417, 505418 and 505419
505385	Lifting Lever
505386	Lifting Lever Connecting Rod
505387	Lifting Lever Connecting Rod Joint
505417	Bell Crank
505418	Bell Crank Bracket
505419	Bell Crank Hinge Pin

ATTACHMENTS AND ACCESSORIES (Supplied with Machine)

12403	Arm Top Cover Spool Pin and Thread Eyelet
55623	Rotating Hook Bobbin (5)
505008	Arm Spool Pin Washer (felt)
541513	Screw Driver (large)

<u>PART NO.</u>	<u>DESCRIPTION</u>
541514	Screw Driver (small)
541515-001	Cloth Guide (purchased part)
541516-001	Hemmer Foot (1/8" hem) (purchased part)
541536	Accessory Box (not illustrated)
546922	Oiler with Oil Spout (130 cc filled with Singer Type "A" Oil) (for treadle operation)
546923	Oiler with Oil Spout (130 cc filled with Singer Type "B" Oil) (for motor drive)
549184-001	Cloth Guide Thumb Screw (purchased part)
CAT.2254	Needle (16 x 231 #14) (3)

BOBBIN WINDER (Supplied with Machine)

For Treadle Operation:

20437	Bobbin Winder Screw Washer
504098 (852)	Bobbin Winder Screw
505395	Bobbin Winder Tension Bracket complete
546907-001	Bobbin Winder complete (purchased part)

For Motor Drive:

505655-001	Universal Bobbin Winder complete with two Nails (purchased part)
------------	--