




# SINGER\*\*



## 253-200



\*\* A TRADE MARK OF  
THE SINGER MANUFACTURING COMPANY




Copyright, U. S. A. 1951  
by The Singer Manufacturing Co.  
All Rights Reserved for all Countries








25005 - 1/3





25004 - 1/2












25011 - 1/2




25010 - 1/2





25012 - 1/2





25013 - 1/2










25017 - 1/4




25018 - 1/6



25019 - 1/2



160588





25020 - 1/2

146636



146753



146645

146549

146548

11/32, 3/8