

Illustrated Parts List

SINGER
INDUSTRIAL PRODUCTS


270


1

Ref. No. Parts No.


Description

1	5055	Arm Front Cover
2	121-A	Screw for Front Cover 5055
3	5056-A	Nipper Releasing Plunger
4	5042	Spring for Plunger 5056-A
5	5056-B	Nut for Plunger 5056-A
6	5264	Thread Guide
7	121	Screw for Thread Guide 5264
8	5156	Thread Guide
9	5068	Screw for Thread Guide 5156
10	5079-B	Thread Guide
11	121	Screw for Thread Guide 5079-B
12	5001-S	Machine Arm
13	5205-S	Side Cover (Left)
14	5204-S	Side Cover (Right)
15	5233	Screw for Side Covers 5204 & 5205
16	5151	Spring for Covers 5004 & 5005
17	5276	Screw for Spring 5151
18	5003-S	Cover (Left)
19	5213	Screw for Arm & Bed
20	5214	Pin for Arm & Bed
21	5150	Hinge Shaft for Covers 5004 & 5005
22	5210-S	Model Plate Cover
23	5216	Knob Screw for Model Plate Cover 5210
24	5207	Nut for Knob Screw 5216
25	5233-A	Screw for Model Plate Cover 5210
26	5004-S	Cover for Stop Motion & Pulley (Right)
27	5153-B	Set Screw for Arm & Sub-Base
28	5275	Washer for Set Screw 5153-B
29	5003	Machine Sub-Base
30	5203	Felt
31	98	Screw for Hinge Shaft 5150 (Left)
32	132	Screw for Hinge Shaft 5150 (Right)
33	98	Screw for Pin Leg 5231
34	5002-S	Machine Bed
35	5147	Swing Cover
36	4140	Washer for Swing Cover 5147
37	4141	Screw for Swing Cover 5147






Ref. No.	Parts No.	Description
1	5077	Thread Guide
2	5176-A	Screw for Thread Guide 5077
3	5075	Thread Nipper
4	4096	Screw Stud for Thread Nipper 5075
5	5076	Thread Releasing Screw Stud
6	5074	Screw on Nipper 5075 & Lever 5073-A
7	5206	Nut for Screw 5074
8	5192	Spring for Block 5062
9	5223	Screw for Spring 5192
10	5160	Screw Stud for Block 5159
11	5161	Spring for Block 5159
12	5159	Nipper Block
13	5073-A	Thread Pull Off Lever
14	5236	Screw for Lever 5073-A
15	5272	Thread Tension Cap
16	5273	Stopper for Springs 5267-B & 79-C
17	5267-B	Thread Tension Spring (Front)
18	79-C	Thread Tension Spring (Rear)
19	5274	Thread Tension Cover
20	5190-A	Thread Tension Disc
21	5067-A	Thread Tension Stuff
22	5071	Thread Tension Releasing Pin
23	5201	Thread Guide
24	5060	Thread Tension Releasing Lever
25	114	Screw for Lever 5060
26	5200	Thread Guide
27	5155-A	Thread Guide Stud
28	5207	Nut for Stud 5155-A
29	5072	Thread Guide
30	5059	Nipper Bar
31	5062	Nipper Bar Block (Front)
32	5061	Nipper Bar Block (Rear)
33	114	Screw for Blocks 5061 & 5062
34	5162	Nipper Bar Spring
35	5065	Screw for Spring 5162
36	5208	Check Nut for Screw 5065
37	5063	Nipper Bar Bearing Block
38	5064	Screw for Spring 5162
39	5188	Screw for Bearing Block 5063
40	5176-B	Screw for Bearing Block 5063
41	5057	Nipper Bar Moving Lever
42	5058	Screw for Lever 5057




Ref. No.	Parts No.	Description
1	5046	Button Clamp Lifting Lever
2	5047-S	Button Clamp Lifting Lever Stop
3	5176-A	Screw for Stop 5047
4	5158	Spring for Lever 5046
5	5157	Washer for Spring 5158
6	5099	Shoulder Screw for Lever 5046
7	5066	Button Clamp Lifting Link
8	5028	Grooved Collar for Link 5066
9	132-A	Screw for Grooved Collar 5028
10	5140	Button Clamp Lifting Link Engaging Lever
11	4024	Screw for Lever 5140
12	5183-A	Shoulder Screw for Lever 5140
13	5141	Button Clamp Lifting Link Connecting Link
14	5217	Screw for Link 5141
15	5013	Button Clamp Lifting Lever Driving Eccentric
16	132-A	Screw for Eccentric 5013
17	5034	Button Clamp Eccentric Fork Lever
18	5036	Collar for Fork Lever 5034
19	130	Screw for Collar 5036
20	5035	Button Clamp Eccentric Fork Lever Shaft
21	5230	Screw for Shaft 5035
22	5048	Button Clamp Lifting Rod
23	5069	Button Clamp Lifting Rod Roll
24	5139	Nut for Roll 5069
25	98-A	Screw for Rod 5048

Ref. No. Parts No. Description

1	5129	Needle Plate
2	5221	Screw for Needle Plate 5129
3	5128	Spacer Plate
4	5127-A	Needle Guard
5	5176-A	Screw for Needle Guard 5127-A
6	5126-B	Loop Positioning Finger
7	5125	Positioning Finger Yoke Slide
8	5124	Yoke Slide Insert
9	5235	Screw for Insert 5124
10	5119	Loop Positioning Finger Lever Roll
11	5118	Loop Positioning Finger Lever
12	5184	Shoulder Screw for Lever 5118
13	5123	Looper
14	5122	Collar on Sleeve 5120
15	5263-A	Screw for Collar 5122
16	5121	Loop Positioning Finger Cam
17	129-B	Screw for Cam 5121
18	5120	Cam & Looper Sleeve
19	5225-C	Screw for Sleeve 5120
20	5117	Loop Positioning Finger Cam (Rear)
21	5225-B	Screw for Cam 5117
22	5111	Looper Shaft Front Bushing
23	131	Screw for Front Bushing 5111
24	5115-A	Looper Shaft
25	5265	Looper Shaft Tube
26	5266	Looper Shaft Collar
27	132-A	Screw for Collar 5266
28	5116	Looper Shaft Spiral Gear
29	5078-A	Screw for Spiral Gear 5116
30	5114	Looper Shaft Ball Bearing
31	5224	Washer for Ball Bearing 5114
32	5112-A	Looper Shaft Rear Bushing
33	98	Screw for Rear Bushing 5112-A
34	5113-A	Looper Shaft Worm
35	5251	Screw for Worm 5113-A
36	591	Loop Positioning Finger Complete (Ref. Nos.) 6, 7 & 8







Ref. No.	Parts No.	Description
1	5020	Ball (Large)
2	5019	Pulley Insert
3	5016	Pulley
4	98	Set Screw for Insert 5019
5	95-B	Cap Screw
6	5017	Needle Bearing
7	5226	Felt for Needle Bearing 5017
8	5018	Washer for Felt 5226
9	5008-A	Stop Motion Clutch Disc
10	5152	Screw for Disc 5008-A
11	5007	Stop Motion Disc
12	5165-A	Spot Screw for Disc 5007
13	5215	Set Screw for Disc 5007
14	5165-C	Allen Screw for Disc 5007
15	5167	Stop Motion Disc Pawl
16	5168	Stop Motion Disc Latch
17	5187	Screw for Pawl 5167 & Latch 5168
18	5222-B	Washer for Screw 5187
19	4068	Nut for Screw 5187
20	5222-B	Washer for Screw 5152
21	4068	Nut for Screw 5152
22	5114	Ball Bearing
23	5224-A	Washer for Ball Bearing 5114
24	5009	Pulley Shaft Bushing (Right)
25	98	Screw for Bushings 5009 & 5010
26	5010	Pulley Shaft Bushing (Left)
27	5012	Pulley Shaft Spiral Gear
28	5251	Screw for Spiral Gear 5012
29	5006	Pulley Shaft
30	5022	Spring
31	5021	Ball (Small)
32	555	Stop Motion Disc Complete (Ref. Nos.) 11-19

Ref. No. Parts No.

Description

1	5134	Stop Motion Plunger Rod
2	5133	Stop Motion Plunger
3	5130-A	Stop Motion Plunger Lever
4	5247-A	Screw for Lever 5240
5	5135	Stop Motion Disc Spring
6	5136	Rubber Washer
7	5039-A	Adjusting Nut for Disc Spring 5135
8	5249	Washer for Nut 5039-A
9	5185	Spot Screw for Lever 5130-A
10	5131	Stop Motion Adjusting Lever
11	5132	Stop Motion Trip Lever Shaft
12	4009	Screw for Lever 5131
13	5271	Nut for Screw 4009
14	5198	Hexagon Screw for Lever 5131
15	5163	Stop Motion Trip Lever
16	4050	Screw for Trip Lever 5163
17	5070	Washer for Screw 4050
18	4068	Nut for Screw 4050
19	5193	Spring for Trip Lever 5163
20	5199	Stop Screw for Trip Lever 5163
21	5207	Nut for Stop Screw 5199
22	5187	Stopper for Trip Lever 5163
23	5164	Stop Motion Trip Lever Bracket
24	5177	Screw for Bracket 5164
25	5137-B	Stop Motion Lever Restoring Spring
26	5197	Pin for Spring 5137-B
27	4094	Screw for Springs 5137-B & 4093-B
28	4095	Nut for Screw 4094
29	5237	Screw Stud for Spring 5137-B
30	4068	Nut for Screw Stud 5237
31	5247-A	Screw for Stud 5237 & Lever 5242
32	5240	Brake Actuating Lever
33	5247-A	Connecting Screw for Lever 5240
34	5242	Brake Supporting Lever
35	5238	Brake Regulating Screw
36	5277	Nut for Screw 5238
37	5241	Bracket for Lever 5242
38	4093-B	Brake Spring
39	4178	Adjusting Thumb Screw for Lever 5242
40	5207	Nut for Screw 4178
41	5243	Brake Lining
42	115	Set Screw for Brake Lining 5243
43	5247-A	Set Screw for Bracket 5241
44	5194	Screw for Lever 5130-A







Ref. No.	Parts No.	Description
1	5146	Stitch Selecting Latch
2	5099	Screw for Latch 5146
3	5218	Screw for Latch 5146
4	5178	Washer for Screw 5218
5	5211	Stop Screw for Latch 5146
6	5206	Nut for Stop Screw 5211
7	5145	Stitch Selecting Lever
8	5031	Stop Motion Cam
9	5171-A	Set Screw for Cam 5031
10	5170	Stop Motion Cam Shoe
11	5172	Hinge Screw for Shoe 5170
12	5173	Stop Motion Cam Knob
13	5175	Spring for Knob 5173
14	5174	Screw for Knob 5173
15	5030	Stop Motion Gear
16	5142	Stop Motion Tripping Lever
17	5143	Cam Roll for Lever 5142
18	5144	Screw for Cam Roll 5143
19	5186	Clamp Screw for Lever 5142
20	5032	Stitch Selecting Spur Gear, Intermediate
21	5033	Bearing Pin for Spur Gear 5032
22	131	Screw for Bearing Pin 5033
23	5014	Stitch Selecting Spur Gear
24	5270	Screw for Spur Gear 5014
25	5015	Hand Knob
26	132-A	Screw for Hand Knob 5015
27	596	Stop Motion Cam Complete (Ref. Nos.) 8-15

Ref. No. Parts No.

Description

1	5085-A	Feed Plate for Flat Button
2	5176-C	Screw for Feed Plate 5085-A
3	5178	Washer for Screw 5176-C
4	5080	Button Clamp Slide Plate
5	5149	Sideways Moving Graduated Plate
6	5148	Block for Graduated Plate 5149
7	5191	Screw for Graduated Plate 5149
8	5084	Sideways Moving Indicator
9	5083	Fulcrum Nut for Indicator 5084
10	5082	Bearing Block for Indicator 5084
11	5081	Screw for Indicator 5084
12	5103	Slide Plate Connecting Link
13	5104-A	Screw for Link 5103
14	5105	Slide Plate Intermediate Connecting Link
15	5104-B	Screw for Link 5105
16	5106	Handle & Indicator Spring Connecting Link
17	5219	Screw for Link 5106
18	5107	Handle & Indicator Spring
19	5229	Screw for Spring 5107
20	5108	Lengthwise Moving Graduated Plate
21	5227	Screw for Graduated Plate 5108
22	5109	Lengthwise Moving Lever
23	5110	Slide Block for Lever 5109
24	5101	Cam Roller
25	5100	Screw for Cam Roller 5101
26	5102	Bearing Pin for Lever 5109
27	5245	Screw for Bearing Pin 5102
28	5098	Sideways Moving Lever
29	5097	Sideways Moving Lever Link
30	5183-A	Screw for Link 5097
31	5228	Pin for Lever 5098
32	131	Screw for Pin 5228
33	5023	Cam Shaft
34	5024-A	Cam Shaft Bushing (Right)
35	98	Screw for Bushings 5024-A & 5025-A
36	5026-A	Sideways Moving Cam
37	5195-B	Screw for Cams 5026-A & 5029-A
38	5252	Cam Boss
39	5254	Screw for Cam Boss 5252
40	5256	Cam Indicating Pin (Right)
41	5027	Cam Shaft Worm Gear
42	5078-A	Screw for Worm Gear 5027
43	5029-A	Lengthwise Moving Cam
44	5255	Cam Indicating Pin (Left)
45	5025-A	Cam Shaft Bushing (Left)
46	586-T	Sideways Moving Indicator Complete (Ref. Nos. 8, 9, 10 & 11)







Ref. No.	Parts No.	Description
1	5094-N	Button Clamp Stop Lever
2	5180-N	Knurled Screw for Lever 5094-N
3	123-N	Clamp Screw for Lever 5094-N
4	5181-N	Shoulder Screw for Slide 5093-AN
5	5088-N	Button Clamp Lever Jaws Holder
6	5090-N	Button Clamp Lever Jaw (Left)
7	5092-N	Button Holding Spring (Left)
8	124-N	Screw for Springs 5091-N & 5092-N
9	5089-N	Button Clamp Lever Jaw (Right)
10	5091-N	Button Holding Spring (Right)
11	5189-N	Button Clamp Bearing Screw
12	5093-AN	Button Clamp Slide
13	5182-N	Slotted Nut for Screw 5181-N
14	5179-N	Hinge Screw for Lever Jaws 5089-N & 5090-N
15	5166-N	Button Clamp Spring
16	5086	Button Clamp Holder
17	5177-N	Hexagon Head Screw for Holder 5086
18	5178-N	Washer for Screw 5177-N
19	98-N	Screw for Rod 5154-N
20	5154-N	Button Clamp Lifting Rod
21	5095-A	Button Clamp Pressure Adjusting Screw Stud
22	5096	Spring for Screw Stud 5095-A
23	5095-B	Nut for Screw Stud 5095-A
24	5087-A	Hinge Pin for Holder 5086
25	9082	Ring for Hinge Pin 5087-A
26	5244	Button Clamp Stopper Pin
27	5207	Nut for Stopper Pin 5244
28	5202	Button Tray
29	5231	Pin Leg for Button Tray 5202
30	98	Screw for Pin Leg 5231
31	585-2	Flat Button Clamp Head (Ref. Nos.) 1-15
32	585-N	Flat Button Clamp Complete (Ref. Nos.) 16-20 & 31

Part No. Parts No.

Description


1	5094-N	Button Clamp Stop Lever
2	5180-N	Knurled Screw for Stop Lever 5094-N
3	123-N	Clamp Screw for Stop Lever 5094-N
4	5181-N	Shoulder Screw for Slide 5093-CN
5	5088-N	Button Clamp Lever Jaws Holder
6	5090-CN	Button Clamp Lever Jaw (Left)
7	5089-CN	Button Clamp Lever Jaw (Right)
8	5189-N	Button Clamp Bearing Screw
9	5093-CN	Button Clamp Slide
10	5182-N	Slotted Nut for Screw 5181-N
11	5166-N	Button Clamp Spring
12	5179-N	Hinge Screw for Lever Jaws
13	5154-N	Button Clamp Lifting Rod
14	98-N	Screw for Rod 5154-N
15	5086	Button Clamp Holder
16	5177-N	Hexagon Head Screw for Holder 5086
17	5178-N	Washer for Screw 5177-N
18	5085-B	Feed Plate for Snap Fastener
19	621-N	Snap Fastener Clamp Complete (Ref. Nos.) 1~18








Ref. No.	Part No.	Description
1	5612	Button Clamp Stud
2	5613	Screw for Stud 5612
3	5611	Button Clamp Block
4	5628	Screw for Block 5611
5	5606	Button Clamp Lever
6	5607	Button Holding Clamp
7	5608	Screw for Clamp 5607
8	5609	Screw for Lever 5606
9	5605	Button Clamp Lever Holding Shaft
10	5602	Collar for Shaft 5605
11	5603	Screw for Collar 5602
12	5604	Spring for Shaft 5605
13	5601	Button Clamp Bracket
14	5154-N	Button Clamp Lifting Rod
15	5086-N	Button Clamp Holder
16	98-N	Screw for Rod 5154-N
17	5177-N	Hexagon Head Screw for Holder 5086-N
18	5178-N	Washer for Screw 5177-N
19	5614	Shank Button Adaptor Base
20	5615	Button Clamp Jaw (Left)
21	5616	Button Clamp Jaw (Right)
22	5617	Screw for Jaws 5615 & 5616
23	5618	Adjusting Screw for Jaws 5615 & 5616
24	5619	Spring for Jaws 5615 & 5616
25	5620	Screw for Spring 5619
26	5610	Screw for Adap or 622-3
27	5621	Feed Pallet for Shank Button
28	5623	Work Supporting Block (Medium Step)
29	5624	Work Supporting Block (Low Step)
30	5625	Screw for Work Supporting Block
31	622-3	Adjusting Adaptor Complete (Ref. Nos.) 19~25
32	622-N	Shank Button Clamp Complete (Ref. Nos.) 1~30

Part No.	Part No.	Description
1	5612	Button Clamp Stud
2	5613	Screw for Stud 5612
3	5611	Button Clamp Block
4	5628	Screw for Block 5611
5	5606	Button Clamp Lever
6	5607	Button Holding Clamp
7	5608	Screw for Clamp 5607
8	5609	Screw for Lever 5606
9	5605	Button Clamp Lever Holding Shaft
10	5602	Collar for Shaft 5605
11	5603	Screw for Collar 5602
12	5604	Spring for Shaft 5605
13	5601	Button Clamp Bracket
14	5154-N	Button Clamp Lifting Rod
15	5086-N	Button Clamp Holder
16	98-N	Screw for Rod 5154-N
17	5177-N	Hexagon Head Screw for Holder 5086-N
18	5178-N	Washer for Screw 5177-N
19	5627	Metal Button Adaptor
20	5626	Metal Button Guard
21	5610	Screw for Adaptor & Guard
22	5621	Feed Plate for Metal Button
23	5623	Work Supporting Block (Medium Step)
24	5624	Work Supporting Block (Low Step)
25	5625	Screw for Work Supporting Block
26	623-N	Metal Button Clamp Complete (Ref. Nos.) 1-25








10



Conversion Parts for 6-12-24 Stitches



Part No.	Description
1	5300-A Label Tacking Clamp
2	5301 Thread Breaking Finger
3	135 Screw for Finger 5301
4	5154-N Clamp Lifting Rod
5	5086 Label Tacking Clamp Holder
6	98-N Screw for Rod 5154-N
7	5177-N Hexagon Head Screw for Holder 5086
8	5178-N Washer for Screw 5177-N
9	5302 Feed Plate for Label Tacking
10	610-N Tacking Clamp Complete (Ref. Nos.) 1-9
Conversion Parts for 6-12-24 Stitches	
11	5307 Cam Shaft Worm Gear
12	5078-A Screw for Worm Gear 5307
13	5306 Loopier Shaft Worm
14	5251 Screw for Worm 5306
15	5304 Sideways Moving Cam
16	5195-B Screw for Cam 5304

M. 610-N. 4.688,80

1522.28

Parts No.	Page	Parts No.	Page	Parts No.	Page	Parts No.	Page	Parts No.	Page
79-C	3	5028	7	5097	17	5167	11	5232	5
95-B	11	5029-A	17	5098	17	5168	11	5233	1
98	1, 9, 11, 17, 19	5030	15	5099	7, 15	5169	5	5234-A	1
98-A	7	5031	15	5100	17	5170	15	5234	5
98-N	19, 21, 23, 25, 27	5032	15	5101	17	5171-A	15	5235	9
105	3	5033	15	5102	17	5172	15	5236	3
108	5	5034	7	5103	17	5173	15	5237	13
114	3	5035	7	5104-A	17	5174	15	5238	13
115	13	5036	7	5104-B	17	5175	15	5240	13
121	1	5037-A	5, 13	5105	17	5176-A	3, 7, 9	5241	13
121-A	1	5038-A	5	5106	17	5176-B	3	5242	13
121-C	5	5039-A	5	5107	17	5176-C	17	5243	13
123-N	19, 21	5040	7	5108	17	5177	13	5244	19
129-B	9	5041	7	5109	17	5177-N	19, 21, 23, 25, 27	5245	19
130	7	5042	7	5110	17	5178	15, 17	5247-A	13
131	9, 15, 17	5043	5	5111	9	5178-N	19, 21, 23, 25, 27	5249	13
132-A	7, 9, 15	5044	5	5112-A	9	5179-N	19, 21	5250	5
135	27	5045	5	5113-A	9, 11	5180-N	19, 21	5251	5, 9, 11, 27
507-B	5	5046	5	5114	9	5181-N	19, 21	5252	17
505	11	5047	5	5115-A	9	5182-N	19, 21	5254	17
505	11	5048	5	5116	9	5183-N	19, 21	5255	17
505-2	19	5049	5	5117	9	5184	7, 17	5256	17
505-C	19	5050	5	5118	9	5185	13	5256-A	9
505-T	17	5051	5	5119	9	5186	15	5257	1
504	9	5052	5	5120	9	5187	11, 13	5258	9
504	5	5053	5	5121	9	5188	3	5259	9
504	15	5054	5	5122	9	5189-N	19, 21	5260	15
504-N	27	5055	5	5123	9	5190-A	3	5261	13
505-2	21	5056	5	5124	9	5191	17	5262	3
505-3	23	5057	5	5125	9	5192	3	5263	1
505-N	23	5058	5	5126-B	9	5193	13	5264	1
505-N	25	5059	5	5127-A	9	5194	13	5265	1
506	13	5060	5	5128	9	5195-B	17, 27	5266	13
506	13	5061	5	5129	9	5196	5	5267	27
506	13	5062	5	5130-A	13	5197	13	5268	27
506	13	5063	5	5131	13	5198	13	5269	27
506	13	5064	5	5132	13	5199	13	5270	27
506	13	5065	5	5133	13	5200	3	5271	13
506	13	5066	5	5134	13	5201	3	5272	13
506	13	5067	5	5135	13	5202	19	5273	13
506	13	5068	5	5136	13	5203	1	5274	13
506	13	5069	5	5137-B	13	5204	1	5275	1
506	13	5070	5	5138	13	5205	1	5276	1
506	13	5071	5	5139	13	5206	1	5277	13
506	13	5072	5	5140	7	5207	1	5278	13
506	13	5073-A	5	5141	7	5208	1	5279	13
506	13	5074	5	5142	15	5209	1	5280	13
506	13	5075	5	5143	15	5210	1	5281	13
506	13	5076	5	5144	15	5211	15	5282	13
506	13	5077	5	5145	15	5212	15	5283	13
506	13	5078-A	9, 17, 27	5146	15	5213-A	5	5284	13
506	13	5079-B	1	5147	15	5214	1	5285	13
506	13	5080	1	5148	17	5215	11	5286	13
506	13	5081	1	5149	17	5216	1	5287	13
506	13	5082	1	5150	1	5217	1	5288	13
506	13	5083	1	5151	1	5218	15	5289	13
506	13	5084	1	5152	11	5219	17	5290	13
506	13	5085-A	17	5153	11	5220	17	5291	13
506	13	5086	17	5154	11	5221	9	5292	13
506	13	5087	17	5155	11	5222-B	11	5293	13
506	13	5088	17	5156	11	5223	3	5294	13
506	13	5089	17	5157	7	5224	9	5295	13
506	13	5090	17	5158	7	5224-A	11	5296	13
506	13	5091	17	5159	7	5225-B	9	5297	13
506	13	5092	17	5160	3	5225-C	9	5298	13
506	13	5093	17	5161	3	5226	11	5299	13
506	13	5094	17	5162	3	5227	17	5300	13
506	13	5095	17	5163	13	5228	17	5301	13
506	13	5096	17	5164	13	5229	17	5302	13
506	13	5097	17	5165-A	11	5230	7	5303	13
506	13	5098	17	5165-C	11	5231	19	5304	13
506	13	5099	17	5166-N	19, 21	5232	19	5305	13
506	13	5100	17	5167	19	5233	19	5306	13
506	13	5101	17	5168	19	5234	19	5307	13
506	13	5102	17	5169	19	5235	19	5308	13
506	13	5103	17	5170	19	5236	19	5309	13
506	13	5104	17	5171	19	5237	19	5310	13
506	13	5105	17	5172	19	5238	19	5311	13
506	13	5106	17	5173	19	5239	19	5312	13
506	13	5107	17	5174	19	5240	19	5313	13
506	13	5108	17	5175	19	5241	19	5314	13
506	13	5109	17	5176	19	5242	19	5315	13
506	13	5110	17	5177	19	5243	19	5316	13
506	13	5111	17	5178	19	5244	19	5317	13
506	13	5112	17	5179	19	5245	19	5318	13
506	13	5113	17	5180	19	5246	19	5319	13
506	13	5114	17	5181	19	5247	19	5320	13
506	13	5115	17	5182	19	5248	19	5321	13
506	13	5116	17	5183	19	5249	19	5322	13
506	13	5117	17	5184	19	5250	19	5323	13
506	13	5118	17	5185	19	5251	19	5324	13
506	13	5119	17	5186	19	5252	19	5325	13
506	13	5120	17	5187	19	5253	19	5326	13
506	13	5121	17	5188	19	5254	19	5327	13
506	13	5122	17	5189	19	5255	19	5328	13
506	13	5123	17	5190	19	5256	19	5329	13
506	13	5124	17	5191	19	5257	19	5330	13
506	13	5125	17	5192	19	5258	19	5331	13
506	13	5126	17	5193	19	5259	19	5332	13
506	13	5127	17	5194	19	5260	19	5333	13
506	13	5128	17	5195	19	5261	19	5334	13
506	13	5129	17	5196	19	5262	19	5335	13
506	13	5130	17	5197	19	5263	19	5336	13
506	13	5131	17	5198	19	5264	19	5337	13
506	13	5132	17	5199	19	5265	19	5338	13
506	13	5133	17	5200	19	5266	19	5339	13
506	13	5134	17	5201	19	5267	19	5340	13
506	13	5135	17	5202	19	5268	19	5341	13
506	13	5136	17	5203	19	5269	19	5342	13
506	13	5137	17	5204	19	5270	19	5343	13
506	13	5138	17	5205	19	5271	19	5344	13
506	13	5139	17	5206	19	5272	19	5345	13
506	13	5140	17	5207	19	5273	19	5346	13
506	13	5141	17	5208	19	5274	19	5347	13
506	13	5142	17	5209	19	5275	19	5348	13
506	13	5143	17	5210	19	5276	19	5349	13
506	13	5144	17	5211	19	5277	19	5350	13
506	13	5145	17	5212	19	5278	19	5351	13
506	13	5146	17	5213	19	5279	19	5352	13
506	13	5147	17	5214	19	5280	19	5353	13
506	13	5148	17	5215	19	5281	19	5354	13
506	13	5149	17	5216	19	5282	19	5355	13
506	13	5150	17	5217	19	5283	19	5356	13
506	13	5151	17	5218	19	5284	19	5357	13
506	13	5152	17	5219	19	5285	19	5358	13
506	13	5153	17	5220	19	5286	19	5359	13
506	13	5154	17	5221	19	5287	19	5360	13
506	13	5155	17	5222	19	5288	19	5361	13
506	13	5156	17	5223	19	5289	19	5362	13
506	13	5157	17	5224	19	5290	19	5363	13
506	13	5158	17	5225	19	5291	19	5364	13
506	13	5159	17	5226	19	5292	19	5365	13
506	13	5160	17	5227	19	5293	19	5366	13
506	13	5161	17	5228	19	5294	19	5367	13
506	13	5162	17	5229	19	5295	19	5368	13
506	13	5163	17	5230	19	5296	19	5369	13
506	13	5164	17	5231	19	5297	19	5370	13
506	13	5165	17	5232	19	5298	19	5371	13
506	13	5166	17	5233	19	5299	19	5372	13
506	13	5167	17	5234	19	5300	19	5373	13
506	13	5168	17	5235	19	5301	19	5374	13
506	13	5169	17	5236	19	5302	19	5375	13
506	13	5170	17	5237	19	5303	19	5376	13
506	13	5171	17	5238	19</				