

ILLUSTRATED

PARTS LIST

FOR

SINGER*

MACHINE

457U135

457U140

Blunt

Cavemac

Controle do Arquivo de Catálogos

Identificação 892

Edição 1987



Conteúdo SINGER 457U135

00000892





*A Trademark of THE SINGER COMPANY
ght ©1987 SINGER SEWING MACHINE COMPANY
All Rights Reserved Throughout The World

 - ORIGINAL




237-833	THREAD CUTTER (ON ROTARY TAKE-UP GUARD) SCREW
1454-850	ROTARY TAKE-UP GUARD SCREW (SHORT)
50429-833	THREAD CUTTER (ON FACE PLATE) ADJUSTING SCREW
230743	ROTARY TAKE-UP GUARD HINGE SCREW SPRING WASHER
272128	ROTARY TAKE-UP GUARD COVER WINDOW
276051	THREAD GUIDE (ON FACE PLATE)
276508	ROTARY TAKE-UP GUARD SPRING CATCH
411014	ROTARY TAKE-UP GUARD CPL. NOS. 237, 230743, 272128, 276508, 411015, 411016, 500246, 502622, 502670, 504507, 543805-003, 544298 AND 545082-452
411015	ROTARY TAKE-UP GUARD
411016	ROTARY TAKE-UP GUARD COVER
411085	FACE PLATE CPL. NOS., 50429, 276051, 411086, 411088, 541178 AND TWO 500262

411086	FACE PLATE
411088	THREAD CUTTER (ON FACE PLATE)
500246-850	FACE PLATE SCREW (8)
500246-850	ROTARY TAKE-UP GUARD SPRING CATCH SCREW
500262-833	THREAD GUIDE (ON FACE PLATE) SCREW
500262-833	THREAD CUTTER (ON FACE PLATE) SCREW
502622	ROTARY TAKE-UP GUARD HINGE SCREW SPRING WASHER
502670	THREAD CUTTER (ON ROTARY TAKE-UP GUARD)
504507	SPRING CATCH SCREW NUT
541178	THREAD CUTTER (ON FACE PLATE) ADJUSTING SCREW NUT
543805-003	ROTARY TAKE-UP COVER WINDOW WASHER
544298	ROTARY TAKE-UP GUARD HINGE SCREW
545082-452	ROTARY TAKE-UP GUARD COVER WINDOW SCREW
545244-452	ROTARY TAKE-UP GUARD SCREW (LONG)




50429-833	BOBBIN WINDER DRIVING WHEEL SCREW (2)
51389-850	NEEDLE BAR CONNECTING LINK CLAMPING PLATE SCREW (2)
141567-833	MACHINE PULLEY SET SCREW (2)
214206	ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE
270161	NEEDLE BAR CRANK STUD PIN
270256	NEEDLE BAR CONNECTING LINK NEEDLE BEARING
272142	MACHINE PULLEY BALL BEARING
272143	ARM SHAFT BALL BEARING
276114	NEEDLE BAR CONNECTING LINK THRUST WASHER
411004	NEEDLE BAR CONNECTING STUD, CONNECTING LINK CPL NOS. 411005, 411007 AND 508585
411005	NEEDLE BAR CONNECTING STUD WITH 502603 AND 545249-452
411007	NEEDLE BAR CRANK STUD WITH 270161
411009	NEEDLE BAR CONNECTING LINK GUIDE BLOCK
411010	NEEDLE BAR CONNECTING LINK CLAMP PLATE
411032	ARM SHAFT CPL NOS. 272143 AND 411183
411083	BOBBIN WINDER DRIVING WHEEL WITH TWO 50429
411160	NEEDLE VIBRATING WORM GEAR WITH FOUR 544306
411183	ARM SHAFT AND NEEDLE BAR CRANK WITH 502927, 504101 AND 544290

411335	MACHINE PULLEY WITH 272142 AND TWO 141567
500244	ROTARY TAKE-UP SCREW (2)
500272-830	ARM SHAFT CONNECTION BELT PULLEY SET SCREW
500274-833	ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW
500307-850	ARM SHAFT BUSHING (CENTER) SCREW
502508	ARM SHAFT CONNECTION BELT
502509	ARM SHAFT CONNECTION BELT PULLEY
502510	ARM SHAFT OIL SHIELD
502603	NEEDLE BAR CONNECTING STUD OIL WICK
502658	ROTARY TAKE-UP MOUNTING DISC
502682	ARM SHAFT CONNECTION BELT PULLEY CPL NOS. 214206, 500272, 500274 AND 502509
502763	ARM SHAFT BUSHING (CENTER)
502831	ARM SHAFT BUSHING (CENTER) SCREW PLUG
504101	NEEDLE BAR CRANK STUD POSITION SCREW
508585	NEEDLE BAR CONNECTING LINK WITH 270256
509087	ROTARY TAKE-UP
543833-002	ARM SHAFT BUSHING (CENTER) SCREW GASKET
544290	NEEDLE BAR CRANK STUD PINCH SCREW
544306	NEEDLE VIBRATING WORM GEAR SET SCREW (4)
545249-452	NEEDLE BAR CONNECTING STUD SCREW





1349-850	PRESSER BAR LIFTER HINGE SCREW
276027	PRESSER BAR LIFTER
411023	TENSION RELEASE CPL. NOS., 411024, 504509-452 AND 544295
411024	TENSION RELEASE
411054	KNEE LIFTER ROCK FRAME CPL. NOS., 411055, 502679 AND 502786
411055	KNEE LIFTER ROCK FRAME HINGE STUD
411120	KNEE LIFTER LIFTING ROD SPRING COLLAR WITH 545205-452
411100	KNEE LIFTER LIFTING ROD WITH TWO 543831-005
500260-833	PRESSER BAR SPRING ADJUSTING SCREW
500261-860	PRESSER BAR SPRING SCREW STUD
500312-850	LIGHT STUD HOLE SCREW PLUG (FOR UN-USED HOLE)
502586	KNEE LIFTER LIFTING ROD SPRING

502653	PRESSER BAR SPRING
502662	TENSION RELEASE SPRING
502679	KNEE LIFTER ROCK FRAME HINGE STUD PIN
502786	KNEE LIFTER ROCK FRAME
504509-452	TENSION RELEASE ADJUSTING SCREW LOCK NUT
543831-005	KNEE LIFTER LIFTING ROD GRIP RING (2)
543833-002	KNEE LIFTER LOCK FRAME HINGE STUD GASKET
543833-003	LIGHT STUD HOLE SCREW PLUG GASKET
543833-004	PRESSER BAR SPRING SCREW STUD GASKET
544292	KNEE LIFTER ROCK FRAME HINGE SCREW
544295	TENSION RELEASE ADJUSTING SCREW
544296	TENSION RELEASE HINGE SCREW
545205-452	KNEE LIFTER LIFTING ROD COLLAR SET SCREW
545347-452	KNEE LIFTER ROCK FRAME HINGE STUD LOCK SCREW





86-860	KNEE LIFTER LIFTING LINK SCREW
223	NEEDLE SET SCREW
238	NEEDLE BAR THREAD GUIDE SET SCREW
238	BED SLIDE SPRING SCREW (2)
* N1906-01	NEEDLE (CAT.NO.1906-01,#14)
50624-833	FEED DOG SCREW (2)
51369-850	NEEDLE BAR CONNECTING STUD GUIDE BLOCK SCREW (2)
51369-850	PRESSER BAR POSITION GUIDE PINCH SCREW
210505	RED PLATE
276025	PRESSER BAR BALL
411001	NEEDLE BAR CONNECTING STUD GUIDE BLOCK
411035	PRESSER BAR POSITION GUIDE WITH 51369
411131	NEEDLE BAR YOKE GUIDE (REAR) CPL. NOS., 502930 AND 508883
411132	NEEDLE BAR YOKE GUIDE (FRONT) CPL. NOS., 502930 AND 508884
500244	BED PLATE SCREW (2)
500244	THROAT PLATE SCREW (2)
500256	PRESSER FOOT SCREW
502584	KNEE LIFTER LIFTING LINK

502594	NEEDLE BAR OIL FELT CORD
502507	NEEDLE BAR THREAD GUIDE
502000	NEEDLE BAR OIL FELT
502872	NEEDLE BAR YOKE BEARING (BACK)
502674	NEEDLE BAR YOKE BEARING (FRONT)
502930	NEEDLE BAR YOKE GUIDE SEAL (FRONT AND REAR) (2)
502948	PRESSER BAR WITH 500256
502993	NEEDLE BAR
* 503582	THROAT PLATE
* 503743	FEED DOG
* 503818	PRESSER FOOT
508506	BED SLIDE SPRING
508507	BED SLIDE WITH 508506 AND TWO 238
503652	PRESSER BAR BUSHING
508879-002	NEEDLE BAR YOKE CPL. NOS., 502594, 502600, 502993 AND 508880
508890	NEEDLE BAR YOKE
508883	NEEDLE BAR YOKE GUIDE (REAR)
508884	NEEDLE BAR YOKE GUIDE (FRONT)
544301	NEEDLE BAR YOKE GUIDE SET SCREW (2)





1664-850	NEEDLE VIBRATING CAM ROLLER STUD NUT
411053	NEEDLE VIBRATING CAM SHAFT BUSHING (BACK)
411074	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING CPL. NOS., 411075 AND TWO 502757
411075	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING WITH 544826
411146	NEEDLE VIBRATING CAM WITH TWO 545135-452
411168	NEEDLE BAR YOKE CONNECTING LINK CPL. NOS., 1664, 411074, 411169, 502785, 502957, 502959, 502961, 502963, 502990, TWO EACH 502802, 502958, 502960 AND 502964
411169	NEEDLE VIBRATING CAM ROLLER STUD
411174	NEEDLE VIBRATING WORM WHEEL CPL. NOS., TWO 544307 AND THREE 545249-452
500303-869	NEEDLE VIBRATING CAM SHAFT BUSHING (FRONT) SET SCREW
502877	NEEDLE VIBRATING CAM SHAFT BUSHING (FRONT) SET SCREW PLUG
502751	NEEDLE VIBRATING CAM SHAFT BUSHING (BACK) PLUG
502757	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING BUSHING (2)
502760	NEEDLE VIBRATING CAM SHAFT BUSHING (FRONT) PLUG
502760	ARM HOLE PLUG
502785	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING STUD

502802	NEEDLE BAR YOKE CONNECTING LINK HINGE STUD SNAP RING (2)
502825	NEEDLE VIBRATING CAM SHAFT BUSHING (FRONT)
502957	NEEDLE BAR YOKE CONNECTING LINK
502958	NEEDLE BAR YOKE CONNECTING LINK SNAP RING (2)
502959	NEEDLE VIBRATING CAM ROLLER GUIDE
502960	NEEDLE VIBRATING CAM ROLLER (2)
502961	NEEDLE VIBRATING CAM ROLLER STUD SPRING WASHER
502963	NEEDLE VIBRATING CAM ROLLER STUD WASHER
502964	NEEDLE VIBRATING CAM ROLLER NEEDLE BEARING CAGE (2)
502966	NEEDLE VIBRATING CAM SHAFT SLIDE BLOCK
502968	NEEDLE VIBRATING CAM SHAFT
502990	NEEDLE VIBRATING CAM ROLLER SPRING WASHER
500050	NEEDLE VIBRATING CAM SHAFT BUSHING SPACER
543833-001	NEEDLE VIBRATING CAM SHAFT BUSHING (BACK) SCREW GASKET (2)
544286	NEEDLE VIBRATING ECCENTRIC SHAFT BUSHING (BACK) SCREW (2)
544286	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING PINCH SCREW
544307	NEEDLE VIBRATING WORM WHEEL SET SCREW (2)
544782	NEEDLE POSITION FINE ADJUSTMENT HOLE PLUG
545135-452	NEEDLE VIBRATING CAM SET SCREW (2)
545249-452	NEEDLE VIBRATING WORM WHEEL DISC SCREW (3)




411046	NEEDLE POSITION ADJUSTING CAM REGULATING STUD
* 411162	ARM COVER (FRONT) CPL. NOS., 411163, 502829 AND TWO 544293
* 411163	ARM COVER (FRONT)
411166	NEEDLE BAR YOKE CONNECTING LINK CARRIER FRAME AND BLOCK CPL. NOS., 411166, 502850, 411246 AND TWO 504048
411166	NEEDLE BAR YOKE CONNECTING LINK CARRIER FRAME
411170	NEEDLE POSITION ADJUSTING CAM SLIDE BLOCK BRACKET CPL. NOS., 544293, 544308 AND TWO 500067
411246	NEEDLE BAR YOKE CONNECTING LINK SLIDE STUD
500067-833	NEEDLE POSITION ADJUSTING CAM STOP SCREW SET SCREW (2)
500302-850	NEEDLE POSITION ADJUSTING ECCENTRIC STOP SCREW (2)
502770	ARM COVER (FRONT) GASKET

502829	STITCH LENGTH INDICATOR PLATE
502850	NEEDLE BAR YOKE CONNECTING LINK SLIDE BEARING
502951-850	NEEDLE POSITION ADJUSTING CAM SET SCREW
504048	NEEDLE BAR YOKE CONNECTING LINK CARRIER FRAME SLIDE STUD SET SCREW (2)
509007	NEEDLE POSITION ADJUSTING LEVER
543833-001	ARM COVER (FRONT) SCREW GASKET RING (3)
544283	NEEDLE POSITION ADJUSTING CAM STOP SCREW (UPPER)
544284	ARM COVER (FRONT) PLUG SCREW
544286	NEEDLE POSITION ADJUSTING CAM SLIDING BLOCK BRACKET SCREW (2)
544286	ARM COVER (FRONT) SCREW (3)
544293	STITCH LENGTH INDICATOR PLATE SCREW (2)
544302	NEEDLE POSITION ADJUSTING CAM REGULATING STUD SET SCREW
544308	NEEDLE POSITION ADJUSTING CAM STOP SCREW (LOWER)




- * 129.860 FEED REGULATING SHAFT INDICATOR LEVER SCREW
- * 411065 FEED REGULATING CONNECTION SHAFT COLLAR WITH TWO 545174-452
- * 411082 FEED REGULATING SHAFT INDICATOR (PL. NOS., 129, 411149, 411150 AND 543801-005)
- * 411149 FEED REGULATING SHAFT INDICATOR LEVER
- * 411150 FEED REGULATING SHAFT INDICATOR LEVER CONNECTING LINK
- * 411184 FEED REGULATING CONNECTION SHAFT
- * 500309.850 FEED REGULATING SHAFT INDICATOR STOP SCREW (2)
- * 500310.833 FEED REGULATING RETAINING SPRING SCREW

- * 502849 FEED REGULATING SHAFT INDICATOR STOP SCREW RETAINING SPRING
- * 502868 FEED REGULATING CONNECTION SHAFT BUSHING
- * 502871 FEED REGULATING SHAFT LEVER POSITION PIN
- * 502878 FEED REGULATING SHAFT LEVER WITH 502871
- * 502979 FEED REGULATING SHAFT SPACER
- * 543801-305 FEED REGULATING SHAFT INDICATOR LEVER HINGE STUD RETAINER
- * 543801-005 FEED REGULATING CONNECTION SHAFT CRANK LINK RETAINING RING
- * 545174-452 FEED REGULATING CONNECTION SHAFT COLLAR SET SCREW (2)




460-833	THREAD PULL OFF SET SCREW
460-833	PRETENSION BRACKET SCREW
460-833	PRETENSION BRACKET SET SCREW
50305-850	TENSION STUD SET SCREW
210958	PRETENSION STUD COLLAR
210993	PRETENSION SLEEVE
270086	TENSION RELEASING PIN
272208	PRETENSION SPRING
272219	TENSION SPRING
411017	PRETENSION CPL. NOS., 210958, 210993, 272208 411018, 411019 AND 411021
411018	PRETENSION STUD
411019	PRETENSION ADJUSTING NUT CPL. NOS., 411020 AND 541181
411020	PRETENSION ADJUSTING NUT SPRING
411021	PRETENSION BRACKET WITH 460

411025	TENSION CPL. NOS., 272219, 411028, 411153 TO 411156, 411158, 509076, 541182 AND TWO 411152
411026	THREAD TAKE-UP SPRING REGULATOR WITH 50305
411152	TENSION FELT WASHER (2)
411153	THREAD TAKE-UP SPRING
411154	TENSION THUMB NUT LOCK WASHER
411155	TENSION WHEEL
411158	TENSION STUD
50246-850	THREAD GUIDE SCREW (2)
502665	THREAD GUIDE
502665	THREAD PULL OFF
509076	TENSION RELEASING DISC
541131	PRETENSION ADJUSTING NUT
541132	TENSION THUMB NUT
544303	THREAD REGULATOR SET SCREW




50429-833	BOBBIN WINDER SHAFT FRICTION WHEEL SET SCREW (2)
50429-833	ARM COVER (TOP) THREAD TENSION STUD SET SCREW
411089	ARM COVER (TOP) CPL. NOS., 50429, 411090, 411092, 411093, 411101, 411106, 500280, 502909, 502986, 508555 TO 508558, 508562 TO 508565, 541179, TWO EACH 502832, 508561, AND 544281
411090	ARM COVER (TOP)
411092	THREAD RETAINER
411093	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) CPL. NOS., 411094, 411095, 411098, 411178, 508553, 508554 AND TWO 547412
411094	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) WITH 411179
411095	BOBBIN WINDER SHAFT WITH 411097
411097	BOBBIN SNAP SPRING
411098	BOBBIN WINDER SHAFT FRICTION WHEEL WITH TWO 50429
411101	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) ROCKING LEVER
411106	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) TRIP LEVER CPL. NOS., 411107, 411108, 543805-008 AND 544211-001
411107	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) TRIP LEVER (LONG)
411108	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) TRIP LEVER (SHORT)
411178	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) CONNECTING LEVER
411179	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) BEARING
500280-050	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) TRIP LEVER CAP SCREW

502832	ARM COVER (TOP) PLUG (2)
502909	ARM COVER (TOP) GASKET
502986	PRESSER FOOT PRESSURE ADJ. HOLE
508553	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) SPRING SHACKLE
508554	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) LINK STUD
508555	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) SNAP RING
508556	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) THREAD GUARD
508557	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) COIL SPRING
508558	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) COIL SPRING STUD
508561	ARM COVER (TOP) POSITION PIN (2)
508562	ARM COVER (TOP) THREAD GUIDE STUD
508563	ARM COVER (TOP) THREAD TENSION STUD
508564	ARM COVER (TOP) THREAD TENSION STUD SPRING
508565	ARM COVER (TOP) THREAD TENSION STUD DISC
541179	THREAD RETAINER LOCK NUT
543805-008	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) TRIP LEVER SCREW WASHER
543833-001	ARM COVER (TOP) SCREW GASKET RING (8)
544211-001	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) TRIP LEVER SCREW
544281	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) THREAD GUARD FASTENING SCREW (2)
544284	ARM COVER (TOP) SCREW (SHORT) (4)
544285	ARM COVER (TOP) SCREW (LONG) (4)
547412	BOBBIN WINDER SHAFT BUSHING (ECCENTRIC) LINK STUD LOCKING WASHER (2)









190-850	BOBBIN CASE STOP SCREW
141507-003	HOOK NEEDLE GUARD AND COUNTERBALANCE SCREW
141525-806	HOOK GIB SCREW (3)
200592-803	BOBBIN CASE CAP TENSION SPRING SCREW
200964-803	BOBBIN CASE LATCH STOP SCREW
201016-803	BOBBIN CASE CAP TENSION SPRING REGULATING SCREW
210735	BOBBIN CASE FULCRUM PIN
210736	BOBBIN CASE LATCH SPRING
210913	BOBBIN CASE LATCH
233028-452	BOBBIN

500306-869	HOOK SET SCREW (2)
502530	BOBBIN CASE CAP WITH 200592, 200964, 201016, 210735, 210736, 210913, 502717 AND 508530
502534	HOOK AND BOBBIN CASE CPL. NDS., 502530 AND 502718
502536	BOBBIN CASE STOP
502717	BOBBIN CASE LATCH LEVER
502718	HOOK WITH 141507, 508537, TWO 500306 AND THREE 141525
508530	BOBBIN CASE CAP TENSION SPRING
508537	HOOK NEEDLE GUARD AND COUNTERBALANCE




271808	HOOK SHAFT OIL FILTER WICK HOLDER SEAL
411003	HOOK DRIVING SHAFT HELICAL GEAR WITH TWO 504101
411039	HOOK DRIVING SHAFT BEVEL GEAR WITH TWO 504101
411040	HOOK SHAFT BEVEL GEAR WITH TWO 504101
411122	HOOK OIL REGULATING SCREW CPL. NOS., 500247 AND 545425-452
411123	HOOK SHAFT WITH 271808, 502928 AND 544320
500247-833	HOOK OIL REGULATING SCREW
500264-833	HOOK SHAFT BUSHING (FRONT) SET SCREW
502516	HOOK DRIVING SHAFT BUSHING WICK
502566	HOOK DRIVING SHAFT
502566	HOOK DRIVING SHAFT BUSHING
502572	HOOK SHAFT BUSHING CAP GASKET
502577	HOOK SHAFT GEAR BOX PLUG
502581	HOOK SHAFT BUSHING (BACK)
502582	HOOK SHAFT BUSHING (BACK) WICK

502611	HOOK SHAFT BUSHING CAP
502676	HOOK SHAFT BUSHING (BACK) CPL. NOS., 502581 AND 502582
502713	HOOK DRIVING SHAFT BUSHING CPL. NOS., 502516 AND 502566
502818	HOOK SHAFT GEAR BOX VENT CAP
502928	HOOK SHAFT OIL FILTER FELT
504101	HOOK DRIVING SHAFT HELICAL GEAR SET SCREW (2)
504101	HOOK DRIVING SHAFT BEVEL GEAR SET SCREW (2)
504101	HOOK SHAFT BEVEL GEAR SET SCREW (2)
504134	HOOK OIL BYPASS PLUG SCREW
503914	HOOK SHAFT BUSHING (FRONT)
544305	HOOK DRIVING SHAFT BUSHING SET SCREW
544305	HOOK SHAFT BUSHING (FRONT) SET SCREW
544320	HOOK SHAFT OIL FILTER WICK HOLDER
545425-452	HOOK OIL REGULATING SCREW LOCK NUT
545013	HOOK SHAFT BUSHING (FRONT) CAP SCREW (3)




1177-250	FEED DRIVING CONNECTION CRANK PINCH SCREW	502866	FEED DRIVING CONNECTION CARRIER FRAME SPRING
51369-850	FEED DRIVING CONNECTION CARRIER FRAME SLIDE STUD SET SCREW	502867	FEED DRIVING CONNECTION CARRIER FRAME SPRING STUD (BED SIDE)
* 411059	FEED DRIVING CONNECTION CARRIER FRAME CPL. NOS., 51369, 411060, 502850, 502857, 502858 AND 502949	502931	FEED DRIVING CONNECTION CARRIER FRAME SPRING RETAINER
* 411060	FEED DRIVING CONNECTION CARRIER FRAME	502932	FEED DRIVING CONNECTION CARRIER FRAME SPRING CPL. NOS., 502866 AND 502931
* 411061	FEED DRIVING CONNECTION CPL. NOS., 502843, 502844, 502847, TWO 502845 AND FOUR 543801-005	502949	FEED DRIVING CONNECTION CARRIER FRAME SPRING STUD
* 411062	FEED REGULATING CONNECTION SHAFT CRANK AND LINK CPL. NOS., 411063, 502862 AND 543801-005	504066-452	FEED DRIVING CONNECTION CARRIER FRAME STUD (LEFT) SET SCREW
* 411063	FEED REGULATING CONNECTION SHAFT CRANK WITH 544286	507523	FEED DRIVING CONNECTION CARRIER FRAME STOP SCREW WASHER (2)
* 502843	FEED DRIVING CONNECTION LEVER	508523	FEED DRIVING CONNECTION CARRIER FRAME STOP (BACK)
* 502844	FEED DRIVING CONNECTION LINK	508524	FEED DRIVING CONNECTION CARRIER FRAME STOP (FRONT)
* 502845	FEED DRIVING CONNECTION LEVER HINGE PIN (2)	543801-005	FEED DRIVING CONNECTION LEVER HINGE PIN RETAINER (4)
* 502847	FEED DRIVING CONNECTION CRANK WITH 1177	543801-005	FEED REGULATING CONNECTION SHAFT CRANK LINK RETAINING RING
502850	FEED DRIVING CONNECTION LEVER SLIDE BEARING	544286	FEED REGULATING CONNECTION SHAFT CRANK PINCH SCREW
502857	FEED DRIVING CONNECTION CARRIER FRAME SLIDE STUD	544287	FEED DRIVING CONNECTION CARRIER FRAME STOP SCREW (2)
* 502858	FEED DRIVING CONNECTION CARRIER FRAME SLIDE STUD OIL WICK	544307	FEED DRIVING CONNECTION CARRIER FRAME STUD (RIGHT) SET SCREW
* 502859	FEED DRIVING CONNECTION CARRIER FRAME BEARING STUD (LEFT)		
* 502860	FEED DRIVING CONNECTION CARRIER FRAME BEARING STUD (RIGHT)		
502862	FEED REGULATING CONNECTION SHAFT CRANK LINK		




* 449-833	FEED DRIVING ECCENTRIC SET SCREW
51388-850	FEED BAR LIFTING LINK PIN CAP SCREW
140930-869	BED SHAFT CONNECTION BELT PULLEY SET SCREW (2)
272144	BED SHAFT BALL BEARING
411002	BED SHAFT GEAR WITH TWO 504101
411023	FEED DRIVING ROCK SHAFT CRANK WITH 500257, 504048 AND 504134
411030	FEED BAR WITH 544291
411037	OIL PUMP DRIVING GEAR WITH TWO 504102
411118	FEED DRIVING ROCK SHAFT COLLAR (2) WITH TWO 544053
500257-850	FEED DRIVING ROCK SHAFT CRANK PINCH SCREW
* 500308-833	FEED DRIVING ECCENTRIC POSITION SCREW
502515	BED SHAFT BUSHING (FRONT)
502516	BED SHAFT BUSHING (FRONT) OIL WICK
502517	BED CONNECTION BELT PULLEY
502518-002	BED CONNECTION BELT PULLEY SPACER
502541	FEED BAR HINGE PIN
502542	FEED BAR HINGE PIN OILING FELT
502544	FEED BAR HINGE PIN THRUST WASHER (2)
502545	FEED BAR LIFTING LINK
502546	FEED BAR LIFTING LINK HINGE PIN
* 502558	FEED DRIVING ROCK SHAFT BUSHING (BACK)
502560-002	FEED DRIVING ROCK SHAFT OIL WICK

502675-002	FEED DRIVING ROCK SHAFT CRANK CPL. NOS., 51388, 411028, 411030, 502541, 502542, 502545, 502546 AND TWO 502544
502703	BED SHAFT BUSHING (FRONT) CPL. NOS., 502515 AND 502516
502704	BED SHAFT CONNECTION BELT PULLEY CPL. NOS., 502517 AND TWO 140930
502752	BED SHAFT OIL HOLE PLUG
502826	FEED DRIVING ROCK SHAFT BUSHING (FRONT)
* 502837	BED SHAFT
502838	BED SHAFT BUSHING (BACK)
* 502839	FEED DRIVING ECCENTRIC WITH 449 AND 500308
* 502879	FEED DRIVING ROCK SHAFT CPL. NOS., 502560-002 AND 502880
* 502880	FEED DRIVING ROCK SHAFT
502888	BED SHAFT BUSHING (CENTER)
502892	FEED DRIVING ROCK SHAFT BUSHING (CENTER)
504048	FEED BAR HINGE PIN SET SCREW (SHORT)
504101	BED SHAFT GEAR SET SCREW (2)
504102	OIL PUMP DRIVING GEAR SET SCREW (2)
504134	FEED BAR HINGE PIN SET SCREW (LONG)
544053	FEED DRIVING SHAFT COLLAR SET SCREW (4)
544291	FEED BAR LIFTING LINK HINGE PIN SCREW
544305	BED SHAFT BUSHING SET SCREW (3)




500295-850	BED SHAFT GEAR BOX COVER DRAIN SCREW
500250	MACHINE LEG SCREW (2)
502571	BED SHAFT GEAR BOX COVER GASKET
502543	FEED BAR HINGE PIN OILING FELT CLAMP
502573	HOOE SHAFT GEAR BOX COVER
502574	HOOE SHAFT GEAR BOX COVER GASKET
502593	MACHINE LEG
502036	ARM COVER (BACK)
502832	FEED REGULATING SHAFT PLUG
502833	ARM COVER (BACK) GASKET

502881	BED SHAFT GEAR BOX COVER
502884	BED PLUG (FRONT AND REAR SIDE) (2)
502885	BED PLUG (BACK) (2)
502925	BED PLUG SCREW
502956	NEEDLE VIBRATING ADJUSTING CRANK SHAFT HOLE PLUG (2)
543833-001	ARM COVER (BACK) SCREW GASKET (5)
544284	ARM COVER SCREW (6)
544287	BED SHAFT GEAR BOX COVER SCREW (6)
544287	HOOE SHAFT GEAR BOX COVER SCREW (4)




201-850	OIL SIGHT BODY SCREW (2)
207-850	HEAD END OIL DRAIN WICK CLAMP SCREW (2)
998-833	OIL RETURN TUBE SCREW
16380	OIL REMOVING LINT SCREEN
117592	HOOK SHAFT GEAR BOX OIL PIPE CONNECTOR
411147	OIL PUMP GEAR WITH TWO 504007
411207	OIL PUMP BODY CPL. NOS. 411147, 411208, 411210, 411211, 504010-451, 540558, AND 540625
411208	OIL PUMP BODY
411210	OIL PUMP SCREW SHAFT
411211	OIL REMOVING PUMP PISTON SPRING BRACKET
411212	OIL REMOVING TUBE, OIL REMOVING LINT SCREEN CPL. NOS., 16380, 411213 AND 411217
411213	OIL REMOVING TUBE
411217	OIL REMOVING TUBE WIRE
411389	OIL RETURN TUBE LOWER (LONG) CPL. NOS., 502648-002 AND 411390
411390	OIL RETURN TUBE
500104-850	ARM OIL SHIELD (AERATED PLASTIC) RETAINER SCREW (2)
500115-850	OIL DISTRIBUTOR PLATE SCREW
502505	HEAD END OIL DRAIN WICK CLAMP (FRONT)
502575	HOOK SHAFT GEAR BOX OIL PIPE WITH 117592

502575	HOOK SHAFT GEAR BOX OIL PIPE WITH 117592
502635-002	OIL DELIVERY TUBE
502647-002	OIL RETURN TUBE UPPER (SHORT)
502648-002	OIL RETURN TUBE LOWER (LONG)
502650-002	OIL SIGHT BODY WITH 502051
502651	OIL SIGHT WICK
502752	RED SHAFT RUSHING (CENTER) OIL HOLE PLUS
502764	OIL GUARD
502834	ARM OIL SHIELD (AERATED PLASTIC) RETAINER
502890	ARM OIL SHIELD (AERATED PLASTIC)
502919	HEAD END OIL DRAIN CLAMP (BACK)
504007	OIL PUMP GEAR SET SCREW (2)
504010-451	OIL REMOVING PUMP PISTON SPRING BRACKET SET SCREW
508514	OIL DISTRIBUTOR PLATE
508878	OIL DISTRIBUTOR PLATE FOAM PAD
508943	OIL DISTRIBUTOR PLATE CPL. NOS. 508514 AND 508878
508960	HOOK SHAFT GEAR BOX OIL PIPE
540558	OIL REMOVING PUMP PISTON
540625	OIL REMOVING PUMP PISTON SPRING
544284	OIL GUARD SCREW (2)
544285	OIL PUMP MOUNTING SCREW (2)



50150-833	FEED REVERSING FOOT CONTROL LEVER PIN COLLAR SET SCREW
87018	KNEE LIFTER RETURNING SPRING
411114	FEED REVERSING FOOT CONTROL LEVER PIN COLLAR WITH 50150
411128	KNEE LIFTER ROCK SHAFT SPACER
411137	MACHINE BASE AND OIL RESERVOIR
411140	MACHINE BASE AND OIL RESERVOIR (CPL.) NOS., 411128, 411137, 502987, 545036-819 AND 545754
411173	MACHINE BASE AND OIL RESERVOIR CUSHION
411384	OIL RESERVOIR AND KNEE LIFTER ASS'Y NOS., 87018, 411114, 411140, 502720, 502937, 502996, 502999, 503000, 508501 AND TWO 508502
416725	KNEE LIFTER KNEE PLATE CPL.
500271-833	KNEE LIFTER CONTROL SHAFT CRANK STOP SCREW
500332-850	KNEE LIFTER ROCK SHAFT HUB PINCH SCREW (2)
500785-850	KNEE LIFTER CONTROL SHAFT CRANK STOP SCREW NUT
502583	KNEE LIFTER KNEE PLATE ARM
502587-002	KNEE LIFTER PLUNGER
502589	KNEE LIFTER ROCK SHAFT
502591	KNEE LIFTER ROCK SHAFT HUB
502720	KNEE LIFTER ROCK SHAFT HUB WITH TWO 500332
502937	FEED REVERSING FOOT CONTROL LEVER PIN




502987	FEED REVERSING PLUNGER HOLE PLUG
502996	KNEE LIFTER CONTROL SHAFT CPL. NOS., 500271, 500785, 502997, 502998 AND 508302
502997	KNEE LIFTER CONTROL SHAFT
502998	KNEE LIFTER CONTROL SHAFT CRANK
502998	KNEE LIFTER ROCK SHAFT CRANK
502999	KNEE LIFTER ROCK SHAFT CPL. NOS., 502589, 502998 AND 508302
503000	KNEE LIFTER CONTROL SHAFT GRIP RING
508302	KNEE LIFTER CONTROL SHAFT CRANK PIN
508302	KNEE LIFTER ROCK SHAFT CRANK PIN
508501	KNEE LIFTER ROCK SHAFT CONNECTION
508502	KNEE LIFTER ROCK SHAFT CONNECTION GRIP RING (2)
540520	MACHINE BASE AND OIL RESERVOIR CUSHION (FRONT) WITH TWO WIRE NAIL (2)
540521	MACHINE BASE AND OIL RESERVOIR CUSHION (BACK) WITH TWO WIRE NAIL (2)
540522	MACHINE HINGE (2)
540523	MACHINE HINGE CONNECTION CUSHION (2)
545036-819	MACHINE BASE AND OIL RESERVOIR DRAIN PLUG SCREW
545754	MACHINE BASE AND OIL RESERVOIR DRAIN PLUG SCREW GASKET



* N1906-01	NEEDLE (CAT. NO. 1906-01, #14) (5)
144455	WRENCH (1/8 INCH HEXAGON)
233028-452	BUBBIN (2)
410154	OIL CAN (750 CC. FILLED WITH SINGER TYPE "C" OIL)
410186	MACHINE REST P/N
411110	OIL FILTER
411116	SCREW DRIVER (LARGE)
411125-451	THREAD UNWINDER FOOT WITH TWO 504029
411127	THREAD UNWINDER ROD (2)
411129-451	THREAD UNWINDER ROD CONNECTION CPL. NOS., 411130-451, TWO EACH 541183 AND 544218-056
411130-451	THREAD UNWINDER ROD CONNECTION
411133	THREAD UNWINDER ROD CAP
411134	THREAD UNWINDER SPOOL (2)
411135-451	THREAD UNWINDER SPOOL CARRIER ARM CPL. NOS., 411136-451, 541166-004, 543805-004 AND 544278-061
411136-451	THREAD UNWINDER SPOOL CARRIER ARM
411138-451	THREAD UNWINDER SPOOL CARRIER PLATE (2)
411139	THREAD UNWINDER SPOOL CARRIER PLATE CUSHION (2)
411141-451	THREAD UNWINDER THREAD GUIDE CPL. NOS., 411142-451, 541166-004, 543805-004 AND 544278-061
411142-451	THREAD UNWINDER THREAD GUIDE WITH TWO 411143
411143	THREAD UNWINDER THREAD GUIDE EYELET (2)
411151-451	THREAD UNWINDER (2-SPOOL) CPL. NOS., 411125-451, 411129-451, 411133, 411135-451, 411141-451, TWO EACH 411127, 411134, 411138-451, 411139, 541166-004, 543803-004, 543805-004, 546893 AND THREE 544112


503669	WRENCH (5/64 INCH HEXAGON)
503673	SOCKET WRENCH
504029	THREAD UNWINDER ROD SET SCREW (2)
509004	BOBBIN CASE ANTISPILLAGE SPRING
541166-004	THREAD UNWINDER SPOOL CARRIER ARM SCREW NUT
541166-004	THREAD UNWINDER SPOOL LOCK NUT (2)
541166-004	THREAD UNWINDER THREAD GUIDE SCREW NUT
541183	THREAD UNWINDER ROD CONNECTION SCREW NUT (2)
541514	SCREW DRIVER (SMALL)
543803-003	MACHINE GROUNDING WIRE SCREW WASHER
543803-004	THREAD UNWINDER SPOOL LOCK NUT WASHER (2)
543805-004	THREAD UNWINDER SPOOL CARRIER ARM SCREW SPRING WASHER
543805-004	THREAD UNWINDER SPOOL LOCK NUT SPRING WASHER (2)
543805-004	THREAD UNWINDER THREAD GUIDE SCREW SPRING WASHER
544112	THREAD UNWINDER FOOT SCREW (WOOD) (3)
544212-003	MACHINE GROUNDING WIRE SCREW
544218-056	THREAD UNWINDER ROD CONNECTION SCREW (2)
544278-001	THREAD UNWINDER SPOOL CARRIER ARM SCREW
544278-061	THREAD UNWINDER THREAD GUIDE SCREW
545082-451	ATTACHMENT SCREW
546893	THREAD UNWINDER SPOOL HOLDER (2)
603251	MACHINE GROUNDING WIRE SYMBOL

PARTS FOR MACHINE 457U140



1664	FEED CONTROL CAM FOLLOWER ARM RETAINING NUT	** 508787	FEED CONTROL CAM MOUNTING BRACKET WITH 500014
411174	FEED CONTROL CAM SHAFT WORM WHEEL CPL. NOS. TWO 544307 AND THREE 545249-452	** 508788	FEED CONTROL CAM SHAFT WITH 411240
** 411195	FEED CONTROL CAM WITH TWO 545136-452	** 508793	FEED CONTROL CAM FOLLOWER ARM HINGE PIN
** 411197	FEED CONTROL CAM FOLLOWER CPL. NOS. 1664, 502802, 502961, 508793, 544371, TWO EACH 502960 AND 502964	** 508795	FEED CONTROL CONNECTION CPL. NOS. 500763, 508796 AND 508797
** 411240	FEED CONTROL CAM SHAFT OIL WICK	** 508796	FEED CONTROL CONNECTION BALL JOINT (FEMALE)
** 500014-860	FEED CONTROL CAM MOUNTING BRACKET BUSHING SET SCREW	** 508797	FEED CONTROL CONNECTION BALL JOINT (MALE)
** 500763-809	FEED CONTROL CONNECTION LOCK NUT	** 541180	FEED CONTROL CONNECTION CRANK ADJUSTING LOCK NUT
** 502744	FEED CONTROL CAM FOLLOWER ARM RETAINING RING	543805-004	FEED CONTROL CAM MOUNTING BRACKET SCREW LOCK WASHER (3)
502802	FEED CONTROL CONNECTION LOCK ARM HINGE PIN RETAINING RING	544285	FEED CONTROL CAM MOUNTING BRACKET SCREW (3)
502960	FEED CONTROL CAM FOLLOWER ROLLER (2)	544307	FEED CONTROL CAM SHAFT WORM WHEEL SET SCREW (2)
502961	FEED CONTROL CAM FOLLOWER BELLEVILLE WASHER	** 544369	FEED CONTROL CONNECTION HINGE SCREW
502963	FEED CONTROL CAM FOLLOWER ARM WASHER	** 544370	FEED CONTROL CONNECTION ADJUSTING SCREW
502964	FEED CONTROL CAM FOLLOWER ROLLER NEEDLE BEARING (2)	** 544371	FEED CONTROL CAM FOLLOWER ARM HINGE SCREW
502990	FEED CONTROL CAM FOLLOWER ARM BELLEVILLE WASHER	545136-452	FEED CONTROL CAM SET SCREW (2)
507523	FEED CONTROL CONNECTION ADJUSTING SCREW BELLEVILLE WASHER	545249-452	FEED CONTROL CAM WORM WHEEL DISC SCREW (3)
		** 546517	FEED CONTROL CAM FOLLOWER ARM WASHER (2)
		** 548035	FEED CONTROL CAM MOUNTING BRACKET DOWEL PIN (2)





PARTS FOR MACHINE 457U140




1177	FEED CONTROL CONNECTION CRANK PINCH SCREW
51388-850	FEED BAR LIFTING LINK P.N. CAP SCREW
140938-869	BED SHAFT CONNECTION BELT PULLEY SET SCREW (2)
272144	BED SHAFT BALL BEARING
411002	BED SHAFT GEAR WITH TWO 504101
411028	FEED DRIVING ROCK SHAFT CRANK WITH 500257, 504048 AND 504134
411030	FEED BAR WITH 544291
411037	OIL PUMP DRIVING GEAR WITH TWO 504102
411118	FEED DRIVING ROCK SHAFT COLLAR (2) WITH TWO EACH 544053
** 411192	BED SHAFT WORM WITH FOUR 504101
** 411193	FEED CONTROL CONNECTION CRANK WITH 1177
500257-850	FEED DRIVING ROCK SHAFT CRANK PINCH SCREW
502515	BED SHAFT BUSHING (FRONT)
502516	BED SHAFT BUSHING (FRONT) OIL WICK
502517	BED CONNECTION BELT PULLEY
502518-002	BED CONNECTION BELT PULLEY SPACER
502541	FEED BAR HINGE PIN
502542	FEED BAR HINGE PIN OILING FELT
502544	FEED BAR HINGE PIN THRUST WASHER (2)
502545	FEED BAR LIFTING LINK
502546	FEED BAR LIFTING LINK HINGE PIN
502560-002	FEED DRIVING ROCK SHAFT OIL WICK

502675-002	FEED DRIVING ROCK SHAFT CRANK CPL. NOS., 51388, 411028, 411030, 502541, 502542, 502545, 502546 AND TWO 502544
502703	BED SHAFT BUSHING (FRONT) CPL. NOS., 502515 AND 502516
502704	BED SHAFT CONNECTION BELT PULLEY CPL. NOS., 502517 AND TWO 140938-869
502752	BED SHAFT PLUG
502826	FEED DRIVING SHAFT BUSHING (FRONT)
502826	FEED DRIVING SHAFT BUSHING (CENTER) (2)
502838	BED SHAFT BUSHING (BACK)
502888	BED SHAFT BUSHING (CENTER)
502832	FEED DRIVING ROCK SHAFT BUSHING (CENTER)
504048	FEED BAR HINGE PIN SET SCREW (SHORT)
504101	BED SHAFT GEAR SET SCREW (2)
504101	BED SHAFT WORM SET SCREW (4)
504102	OIL PUMP DRIVING GEAR SET SCREW (2)
504134	FEED BAR HINGE PIN SET SCREW (LONG)
** 508784	BED SHAFT
** 508799	FEED DRIVING ROCK SHAFT WITH 502560-002
544053	FEED DRIVING ROCK SHAFT COLLAR SET SCREW (4)
544291	FEED BAR LIFTING LINK HINGE PIN SCREW
544305	BED SHAFT BUSHING SET SCREW (3)

PARTS FOR MACHINE 457U140





Accessories



- ** N3752-62 NEEDLE (CAT. NO. 8752-62, #14)
- ** N3752-62 NEEDLE (CAT. NO. 8752-62, #14) (5)
- (FOR ACCESSORIES)
- ** 200304 PRESSER FOOT CONNECTION HINGE SCREW
- ** 200391 PRESSER FOOT SHANK HINGE PIN SET SCREW
- ** 241414 PRESSER FOOT BRACKET WITH 200391-452
- ** 241415 PRESSER FOOT CONNECTION LEVER
- ** 241421 PRESSER FOOT SHANK HINGE PIN
- ** 241422 PRESSER FOOT SHANK SPRING (2)
- ** 266008 FEED DOG
- ** 266123 PRESSER FOOT COMPENSATING SHANK (LEFT)
- WITH 503979-015
- ** 266124 PRESSER FOOT COMPENSATING SHANK (RIGHT)
- WITH 503979-015

- ** 266125 PRESSER FOOT (HINGED) (COMPENSATING) CPL.
- NOS., 200304-452, 241414, 241415, 241421, 266123,
- 266124 AND TWO 241422
- ** 266132 THROAT PLATE
- ** 411187 ARM COVER (FRONT)
- ** 411196 FEED CONTROL CAM (FOR ACCESSORIES) WITH TWO
- 545136-452
- ** 502986 FEED REGULATING SHAFT PLUG
- ** 503979-015 PRESSER FOOT PLATE (LEFT) HINGE PIN
- ** 503979-015 PRESSER FOOT PLATE (RIGHT) HINGE PIN
- ** 545136-452 FEED CONTROL CAM SET SCREW (2)
- (FOR ACCESSORIES)



457U OPTIONAL PARTS



411198	BELT GUARD CPL. VOS, 411199, 411200, 411202, 544387, TWO 544085 AND EIGHT 544217-001
411199	BELT GUARD
411200	BELT GUARD (LOWER)
411202	BELT GUARD PLATE
411243	FOOT CONTROL REVERSE FEED BLOCK WITH 549163

* 503689	PRESSER FOOT
* 503822	PRESSER FOOT
544085	BELT GUARD (LOWER) SCREW (WOOD) (2)
544217-001	BELT GUARD SCREW (SMALL) (4)
544217-001	BELT GUARD PLATE SCREW (4)
544387	BELT GUARD SCREW (LARGE)
549163	FOOT CONTROL REVERSE FEED BLOCK SCREW

PARTS FOR 457UX 135/UX 140



1664-850	NEEDLE VIBRATING CAM ROLLER STUD NUT
411053	NEEDLE VIBRATING CAM SHAFT BUSHING (BACK)
411075	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING WITH 544286
411146	NEEDLE VIBRATING CAM WITH TWO 545136-452
411169	NEEDLE VIBRATING CAM ROLLER STUD
411174	NEEDLE VIBRATING WORM WHEEL CPL. NOS., TWO 544307 AND THREE 545249-452
411220	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING STUD
411221	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING BUSHING (FRONT)
411222	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING BUSHING (BACK)
411223	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING CPL. NOS., 411075, 411221, 411222 AND 544286
411226	NEEDLE BAR YOKE CONNECTING LINK CPL. NOS., 1664, 411169, 411220, 411223, 411226, 502619, 502959, 502961, 502963, 502990, 545181-451, TWO EACH 502953, 502960 AND 502964
500303-889	NEEDLE VIBRATING CAM SHAFT BUSHING (FRONT) SET SCREW
502577	NEEDLE VIBRATING CAM SHAFT BUSHING (FRONT) SET SCREW PLUG
502619	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING FELT
502751	NEEDLE VIBRATING CAM SHAFT BUSHING (BACK) PLUG
502760	NEEDLE VIBRATING CAM SHAFT BUSHING (FRONT) PLUG

502760	ARM HOLE PLUG
502825	NEEDLE VIBRATING CAM SHAFT BUSHING (FRONT)
502958	NEEDLE BAR YOKE CONNECTING LINK SNAP RING (2)
502959	NEEDLE VIBRATING CAM ROLLER GUIDE
502960	NEEDLE VIBRATING CAM ROLLER (2)
502961	NEEDLE VIBRATING CAM ROLLER STUD SPRING WASHER
502963	NEEDLE VIBRATING CAM ROLLER STUD WASHER
502964	NEEDLE VIBRATING CAM ROLLER NEEDLE BEARING CAGE (2)
502966	NEEDLE VIBRATING CAM SHAFT SLIDE BLOCK
502968	NEEDLE VIBRATING CAM SHAFT
502990	NEEDLE VIBRATING CAM ROLLER SPRING WASHER
502950	NEEDLE VIBRATING CAM SHAFT BUSHING SPACER
543801-003	NEEDLE BAR YOKE CONNECTING LINK HINGE STUD SNAP RING
543833-001	NEEDLE VIBRATING CAM SHAFT BUSHING (BACK) SCREW WASHER (2)
544286	NEEDLE VIBRATING ECCENTRIC SHAFT BUSHING (BACK) SCREW (2)
544286	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING PINCH SCREW
544307	NEEDLE VIBRATING WORM WHEEL SET SCREW (2)
545136-452	NEEDLE VIBRATING CAM SET SCREW (2)
545181-451	NEEDLE BAR YOKE CONNECTING LINK HINGE BEARING STUD SCREW
545249-452	NEEDLE VIBRATING WORM WHEEL DISC SCREW (3)

NUMERICAL PART NUMBER FOR 457U135/140

PART NO	PAGE	PART NO	PAGE	PART NO	PAGE	PART NO	PAGE
86-830	4	276509	1	411123	11	500196	17
129-850	7	411001	4	411125	17	500244	2, 4
190-850	10	411002	13, 19	411127	17	500245-850	14
201-850	15	411003	11	411128	16	500246-850	1, 9
207-850	15	411004	2	411129	17	500247-833	11
223	4	411005	2	411130	17	500250	14
237-833	1	411007	2	411131	4	500256	4
238	4	411009	2	411132	4	500257-850	13, 19
449-833	13	411010	2	411133	17	500260-833	3
460-833	9	411012	15	411134	17	500261-850	3
396-833	15	411013	15	411135	17	500262-833	1
1177-850	12, 19	411014	1	411136	17	500264-833	11
1349-850	3	411015	1	411137	10	500271-833	16
1454-850	1	411016	1	411138	17	500272-830	2
1664-850	5, 18	411017	9	411139	17	500274-833	2
16390	15	411018	9	411140	16	500280-850	8
41400	17	411019	9	411141	17	500302-850	6
50150-833	16	411020	9	411142	17	500303-869	5
50305-850	9	411021	9	411143	17	500306-869	10
50429-833	1, 2, 8	411023	3	411146	5	500307-850	2
50624-833	4	411024	3	411147	15	500308-833	13
51365-850	2, 4, 12	411025	9	411149	7	500309-850	7
51385	13, 19	411026	9	411150	7	500310-833	7
87018	16	411028	10, 19	411151	17	500312-850	3
117587	15	411030	13, 19	411152	9	500332-850	16
140930-869	13, 19	411032	2	411153	9	500763-909	18
141307-803	10	411035	4	411154	9	500765-850	16
141525-806	10	411037	13, 19	411155	9	502505	13
141667-833	2	411039	11	411158	9	502508	2
144465	17	411043	11	411160	2	502509	2
200304	20	411045	6	411162	6	502510	2
200301	20	411053	5	411163	6	502515	13, 19
200992-803	10	411054	3	411165	6	502516	11, 13, 19
200954-803	10	411055	3	411166	6	502517	13, 19
201016-809	10	411059	12	411168	5	502518-002	13, 19
210505	4	411060	12	411170	6	502521	14
210735	10	411061	12	411173	16	502530	10
210736	10	411062	12	411174	5, 18	502534	10
210813	10	411063	12	411178	8	502536	10
210958	9	411065	7	411179	8	502541	13, 19
210993	9	411074	5	411180	3	502542	13, 19
214206	2	411075	5	411183	2	502543	14
230743	1	411082	7	411184	7	502544	13, 19
233028	10, 17	411083	2	411187	20	502545	13, 19
241414	20	411085	1	411182	19	502546	13, 19
241415	20	411086	1	411193	19	502558	13
241421	20	411088	1	411195	18	502560-002	13, 19
241422	20	411089	8	411196	20	502565	11
266008	20	411090	8	411197	19	502566	11
266123	20	411092	8	411198	21	502572	11
266124	20	411093	8	411199	21	502573	14
266125	20	411094	8	411200	21	502574	14
266132	20	411095	8	411202	21	502575	15
270086	5	411097	8	411207	15	502577	5, 11
270161	2	411098	8	411208	15	502581	11
270286	2	411101	8	411210	15	502582	11
271808	11	411106	8	411211	15	502583	16
272126	1	411107	8	411212	15	502584	4
272142	2	411108	8	411213	15	502586	3
272143	2	411109	17	411217	15	502587-002	16
272144	13, 19	411110	17	411240	16	502589	16
272208	9	411112	16	411243	21	502591	16
272219	9	411114	16	411384	16	502593	14
276025	4	411116	17	500014-850	18	502594	4
276027	3	411118	13, 19	500067-833	6	502597	4
276051	1	411120	3	500104-850	15	502603	2
276114	2	411122	11	500115-850	15	502608	4

PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE	PART NO.	PAGE
502611	14	502884	14	508553	8	544283	6
502622	1	502885	14	508554	8	544284	8, 14, 15
502635-002	15	502888	13, 19	508555	8	544285	8, 15, 19
502647-002	15	502890	15	508556	8	544286	5, 6, 12
502648-002	15	502892	13, 19	508557	8	544287	12, 14
502650-002	15	502909	8	508558	8	544290	2
502651	15	502917	15	508561	8	544291	13, 19
502653	3	502919	15	508562	8	544292	3
502659	2	502925	14	508563	8	544293	6
502662	3	502927	2	508564	8	544295	3
502665	9	502928	11	508565	8	544296	3
502666	9	502930	4	508585	2	544298	1
502670	1	502931	12	508552	4	544301	4
502672	4	502932	12	508784	19	544302-850	6
502674	4	502937	16	508787	19	544303	9
502675-002	13, 19	502948	4	508788	18	544305	19
502676	11	502949	12	508793	18	544306	2
502679	3	502951-850	6	508795	18	544307	5, 12, 18
502682	2	502957	5	508796	18	544320	11
502703	13, 19	502958	5	508797	18	544369	18
502704	13, 19	502959	5	508799	19	544370	18
502713	11	502960	5, 18	508820	2	544371	18
502717	10	502961	5, 18	508878	15	544387	21
502718	10	502963	5, 18	508879-002	4	545036-819	16
502720	15	502964	5, 18	508880	4	545082-452	1, 17
502744	18	502968	5	508883	4	545136-452	5, 18, 20
502751	5	502968	5	508884	4	545174-452	7
502752	13, 15, 19	502979	7	508914	11	545208-452	3
502757	5	502986	14	508943	15	545244-452	1
502760	5	502987	16	508960	15	545249-452	2, 5, 18
502763	2	502990	5, 18	509004	17	545347-452	3
502764	15	502993	4	509007	5	545425-452	11
502770	6	502996	16	509050	5	545754	16
502785	5	502997	16	509076	9	545927	17
502786	3	502998	16	509087	2	546517	18
502802	5, 18	502999	16	540520	16	546883	17
502806	14	503000	16	540521	16	547412	8
502818	13	503669	17	540522	16	548035	18
502825	8	503673	17	540523	16	549013	11
502826	13, 19	503682	4	540556	15	549163	21
502829	6	503689	21	540625	15	603291	17
502831	2	503743	4	541166-004	17		
502832	8, 14	503818	4	541178	1		
502833	14	503822	21	541179	8		
502834	15	503979-016	20	541180	18		
502837	13	504007	15	541181	9		
502838	13, 19	504010-451	15	541182	9		
502839	13	504029	17	541183	17		
502843	12	504048	6, 12, 19	541514	17		
502844	12	504066-452	12	543801-005	3, 7, 12		
502845	12	504101	2, 11, 13, 19	543803-003	17		
502847	12	504102	13, 19	543803-004	17		
502849	7	504105	16	543805-003	1, 17		
502850	6, 12	504134	11, 13, 19	543805-004	17, 18		
502857	6, 12	504507	1	543805-008	8		
502858	12	504509-452	3	543833-001	5, 6, 8, 14		
502859	12	507523	12, 18	543833-002	2, 3		
502860	12	508302	16	543833-003	3		
502862	12	508501	16	543833-004	3		
502866	12	508502	16	544053	13, 19		
502867	12	508506	4	544085	21		
502868	7	508507	4	544112	17		
502871	7	508514	15	544211-051	8		
502878	7	508523	12	544217-001	21		
502879	13	508524	12	544218-056	17		
502880	13	508530	10	544278-061	17		
502881	14	508537	19	544281	6		