

PFAFF


9491


9493



BESTANDTEILELISTE
LIST OF SPARE PARTS
LISTE DE PIÈCES DÉTACHÉS
LISTA DE PIEZAS DE REPUESTO


MÁQUINA DE COLUNA


Register Section Registre Registro	
0	Erläuterungen Explanations Légende Explicaciones
1	Kopfteile Front parts Pièces de tête Piezas de la cabeza Platt 9493
2	Armteile Arm parts Pièces de bras, Piezas del brazo Platt 9493
3	Grundplattenteile Bedplate parts Pièces du plateau fondamental Pieza de la placa-base Platt 9493
4	Ergänzungsteile Complementary parts Pièces complémentaires Piezas especiales Platt 9491
5	Unterklasse Subclass Sous-classe Subclase -944/01
6	Unterklasse Subclass Sous-classe Subclase
7	Unterklasse Subclass Sous-classe Subclase
8	Unterklasse Subclass Sous-classe Subclase
9	Unterklasse Subclass Sous-classe Subclase
10	Zubehörteile Accessory parts Accessoires Accesorios
11	
12	
13	
14	
























91-010 165-91

4

91-010 896-91


1

91-010 158-05



91-010 159-91

91-010 158-05



91-010 159-91

91-010 157-01



91-010 157-01



91-000 529-15

91-000 529-15


91-000 529-15

91-010 164-91

91-010 178-05

91-010 161-05

91-010 167-05



91-000 529-15

91-000 529-15

91-010 164-91

91-010 893-05

91-010 894-05

91-010 167-05




91-000 525-15

91-010 079-05



91-000 525-15

91-000 412-15



91-011 879-44 4 9/4

91-000 405-15

91-001 512-15


91-000 172-15



91-012 458-45 6/7

94-000 048-45

94-000 062-25





91-011 878-44 4 9/4


91-000 412-15

91-015 544-05



91-000 640-15










91-171 182-92



91-069 301-92



Platt 049

Platt 949

91-170 911-92

11-341 902-15
11-341 902-15

14-010 665-01

91-069 732-15

91-068 730-06

91-069 730-08

99-069 713-01 (2) (b)

99-069 713-01 32 40/3

91-069 729-0532

11-314 166-15-8

91-174 154-12 c

22 40/3 99-069 713-01

11-314 946-15

91-069 771-12 32

91-069 770-04 [3]

99-069 713-01 [32] [302]

[32] [40/3] 99-069 713-01

91-069 650-45 27

91-069 035-0450

91-174 156-12

91-171 441-01

11-314 983-15 --(2)

91-659 735-05

91-169 120-45

91-069 654-01 30

94-000 099-97

91-069 651-92

...

14-215 016-13 32 40/3

91-069 657-04 32

94-000 043-11 52

91-069 773-92


12-305 174-15

12-500 190-45.


12-024 191-15

14-215 016-13.52 4073

11-108 225-15



0



91-129 139-01
last
empty
wide
vacuum


91-032 803-45 028




91-032 804-45



91-029 450-15




91-032 806-51



91-032 806-45


91-129 153-01



91-029 545-01



91-029 007-01




System 134 (1)
Systeme 134 (1)
Sistema 134 (1)


60-754 701-00



91-032 807-01




91-101 775-05



91-032 806-45

91-087 074-45



91-119 140-91

91-119 233-93

91-058 289-04

11-205 171-15

91-119 141-35

91-119 142-35

11-173 090-15

13-070 103-05

91-119 136-05

91-119 138-05

11-173 090-15

91-119 143-05

12-005 151-15

91-119 101-45

12-305 111-15

11-108 174-15

11-268 095-15

91-119 499-45

11-268 095-15

12-305 171-15

91-118 766-05

91-119 497-90

11-268 095-15

91-119 137-05

91-119 695-45

91-700 689-15

11-268 095-15

11-174 173-15

91-119 120-91

91-119 121-12

12-660 350-45

14-016 120-01

91-700 689-15

91-119 087-05

14-012 555-01

12-664 350-45

12-610 210-45

91-119 087-05

11-174 173-15

91-119 116-91

11-174 173-15

91-119 112-91

14-012 555-01

91-119 115-91

11-108 174-15

91-119 217-45

91-119 216-45

11-108 174-15

siehe Erläuterungen
see explanations
voir explications
ver explicaciones

1) siehe Tabelle Seite 52
see table on page 52
voir tableau d la page 52
ver la tabla de la página 52

