


SIRUBA®



銀箭牌工業用縫紉機
INDUSTRIAL SEWING MACHINE

F007J/F007JD

零件圖 PARTS LIST






高林股份有限公司
KAULIN MFG. CO., LTD.

									
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE
機 型	規 格	針 座	針 板	主 送 具	差 送 具	押 具	勾 針	上 叉	針 號
F007J-W121	240	M5240	E1514	D1206	H1258	P2544	ME28	MH41	UY128GAS #10
	248	M5248	E1515	D1206	H1258	P2545			
	356	M5356	E1816	D1207	H1259	P2446			
	364	M5364	E1817	D1207	H1259	P2447			
F007J-W121 /UTG(UTJ)	240	M5240	E1514	D1206	H1258	P2544	ME28	MH41	UY128GAS #10
	248	M5248	E1515	D1206	H1258	P2545			
	356	M5356	E1816	D1207	H1259	P2446			
	364	M5364	E1817	D1207	H1259	P2447			
F007J-U121	240	M5240	E1514	D1206	H1258	P2544	ME28	—	UY128GAS #10
	248	M5248	E1515	D1206	H1258	P2545			
	356	M5356	E1816	D1207	H1259	P2446			
	364	M5364	E1817	D1207	H1259	P2447			
F007J-U121 /UTH(UTK)	240	M5240	E1514	D1206	H1258	P2544	ME28	—	UY128GAS #10
	248	M5248	E1515	D1206	H1258	P2545			
	356	M5356	E1816	D1207	H1259	P2446			
	364	M5364	E1817	D1207	H1259	P2447			
F007J-W122	240	M5240	E1524	D1206	H1258	P2544	ME28	MH41	UY128GAS #10
	248	M5248	E1525	D1206	H1258	P2545			
	356	M5356	E1826	D1207	H1259	P2446			
	364	M5364	E1827	D1207	H1259	P2447			
F007J-W122 /UTG(UTJ)	240	M5240	E1524	D1206	H1258	P2544	ME28	MH41	UY128GAS #10
	248	M5248	E1525	D1206	H1258	P2545			
	356	M5356	E1826	D1207	H1259	P2446			
	364	M5364	E1827	D1207	H1259	P2447			
F007J-U122	240	M5240	E1524	D1206	H1258	P2544	ME28	—	UY128GAS #10
	248	M5248	E1525	D1206	H1258	P2545			
	356	M5356	E1826	D1207	H1259	P2446			
	364	M5364	E1827	D1207	H1259	P2447			
F007J-U122 /UTH(UTK)	240	M5240	E1524	D1206	H1258	P2544	ME28	—	UY128GAS #10
	248	M5248	E1525	D1206	H1258	P2545			
	356	M5356	E1826	D1207	H1259	P2446			
	364	M5364	E1827	D1207	H1259	P2447			


註：P2544/2545 為固定式押具舌，亦可使用活動式押具舌 P2565代替 P2544/P2545
P2446/2447 為固定式押具舌，亦可使用活動式押具舌 P2466代替 P2446/2447

規格件表 CONVERSION CHART-1

規格件表 CONVERSION CHART-2

									
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE
機 型	規 格	針 座	針 板	主送具	差送具	押 具	勾 針	上 叉	針 號
F007J-U122/FP	232	M5232	E1613	D1206	H1257	P4011	ME28P	—	TV*5 #14
F007J-W123	240 248 356 364	M5240 M5248 M5356 M5364	E1534 E1535 E1836 E1837	D1206 D1206 D1207 D1207	H1258 H1258 H1259 H1259	P2544 P2545 P2446 P2447	ME28	MH41	UY128GAS #10
F007J-W123/UTG(UTJ)	240 248 356 364	M5240 M5248 M5356 M5364	E1534 E1535 E1836 E1837	D1206 D1206 D1207 D1207	H1258 H1258 H1259 H1259	P2544 P2545 P2446 P2447	ME28	MH41	UY128GAS #10
F007J-W162	356 364	M5356 M5364	E1846 E1847	D1207 D1207	H1259 H1259	P2446 P2447	ME28A	MH41	TV*5 #14~16
F007J-U162	356 364	M5356 M5364	E1846 E1847	D1207 D1207	H1259 H1259	P2446 P2447	ME28A	—	TV*5 #14~16
F007J-W162/UTG(UTJ)	356 364	M5356 M5364	E1846 E1847	D1207 D1207	H1259 H1259	P2446 P2447	ME28A	MH41	TV*5 #14~16
F007J-U162/UTH(UTK)	356 364	M5356 M5364	E1846 E1847	D1207 D1207	H1259 H1259	P2446 P2447	ME28A	—	TV*5 #14~16
F007J-W222/FQ	232 240 248 356 364	M5232 M5240 M5248 M5356 M5364	E3023 E3024 E3025 E3326 E3327	D1215 D1215 D1215 D1216 D1216	H1261 H1261 H1261 H1262 H1262	P1813 P1814 P1815 P2116 P2117	ME28	MH41	UY128GAS #10
F007J-W222/UTG(UTJ)/FQ	240 248 356 364	M5240 M5248 M5356 M5364	E3024 E3025 E3326 E3327	D1215 D1215 D1216 D1216	H1261 H1261 H1262 H1262	P1814 P1815 P2116 P2117	ME28	MH41	UY128GAS #10
F007J-U222/UTH(UTK)/FQ	240 248 356 364	M5240 M5248 M5356 M5364	E3024 E3025 E3326 E3327	D1215 D1215 D1216 D1216	H1261 H1261 H1262 H1262	P1814 P1815 P2116 P2117	ME28	MH41	UY128GAS #10

註：P2544/2545 為固定式押具舌，亦可使用活動式押具舌 P2565代替 P2544/P2545
P2446/2447 為固定式押具舌，亦可使用活動式押具舌 P2466代替 P2446/2447

									
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE
機 型	規 格	針 座	針 板	主送具	差送具	押 具	勾 針	上 叉	針 號
F007J-W222 /FQ/FEC(FAC)	240	M5240	E 3024	D1215	H1261	P1814	ME28	MH41	UY128GAS #10
	248	M5248	E 3025	D1215	H1261	P1815			
	356	M5356	E 3326	D1216	H1262	P2116			
	364	M5364	E 3327	D1216	H1262	P2117			
F007J-U222 /FQ	240	M5240	E 3024	D1215	H1261	P2314	ME28	—	UY128GAS #10
	248	M5248	E 3025	D1215	H1261	P2315			
	356	M5356	E 3326	D1216	H1262	P2616			
	364	M5364	E 3327	D1216	H1262	P2617			
F007J-W222A FQ/FEC(FAC)	240	M5240	E 3124	D1315	H1261	P1914	ME28	MH41	UY128GAS #10
	248	M5248	E 3125	D1315	H1261	P1915			
	356	M5356	E 3426	D1316	H1262	P2216			
	364	M5364	E 3427	D1316	H1262	P2217			
F007J-W222 /FFD(FFP)	240	M5240	E 3024	D1215	H1261	P1814	ME28	MH41	UY128GAS #10
	248	M5248	E 3025	D1215	H1261	P1815			
	356	M5356	E 3326	D1216	H1262	P2116			
	364	M5364	E 3327	D1216	H1262	P2117			
F007J-U222 /FFD(FFP)	240	M5240	E 3024	D1215	H1261	P2314	ME28	—	UY128GAS #10
	248	M5248	E 3025	D1215	H1261	P2315			
	356	M5356	E 3326	D1216	H1262	P2616			
	364	M5364	E 3327	D1216	H1262	P2617			
F007J-W222 /FSM	240-4	M5240P	E 3724		H1262	P2714	ME28	MH41	UY128GAS #10
	248-4	M5248P	E 3725	D1516	H1262	P2715			
	364-4	M5364P	E 3727		H1262	P2717			
F007J-W322 /FDC	356	M5356	E 4826	D1207	H1359	P2446	ME28	MH41	UY128GAS #10
	364	M5364	E 4827	D1207	H1359	P2447			
F007J-W322 /UTG(UTJ)/FDC	356	M5356	E 4826	D1207	H1359	P2446	ME28	MH41	UY128GAS #10
	364	M5364	E 4827	D1207	H1359	P2447			
F007J-U322 /FDC	356	M5356	E 4826	D1207	H1359	P2446	ME28	—	UY128GAS #10
	364	M5364	E 4827	D1207	H1359	P2447			



W222A-FAC(FEC) 短切刀

W222-FAC(FEC) 長切刀





註：P2544/2545 為固定式押具舌，亦可使用活動式押具舌 P2565代替P2544/P2545

P2446/2447 為固定式押具舌，亦可使用活動式押具舌 P2466代替P2446/2447

規格件表 CONVERSION CHART-4

									
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE
機 型	規 格	針 座	針 板	主送具	差送具	押 具	勾 針	上 叉	針 號
F007J-U322 /UTH(UTK)/FDC	356 364	M5356 M5364	E 4826 E 4827	D1207 D1207	H1359 H1359	P2446 P2447	ME28	—	UY128GAS #10
F007J-W322 /FDE	356 364	M5356 M5364	E 4836M E 4837M	D1207 D1207	H1459 H1459	P2446 P2447	ME28	MH41	UY128GAS #10
F007J-W322 /UTG(UTJ)/FDE	356 364	M5356 M5364	E 4836M E 4837M	D1207 D1207	H1459 H1459	P2446 P2447	ME28	MH41	UY128GAS #10
F007J-U322 /FDE	356 364	M5356 M5364	E 4836M E 4837M	D1207 D1207	H1459 H1459	P2446 P2447	ME28	—	UY128GAS #10
F007J-U322 /UTH(UTK)/FDE	356 364	M5356 M5364	E 4836M E 4837M	D1207 D1207	H1459 H1459	P2446 P2447	ME28	—	UY128GAS #10
F007J-W522 /FE(FFC)/FR	232 240 248 356 364	M5232 M5240 M5248 M5356 M5364	E 6023 E 6024 E 6025 E 6326 E 6327	D 2221 D 2221 D 2221 D 2222 D 2222	H 2267 H 2267 H 2267 H 2268 H 2268	P2813 P2814 P2815 P3116 P3117	ME28	MH41	UY128GAS #10
F007J-U522 /FE(FFC)/FR	240 248 356 364	M5240 M5248 M5356 M5364	E 6024 E 6025 E 6326 E 6327	D 2221 D 2221 D 2222 D 2222	H 2267 H 2267 H 2268 H 2268	P2814 P2815 P3116 P3117	ME28	—	UY128GAS #10




註：F007J-W/U322A-356 /FDC 時，該針板與送具改用 F007H-W/U122-364 之針板與送具
 註：P2544/2545 為固定式押具舌，亦可使用活動式押具舌 P2565 代替 P2544/P2545
 P2446/2447 為固定式押具舌，亦可使用活動式押具舌 P2466 代替 P2446/2447



									
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE
機 型	規 格	針 座	針 板	主 送 具	差 送 具	押 具	勾 針	上 叉	針 號
F007J-W512 /FE(FFC)	240	M5240	E1524	D1206	H1258	P 2914	ME28	MH41	UY128GAS #10
	248	M5248	E1525	D1206	H1258	P 2915			
	356	M5356	E1826	D1207	H1259	P 3216			
	364	M5364	E1827	D1207	H1259	P 3217			
F007J-U512 /FE(FFC)	240	M5240	E1524	D1206	H1258	P 3414	ME28	—	UY128GAS #10
	248	M5248	E1525	D1206	H1258	P 3415			
	356	M5356	E1826	D1207	H1259	P 3716			
	364	M5364	E1827	D1207	H1259	P 3717			

註：F007J-W/U322A-³⁵⁶ /FDC 時，該針板與送具改用 F007H-W/U122-³⁶⁴ 之針板與送具



註：P2544/2545 為固定式押具舌，亦可使用活動式押具舌 P2565代替 P2544/P2545
P2446/2447 為固定式押具舌，亦可使用活動式押具舌 P2466代替 P2446/2447

規格件表 CONVERSION CHART-6


									
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE
機 型	規 格	針 座	針 板	主送具	差送具	押 具	勾 針	上 叉	針 號
F007J-U613 /FBP	256	M5356	E 1836L	D 1207	H 1259	P 4000	ME28	—	TV*5 #14~18
	264	M5364	E 1837L	D 1207	H 1259	P 4001	ME28	—	
F007J-U712	264	M5264	E 5827	D 5207	H 5259	P 4117	ME28	—	TV*3 #11~16
F007J-U712 /FSP	264	M5264	E 5827	D 5207	H 5259	P5117(成品寬1.0mm用)	FS03/04	—	TV*3 #11~16
F007J-U712A /FSP	264	M5264	E 5827	D 5207	H 5259	P5118(成品寬1.2mm用)	FS03/04	—	TV*3 #11~16
F007J-U712 /FSR	264	M5264	E 5927	D 5307	H 5359	P 4217	FS03/04	—	TV*7 #12~14
F007J-W722 /FY	388	M4388	E 6828	D 6207	H 6259	P 6117	FS03/04/FY02	FY09	TV*7 #12
F007J-W922 /FW(FWP)	456 460 464	M5456 M5460 M5464	E1828P E1838P E1848P	D1207P	H1259	P2428P P2438P P2448P	FW28	MH41	SM1014B #10 (MY1014B #70 ,SY7256)

										
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE	Motor
機 型	規 格	針 座	針 板	主送具	差送具	押 具	勾 針	上 叉	針 號	馬 達
F007JD-W121	240	M5240	E1514	D1206	H1258	P2544	ME28	MH41	UY128GAS #10	H T6401UHM
	248	M5248	E1515	D1206	H1258	P2545				
	356	M5356	E1816	D1207	H1259	P2446				
	364	M5364	E1817	D1207	H1259	P2447				
F007JD-W121 /UTG(UTJ)	240	M5240	E1514	D1206	H1258	P2544	ME28	MH41	UY128GAS #10	
	248	M5248	E1515	D1206	H1258	P2545				
	356	M5356	E1816	D1207	H1259	P2446				
	364	M5364	E1817	D1207	H1259	P2447				
F007JD-U121	240	M5240	E1514	D1206	H1258	P2544	ME28	—	UY128GAS #10	
	248	M5248	E1515	D1206	H1258	P2545				
	356	M5356	E1816	D1207	H1259	P2446				
	364	M5364	E1817	D1207	H1259	P2447				
F007JD-U121 /UTH(UTK)	240	M5240	E1514	D1206	H1258	P2544	ME28	—	UY128GAS #10	
	248	M5248	E1515	D1206	H1258	P2545				
	356	M5356	E1816	D1207	H1259	P2446				
	364	M5364	E1817	D1207	H1259	P2447				
F007JD-W122	240	M5240	E1524	D1206	H1258	P2544	ME28	MH41	UY128GAS #10	H T6401UHM
	248	M5248	E1525	D1206	H1258	P2545				
	356	M5356	E1826	D1207	H1259	P2446				
	364	M5364	E1827	D1207	H1259	P2447				
F007JD-W122 /UTG(UTJ)	240	M5240	E1524	D1206	H1258	P2544	ME28	MH41	UY128GAS #10	
	248	M5248	E1525	D1206	H1258	P2545				
	356	M5356	E1826	D1207	H1259	P2446				
	364	M5364	E1827	D1207	H1259	P2447				
F007JD-U122	240	M5240	E1524	D1206	H1258	P2544	ME28	—	UY128GAS #10	
	248	M5248	E1525	D1206	H1258	P2545				
	356	M5356	E1826	D1207	H1259	P2446				
	364	M5364	E1827	D1207	H1259	P2447				
F007JD-U122 /UTH(UTK)	240	M5240	E1524	D1206	H1258	P2544	ME28	—	UY128GAS #10	
	248	M5248	E1525	D1206	H1258	P2545				
	356	M5356	E1826	D1207	H1259	P2446				
	364	M5364	E1827	D1207	H1259	P2447				

註：P2544/2545 為固定式押具舌，亦可使用活動式押具舌 P2565代替 P2544/P2545
P2446/2447 為固定式押具舌，亦可使用活動式押具舌 P2466代替 P2446/2447

										
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE	Motor
機 型	規 格	針 座	針 板	主送具	差送具	押 具	勾 針	上 叉	針 號	馬 達
F007JD-U122 /FP	232	M5232	E 1613	D1206	H1257	P4011	ME28P	—	TV*5 #14	T6401UHM
F007JD-W123 /UTG(UTJ)	240	M5240	E 1534	D1206	H1258	P2544	ME28	MH41	UY128GAS #10	
	248	M5248	E 1535	D1206	H1258	P2545				
	356	M5356	E 1836	D1207	H1259	P2446				
	364	M5364	E 1837	D1207	H1259	P2447				
F007JD-W123 /UTG(UTJ)	240	M5240	E 1534	D1206	H1258	P2544	ME28	MH41	UY128GAS #10	
	248	M5248	E 1535	D1206	H1258	P2545				
	356	M5356	E 1836	D1207	H1259	P2446				
	364	M5364	E 1837	D1207	H1259	P2447				
F007JD-W162	356	M5356	E 1846	D1207	H1259	P2446	ME28A	MH41	TV*5 #14~16	
	364	M5364	E 1847	D1207	H1259	P2447				
F007JD-U162	356	M5356	E 1846	D1207	H1259	P2446	ME28A	—	TV*5 #14~16	
	364	M5364	E 1847	D1207	H1259	P2447				
F007JD-W162 UTG(UTJ)	356	M5356	E 1846	D1207	H1259	P2446	ME28A	MH41	TV*5 #14~16	
	364	M5364	E 1847	D1207	H1259	P2447				
F007JD-U 162 /UTH(UTK)	356	M5356	E 1846	D1207	H1259	P2446	ME28A	—	TV*5 #14~16	
	364	M5364	E 1847	D1207	H1259	P2447				
F007JD-W222 /FQ	240	M5240	E 3024	D1215	H1261	P1814	ME28	MH41	UY128GAS #10	
	248	M5248	E 3025	D1215	H1261	P1815				
	356	M5356	E 3326	D1216	H1262	P2116				
	364	M5364	E 3327	D1216	H1262	P2117				
F007JD-W222 /UTG(UTJ)/FQ	240	M5240	E 3024	D1215	H1261	P1814	ME28	MH41	UY128GAS #10	
	248	M5248	E 3025	D1215	H1261	P1815				
	356	M5356	E 3326	D1216	H1262	P2116				
	364	M5364	E 3327	D1216	H1262	P2117				
F007JD-U 222 /UTH(UTK)/FQ	240	M5240	E 3024	D1215	H1261	P1814	ME28	MH41	UY128GAS #10	
	248	M5248	E 3025	D1215	H1261	P1815				
	356	M5356	E 3326	D1216	H1262	P2116				
	364	M5364	E 3327	D1216	H1262	P2117				

註：P2544/2545 為固定式押具舌，亦可使用活動式押具舌 P2565代替P2544/P2545
P2446/2447 為固定式押具舌，亦可使用活動式押具舌 P2466代替P2446/2447


										
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE	MOTOR
機 型	規 格	針 座	針 板	主送具	差送具	押 具	勾 針	上 叉	針 號	馬 達
F007JD-W222 /FQ/FEC(FAC)	240 248 356 364	M5240 M5248 M5356 M5364	E 3024 E 3025 E 3326 E 3327	D 1215 D 1215 D 1216 D 1216	H 1261 H 1261 H 1262 H 1262	P1814 P1815 P2116 P2117	ME28	MH41	UY128GAS #10	T6401UHM
F007JD-U222 /FQ	240 248 356 364	M5240 M5248 M5356 M5364	E 3024 E 3025 E 3326 E 3327	D 1215 D 1215 D 1216 D 1216	H 1261 H 1261 H 1262 H 1262	P2314 P2315 P2616 P2617	ME28	—	UY128GAS #10	
F007JD-W222A FQ/FEC(FAC)	240 248 356 364	M5240 M5248 M5356 M5364	E 3124 E 3125 E 3426 E 3427	D 1315 D 1315 D 1316 D 1316	H 1261 H 1261 H 1262 H 1262	P1914 P1915 P2216 P2217	ME28	MH41	UY128GAS #10	
F007JD-W222 /FFP	240 248 356 364	M5240 M5248 M5356 M5364	E 3024 E 3025 E 3326 E 3327	D 1215 D 1215 D 1216 D 1216	H 1261 H 1261 H 1262 H 1262	P1814 P1815 P2116 P2117	ME28	MH41	UY128GAS #10	
F007JD-U222 /FFP	240 248 356 364	M5240 M5248 M5356 M5364	E 3024 E 3025 E 3326 E 3327	D 1215 D 1215 D 1216 D 1216	H 1261 H 1261 H 1262 H 1262	P2314 P2315 P2616 P2617	ME28	—	UY128GAS #10	
F007JD-W322 /FDC	356 364	M5356 M5364	E 4826 E 4827	D 1207 D 1207	H 1359 H 1359	P2446 P2447	ME28	MH41	UY128GAS #10	
F007JD-W322 /UTG(UTJ)/FDC	356 364	M5356 M5364	E 4826 E 4827	D 1207 D 1207	H 1359 H 1359	P2446 P2447	ME28	MH41	UY128GAS #10	
F007JD-U322 /FDC	356 364	M5356 M5364	E 4826 E 4827	D 1207 D 1207	H 1359 H 1359	P2446 P2447	ME28	—	UY128GAS #10	
F007JD-U322 /UTH(UTK)/FDC	356 364	M5356 M5364	E 4826 E 4827	D 1207 D 1207	H 1359 H 1359	P2446 P2447	ME28	—	UY128GAS #10	

W222A-FAC(FEC) 短 切 刀

W222-FAC(FEC) 長 切 刀







註：P2544/2545 為固定式押具舌,亦可使用活動式押具舌 P2565代替P2544/P2545
P2446/2447 為固定式押具舌,亦可使用活動式押具舌 P2466代替P2446/2447

規格件表 CONVERSION CHART-10

										
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE	Motor
機 型	規 格	針 座	針 板	主送具	差送具	押 具	勾 針	上 叉	針 號	馬 達
F007JD-W322 /FDE	356 364	M5356 M5364	E 4836M E 4837M	D1207 D1207	H1459 H1459	P2446 P2447	ME28	MH41	UY128GAS #10	T6401UHM
F007JD-W322 /UTG(UTJ)/FDE	356 364	M5356 M5364	E 4836M E 4837M	D1207 D1207	H1459 H1459	P2446 P2447	ME28	MH41	UY128GAS #10	
F007JD-U322 /FDE	356 364	M5356 M5364	E 4836M E 4837M	D1207 D1207	H1459 H1459	P2446 P2447	ME28	—	UY128GAS #10	
F007JD-U322 /UTH(UTK)/FDE	356 364	M5356 M5364	E 4836M E 4837M	D1207 D1207	H1459 H1459	P2446 P2447	ME28	—	UY128GAS #10	
F007JD-W522 /FE/FR	240 248 356 364	M5240 M5248 M5356 M5364	E 6024 E 6025 E 6326 E 6327	D 2221 D 2221 D 2222 D 2222	H 2267 H 2267 H 2268 H 2268	P2814 P2815 P3116 P3117	ME28	MH41	UY128GAS #10	
F007JD-U522 /FE/FR	240 248 356 364	M5240 M5248 M5356 M5364	E 6024 E 6025 E 6326 E 6327	D 2221 D 2221 D 2222 D 2222	H 2267 H 2267 H 2268 H 2268	P2814 P2815 P3116 P3117	ME28	—	UY128GAS #10	
F007JD-W512 /FE	240 248 356 364	M5240 M5248 M5356 M5364	E 1524 E 1525 E 1826 E 1827	D 1206 D 1206 D 1207 D 1207	H 1258 H 1258 H 1259 H 1259	P 2914 P 2915 P 3216 P 3217	ME28	MH41	UY128GAS #10	
F007JD-U512 /FE	240 248 356 364	M5240 M5248 M5356 M5364	E 1524 E 1525 E 1826 E 1827	D 1206 D 1206 D 1207 D 1207	H 1258 H 1258 H 1259 H 1259	P 3414 P 3415 P 3716 P 3717	ME28	—	UY128GAS #10	





註：F007JD-W/U322A-356 /FDC 時，該針板與送具改用 F007H-W/U122-356 之針板與送具

註：P2544/2545 為固定式押具舌，亦可使用活動式押具舌 P2565 代替 P2544/P2545
P2446/2447 為固定式押具舌，亦可使用活動式押具舌 P2466 代替 P2446/2447




										
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE	MOTOR
機 型	規 格	針 座	針 板	主送具	差送具	押 具	勾 針	上 叉	針 號	馬 達
F007JD-U613 /FBP	256	M5356	E 1836L	D1207	H1259	P4000	ME28	—	TV*5 #14~18	T6401UHM
	264	M5364	E 1837L	D1207	H1259	P4001	ME28	—		
F007JD-U712	264	M5264	E 5827	D 5207	H 5259	P4117	ME28	—	TV*3 #11~16	
F007JD-U712 /FSP	264	M5264	E 5827	D 5207	H 5259	P5117(差送具 0mm)	FS03/04	—	TV*3 #11~16	
F007JD-U712A /FSP	264	M5264	E 5827	D 5207	H 5259	P5118(差送具 2mm)	FS03/04	—	TV*3 #11~16	
F007JD-U712 /FSR	264	M5264	E 5927	D 5307	H 5359	P4217	FS03/04	—	TV*7 #12~14	
F007JD-W722 /FY	388	M4388	E 6828	D 6207	H 6259	P6117	FS03/04/FY02	FY09	TV*7 #12	
F007JD-W922 /FW(FWP)	456 460 464	M5456 M5460 M5464	E1828P E1838P E1848P	D1207P	H1259	P2428P P2438P P2448P	FW28	MH41	SM1014B #10 (MY1014B #70 ,SY7256)	

F007J: 為一般馬達,外置式機種 ; F007JD: 為加裝直驅伺服馬達機種

規格件表 CONVERSION CHART-12


										
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE	Motor
機 型	規 格	針 座	針 板	主送具	差送具	押 具	勾 針	上 叉	針 號	馬 達
F007JD-W121 /K	240	M5240	E 1514	D1206	H1258	P2544	ME28	MH41	UY128GAS #10	□ T6400UPM
	248	M5248	E 1515	D1206	H1258	P2545				
	356	M5356	E 1816	D1207	H1259	P2446				
	364	M5364	E 1817	D1207	H1259	P2447				
F007JD-W121 /UTG(UTJ)/K	240	M5240	E 1514	D1206	H1258	P2544	ME28	MH41	UY128GAS #10	
	248	M5248	E 1515	D1206	H1258	P2545				
	356	M5356	E 1816	D1207	H1259	P2446				
	364	M5364	E 1817	D1207	H1259	P2447				
F007JD-U121 /K	240	M5240	E 1514	D1206	H1258	P2544	ME28	—	UY128GAS #10	
	248	M5248	E 1515	D1206	H1258	P2545				
	356	M5356	E 1816	D1207	H1259	P2446				
	364	M5364	E 1817	D1207	H1259	P2447				
F007JD-U121 /UTH(UTK)/K	240	M5240	E 1514	D1206	H1258	P2544	ME28	—	UY128GAS #10	
	248	M5248	E 1515	D1206	H1258	P2545				
	356	M5356	E 1816	D1207	H1259	P2446				
	364	M5364	E 1817	D1207	H1259	P2447				
F007JD-W122 /K	240	M5240	E 1524	D1206	H1258	P2544	ME28	MH41	UY128GAS #10	
	248	M5248	E 1525	D1206	H1258	P2545				
	356	M5356	E 1826	D1207	H1259	P2446				
	364	M5364	E 1827	D1207	H1259	P2447				
F007JD-W122 /UTG(UTJ)/K	240	M5240	E 1524	D1206	H1258	P2544	ME28	MH41	UY128GAS #10	
	248	M5248	E 1525	D1206	H1258	P2545				
	356	M5356	E 1826	D1207	H1259	P2446				
	364	M5364	E 1827	D1207	H1259	P2447				
F007JD-U122 /K	240	M5240	E 1524	D1206	H1258	P2544	ME28	—	UY128GAS #10	
	248	M5248	E 1525	D1206	H1258	P2545				
	356	M5356	E 1826	D1207	H1259	P2446				
	364	M5364	E 1827	D1207	H1259	P2447				
F007JD-U122 /UTH(UTK)/K	240	M5240	E 1524	D1206	H1258	P2544	ME28	—	UY128GAS #10	
	248	M5248	E 1525	D1206	H1258	P2545				
	356	M5356	E 1826	D1207	H1259	P2446				
	364	M5364	E 1827	D1207	H1259	P2447				

註：P2544/2545 為固定式押具舌，亦可使用活動式押具舌 P2565代替 P2544/P2545
P2446/2447 為固定式押具舌，亦可使用活動式押具舌 P2466代替 P2446/2447

										
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE	MOTOR
機 型	規 格	針 座	針 板	主 送 具	差 送 具	押 具	勾 針	上 叉	針 號	馬 達
F007JD-U122 /FP/K	232	M5232	E 1613	D1206	H1257	P4011	ME28P	—	TV*5 #14	P T6400UPM
F007JD-W123 /K	240	M5240	E 1534	D1206	H1258	P2544	ME28	MH41	UY128GAS #10	
	248	M5248	E 1535	D1206	H1258	P2545				
	356	M5356	E 1836	D1207	H1259	P2446				
	364	M5364	E 1837	D1207	H1259	P2447				
F007JD-W123 /UTG(UTJ)/K	240	M5240	E 1534	D1206	H1258	P2544	ME28	MH41	UY128GAS #10	
	248	M5248	E 1535	D1206	H1258	P2545				
	356	M5356	E 1836	D1207	H1259	P2446				
	364	M5364	E 1837	D1207	H1259	P2447				
F007JD-W162 /K	356	M5356	E 1846	D1207	H1259	P2446	ME28A	MH41	TV*5 #14~16	
	364	M5364	E 1847	D1207	H1259	P2447				
F007JD-U162 /K	356	M5356	E 1846	D1207	H1259	P2446	ME28A	—	TV*5 #14~16	
	364	M5364	E 1847	D1207	H1259	P2447				
F007JD-W162 /UTG(UTJ)/K	356	M5356	E 1846	D1207	H1259	P2446	ME28A	MH41	TV*5 #14~16	
	364	M5364	E 1847	D1207	H1259	P2447				
F007JD-U162 /UTH(UTK)/K	356	M5356	E 1846	D1207	H1259	P2446	ME28A	—	TV*5 #14~16	
	364	M5364	E 1847	D1207	H1259	P2447				
F007JD-W222 /FQ/K	240	M5240	E 3024	D1215	H1261	P1814	ME28	MH41	UY128GAS #10	
	248	M5248	E 3025	D1215	H1261	P1815				
	356	M5356	E 3326	D1216	H1262	P2116				
	364	M5364	E 3327	D1216	H1262	P2117				
F007JD-W222 /UTG(UTJ)/FQ/K	240	M5240	E 3024	D1215	H1261	P1814	ME28	MH41	UY128GAS #10	
	248	M5248	E 3025	D1215	H1261	P1815				
	356	M5356	E 3326	D1216	H1262	P2116				
	364	M5364	E 3327	D1216	H1262	P2117				
F007JD-U222 /UTH(UTK)/FQ/K	240	M5240	E 3024	D1215	H1261	P1814	ME28	MH41	UY128GAS #10	
	248	M5248	E 3025	D1215	H1261	P1815				
	356	M5356	E 3326	D1216	H1262	P2116				
	364	M5364	E 3327	D1216	H1262	P2117				

註：P2544 /2545 為固定式押具舌 亦可使用活動式押具舌 P2585代替P2544/P2545
P2446 /2447 為固定式押具舌 亦可使用活動式押具舌 P2486代替P2446/2447





規格件表 CONVERSION CHART-14

										
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE	MOTOR
機 型	規 格	針 座	針 板	主 送 具	差 送 具	押 具	勾 針	上 叉	針 號	馬 達
F007JD-W222 /FQ/FEC(FAC)/K	240	M5240	E 3024	D1215	H1261	P1814	ME28	MH41	UY128GAS #10	P T6400UPM
	248	M5248	E 3025	D1215	H1261	P1815				
	356	M5356	E 3326	D1216	H1262	P2116				
	364	M5364	E 3327	D1216	H1262	P2117				
F007JD-U222 /FQ/K	240	M5240	E 3024	D1215	H1261	P2314	ME28	—	UY128GAS #10	
	248	M5248	E 3025	D1215	H1261	P2315				
	356	M5356	E 3326	D1216	H1262	P2616				
	364	M5364	E 3327	D1216	H1262	P2617				
F007JD-W222A /FQ/FEC(FAC)/K	240	M5240	E 3124	D1315	H1261	P1914	ME28	MH41	UY128GAS #10	
	248	M5248	E 3125	D1315	H1261	P1915				
	356	M5356	E 3426	D1316	H1262	P2216				
	364	M5364	E 3427	D1316	H1262	P2217				
F007JD-W222 /FFP/K	240	M5240	E 3024	D1215	H1261	P1814	ME28	MH41	UY128GAS #10	
	248	M5248	E 3025	D1215	H1261	P1815				
	356	M5356	E 3326	D1216	H1262	P2116				
	364	M5364	E 3327	D1216	H1262	P2117				
F007JD-U222 /FFP/K	240	M5240	E 3024	D1215	H1261	P2314	ME28	—	UY128GAS #10	
	248	M5248	E 3025	D1215	H1261	P2315				
	356	M5356	E 3326	D1216	H1262	P2616				
	364	M5364	E 3327	D1216	H1262	P2617				
F007JD-W322 /FDC/K	356	M5356	E 4826	D1207	H1359	P2446	ME28	MH41	UY128GAS #10	
	364	M5364	E 4827	D1207	H1359	P2447				
F007JD-W322 /UTG(UTJ)/FDC/K	356	M5356	E 4826	D1207	H1359	P2446	ME28	MH41	UY128GAS #10	
	364	M5364	E 4827	D1207	H1359	P2447				
F007JD-U322 /FDC/K	356	M5356	E 4826	D1207	H1359	P2446	ME28	—	UY128GAS #10	
	364	M5364	E 4827	D1207	H1359	P2447				
F007JD-U322 /UTH(UTK)/FDC/K	356	M5356	E 4826	D1207	H1359	P2446	ME28	—	UY128GAS #10	
	364	M5364	E 4827	D1207	H1359	P2447				

W222A-FAC(FEC) 短 切 刀

W222-FAC(FEC) 長 切 刀




註：P2544/2545 為固定式押具舌，亦可使用活動式押具舌 P2565代替 P2544/P2545
P2446/2447 為固定式押具舌，亦可使用活動式押具舌 P2466代替 P2446/2447

										
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE	MOTOR
機 型	規 格	針 座	針 板	主送具	差送具	押 具	勾 針	上 叉	針 號	馬 達
F007JD-W322 /FDE/K	356 364	M5356 M5364	E 4836M E 4837M	D1207 D1207	H1459 H1459	P2446 P2447	ME28	MH41	UY128GAS #10	T6400UPM
F007JD-W322 /UTG(UTJ)/FDE/K	356 364	M5356 M5364	E 4836M E 4837M	D1207 D1207	H1459 H1459	P2446 P2447	ME28	MH41	UY128GAS #10	
F007JD-U322 /FDE/K	356 364	M5356 M5364	E 4836M E 4837M	D1207 D1207	H1459 H1459	P2446 P2447	ME28	—	UY128GAS #10	
F007JD-U322 /UTH(UTK)/FDE/K	356 364	M5356 M5364	E 4836M E 4837M	D1207 D1207	H1459 H1459	P2446 P2447	ME28	—	UY128GAS #10	
F007JD-W522 /FE/FR/K	240 248 356 364	M5240 M5248 M5356 M5364	E 6024 E 6025 E 6326 E 6327	D 2221 D 2221 D 2222 D 2222	H 2267 H 2267 H 2268 H 2268	P 2814 P 2815 P 3116 P 3117	ME28	MH41	UY128GAS #10	
F007JD-U522 /FE/FR/K	240 248 356 364	M5240 M5248 M5356 M5364	E 6024 E 6025 E 6326 E 6327	D 2221 D 2221 D 2222 D 2222	H 2267 H 2267 H 2268 H 2268	P 2814 P 2815 P 3116 P 3117	ME28	—	UY128GAS #10	
F007JD-W512 /FE/K	240 248 356 364	M5240 M5248 M5356 M5364	E 1524 E 1525 E 1826 E 1827	D1206 D1206 D1207 D1207	H1258 H1258 H1259 H1259	P 2914 P 2915 P 3216 P 3217	ME28	MH41	UY128GAS #10	
F007JD-U512 /FE/K	240 248 356 364	M5240 M5248 M5356 M5364	E 1524 E 1525 E 1826 E 1827	D1206 D1206 D1207 D1207	H1258 H1258 H1259 H1259	P 3414 P 3415 P 3716 P 3717	ME28	—	UY128GAS #10	

註： F007JD-W/U322A-³⁵⁶ /FDC 時，該針板與送具改用 F007H-W/U122-³⁵⁶ 之針板與送具

註： P2544/2545 為固定式押具舌，亦可使用活動式押具舌 P2565 代替 P2544 /P2545
P2446/2447 為固定式押具舌，亦可使用活動式押具舌 P2466 代替 P2446 /2447


規格件表 CONVERSION CHART-16

										
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE	MOTOR
機 型	規 格	針 座	針 板	主 送 具	差 送 具	押 具	勾 針	上 叉	針 號	馬 達
F007JD-U613 /FBP/K	256	M5356	E1836L	D1207	H1259	P4000	ME28	—	TV*5 #14~18	T6400UPM
	264	M5364	E1837L	D1207	H1259	P4001	ME28	—		
F007JD-U712 /K	264	M5264	E5827	D5207	H5259	P4117	ME28	—	TV*3 #11~16	
F007JD-U712 /FSP/K	264	M5264	E5827	D5207	H5259	P5117(※差送1.0mm時)	FS03/04	—	TV*3 #11~16	
F007JD-U712A /FSP/K	264	M5264	E5827	D5207	H5259	P5118(※差送1.2mm時)	FS03/04	—	TV*3 #11~16	
F007JD-U712 /FSR/K	264	M5264	E5927	D5307	H5359	P4217	FS03/04	—	TV*7 #12~14	
F007JD-W722 /FY/K	388	M4388	E6828	D6207	H6259	P6117	FS03/04/FY02	FY09	TV*7 #12	
F007JD-W922 /FW(FWP)/K	456	M5456	E1828P	D1207P	H1259	P2428P P2438P P2448P	FW28	MH41	SM1014B #10 (MY1014B #70 ,SY7256)	
	460	M5460	E1838P							
	464	M5464	E1848P							

F007J: 為一般馬達,外置式機種 ; F007JD: 為加裝直驅伺服馬達機種


FHA

FOR HEMMING BOTTOMS
WITH F007-W122 SYSTEM




FHB

FOR COLLARETT
WITH F007-W122 SYSTEM




FHC

FOR HEMMING BOTTOMS
WITH F007-W122 SYSTEM




PARTS LIST FOR FHA/FHB/FHC GROUP


MXXXX




PXXXX




EXXXX




SM033



DXXXX




HXXXX





PARTS LIST FOR FP GROUP

PARTS LIST FOR FDC GROUP




PARTS LIST FOR FDE GROUP






PARTS LIST FOR MC GROUP




FOR F007J/F007JD
*USE FOR F007JD

PARTS LIST FOR MD GROUP


PARTS LIST FOR ME GROUP




PARTS LIST FOR MF GROUP






FOR F007J/F007JD
* USE FOR F007JD



FOR F007J/F007JD
*USE FOR F007JD









FOR F007J/F007JD
*USE FOR F007JD

PARTS LIST FOR MY GROUP



FOR F007J/F007JD
*USE FOR F007JD

PARTS LIST FOR MZ GROUP





F007J/F007JD

高林股份有限公司 KAULIN MFG. CO., LTD.