


SC9000

SunStar[®]
SERIES




MODEL
SC9023

PARTS LIST

SUNSTAR MACHINERY CO.,LTD


BL03B 縫線張力控制組 Thread Tension Control



BL03B 縫線張力控制組 Thread Tension Control

序號 Ref.NO.	圖號 Parts NO.	通用	名稱 Description	單位用量 Amt.Req.
1	BL03B0101		楔片座 Wedge Seat	1
2	BL03B0102		楔片 Wedge	1
3	BL03B0103		彈簧 Spring	1
4	BL03B0104		螺樁 Stud	1
5	BL030105		螺線管 Pipe	1
6	BL030106		接頭 Joint	1
7	BL030107		接頭座 Bracket	1
8	BL030108	SH0208	螺絲 Screw	2
9	BL030109	SH0645	墊圈 Washer	1
10	BL030110	CT1028	螺帽 Nut	3
11	BL03B0111		連桿 Level	1
12	BL030112	SH0135	螺絲 Screw	1
13	BL03B0113		螺絲 Screw	1
14	BL03B0114		連結片 Joint	1
15	MA06400510A	CT0533	螺帽 Nut	1
16	BL03B0116		螺絲 Screw	1
17	BL030117		隔環 Ring	1
18	BL030118		鋼線 Wire	1
19	BL030119		接頭 Joint	1
20	BL030120		楔片座 Wedge Seat(For BL03-S Use)	1
21	SA36400307A		螺帽 Nut	1
22	R6031118B700		導線 Thrend quide	1
23	BL030123	SH1121	調節螺帽(紅) Tension Nut	1
24	BL030124	SH1122	止滑齒輪 Bush	1
25	BL030125	SH1123	錐型彈簧(紅) Spring	1
26	BL030126	SH1125	彈簧座 Tension Spring Retainer	1
27	BL030127	SH1126	張力控制盤 Tension Disc	2
28	BL030128	SH1127	羊毛氈 Felt	1
29	BL030129	SH1120	螺樁 Stud	1
30	SB44400608K	SH0128	螺絲 Screw	1
31	BL03B0131		墊圈 Washer	1
32	BL03B0132		上蓋 Upper Cover	1
33	R6031139		導線 Thrend quide	1
34	R6031130		螺絲 Screw	1

BT082線頭夾持組



機型 Models	Main parts 更換零件	針板 Throat plate	壓腳 Presser foot asm	主送布齒 Main feed dog	副送布齒 Diffreantial feed dog	輔送布齒 Auxiliary feed dog
SC9023-032-M04		TP623032	PF603032	FD60821	DF8040T	AF60871
SC9023-053-H04		TP623053	PF603052	FD60822	DF85100	AF60871
SC9024-A43-A14		TP624A43	PF604A32	FD60824	DF86504	AF60871

BT082 線頭夾持組

序 號	圖 號	名 稱	單位用量
Ref. No.	Parts No.	Description	Amt. Req.
1	BT0820101	夾簧座 Springbase -----	1
2	BT0820102	止動壓板 Stopper -----	1
3	SB24560205A	螺絲 Screw -----	2
4	BT0820104	切線刀 Cutter -----	1
5	SB24560205A	螺絲 Screw -----	6
6	BT0820106	調壓簧片 Spring -----	1
7	BT0820107	螺絲 Screw -----	1
8	BT0820108	夾線簧片 Thread Holder -----	1
9	BT0820109	針板座(7023用)Bracket-----	1
10	SE44400682	螺絲 Screw -----	2
11	BT0820111	線頭定位鉤 Stopper -----	1
12	BT0820112	布板 Cloth Plate -----	1
13	BT0820113	護蓋 Spring Cover -----	1
14	6031213A600	減震橡膠 Rubber -----	1
15	-----	針板 Needl Plate (See Left Page) -----	1
16	-----	壓腳 Press Foot (See Left Page) -----	1
17	-----	主送布齒 Main Feed Dog (See Left Page) -----	1
18	-----	副送布齒 Diff. Feed Dog (See Left Page) -----	1
19	-----	輔助送布齒 Auxiliary Feed Dog (See Left Page) -----	1