


Union Special

SAYLES 10500A 10500B 10500P



CLASS 39500



STREAMLINED HIGH SPEED OVERSEA

Union Special MACHINE

FOREWORD

The Class 39500 machine is Union Special's latest overedger. streamlined styling, automatic lubrication, and light running him performance are characteristics of these machines. All parts are precision methods insuring complete interchangeability.

It is our constant aim to furnish carefully prepared information enable the customer to secure all possible advantages from the use of Unon Specials. The following pages contain valuable operating and adjusting day and illustrate and describe the parts for Styles in Class 39500.

Union Special representatives will be found in all manufacturing cen anxious to cooperate with you to plan and estimate requirements.

Union Special ACHINE COMPANY
Engineering Department

IDENTIFICATION OF MACHINES

Each Union Special carries a Style number which is stamped in the namplate on the machine. Style numbers are classified as standard and special Standard Style numbers have one or more letters suffixed, but never contain the letter "Z". Example: "Style 39500 A". Special Style numbers contain the letter "Z". When only minor changes are made in a standard machine, a "Z is suffixed to the standard Style number. Example: "Style 39500 AZ".

Syles of machines similar in construction are grouped under a Claimumbr, which contains no letters. Example: "Class 39500".

APPLICATION OF CATALOG

This catalogapplies specifically to the standard Styles of machines as listed ferein. It can also be applied with discretion to some special machines class 39500. All references to directions, such as right and left, front a pack, etc., are taken from the operator's position while seated at the machine operating direction of handwheel is away from operator.

STYLES OF MACHINES

Single Curved Blade Needle, Two Looper, Three Thread, Overseaming Machae. Differential Feed, Trimming Mechanism with Spring Pressed Low Knie, Automatic Lubricating System.

39:00 A For seaming light and medium weight flat, warp, and ribbed kn fabrics of cotton, silk, or similar weight synthetics. The sewing comb nation has been designed especially for use on women's and children slips, pajamas, nightgowns, or similar articles where long straight hangi seams are a primary requisite. Seam specification, 504-SSa-1; standal seam widths, 3/32 and 1/8 inch; stitch range, 8-30 per inch; cam adjust main and differential feeds.

fabrics of cotton, silk, or similar weight synthetics. The sewing comb nation has been designed for general purpose seaming of "T" shirts, positives, panties, infants' and children's knit wear, and similar garment sym specification, 504-SSa-1; standard seam widths, 3/32 and 1/8 incesting the seaming medium to heavy weight flat, warp, and ribbed known fabris made from cotton and wool, used on snow suits, sweat shirt underwar and similar garments. Seam specification, 504-SSa-1, standarseam with, 1/8 inch; stitch range, 8-20 per inch; cam adjusted main and differential feeds.

9500 AF Same as 39500 P, except fitted with 39500 B sewing parts. F seaming all types and weights of flat, warp and ribbed knit cotton, we rayon and sik fabrics. Seam specification, 504-SSa-1; standard see widths, 3/32.1/8 and 5/32 inch; stitch range, 8-20 per inch; cam adjust main and differential feeds.

OILING

CAUTION! Oil was drained from machine when shipped, so reserve must be filled before beginning to operate. Oil capacity of Class 39500 is sounces. A straight mineral oil of a Saybolt viscosity of 200 to 250 seconds 100 Fahrenheit should be used.

Machine is filled with oil at spring cap in top cover. Oil level is check at sight gauge on front of machine. Red bulb on oil level indicator should she between gauge lines.

OILING (Continued)

Machine is automatically lubricated. No oiling is necessary, other to keeping main reservoir filled. Check oil daily before the morning start; acoil as required.

Drain plug screw is located at back of machine near bottom edge of base. It is a magnetic screwdesigned to accumulate possible foreign materials which may have entered the crank case. It should be removed and cleaned periodically.

NEEDLES

Each Union Special needle has both type and size number. The type number denotes the kind of shank, point, length, groove, finish and other details size number, stamped on the needle shank, denotes largest diameter of blade, measured in thousandths of an inch, midway between shank and eye. Collectively, type and size number represent the complete symbol which is given on the label of all needles packaged and sold by Union Special.

39500 A, 39500 B, 39500 P and 39500 AF use a curved blade no standard needle for these styles is Type 154GAS. It is a curved bladelength, single groove, shallow spot, long tapered point, structure plated in sizes 022, 025, 027, 029, 032, 036, 040, 044

To have needle orders promptly and accurately filled, an empty a sample needle, or the type and size number should be forwarded. scription on label. A complete order would read: "1000 Needles, Type 154GAS, Size 036".

Selection of proper needle size is determined by size of thread used. Thread should pass freely through needle eye in order to produce a good stitch formation.

Success in the operation of Union Special machines can be secured only by use of needles packaged under our brand name, Union Special which is backed by a reputation for producing highest quality needles in materials and work-manship for more than three-quarters of a century.

CHANGING NEEDLES

Release pressure on presser foot by turning presser foot release bushing (U, Fig. 1) and swing presser arm (H) out of position. Turn handwheel in operating direction until needle is at its lowest point of travel. Using hexagonal socket wrench No. 21388 AS, furnished with machine, loosen needle clamp nut about 1/4 turn. Again turn handwheel until needle is at high position; withdraw needle.

To replace needle, leave needle holder at high position and, with the flat to the left, insert needle in holder until it rests against stop pin. Keeping medle in this position, turn handwheel until holder is again at its low point of travel; then tighten nut. Return presser arm (H) to position; re-lock presser release bushing (U).

After thread comes from cone on thread stand (V, Fig. 1), it is brought up through back thread eyelet, then downthrough front thread eyelet (W). Next it is threaded through each pair of holes in tension thread guide wire (A), down right hand hole and up through left hand hole. Then thread continues between tension discs (AD), through slot (AE), and on through thread guide (B),

THREADING

Only parts involved in threading are shown in threading diagram (Fig. 1). Parts are placed in their relative positions for clarity.

It will simplify threading this machine to follow recommended sequence of threading lower looper first, upper looper second, and needle third.

Before beginning to thread, swing cloth plate open, turn handwheel in operating direction until needle (N) is at high position, release pressure on presse foot by turning presser foot release bushing (U); and swing presser arm (H) ou of position.

Be sure threads, as they come from the tension thread guide, are between tension discs (AD) and in diagonal slots (AE) in tension posts (AC).

TO THREAD LOWER LOOPER

Double end of thread and lead it through both eyes of lower looper threa eyelet (E, Fig. 1) from right to left. Note: thread must pass in front of loope thread pull-off (T). Lead thread behind fabric guard (F) and through both hole of frame looper thread guide (G). Turn handwheel in operating direction until heel of lower looper (K) is all the way to the left; then thread through both eye from left to right. Left eye of lower looper can be threaded easily if tweezer are in left hand.

TO THREAD UPPER LOOPER

Turn handwheel until point of upper looper (L) is all the way left. Leathread through auxiliary looper thread eyelet (D) from back to front, the through both eyes of upper looper thread eyelet (C) from left to right. No thread must pass in front of looper thread pull-off (T). After pulling up upp looper thread tube assembly (M), lead thread under neck of top cover castia and down through thread tube assembly (M). Pull thread out bottom of tube push tube down, then insert thread through upper looper eye from front to back

CAUTION! Be sure upper looper thread is under lower looper thread wh passing from tube assembly to upper looper eye.


TO THREAD THE NEEDLE

Turn handwheel in operating direction until needle (N, Fig. 1) is at highest position. Insert needle thread from right to left, through both eyes needle thread eyelet (R), under neck of top cover casting; then down through hole in top cover needle thread eyelet (P). Thread needle from front.

THREAD TENSION

The amount of tension on needle and looper threads is regulated by the Tension on threads should be only enough knurled tension nuts (AA, Fig. 1). to secure proper stitch formation.

6



PRESSER FOOT

Sufficient pressure to feed work uniformly should be maintained. Should it be necessary to increase or decrease amount of pressure on presser foot, loosen lock nut (A, Fig. 2) and turn adjusting screw (B). Adjusting screw has a right hand thread so tightening increases pressure, loosening decreases pressure. When pressure adjusting screw (B) has been properly set, tighten lock nut (A). With presser foot resting on throat plate, position locking nut (C) so that its under surface is approximately 1/32 inch to 1/16 inch from the top surface of adjusting screw (B). Set cap (D) against locking nut (C).



Fig. 2

FEED ECCENTRICS

Feed eccentrics used in these machines have been selected to produce apprentately 12 stitches per inch. It will be noted that the part number of main eccentric is No. 39540-12 while that of differential feed eccentric is No. 39540 Minor numbers of the part symbol indicate approximately the number of stite obtainable when using that eccentric. Unless otherwise specified, machine will shipped with above combination of eccentrics.

of material being sewn, or type of operation.



22, 24, 26, 28, 30, 32, 34, 36, 40. Only two eccentrics supplied with each machine. Additional eccentrics may be ord separately. To order an eccentric, use No. 39540 with a m number suffixed to indicate number of stitches desired. Exam

"39540-12".

ASSEMBLING AND ADJUSTING SEWING PARTS

Generally speaking, differential (right hand) feed eccer determines number of stitches produced; main (left hand) eccentric is selected in relation to degree and direction of str

Following stitch number feed eccentrics are available w No. 39540-4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 18,

Before assembling sewing parts, remove cloth plate, for guard, chip guard, upper knife assembly, lower knife hassembly, then follow this suggested sequence:

Fig. 3

SETTING THE NEEDLE

With throat plate in position, needle should center in the front end of needle slot. When needle is at high position, needle point should be set 1/2 inch above throat plate (Fig. 3). Move needle driving arm (A, Fig. 3) by loosening clamp screw (B). Remove throat plate.

If needle thread cam pull-off (A, Fig. 4) overlaps looper thread pull-off (B), separate by moving looper thread pull-off back. When retightening looper pull-off screw, be sure to take up end play in needle driving arm.



Fig. 4

SETTING THE NEEDLE (Continued)




Fig. 5

At this point, insert lower looper (A, Fig. 6) into bar (B). With lower looper at left end of its stroke, set looper point 1/8 inch from center of needle (Fig. 6), using looper gauge No. 21225-1/8. Do not have lower looper deflecting needle. Tighten nut.




Fig. 6

Now assemble differential (front) feed dog.

SETTING THE REAR NEEDLE GUARD

Set rear needle guard (A, Fig. 5) as high sible, without interfering with either lower movement of lower knife holder, but still to deflect needle forward -. 002 - . 004 inch is used to set rear needle guard. Make sure no interference between rear needle guard and looper.

SETTING THE LOWER LOOPER

Now finish lower looper adjustment. As lower looper moves to the right, its point should be set into the needle scarf (A, Fig. 7) until the needle springs forward from rear guard surface another . 002 - .004 inch.

SETTING THE FRONT NEEDLE GUARD

Assemble front needle guard (C, Fig. 5). When lower looper is springing needle off backguard, set front needle guard as close as possible to needle without touching. Screw (D) is used to adjust and set front needle guard. After this setting make sure there is no interference between needle guards and differential feed dogs.




Fig. 7

B B

Fig. 8

SETTING THE UPPER LOOPER

Insert upper looper (A, Fig. 8) in its holder. Screw (B, Fig. 8) holds upper looper in its holder, and permits it to be pushed in or out or turned around its shank. Insert upper looper holder into upper looper shaft, if it is not already in place. Screw (C, Fig. 8) on clamp holds the upper looper holder in the shaft. Locate upper looper in its holder so that the shank extends 1/16 to 3/32 inch beyond holder (Fig. 8).

When the upper looper is at the right end of its stroke, upper looper holder should be set to position upper looper shank back of vertical on 39500 A and B (Fig. 8).

NOTE: On Styles 39500 P and AF, the upper looper holder should be set to position the upper looper shank about vertically. Be sure, on all styles, there is a clearance between heel of looper and casting. By adjusting looperholder in or out of upper looper shaft and by turning the looper around its shank, set upper looper point to cross lower looper to the left of the lower looper eye with 0.002 to 0.004 clearance (Fig. 9).




Fig. 10

turn handwheel until looper is at the left end of its travel: check dimensions of upper looper point with respect to needle and throat plate (Fig. 10). If resetting

is necessary, do it by moving the upper looper holde (A, Fig. 10). Figure 10 represents the dimensional setting for Styles 39500 A and B.

NOTE: For Styles 39500 P and AF, the settings ar *1/2 and **9/64. For example, dimension 31/64 inch increased by turning upper looper holder counterclock wise looking from left end of machine; dimension 5/3 inch is increased by pulling upper looper holder left, or of upper looper shaft. After these changes are made, may be necessary to turn upper looper around its shar slightly to maintain the condition shown in Fig. 9.

When the correct setting is obtained, it can be checked quickly as follows: As upper looper is moving to the right, when upper looper eye centers on the needle, bottom of the needle eye should be about level with top surface of upper looper (Fig. 11) for Styles 39500 A and B.

NOTE: For Styles 39500 P and AF, the eyes of the upper looper and needle should align exactly.

Check setting to avoid interference between upper looper and needle on needle downstroke. If needle rubs the back of upper looper, pull looper out of its holder slightly and rotate looper a short distance counterclockwise, looking from left end of machine. Reset to maintain dimensions of Figs. 9, 10, 11.



Fig. 9

Fig. 11




Fig. 12

SETTING THE FEED DOGS

On Style 39500 A, set three feed dogs (A, B, C, Fig. so the top surfaces of teeth all in the same plane. This can checked by sighting across ted with a straight edge. Feed do should now be leveled with thre plate surface by rotating fe tilting adjusting pin (D). This raises or lowers the back end both feed bars at the same time

SETTING THE FEED DOGS (Continued)

The feed dogs should be set level at the time teeth first appear above the throat plate. Screw (E) locks feed tilting adjusting pin in place. Now set feed dogs so that teeth rise about 3/64 inch above throat plate.

NOTE: On Styles 39500 B, P and AF, set chaining feed dog (C) level with top of throat plate when dog is at top of its travel.

SETTING THE LOWER KNIFE

Replace lower knife holder assembly. Lower knife (A, Fig. 13) should be set with cutting edge flush with throat plate surface. Adjustments are made with hexagonal head screw which holds lower knife. Lower knife is spring pressed against upper knife, so no lateral adjustment is necessary when width of trim is changed.

Lower knife may be secured in any position by tightening screw (B) and locking nut (C) against support bracket. Because screw (B) also serves as latch pin for the cloth plate latch spring, it should always be locked with nut (C) even when screw is not tightened against lower knife holder.

SETTING THE UPPER KNIFE

Replace upper knife assembly. Clamp upper knife (D, Fig. 13) in position, setting nut (E) to hold clamp (F) in its most clockwise position against upper knife.




Fig. 13

At bottom of its stroke, front cutting edge of upper knife should extend not less than 1/64 inch below cutting edge of lower knife. The chain guard (J) should be set down against the upper knife and slightly back from the cutting edge.

After upper knife has been set for proper width of trim, screw (G) should be tightened to lock upper knife holding block (H) in place. This will simplify resetting when upper knife is replaced.

SETTING THE STITCH LENGTH

Length of stitch is determined by the combination of feed eccentrics used. Outer (left) eccentric (A, Fig. 14) actuates main (rear) feed dog; while the inner (right) eccentric (B) actuates the differential (front) feed dog.

In assembling feed eccentrics, be sure hubs are facing each other. Be careful notto damage shaft or key. Tighten nut (C) securely. Be sure wool yarn in oil tube (F) touches feed eccentric connections.

To change feed eccentrics, remove nut (C) from end of shaft (D). Turn handwheelin operating direction until key slot in eccentric is toward front. Using hooked eccentric extractor (E), supplied with machine, reach behind eccentrics as shown and withdraw eccentrics. It may be necessary to move handwheel back and forth slightly during extraction.



Fig. 14




Fig. 15

Foot lifter lever arm (A, Fig. 16) and collar (B) secure the shaft. Be sure presser arm does not bind and rise when presser foot release bushing is unlocked. To center presser foot and stitch tongue with respect to throat plate needle hole,

loosen presser foot hinge screw.

Adjust lifter lever stop screw (C) so that presser foot can be raised no higher than upper looper will permit; then, lock nut (D). To find this maximum safe position, turn the handwheel so point of upper looper is directly over presser foot tongue. Raise presser foot by depressing the presser foot treadle and manually

If eccentrics are unusually tig fitting, in addition to removing nut (Fig. 15) from shaft (D), it may be helf ful to remove nut (G) and feed drive connection (H). Then continue as originally suggested.

SETTING THE PRESSER FOOT

Assemble presser foot to pressure. With needle in high position, swippresser arm into sewing position a lock in place. If necessary, pressured to the can be realigned with throat places by shifting foot lifter lever shall




Fig. 16

lower the toe of foot. Height adjustment is correct if presser foot tongue de not contact the upper looper. There should be from 1/16 to 1/8 inch fa motion of foot lifter lever before presser foot begins to rise. This adjustment is made with screw (E), locked with nut (F).

Finally, re-assemble chip guard, fabric guard, cloth plate.

STARTING TO OPERATE

Be sure machine is threaded according to threading diagram (Fig. 1, part). With thread tensions light, set looper thread eyelets (C & E) about how zontal and in the middle of their front to back locations. Operate machines slowly, without presser foot in place, to make sure that chain forms and move off the tongue freely. Swing presser foot into position, insert material.

NEEDLE THREAD CONTROL

While sewing on material, check needle thread control as follows: Usua all needle thread is drawn on needle down stroke. At top of needle strothread should be just tight enough to feed chain off stitch tongue. Stitch ten to pull down slightly if excessive thread is pulled on the up stroke. With need at bottom of stroke, position needle thread eyelet (R, Fig. 1) so that need thread cam pull-off (S) just contacts needle thread.

NEEDLE THREAD CONTROL (Continued)

On Styles 39500 P and AF, it is desirable to adjust the needle thread pull-off eyelet well-forward (toward the operator) to delay, slightly, the tightening of the needle thread.

LOWER LOOPER THREAD CONTROL

With material under presser foot, set lower looper thread eyelet (E, Fig. 1) back far enough so thread is a little slack when looper thread pull-off (T) reaches its most rearward position. Looper thread pull-off (T) is set about 1/8 inch distance behind needle thread cam pull-off (S). Frame looper thread guide (G) should be set with its left hand eyelet approximately 1/8 inch right of lower looper (K) heel eyelet at the time lower looper is at extreme left end of its travel.

While sewing on material, check drawing off of looper thread as follows: A portion of lower looper thread should be drawn through the tension before lower looper thread comes off upper looper. To increase amount of thread drawn through the tension while lower looper thread is on upper looper lower looper thread eyelet (E) down, keeping the same amount of pull-

UPPER LOOPER THREAD CONTROL

Before proceeding to adjust upper looper thread eyelet (C, Fig. 1) all three tensions to give a normal appearing stitch. Moderate change in the tensions will not markedly effect the purl.

During needle down stroke, forward stroke of looper thread pull-off (T) will draw upper looper thread through the tension. When normal amount of looper thread is drawn, upper looper thread will have almost all slack taken up as looper thread pull-off reaches its most rearward position.

POSITIONING THE PURL

To move the purl more under the edge, both looper thread eyelets (C & E, Fig. 1) should be raised keeping the same amount of pull-off. Usually it is better to have slightly more pull-off on upper thread than on lower thread.

If it becomes necessary to move looper thread pull-off (T), be sure to take up all end play in needle drive shaft before tightening. If upper looper is located so that it is higher over throat plate than recommended in (Fig. 10), the purl will tend to form near top edge. If upper looper is too low, the purl will form nearer bottom edge.

THREAD TENSIONS

The needle thread tension required is a function of needle thread and material being sewn. In general, lower looper thread tension should be set as high as possible without causing needle thread to be pulled down. Upper looper thread tension should be increased as long as the elasticity of the chain increases, or until the purl is pulled too far over the top.




Fig. 17

TO REMOVE CRANKSHAFT

Crankshaft can be withdrawn easier if these steps are followed:

- Drain oil by removing plug screw located on back of machine near bottom edge of base.
- 2. Remove top and bottom covers of machine.
- 3. Remove feed eccentric nut (E, Fig. 17) and, with the aid of the eccentric extractor, slip off the eccentrics (F).
- 4. Remove key (G).
- 5. Remove three counterweights (H). Identify these counterweights so that they will be re-assembled in the proper places.
- 6. Remove screw (J) which holds crankshaft split bearing. This screw is reached through bottom of bed casting.
- 7. Remove caps of bearings on crankshaft at points A, B, and D. When reassembling bearing caps make sure they are in their original position. Trade marks are stamped on both halves of the caps and both trade marks should be on the same side of the bearings. Also, screws should be reassembled in the same holes from which they were removed.
- 8. Loosen clamp nut (A, Fig. 18) which holds upper knife driving arm (B). Access to clamp nut is through top cover. Draw driving arm to the left until upper knife driving lever (C) and connecting rod (D) drop, allowing removal of bearing cap (E). This is at bearing point (C, Fig. 17) on crankshaft. Observe same precautions when re-assembling cap as described in 7 above.
- 9. Remove screw (K, Fig. 17) which holds inner right crankshaft bearing. This screw is reached through bottom of bed casting.
- Loosen two screws (L) in fan collar; remove both halves of cooling fan.
- 11. Remove screw (M); take off pulley cap (N).
- 12. Loosen two screws (P); remove pulley (R).
- 13. Remove three screws (S); take off bearing retaining plate (T).
- 14. Crankshaft may now be removed.

- 15. If necessary to replace ball bearing (V), it should be pressed off shaft on an arbor press. In replacing bearing it must be pressed on carefully until it seats against ground thrust washer (U).
- 16. Carefully observing reverse of the foregoing operations should simplify re-assembly of crankshaft. Checking exploded view drawings for location of various parts and constant testing for binds during re-assembly will also prove helpful.
- 17. Before re-assembling, thoroughly clean and dry top and bottom cover and gaskets. Before re-assembling bottom cover make sure that spring pressed oil wick which lubricates less crankshaft bearing is inserted in hold in casting and that it contacts shaft. The wick stands vertically on its spring against bottom cover. Coat drain plug with a sealing compound be fore re-assembling to prevent eleakage. No. 1 Crane Lead Seal recommended.




Fig. 18

ILLUSTRATIONS

This catalog has been arranged to simplify ordering repair parts. Exploded views of various sections of the mechanism are shown so that the parts may be seen in their actual position in the machine. On the page opposite the illustration will be found a listing of the parts with their part numbers, description and the number of pieces required in the particular view being shown.

Numbers in the first column are reference numbers only, and merely indicate the position of that part in the illustration. Reference number should never be used in ordering parts. Always use the part number listed in the second column.

Component parts of sub-assemblies which can be furnished for repairs are indicated by indenting their descriptions under the description of the main sub-assembly.

41 42 42 A 43 44	29126 DF 22729 D 22729 E 97 39544 S	Lower Looper Drive Lever Connecting Rod Assembly Screw, for No. 39544 N	2
45	39544 U	Lower Looper Bar Driving Lever	

It will be noted in the above example that the eccentric, ball stud, and bear listed. The reason is that replacement of these parts individually is not recomplete sub-assembly should be ordered.

where parts for Styles 39500 A, 39500 B, 39500 P and 39500 AF are not the difference will be shown in the illustrations or mentioned in the description.

part is used in all machines covered by this catalog no machine style will be mentioned.

At the back of the book will be found a numerical index of all the parts shown in this cook. This will facilitate locating the illustration and description when only the part number is known.

IDENTIFYING PARTS

Where the construction permits, each part is stamped with its part number. On some f the smaller parts, and on those where construction does not permit, an identification etter is stamped in to distinguish the part from similar ones.

PART NUMBERS REPRESENT THE SAME PART, REGARDLESS OF CATALOG IN


USE GENUINE NEEDLES AND REPAIR PARTS

Success in the operation of these machines can be secured only with genuine Union secial Needles and Repair Parts as furnished by the Union Special Machine Company, subsidiaries and authorized distributors. They are designed according to the most sentific principles, and are made with utmost precision. Maximum efficiency and trability are assured.

Genuine needles are packaged with labels marked Union Special . Genuine repair rts are stamped with the Union Special trade mark. Each trade mark is your guarantee the highest quality in materials and workmanship.


TERMS

Prices are net cash and subject to change without notice. All shipments are forwarded be a be shipping point. Parcel post shipments are insured unless otherwise directed. A arge is made to cover postage and insurance.



MAIN FRAME, MISCELLANEOUS COVERS, PLATES

Ref. No.	Part No.	Description	Amt. Req.
1	39557 B	Presser Spring Plunger Cap Nut	1
2	39557 E	Presser Spring Plunger Locking Nut	
3	39557 C	Presser Spring Plunger Adjusting Screw	
4	39557 F	Lock Nut - Adjusting Screw	1
5	39557	Pnesser Spring	1
6	39556 A	Presser Foot Release Bushing	1
8	39557 A	Presser Spring Plunger	1
- 9	22541	Screws - Top Cover	
10	39582 S	Top Cover	1
11	51-103 Blk	Hinge Pin	1
12	39582 L	Oil Filler Cover	
13	39582 V	Spring	ă.
14	39582 AA	Top Cover Gasket	
15	39563 F	Top Cover Needle Thread Eyelet	1
16	22569 B	Screw - Eyelet	2
17	22571 E	Magnetic Oil Drain Plug Screw	1
18	2565	Screw - Upper Looper Thread Tube Assemble	
19 20	29477 GW 22743	Upper Looper Thread Tube Assembly Screw - Tube Tension Spring	
21	39568 J	Looper Thread Tube Tension Spring	
21 A	39 56 8 G	Thread Tube	
22	39534 R	Feed Bar Oil Shield	
23	90	Screw - Feed Bar Oil Shield	
24	660-234	Oil Tube Coupling	
25	39594	Feed Bar Connecting Rod Oil Tube	
27	22569	Screw - Cloth Plate Stud	i
30-	39501 A	Cloth Plate, semisubmerged installation	-
31	39501	Cloth Plate, nonsubmerged installation	
32	39501 C	Cloth Plate, semisubmerged installation	
3 3	39 501 B	Cloth Plate, nonsubmerged installation	
34 35	90	Screws - Latch Spring	
	39532 A	Cloth Plate Latch Spring	
36	39582 D	Feed Mechanism Cover	
37	41071 G .	Nut - Feed Mechanism Cover	
38	86 X	Screw - Feed Mechanism Cover	1
39	22569 A	Screws - Oil Screen and Strainer	3
40	39594 G	Oil Filter Screen	1
41	39594 H	Oil Strainer	1
4.2	39578 B	Chip Guard	1
42 43 44 45 46	22569 D	Oil Gauge Float	2
### # 5	39593 C 39593 D	Oil Gauge Indicator	1
10	- 660-243	Oil Gauge Seal Ring	1
47	39593 E	Oil Gauge Seal RingOil Sight Gauge	1 1
48	22894 AD	Screws - Lower Looper Bar Drive Lever Shaft	2
48 49	22565	Screws - Upper Looper Drive Lever Shaft	2
50	39582 Y	Bottom Cover Gasket	1
51	39582 X	Bottom Cover	1
52	22569 C	Screws - Bottom Cover	
52A	22586 R	Screw - Bottom Cover	1
53	22653 D-4	Screws - Bottom Cover Extension	2
54	39582 F	Bottom Cover Extension	1
55	39578 F ;	Cloth Plate Fabric Guard	1
56	138	Screw - Cloth Plate Fabric Guard	2
57	22657 D-12	Screw - Cloth Plate	1
58	39501 K	Stud - Cloth Plate	1




CRANKSHAFT MECHANISM AND BUSHINGS

Ref. No.	Part No.	Description	Amt. Req.
1	22769 A	Screw, for pulley capPulley Cap	1
2	39 521 A	Pulley Cap	1
3	39521	Pulley	1
4	95	Screw	2
5	39590 H	Crankshaft Ball Bearing Retaining Plate	1
6	22569	Screw	3
6A	39590 S	Spacer Collar	1
6B	39590 R	Ball Bearing Stop Collar	
7	660-268	Crankshaft Ball Bearing Harring	1
8 9	39590 G 39590 J	Crankshaft Ball Bearing Housing Thrust Washer	
10	39591 G		
11	39591 H	Crank Chamber Cooling Fan	1
12	22894 D	Screw	
13	39590 K	Crankshaft Bearing, inner right	
13A	22565 F	Screw	
14	39590 P	ScrewOil Slinger Collar	
14A	77 Q	Screw	
15	39522 C	† Crankshaft, for Styles 39500 A & B	
	39522 B	* Crankshaft, for Styles 39500 P & AF	
16	39590 D	Crankshaft Split Bearing	
17	97 A	Screw, for split bearing	
18	22747 B	Screw, for crankshaft counterweight	
19	39591 B	Crankshaft Counterweight, right	1
20	39 591 A	Crankshaft Counterweight, middle	1
21	22747 B	Screw, for crankshaft counterweight	2
22	39590 N	Stud, for crankshaft split bearing	1
23	39591	Crankshaft Counterweight, leftScrew, for crankshaft counterweight	< 1
24	22747 B	Screw, for crankshaft counterweight	2
25	39541 666-94	Feed Driving Eccentric Key	1
26 27	39590	Oil Wick and Spring	
28	39590 T	Crankshaft Bushing, left	10 Total Tot
29	39555 E	Crankshaft Bushing, inner left	_
30	39142 G	Foot Lifter Shaft Bushing, right	_
31	39573 K	Upper Knife Driving Arm Bushing, left	
32	39573 L	Upper Knife Driving Arm Bushing, right	
33	39552 N	Needle Driving Arm Crank Bushing	
34	39544 L	Lower Looper Bar Bushing	

NO.TE:


DISCONTINUED - For repairs order No. 29477 JA. DISCONTINUED - For repairs order No. 29477 JP.



NEEDLE DRIVE AND FEED MECHANISM


			NEEDLE DRIVE AND FEED MECHANISM	1200
Ref.	Part			**
No.	No.		· · · · · · · · · · · · · · · · · · ·	Amt.
240.	140,		Description	Req.
1	87		Sanawa - Pahnia Cuand	
$\frac{1}{2}$	39578 R		Screws - Fabric Guard	- 2
3	22569 B		Fabric Guard	
4	8372 A		Screws - Mounting Bracket	- 2
5	39578 P		Mounting Bracket Washers	<u> </u>
6	22565-F		Fabric Guard Mounting Bracket	- 1
7	39535 C		Screw - Adjusting Pin	4 1
8	39535		Feed Tilting Adjusting Pin	- 1
- # g	53634 C		Main Feed Bar Guide, left	- 1
8 9 10	22569		Feed Bar Guide Washer, left	- 2
11	3953 5 B		Screws - Feed Bar Guide, left	- 2
12	3953 5 D		Feed Bar Guide Blocks	- 2
13	53634 C		Differential Feed Bar Guide, right	
14	22569 B		Feed Bar Guide Washers, right	
15	22569 G		Screws - reed Bar Guide, right	
16	39534 H		Screws - Feed Bar Guide, right	- 3
17	39534 H 39538		Differential Feed Bar Thrust Washer	. 1
18	39534 G	*	reed but Block	
- 19	39526 B		Differential Feed Bar	• ī
ad d			Differential Feed Dog, for Styles 39500 A, B & AF,	70
20	39526 P		Differential Feed Dog, for Style 39500 P,	
as total	1000 P		12 teeth to inch	
	*39526 D		Same as 39526 B, except 20 teeth to inch	
20	.722528		Screw - Differential Feed Dog	
21	39505 C		Chaining Feed Dog, marked "C", for Style 39500 A	
**	39505		Chaining Feed Dog, for Style 39500 B & AF	
ratio	39505 E		Chaining Feed Dog, for Style 39500 P	
22	22707 A		Screw - Chaining Feed Dog	
23	39534		Main Feed Bar	
24	39505 B · 4		Main Feed Dog, marked "B", for Styles 39500 A, B & AF,	
Art Contract	39505 P		Main Feed Dog, marked "J", for Style 39500 P, 12 teeth to inchSame as 39505 B, except 20 teeth to inch, marked "E"	1
7	*39505 D		Same as 39505 B, except 20 teeth to inch marked "F"	1
25 5	93 A		Screw - Main Feed Dog	1
26	39540 B-10		Differential Feed Driving Eccentric, . 022 inch throw	1
. 27	39536 A		Differential Feed Bar Driving Connection	1
28	39540 B-12		Main Feed Driving Eccentric, .006 inch throw	1
29	39536 Z		Main Feed Bar Driving Connection	1
, 29A	20		washer - Crankshaft	1
30 31	18		Nut - Crankshaft	1
32	39536 E		Nuts - Feed Bar Driving Studs	
83	39536 C		Feed Bar Driving Connections Bushings	
34	39536 B 14077		Feed Bar Driving Studs	2
2.2	39551 A		Nut - Needle Clamp Stud	1
9 5 36	154 GAS		Needle Clamp Washer	1
37	39552		Needle Driving Arm	1
38	22596 E		Screw - Noodle Driving Ann	1 *
1Q	750-774 Blk.		Screw - Needle Driving Arm	1
40	39551 F		Stop Pin - Needle Driving Arm Needle Clamp Stud	1
41	39563 G		Needle Thread Cam Pull-off	1
12	28		Screw - Needle Thread Cam Pull-off	1
43	22584		Screw - Looper Thread Pull-off	1
14	39568 A	-	Looper Thread Pull-off	1
45	39568 Y		Looper Thread Pull-off Lever	1
46	88 B		Screw - Looper Thread Pull-off Lever	1
47	39552 C		Needle Driving Arm Crank Thrust Washer	2
48			Needle Driving Arm Crank	2
`.9 _.	39552 E		Needle Driving Arm Crank Connecting Rod	1
50	22587 J		Screws - Connecting Rod	1
180	39594 N		Oil Splasher	1
52	77		Screw - Oil Splasher	1
# B	660-207		Oil Ring Seal - Needle Driving Arm Crank	1
				1

Available as extra send and charge item.




UPPER AND LOWER LOOPER DRIVING PARTS

Ref.	Part		8
No.	No.	Description	Amt.
-	***************************************		Req.
1	482 C	Upper Looper Shaft Collar	. 1
2	22894 C	Screws - Collar	9
0	22565	Screws - Upper Looper Drive Lever Shaft	2
4	7446 A	Upper Looper Drive Lever Shaft	1
3 5	1280	Nut - Locking Stud	1
6	39543 R	Locking Stud Washer	1
- 1	43143 N	Locking Stud - Upper Looper Drive Lever	1
8	395 43 H	Upper Looper Drive Lever	1
9	29126 CG	Upper Looper Drive Lever Connecting Rod Assembly	1
10	22559 A	Screws - Connecting Rod Assembly	,
11	77	Screw * On Spiasner	
× 12	39594 N	Oil Splasher	1
12 A	666-255	Felt Plug, for connecting rod	1
10	22747	ociew - duide rork	1
14	41255 B	Ball Joint Guide Fork - Upper Looper Drive Assembly	1
15	39543 M	Coliar Clamp	
15 18 17	22562 A	Screw - Collar Clamp	
7	39543 P	Upper Looper Shaft Thrust Washers	
	~39543 K	Upper Looper Shaft	
19 20	39543 S 22565 H	Bushing and Cam Guide	
×21		Screw - Cam Guide	
	39543 T 39543 E	Cam Follower	
22. 23	22503 F	Cam Follower Locking Clamp	
₹24	22 KH	Screw - Locking Clamp Screw - Unpan Laborate G. H.	
25	39543 A	Screw - Upper Looper Holder Collar	1
	39543	Upper Looper Holder Collar	1
26 27	22564 G	Screw - Upper Looper Holder	1
*2 R	- 39508 A	Upper Looper	1
30 31	22539 K	Plug Screw - Lower Looper Shaft	1
31	482 C	Lower Looper Shaft Collar	1
32	22894 C	Screws - Collar	1
33	22894 AD	Screws - Lower Looper Bar Driving Lever Shaft	2
34	51235 B	Lower Looper Bar Driving Lever Shaft	1
35	39508 B	Lower Looper	1
*36	39151	Nut - Lower Looper Bar	1
ئے عو	39544	Lower Looper Bar	1
) Q	77	Screws - Connection Link Pin	2
239	39544 D	Lower Looper Bar Connection Link Pins	2
#0	39544 B	Lower Looper Bar Connection Link	1
1	29126 DF	Lower Looper Bar Driving Lever and Connecting	-
18.00	00000	Rod Assembly	1
#2	22729 D	Screw for No. 39544 N	2
2 A 3	22729 E	Screw, for No. 39544 N	2
) A	97 20544 C	Screw, for No. 39544 S	2
F	39544 S	Ball Joint Guide Fork	1
M.	39544 U	Lower Looper Bar Driving Lever	1
217	39594 N 77		1
-8	22539 K	Screw - Lower Looper Shaft	1



UPPER AND LOWER KNIFE MECHANISM

Ref.	Part		•
No.	No.	Description	Amt
	•		Req
1	39573 J	Upper Knife Driving Connecting Rod	•
3	22587 J	ocrews - councting tod	•
3	39573 E	opper Amie Driving Lever	_
4	55235 D	Locking Stud - Driving Lever	- 1
5	6042 A	Washer - Driving Lever	- I
5 8	55235 E	Nut - Driving Lever	. 1
7	39573 A	Upper Knife Driving Arm Washer	• 1
8	39573 H	Upper Knife Driving Arm	1
9	39571 D	opper Kniie Clamp Stud	• 1
10	39572 -	Upper Knife Holder Block	
11	22738 -	Screw - Holder Block	
12	39570	Upper Knife	. 1
13 14	39571-F	Upper Knife Clamp	1
	39571 B	Upper Knife Chain Guard	, 1
15 18/	14077 -	Nut - Upper Knife Assembly	
16	22585 A	Screw - Needle Guard, front	
17.	39525	Needle Guard, front	
(8*	22585 A	Screw - Needle Guard, rear	
19) 10	39525 A	Needle Guard, rear	
10	22524	Screw - Throat Plate	
	39524 C-3/32	Throat Plate, marked "AC-3/32", 3/32 inch with	
	00001 0 1/0		
	39524 C-1/8	Throat Plate, marked "AC-1/8", 1/8 inch wide seam,	
	39524 B-3/32	for Style 39500 A	
	39344 D=3/32	Throat Plate, marked "V-3/32", 3/32 inch wide seam, for Style 39500 B AF	1
	39524 B-1/8	for Style 39500 B, AF	1
	05024 D-1/0	Throat Plate, marked "V-1/8", 1/8 inch wide seam,	-
140	39524 P	for Style 39500 B, AF	1
4	00024 1	Throat Plate, marked "AJ", 1/8 inch wide seam, for Style 39500 P	
	39524 B-5/32	for Style 39500 P	1
	00002 25 0/02	Throat Plate, marked "BH", 5/32 inch wide seam, for Style 39500 AF	
2	39550 E	TOT OUT OUT THE THE THE THE THE THE THE THE THE TH	1
3 6 5	39540 B	Lower Knife Holder SpringLower Knife Holder	. 1
	39549 >	Lower Knife	1
5	39550.M	Lower Knife Clamp Spring	1
la.	39550	Lower Knife Clamp	1
	22588 A	Screw - Lower Knife Holder	1
	22729 B	Screw - Lower Knife Holder Locking Stud-	1
	39550 C	Lower Kittle Holder Locking Stud	1
	14077	Nut - Locking Screw - Lower Knife Holder	T
	22892 B	Locking Screw - Lower Knife Holder	1
	39580 A	Inroat Plate and Lower Knife Support Bracket	1
	22653 B-12	Screws - Support Bracket	7



FOOT LIFTER, THREAD TENSIONS AND MISCELLANEOUS EYELETS

71		MISCELLANEOUS EYELETS	
Ref.	Part		
No.	No.	The second secon	Amad
		Description	Amt.
1 7	39555	Foot Lifton Larray	Req.
2	39555 B	Foot Lifter Lever Spring	
3	39555 D		-
4	660-142		
5	39555 F	Collife Cilip Lunk	
6	22566 B	THE POLICY COUNTRY IN TAKE	-
> 7	39555 C		
8	627	- oo miioi never williams	1
~ 9	22597 E	octew - Dever Arm	1
月 10	12538	ociews - Lever Arm	
11	12865	Lock Nuts - Lever Arm	6,
_ 12	88	The state of the s	2
12	39555 A		2
≢ 14	22598 E	and refer the Aet, Ottall ==================================	8
15	14077	ociew - Presser Arm	
16	39556 F	Nut - Presser Arm	
17	39520 B	Presser Arm	
18	39520 Å	Presser Foot, for Style 39500 A	
_25	39530 P	Tesser Foot, for Style 39500 B AF	
25 26	22738 B	r resser root enip Guardana	
至27	39597 A	ociew - Chip Guard	
28	39530	resser root Stitch Tongue monked Upgu	
79	22768 B	T CBBCI FOOL HInge Spring	
#80°	22738 B	+ ONE OF BILL DISTURBLE	
#81	39530 C		1
) 2 3 3	39520 P	- + Chact I for thain shiple.	1
9 3	22768 B	Presser Foot, for Style 39500 P Screw - Stitch Tongue Hinge Spring	1
34	3953 0	Hinge Spring	ì
. 5 م	39597 P		1
平 ⁵ 。 6	108 4	Stitch Tongue, marked "EA"	1
97	51292 F-4	TOTIOIOI I ODI IVUIS THE	3
X	51292 F-8	- oper intead tension oprings	2
8 •0	107		1
9 9	109		3
4 0	35792 H	Tension Discs	6
.11	39592 F	Tension Post Mounting Pro-	3
2	22891	Tension Post Mounting Bracket	1
169479	22565 C	Screw - Tension Post Mounting Bracket	1
-4	90	Screws - Tension Posts	3
73	39563 S	Thread Guide	1
19	22569 B		1
47	39568 D	Screw - Eyelet Mounting Bracket	1
4	39568 L	Looper Thread Eyelet Mounting Bracket	1
7	39568 E	Upper Looper Thread Eyelet-	1
90	376 A	Auxiliary Looper Thread Eyelet	1
M	43139 A	Screws - Looper Thread Eyelets	2
> 100	73 X	Truck - Looper Inread Evelets	2
	39568 W	Screws - Frame Thread Guide	2 🛊
	22569 D	Frame Thread Guide - Lower Looper Thread	
/	39563 H	Coron - treedie inread Poblet	
A STATE OF THE STA	39568 B	Needle Thread Eyelet	
		Lower Looper Thread Eyelet	

